

1995 Mazda MX-3 Workshop Manual

© 1994 Mazda Motor Corporation
PRINTED IN THE U.S.A. AUG. '94
FORM NO. 1472-10-94H
PART NO. 9999-95-056B-95

WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury and property damage increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing servicing operations. However, all users of this manual are expected to know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Nonrecommended procedures and tools should include consideration for safety of the technician and continued safe operation of the vehicle.

Parts should be replaced with genuine Mazda replacement parts, not parts of lesser quality. Use of a nonrecommended replacement part should include consideration for safety of the technician and continued safe operation of the vehicle.

1995 Mazda MX-3 Workshop Manual

FOREWORD

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical—including photocopying and recording and the use of any kind of information storage and retrieval system—without permission in writing.

WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

| Title | | Section |
|---|--|---------|
| General Information | | GI |
| Pre-Delivery Inspection and Scheduled Maintenance | | A |
| Engine | B6 DOHC | B1 |
| | K8 DOHC | B2 |
| Lubrication System | B6 DOHC | D1 |
| | K8 DOHC | D2 |
| Cooling System | B6 DOHC | E1 |
| | K8 DOHC | E2 |
| Fuel and Emission Control Systems | B6 DOHC | F1 |
| | K8 DOHC | F2 |
| Engine Electrical System | | G |
| Clutch | | H |
| Manual Transaxle | F25M-R | J1 |
| | G25M-R | J2 |
| Automatic Transaxle | Electronically Controlled | K |
| Front and Rear Axles | | M |
| Steering System | | N |
| Braking System | | P |
| Wheels and Tires | | Q |
| Suspension | | R |
| Body | | S |
| *Body Electrical System | | T |
| *Heater and Air Conditioner Systems | | U |
| Technical Data | | TD |
| Special Tools | | ST |
| Wiring Diagram | Form No. 5330-10-94G Part No. 9999-95-034G-95 | Z |

* Refer to the 1995 MX-3 Body Electrical Troubleshooting Manual (Form No. 1474-10-94H, Part No. 9999-95-086F-95) for servicing of the body electrical components.

© 1994 Mazda Motor Corporation
PRINTED IN THE U.S.A AUG. '94
Form No. 1472-10-94H
Part No. 9999-95-056B-95

VEHICLE IDENTIFICATION NUMBERS (VIN)

JM1 EC433 * S0 400001 —
JM1 EC434 * S0 400001 —

PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE

| | |
|--|------------|
| PRE-DELIVERY INSPECTION | A-2 |
| PRE-DELIVERY INSPECTION TABLE | A-2 |
| SCHEDULED MAINTENANCE | A-3 |
| SCHEDULED MAINTENANCE TABLE (EXCEPT CANADA) | A-3 |
| SCHEDULED MAINTENANCE TABLE (CANADA) | A-6 |

PRE-DELIVERY INSPECTION

PRE-DELIVERY INSPECTION TABLE

The following items may be done at any time prior to delivery to your customer.

EXTERIOR

INSPECT and **ADJUST**, if necessary, the following items to specification:

- Glass, exterior bright metal, and paint for damage
 - Wheel lug nuts and locks (if equipped)
89–117 N·m {9–12 kgf·m, 66–86 ft·lbf}
 - All weatherstrips for damage or detachment
 - Operation of hood release and lock
 - Operation of rear hatch, and fuel lid opener
 - With trunk open, check for spare jack, tire, tools, and fasteners securing these items in place.
 - Door operation and alignment
 - Headlight aim
- INSTALL** the following parts:
- Wheel caps or rings (if equipped)

UNDER HOOD-ENGINE OFF

INSPECT and **ADJUST**, if necessary, the following items to specification:

- Fuel, coolant and hydraulic lines, fittings, connections, and components for leaks
- Engine oil level
- Power steering fluid level
- Brake and clutch master cylinder fluid level
- Windshield washer reservoir fluid level
- Radiator coolant level
- Tightness of battery terminals
- Manual transaxle oil level

INTERIOR

INSTALL the following parts:

- Rubber stopper for rearview mirror
- CHECK** operation of the following items:
- Seat controls (slide and recline) and headrests
 - Folding rear seat
 - Door locks
 - Seat belts and warning system
 - Ignition switch and steering lock
 - Transaxle range switch (ATX only)
 - Starter interlock switch (clutch pedal, MTX only)
 - All lights, including warning and indicator lights
 - Sound warning system
 - Horn, wipers, and washers (front and rear, if equipped)
 - Audio system (if equipped)
 - Cigarette lighter and clock

- Sliding sunroof (if equipped)
- Power door lock (if equipped)
- Power outside mirrors (if equipped)
- Power windows (if equipped)
- Heater, defroster, and air conditioner at various mode selections (if equipped)

CHECK the following items:

- Presence of spare fuses
 - Upholstery and interior finish
- CHECK** and **ADJUST**, if necessary, the following items:
- Pedal height and free play of brake and clutch pedal

| | Pedal height mm {in} | Free play mm {in} |
|--------------|--------------------------------------|-------------------|
| Clutch pedal | 199–204 {7.83–8.03} {With carpet} | 5–16 {0.19–0.63} |
| Brake pedal | 193–196 {7.60–7.72} | 4–7 {0.16–0.28} |

- Parking brake
5–7 notches/98 N {10 kgf, 22 lbf}

UNDER HOOD-ENGINE RUNNING AT OPERATING TEMPERATURE

CHECK the following items:

- Automatic transaxle fluid level

ON HOIST

CHECK the following items:

- Underside fuel, coolant and hydraulic lines, fittings, connections, and components for leaks
- Tires for cuts or bruises
- Steering linkage, suspension, exhaust system, and all underside hardware for looseness or damage

ROAD TEST

CHECK the following items:

- Brake operation
- Clutch operation
- Steering control
- Operation of gauges
- Squeaks, rattles or unusual noises
- Emergency locking retractors
- Cruise control system (if equipped)

AFTER ROAD TEST

CHECK for owner information materials.

The following items must be done just before delivery to your customer.

- Load test battery and charge if necessary
- Adjust tire pressure to specification
(Refer to door label)
- Clean outside of vehicle

Volts
 Load test result

- Install fuses for accessories
- Remove seat and cabin carpet protective covers
- Vacuum and clean interior of vehicle
- Inspect installation of optional parts

SCHEDULED MAINTENANCE**SCHEDULED MAINTENANCE TABLE (EXCEPT CANADA)****Schedule 1 (Normal driving conditions)**

The vehicle is mainly operated where none of the “unique driving conditions” apply.

Schedule 2 (Unique driving conditions)

- Repeated short-distance driving.
- Driving in dusty conditions.
- Driving with extended use of brakes.
- Driving in areas where road salt or other corrosive materials are used.
- Driving on rough or muddy roads.
- Extended periods of idling or low-speed operation.
- Driving for long prolonged periods in cold temperatures or extremely humid climates.

A

SCHEDULED MAINTENANCE

Schedule 1 (Normal driving conditions)

| Maintenance Interval Maintenance Item | Number of months or miles (kilometers), whichever comes first | | | | | | | | |
|--|---|-----|----|------|----|------|----|------|----|
| | Months | 6 | 12 | 18 | 24 | 30 | 36 | 42 | 48 |
| | × 1,000 Kilometers Miles | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 |
| | | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | 60 |

Engine

| | | | | | | | | | |
|---------------------------------|---|---|---|---|---|---|---|---|-----|
| Engine oil | R | R | R | R | R | R | R | R | R |
| Oil filter | R | R | R | R | R | R | R | R | R |
| Tension of all drive belts | | | | I | | | | | I |
| Engine timing belt | Replace every 60,000 miles (96,000 km) | | | | | | | | |
| Engine timing belt (California) | Inspect at 60,000 miles (96,000 km) and again at 90,000 miles (144,000 km) *2 | | | | | | | | |
| | Replace every 105,000 miles (168,000 km) | | | | | | | | |
| Hose and tube for emission | | | | | | | | | I*2 |

Air cleaner

| | | | | | | | | | |
|---------------------|--|--|--|---|--|--|--|--|---|
| Air cleaner element | | | | R | | | | | R |
|---------------------|--|--|--|---|--|--|--|--|---|

Ignition system

| | | | | | | | | | |
|-------------|--|--|--|---|--|--|--|--|---|
| Spark plugs | | | | R | | | | | R |
|-------------|--|--|--|---|--|--|--|--|---|

Fuel system

| | | | | | | | | | |
|-------------------------|--|--|--|-----|--|--|--|--|-----|
| Idle speed | | | | I*2 | | | | | I*1 |
| Fuel filter | | | | | | | | | R*1 |
| Fuel lines and hoses | | | | I*2 | | | | | I*1 |
| Fuel hoses (California) | Inspect every 105,000 miles (168,000 km) | | | | | | | | |

Cooling system

| | | | | | | | | | |
|----------------|--|--|--|---|--|--|--|--|---|
| Cooling system | | | | I | | | | | I |
| Engine coolant | | | | R | | | | | R |

Chassis and body

| | | | | | | | | | |
|-------------------------------------|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses, and connections | | | | I | | | | | I |
| Drum brakes | | | | I | | | | | I |
| Disc brakes | | | | I | | | | | I |
| Steering operation and linkages | | | | I | | | | | I |
| Front suspension ball joints | | | | I | | | | | I |
| Drive shaft dust boots | | | | I | | | | | I |
| Bolts and nuts on chassis and body | | | | I | | | | | I |
| Exhaust system heat shields | | | | I | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L |

Air conditioner system (if equipped)

| | | | | | | | | | |
|--------------------------|--|---|--|---|--|---|--|---|--|
| Refrigerant amount | | I | | I | | I | | I | |
| A/C compressor operation | | I | | I | | I | | I | |

Chart symbols:

I : Inspect and repair, clean, or replace if necessary.

R: Replace

L: Lubricate

Remarks:

After 48 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.

*1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.

*2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

SCHEDULED MAINTENANCE

A

Schedule 2 (Unique driving conditions)

| Maintenance Interval | Number of months or miles (kilometers), whichever comes first | | | | | | | | | | | | |
|----------------------|---|------------|----|----|----|----|----|----|----|----|----|----|----|
| | Months | 4 | 8 | 12 | 16 | 20 | 24 | 28 | 32 | 36 | 40 | 44 | 48 |
| | × 1,000 | Kilometers | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 |
| Miles | | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

Engine

| | | | | | | | | | | | | | |
|---------------------------------|--|---|---|---|---|---|---|---|---|---|---|---|-----|
| Engine oil | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Engine oil (Puerto Rico) | Replace every 3,000 miles (4,800 km) or 3 months | | | | | | | | | | | | |
| Oil filter | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Tension of all drive belts | | | | | | I | | | | | | | I |
| Engine timing belt | Replace every 60,000 miles (96,000 km) | | | | | | | | | | | | |
| Engine timing belt (California) | Inspect at 60,000 miles (96,000 km) and again at 90,000 miles (144,000 km)*2 | | | | | | | | | | | | |
| Hose and tube for emission | | | | | | | | | | | | | I*2 |

Air cleaner

| | | | | | | | | | | | | | |
|---------------------|--|--|-----|--|--|--|---|--|--|-----|--|--|---|
| Air cleaner element | | | I*2 | | | | R | | | I*2 | | | R |
|---------------------|--|--|-----|--|--|--|---|--|--|-----|--|--|---|

Ignition system

| | | | | | | | | | | | | | |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|---|
| Spark plugs | | | | | | | R | | | | | | R |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|---|

Fuel system

| | | | | | | | | | | | | | |
|-------------------------|--|--|--|--|--|--|-----|--|--|--|--|--|-----|
| Idle speed | | | | | | | I*2 | | | | | | I*1 |
| Fuel filter | | | | | | | | | | | | | R*1 |
| Fuel lines and hoses | | | | | | | I*2 | | | | | | I*1 |
| Fuel hoses (California) | Inspect every 105,000 miles (168,000 km) | | | | | | | | | | | | |

Cooling system

| | | | | | | | | | | | | | |
|----------------|--|--|--|--|--|--|---|--|--|--|--|--|---|
| Cooling system | | | | | | | I | | | | | | I |
| Engine coolant | | | | | | | R | | | | | | R |

Chassis and body

| | | | | | | | | | | | | | |
|-------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses, and connections | | | | | | | I | | | | | | I |
| Drum brakes | | | | | | | I | | | | | | I |
| Disc brakes | | | I | | | | I | | | I | | | I |
| Steering operation and linkages | | | | | | | I | | | | | | I |
| Front suspension ball joints | | | | | | | I | | | | | | I |
| Drive shaft dust boots | | | | | | | I | | | | | | I |
| Bolts and nuts on chassis and body | | | I | | | | I | | | I | | | I |
| Exhaust system heat shields | | | | | | | I | | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L | L | L | L | L |

Air conditioner system (if equipped)

| | | | | | | | | | | | | | |
|--------------------------|--|--|---|--|--|--|---|--|--|---|--|--|---|
| Refrigerant amount | | | I | | | | I | | | I | | | I |
| A/C compressor operation | | | I | | | | I | | | I | | | I |

Chart symbols:

- I : Inspect and repair, clean, or replace if necessary.
(Inspect, and if necessary replace—Air cleaner element only)
- R: Replace
- L: Lubricate

Remarks:

- After 48 months or 60,000 miles (96,000 km), continue to follow the described maintenance at the recommended intervals.
- *1 This maintenance is required for all states except California. However, we recommend that it also be performed on California vehicles.
- *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.

SCHEDULED MAINTENANCE TABLE (CANADA)

| Maintenance Interval | Number of months or miles (kilometers), whichever comes first | | | | | | | | | | | | |
|----------------------|---|------------|----|----|----|----|----|----|----|----|----|----|----|
| | Months | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |
| | × 1,000 | Kilometers | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 |
| Miles | | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

Engine

| | | | | | | | | | | | | | |
|----------------------------|---|---|---|---|---|---|---|---|---|---|---|---|-----|
| Engine oil | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Oil filter | R | R | R | R | R | R | R | R | R | R | R | R | R |
| Tension of all drive belts | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Engine timing belt | | | | | | | | | | | | | R*1 |

Air cleaner

| | | | | | | | | | | | | | |
|---------------------|--|--|---|--|--|--|---|--|--|---|--|--|---|
| Air cleaner element | | | I | | | | R | | | I | | | R |
|---------------------|--|--|---|--|--|--|---|--|--|---|--|--|---|

Ignition system

| | | | | | | | | | | | | | |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|---|
| Spark plugs | | | | | | | R | | | | | | R |
|-------------|--|--|--|--|--|--|---|--|--|--|--|--|---|

Cooling system

| | | | | | | | | | | | | | |
|-----------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Engine coolant level and strength | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Cooling system for leaks | | | I | | | | I | | | I | | | I |
| Engine coolant | | | | | | | R | | | | | | R |

Fuel system

| | | | | | | | | | | | | | |
|--------------------------|--|--|---|--|--|--|-----|--|--|---|--|--|-----|
| Idle speed | | | I | | | | I | | | I | | | I |
| Fuel lines and hoses | | | | | | | I*2 | | | | | | I |
| Fuel filter | | | | | | | R | | | | | | R |
| PCV valve | | | | | | | | | | | | | I*2 |
| Emission hoses and tubes | | | | | | | | | | | | | I |

Chassis and body

| | | | | | | | | | | | | | |
|--|---|---|----|---|---|---|-----|---|---|----|---|---|-----|
| Automatic transaxle fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Transaxle oil (MTX and ATX) | | | | | | | R | | | | | | R |
| Drive shaft dust boots | | | | | | | I | | | | | | I |
| Brake lines and hoses | | | | | | | I | | | | | | I |
| Brake and clutch fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Brake fluid | | | | | | | R*3 | | | | | | R*3 |
| Disc brakes (front and rear) | | | I | | | | I | | | I | | | I |
| Rear drum brakes | | | | | | | I | | | | | | I |
| Tire inflation pressure and tire wear | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Tires | | | Rt | | | | Rt | | | Rt | | | Rt |
| Power steering fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Steering operation and linkage (includes four wheel alignment) | | | | | | | I | | | | | | I |
| Front and rear suspension components | | | | | | | I | | | | | | I |
| All chassis and body nuts and bolts | | | I | | | | I | | | I | | | I |
| Exhaust system heat shields | | | | | | | I | | | | | | I |
| All locks and hinges | L | L | L | L | L | L | L | L | L | L | L | L | L |
| Washer fluid level | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Function of all lights | I | I | I | I | I | I | I | I | I | I | I | I | I |

Air conditioner system (if equipped)

| | | | | | | | | | | | | | |
|--------------------------|--|---|--|---|--|---|--|---|--|---|--|---|--|
| Refrigerant amount | | I | | I | | I | | I | | I | | I | |
| A/C compressor operation | | I | | I | | I | | I | | I | | I | |

Chart symbols:

- I** : Inspect and repair, clean, or replace if necessary.
(Inspect, and if necessary replace.....Air cleaner element only)
- R**: Replace
- L** : Lubricate
- Rt** : Rotation (tires)

Remarks:

After 60 months or 60,000 miles {96,000 km}, continue to follow the described maintenance at the recommended intervals.

- *1 Replacement of the timing belt is required every 60,000 miles {96,000 km}. Failure to replace this belt may result in damage to the engine.
- *2 This maintenance is recommended by Mazda. However, it is not necessary for emission warranty coverage or manufacturer recall liability.
- *3 This maintenance is recommended by Mazda.

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

ENGINE (K8)

| | | | |
|--|--------|--------------------------------------|--------|
| INDEX | B2- 2 | INSPECTION / REPAIR | B2- 73 |
| OUTLINE | B2- 3 | PREPARATION | B2- 73 |
| SPECIFICATIONS | B2- 3 | CYLINDER HEAD | B2- 73 |
| TROUBLESHOOTING GUIDE | B2- 3 | VALVE MECHANISM | B2- 74 |
| ENGINE TUNE-UP | B2- 5 | CAMSHAFT | B2- 78 |
| PREPARATION | B2- 5 | HLA | B2- 80 |
| ENGINE OIL | B2- 5 | CYLINDER BLOCK | B2- 81 |
| ENGINE COOLANT | B2- 5 | PISTON, PISTON RING, AND | |
| DRIVE BELT | B2- 6 | PISTON PIN | B2- 82 |
| HLA TROUBLESHOOTING | | CONNECTING ROD | B2- 83 |
| GUIDE | B2- 8 | CRANKSHAFT | B2- 84 |
| IGNITION TIMING, IDLE SPEED ... | B2- 8 | BEARING | B2- 84 |
| COMPRESSION | B2- 10 | OIL JET | B2- 85 |
| PREPARATION | B2- 10 | TIMING BELT | B2- 85 |
| INSPECTION | B2- 10 | TIMING BELT AUTO | |
| ON-VEHICLE MAINTENANCE | B2- 11 | TENSIONER, IDLER | B2- 85 |
| PREPARATION | B2- 11 | PULLEY | B2- 85 |
| TIMING BELT | B2- 13 | TIMING BELT COVER | B2- 85 |
| CYLINDER HEAD GASKET | B2- 23 | ASSEMBLY | B2- 86 |
| HLA | B2- 37 | PREPARATION | B2- 86 |
| FRONT OIL SEAL | B2- 40 | CYLINDER BLOCK | |
| REAR OIL SEAL | B2- 42 | (INTERNAL PARTS) | B2- 88 |
| REMOVAL | B2- 44 | CYLINDER BLOCK | |
| PROCEDURE | B2- 44 | (EXTERNAL PARTS) | B2- 96 |
| ENGINE STAND MOUNTING | B2- 52 | CYLINDER HEAD | B2-100 |
| PREPARATION | B2- 52 | TIMING BELT | B2-107 |
| PROCEDURE | B2- 53 | AUXILIARY PARTS | B2-112 |
| DISASSEMBLY | B2- 56 | ENGINE STAND DISMOUNTING | B2-116 |
| PREPARATION | B2- 56 | PROCEDURE | B2-116 |
| AUXILIARY PARTS | B2- 58 | INSTALLATION | B2-117 |
| TIMING BELT | B2- 60 | PROCEDURE | B2-117 |
| CYLINDER HEAD | B2- 62 | | |
| CYLINDER BLOCK | | | |
| (EXTERNAL PARTS) | B2- 66 | | |
| CYLINDER BLOCK | | | |
| (INTERNAL PARTS) | B2- 69 | | |

INDEX

INTAKE MANIFOLD TIGHTENING TORQUE
19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}

COMPRESSION INSPECTION, PAGE B2-10
STANDARD: 1334 kPa {13.6 kgf/cm², 193 psi}-300 rpm
MINIMUM: 981 kPa {10.0 kgf/cm², 142 psi}-300 rpm

DEFLECTION AT 98 N {10 kgf, 22 lbf}

| | mm {in} | |
|-----------------|---------------------|---------------------|
| | NEW | USED |
| DRIVE BELT | | |
| GENERATOR | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} |
| GENERATOR + A/C | 5.5-6.5 {0.22-0.25} | 6.5-7.5 {0.26-0.29} |
| P/S | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} |

ENGINE OIL INSPECTION/ SERVICE, SECTION D2

EXHAUST MANIFOLD TIGHTENING TORQUE
19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}

| | kPa {kgf/cm ² , psi}-rpm |
|----------|-------------------------------------|
| STANDARD | 1,334 {13.6, 193}-300 |
| MINIMUM | 981 {10.0, 142}-300 |

- 1. Timing belt
Removal / Inspection /
Installation page B2-13
- 2. Cylinder head gasket
Replacement page B2-23
- 3. HLA
Removal / Installation page B2-37
- 4. Front oil seal
Replacement page B2-40

- 5. Rear oil seal
Replacement page B2- 42
- 6. Engine
Removal page B2- 44
Engine stand mounting page B2- 52
Disassembly page B2- 56
Inspection / Repair page B2- 73
Assembly page B2- 86
Engine stand dismounting ... page B2-116
Installation page B2-117


OUTLINE

SPECIFICATIONS

| Item | | Engine | K8 DOHC | |
|---------------------------------|----|-------------------------------------|----------------------------------|-----|
| Type | | | Gasoline, 4-cycle | |
| Cylinder arrangement and number | | | 60°-V configuration, 6 cylinders | |
| Combustion chamber | | | Pentroof | |
| Valve system | | | DOHC, belt-driven, 24 valves | |
| Displacement | | ml {cc, cu in} | 1,844 {1,844, 112.4} | |
| Bore stroke | | mm {in} | 75 × 69.6 {2.95 × 2.74} | |
| Compression ratio | | | 9.2 | |
| Compression pressure | | kPa {kgf/cm ² , psi}-rpm | 1,334 {13.6, 193}-300 | |
| Valve timing | IN | Open | BTDC | 6° |
| | | Close | ABDC | 37° |
| | EX | Open | BBDC | 49° |
| | | Close | ATDC | 6° |
| Valve clearance | IN | mm {in} | 0 {0} : Maintenance-free | |
| | EX | mm {in} | 0 {0} : Maintenance-free | |
| Firing order | | | 1-2-3-4-5-6 | |

B2

Cylinder Arrangement



TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|--------------------|---|---------------------|-------|
| Difficult starting | Malfunction of engine-related components | | |
| | Burned valve | Replace | B2-74 |
| | Worn piston, piston ring, or cylinder | Replace or repair | B2-82 |
| | Damaged cylinder head gasket | Replace | B2-23 |
| | Malfunction of fuel system | Refer to section F2 | |
| | Malfunction of electrical system | Refer to section G | |
| Poor idling | Malfunction of engine-related components | | |
| | Malfunction of HLA | Replace | B2-37 |
| | Poor valve-to-valve seat contact | Repair or replace | B2-76 |
| | Damaged cylinder head gasket | Replace | |
| | Malfunction of fuel system | Refer to section F2 | |

*Tappet noise may occur if the engine has not been started for an extended period of time. The noise should stop after the engine reaches normal operating temperature. (HLA troubleshooting: Refer to page B2-8.)

| Problem | Possible Cause | Action | Page |
|---------------------------|---|---|--|
| Insufficient power | Insufficient compression Malfunction of HLA Compression leakage from valve seat Stuck valve Weak or broken valve spring Damaged cylinder head gasket Cracked or distorted cylinder head Stuck, damaged, or worn piston ring Cracked or worn piston | Replace Repair Replace Replace Replace Replace Replace Replace | B2-37 B2-76 B2-74 B2-77 B2-23 B2-73 B2-82 B2-82 |
| | Malfunction of fuel system | Refer to section F2 | |
| | Others Dragging brake Wrong size tires | Refer to section P Refer to section Q | |
| Abnormal combustion | Malfunction of engine-related components Malfunction of HLA Stuck or burned valve Weak or broken valve spring Carbon accumulation in combustion chamber | Replace Replace Replace Eliminate carbon | B2-37 B2-74 B2-77 |
| | Malfunction of fuel system | Refer to section F2 | |
| Excessive oil consumption | Oil working up Worn piston ring groove or stuck piston ring Worn piston or cylinder | Replace Replace or repair | B2-82 B2-81,82 |
| | Oil working down Worn valve seal Worn valve stem or guide | Replace Replace | B2-65 B2-75 |
| | Oil leakage | Refer to section D2 | |
| Engine noise | Crankshaft- or bearing-related parts Excessive main bearing oil clearance Main bearing heat-damaged Excessive crankshaft end play Excessive connecting rod bearing oil clearance Connecting rod bearing heat-damaged | Replace or repair Replace Replace or repair Replace or repair Replace | B2-91 B2-84 B2-93 B2-94 B2-84 |
| | Piston-related parts Worn cylinder Worn piston or piston pin Damaged piston ring Bent connecting rod | Replace or repair Replace Replace Replace | B2-81 B2-82,83 B2-82 B2-83 |
| | Valve train-related parts Malfunction of HLA* Broken valve spring Excessive valve guide clearance Malfunction of timing belt auto tensioner Malfunction of friction gear | Replace Replace Replace Replace Replace | B2-80 B2-77 B2-75 B2-85 B2-76 |
| | Malfunction of cooling system | Refer to section E2 | |
| | Malfunction of fuel system | Refer to section F2 | |
| | Others Malfunction of water pump bearing Improper drive belt tension Malfunction of generator bearing Exhaust gas leakage | Replace Adjust Replace Repair | — B2-5 — — |

* Tappet noise may occur if the engine has not been started for an extended period of time. The noise should stop after the engine reaches normal operating temperature. (HLA troubleshooting: Refer to page B2-8.)



Warning


- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

ENGINE TUNE-UP

PREPARATION

SST

| | | | |
|--|---|---|---|
| <p>49 9200 020A</p> <p>V-ribbed belt tension gauge</p>  | <p>For inspection of drive belt tension</p> | <p>49 B019 9A0</p> <p>System selector</p>  | <p>For inspection of ignition timing and idle speed</p> |
|--|---|---|---|



ENGINE OIL

Inspection

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil if necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.9 Imp qt}.


ENGINE COOLANT

Inspection


Coolant level (engine cold)

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam can shoot out and cause serious injury. It can also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap – still using a cloth – turn it, and remove it.




1. Verify that the coolant level is near the filler neck.
2. Verify that the coolant level in the coolant reservoir is between the FULL and LOW marks.
3. Add coolant if necessary.



Coolant quality


1. Verify that there is no buildup of rust or scale around the radiator cap, filler cap, or filler neck.
2. Verify that the coolant is free of oil.
3. Replace the coolant if necessary.



DRIVE BELT

Inspection

1. Check the drive belts for wear, cracks, and fraying. Replace if necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.




3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure 98 N {10kgf, 22 lbf} midway between the specified pulleys.


Deflection


| Drive belt | mm {in} | | |
|-----------------|------------------------|------------------------|---------------|
| | New * | Used | Limit |
| Generator | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} | 9.0 {0.35} |
| Generator + A/C | 5.5-6.5 {0.22-0.25} | 6.5-7.5 {0.26-0.29} | 8.0 {0.32} |
| P/S | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} | 9.0 {0.35} |

* A belt that has been on a running engine for less than five minutes.



4. If the deflection is not within the specification, adjust it. (Refer to page B2-7.)



**Drive belt tension check**

Belt tension can be checked in place of belt deflection.


1. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the SST, check the belt tension between any two pulleys.

Tension

| Drive belt | N {kgf, lbf} | | |
|--------------------|--------------------------------|--------------------------------|----------------|
| | New * | Used | Limit |
| Generator | 690-880 {70-90, 160-190} | 500-680 {50-70, 110-150} | 440 {45,99} |
| Generator + A/C | 690-880 {70-90,160-190} | 500-680 {50-70,110-150} | 440 {45,99} |
| P/S | 540-680 {55-70,130-150} | 400-530 {40-55, 90-120} | 340 {35,77} |

* A belt that has been on a running engine for less than five minutes.

2. If the tension is not within the specification, adjust it. (Refer to below.)

**Adjustment****Generator + A/C, Generator**

1. Loosen idler pulley locknut (A).
2. Adjust the belt deflection by turning adjusting bolt (B).

Deflection**(Generator + A/C)**

New : 5.5-6.5mm {0.22-0.25 in}

Used: 6.5-7.5mm {0.26-0.29 in}

(Generator)


New: 6.0-7.0 mm {0.24-0.27 in}

Used: 7.0-8.0 mm {0.28-0.31 in}

3. Tighten pulley locknut (A).

Tightening torque:

32-46 N·m {3.2-4.7 kgf·m, 24-33 ft·lbf}

**P/S**

1. Loosen idler pulley locknut (A).
2. Adjust the belt deflection by turning adjusting bolt (B).

Deflection

New : 6.0-7.0mm {0.24-0.27 in}

Used: 7.0-8.0mm {0.28-0.31 in}


3. Tighten pulley locknut (A).

Tightening torque:

32-46 N·m {3.2-4.7 kgf·m, 24-33 ft·lbf}

HLA TROUBLESHOOTING GUIDE


| Problem | Possible Cause | Action |
|---|---|--|
| 1. Noise when engine is first started after oil is changed. 2. Noise when engine is started after setting approx. one day. | Insufficient oil in HLA Oil leakage from HLA | Run engine at 2,000–3,000 rpm. If noise stops after 2 seconds–10 minutes,* HLA is normal. If not, replace HLA. * Time required for engine oil to circulate within engine includes tolerance for engine oil condition and ambient temperature. |
| 3. Noise when engine is started after cranking for 3 seconds or more. | | |
| 4. Noise when engine is started after new HLA is installed. | | |
| 5. Noise continues more than 10 minutes. | | |
| 6. Noise during idle after high speed running. | Insufficient oil pressure | Check oil pressure. If lower than specification, check for cause. Oil pressure: 334–490 kPa {3.4–5.0 kgf/cm ² , 49–71 psi}-3,000 rpm |
| | Faulty HLA | (Refer to page B2–79.) Press down HLA by hand. If it does not move, HLA is normal. If it moves, replace HLA. Measure valve clearance. If more than 0mm {0 in}, replace HLA. |
| 6. Noise during idle after high speed running. | Incorrect oil amount | Check oil level. Drain or add oil as necessary. |
| | Deteriorated oil | Check oil quality. If deteriorated, replace with specified type and amount of oil. |



IGNITION TIMING, IDLE SPEED

Preparation

- Warm up the engine to normal operating temperature.
- Turn all electric loads off.
 - Headlight switch
 - Blower switch
 - Rear window defroster switch
- Connect the **SST** to the data link connector.
- Connect a timing light.
- Connect a tachometer to the data link connector terminal **IG-**.




Ignition timing


- Perform "Preparation." (Refer to above.)
- Make sure the idle speed is within the specification. If not, adjust the idle speed.

Idle speed (MTX in Neutral, ATX in P range)
:650–710 rpm

- Set switch **A** to position 1.
- Set **TEST SW** to **SELF-TEST**.
- If the **SST** is not used, jump across the **TEN** and **GND** terminals of the data link connector.
- Make sure the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition timing: 9–11° BTDC






7. If the marks are not aligned, loosen the distributor mounting bolts and turn the distributor to make the adjustment.
8. Tighten the distributor bolts to the specified torque.

Tightening torque:

19–25 N·m (1.9–2.6 kgf·m, 14–18 ft·lbf)

9. Disconnect the jumper wire or the SST.



Idle Speed

1. Apply parking brake.
2. Perform "Preparation." (Refer to page B2–8.)
3. With the coolant fan off, verify that the idle speed is within the specification.

Idle speed (Neutral or P range) : 640–700 rpm

4. If not, adjust the idle speed by turning the air adjusting screw (AAS).
5. Disconnect the jumper wire or the SST.



COMPRESSION



If the engine exhibits low power, poor fuel economy, or poor idle, check the following:

1. Ignition system (Refer to section G.)
2. Compression (Refer to below.)
3. Fuel system (Refer to section F2.)

PREPARATION

SST

| | | | |
|--|--|--|--|
| <p>49 H010 103 Compression gauge</p>  | <p>For Inspection of compression</p> | <p>49 H010 104 Adaptor</p>  | <p>For Inspection of compression</p> |
|--|--|--|--|



INSPECTION

1. Verify that the battery is fully charged. Recharge it if necessary.
2. Warm up the engine to the normal operating temperature.
3. Stop the engine and allow it to cool for about 10 minutes.
4. Remove the all spark plugs.
5. Disconnect the distributor connector.
6. Install **SST** into the No.1 spark plug hole.
7. Fully depress the accelerator pedal and crank the engine.
8. Note the maximum gauge reading.
9. Check each cylinder as above.

Compression

| | kPa {kgf/cm ² , psi}-rpm |
|--------------------------------------|-------------------------------------|
| Standard | 1,334 {13.6, 193}-300 |
| Minimum | 981 {10.0, 142}-300 |
| Maximum difference between cylinders | 196 {2.0, 28} |

















10. If the compression in one or more cylinders is low, pour a small amount of clean engine oil into the cylinder and recheck the compression.
 - (1) If the compression increases, the piston, piston rings, or cylinder wall may be worn.
 - (2) If the compression stays low, the valve may be stuck or improperly seated.
 - (3) If the compression in adjacent cylinders stays low, the cylinder head gasket may be damaged or the cylinder head distorted.
11. Remove the **SST**.
12. Connect the distributor connector.
13. Install all spark plugs.

Tightening torque:

15–22 N·m {1.5–2.3 kgf·m, 11–16 ft·lbf}

ON-VEHICLE MAINTENANCE

PREPARATION
SST

| | | | |
|--|---|---|---|
| <p>49 S120 710 Holder, coupling flange</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 1A1 Set, holder</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 101 Holder (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 102 Bolts (Part of 49 E011 1A1)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 G017 501 Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 502 Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 503 Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 E011 1A0 Brake set, ring gear</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 0118 850C Puller, ball joint</p>  | <p>For removal of tie rod end ball joint</p> | <p>49 G019 017 Installer, oil seal</p>  | <p>For installation of rear oil seal</p> |
| <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of camshaft oil seals</p> | <p>49 F401 337A Attachment C (Part of 49 F401 330B)</p>  | <p>For installation of camshaft oil seals</p> |


Warning

- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**


TIMING BELT

Removal / Inspection / Installation

1. Disconnect the negative battery cable.
2. Remove the right front wheel.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Splash shield (RH) 2. Drive belt Removal / Installation page B2- 6 3. Water pump pulley 4. Idler pulley and bracket 5. P/S oil pump Removal Note page B2-14 Installation Note page B2-21 6. Crankshaft pulley Removal Note page B2-15 Installation Note page B2-21 7. Dipstick and pipe Removal Note page B2-15 Installation Note page B2-20 8. Crankshaft position sensor harness bracket | <ol style="list-style-type: none"> 9. Engine harness bracket 10. Timing belt cover Removal Note page B2-15 Installation Note page B2-19 11. Timing belt Removal Note page B2-16 Inspection page B2-85 Installation Note page B2-17 12. Timing belt auto tensioner Inspection page B2-85 Installation Note page B2-17 13. Tensioner pulley 14. No.2 idler pulley 15. No.1 idler pulley |
|--|--|




Removal Note
P/S oil pump

1. Disconnect the P/S oil pump hose from the engine.
2. Disconnect the steering pressure sensor connector.




3. Remove the bolts shown in the figure and secure the P/S oil reservoir away from the engine.




4. Loosen the pulley nut as shown.
5. Remove the pulley.



6. Remove the bolt shown.




7. Remove the bolts shown in the figure and remove the P/S oil pump.
8. Position the P/S oil pump away from the engine and secure it with wire.




Crankshaft pulley

Caution

- The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.




1. Install the **SST** to the crankshaft pulley with bolts (M10 X 1.25).
2. Remove the crankshaft pulley bolt and the pulley.




Dipstick and pipe

1. Disconnect the crankshaft position sensor connector.
2. Remove the clip from the dipstick pipe.




3. Remove the dipstick and pipe.
4. Plug the hole in the engine after removing the pipe.




Timing belt cover


1. Support the engine by using the **SST** (engine support).



2. Remove the No.3 engine mount.




3. Remove the right and left timing belt covers.



Timing belt


1. Install the crankshaft pulley bolt into the crankshaft.
2. Turn the crankshaft clockwise and align the timing marks. (No.1 piston is at TDC of the compression stroke.)
3. Mark the timing belt rotation on the belt for proper reinstallation.



4. Loosen the auto tensioner bolts and remove the lower bolt.

Caution


- When removing the bolt, hold the tensioner so that the bolt holes are aligned, otherwise the threads can be damaged.



5. Remove the No.1 idler pulley and remove the timing belt.


Caution

- When removing the pulley bolt, hold the pulley so that the bolt holes are aligned, otherwise the threads can be damaged.
- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

**Inspection**

Inspect the following and repair or replace as necessary.


- (1) Timing belt (Refer to page B2-85.)
- (2) Timing belt auto tensioner (Refer to page B2-85.)
- (3) Timing belt pulley (Refer to page B2-85.)
- (4) Camshaft pulleys (Refer to page B2-85.)

**Installation Note****Timing belt auto tensioner**

1. Slowly press the tensioner rod into the tensioner body by using a press.

Caution


- Applying pressure of more than 9,807 N {1,000 kgf, 2,200 lbf} can damage the tensioner.



2. Insert a pin into the second hole in the body as shown to hold the tensioner rod.

Note


- Pin diameter: 1.6mm {0.063 in}




3. Set the tensioner in place and snugly tighten the tensioner upper bolt.

Note


- This must be done to reduce the timing belt resistance when the idler pulley is installed.

**Timing belt**


1. Turn the camshaft pulleys clockwise and align the timing marks.



- Using the crankshaft bolt, turn the crankshaft clockwise and align the timing marks of the timing belt pulley and the oil pump.




- Install the timing belt on the pulleys in the order shown below.
 - Timing belt pulley
 - No.2 idler pulley
 - LH camshaft pulley
 - Tensioner pulley
 - RH camshaft pulley



- Verify that there is tension between pulleys ③ and ①, and between pulleys ① and ⑤.
- Install the No.1 idler pulley while applying pressure on the timing belt.

Tightening torque:


38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}




- Push the auto tensioner in the direction of the arrow and tighten the bolts.

Tightening torque:


19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



- Remove the pin from the auto tensioner to apply tension to the belt.




8. Turn the crankshaft clockwise twice, and align the timing marks.
9. Verify that all timing marks are correctly aligned. If necessary, repeat the procedure beginning from installation of the timing belt auto tensioner.



10. Check the timing belt deflection by applying moderate pressure **98 N {10 kgf, 22 lbf}** midway between the crankshaft pulley and the auto tensioner. If not correct, replace the auto tensioner.

Deflection: 6.0–8.0mm {0.24–0.31in}




Timing belt cover

1. Install the right timing belt cover.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



2. Install the left timing belt cover.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



3. Install the crankshaft position sensor connector bracket on the left timing belt cover.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



4. Install the harness bracket on the right timing belt cover.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



5. Install the No.3 engine mount.


Tightening torque

Ⓐ : 74–102 N·m {7.5–10.5 kgf·m, 55–75.9 ft·lbf}

Ⓑ : 86–116 N·m {8.7–11.9 kgf·m, 63–86.0 ft·lbf}



6. Remove the **SST** (engine support).




Dipstick and pipe

1. Apply clean engine oil to a new O-ring, and install it on the pipe.
2. Remove the plug from the engine and install the pipe.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

3. Install the dipstick.



4. Install the crankshaft position sensor harness and clip to the dipstick pipe.


5. Connect the connector.

**Crankshaft pulley**

1. Remove the crankshaft pulley bolt.
2. Install the crankshaft pulley and hand tighten the bolt.
3. Mount the **SST** on the crankshaft pulley to hold the crankshaft.
4. Tighten the crankshaft pulley bolt.

Tightening torque:

157–166 N·m {16.0–17.0 kgf·m, 116–122 ft·lbf}

**P/S oil pump**

1. Install the P/S oil pump.

Tightening torque

Ⓐ : 32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}


Ⓑ : 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



2. Install the P/S oil pump pulley and hand tighten the pulley nut.
3. Tighten the pulley nut by using a 12mm {0.47 in} socket on the P/S oil pump mount bolts.

Tightening torque:


63–93 N·m {6.4–9.5 kgf·m, 46–69 ft·lbf}




4. Install the P/S oil reservoir.


Tightening torque:

6.9–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}



**Drive belt**

1. Install the water pump pulley and hand tighten the bolts.




2. Install the P/S oil pump and water pump drive belt on the pulleys.

3. Adjust the drive belt deflection. (Refer to page B2-6.)

4. Tighten the water pump pulley.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



5. Install the A/C compressor drive belt on the pulleys, and adjust the belt deflection. (Refer to page B2-6.)

Steps After Installation

1. Install the right front wheel.


2. Fill the radiator and coolant reservoir with the specified amount and type of engine coolant.

3. Perform the necessary engine adjustments. (Refer to ENGINE TUNE-UP, page B2-5.)

- | | | |
|----------------------------|--------------------------------|---------------------------------|
| 1. Fresh-air duct | 9. Intake manifold assembly | 15. Seal plate |
| 2. Air cleaner assembly | Removal Note page B2-26 | 16. Water outlet |
| 3. Battery and carrier | Installation Note | 17. Exhaust pipe |
| 4. Accelerator cable | page B2-34 | 18. Engine hanger |
| Installation Note | 10. Distributor | 19. Camshaft cap and oil seal |
| page B2-36 | Installation Note | Removal Note page B2-27 |
| 5. Throttle cable (ATX) | page B2-33 | Installation Note |
| Installation/ | 11. Cylinder head cover | page B2-30 |
| Adjustment section K | Removal Note page B2-26 | 20. Camshaft |
| 6. High-tension lead | Installation Note | Installation Note |
| 7. Harness | page B2-33 | page B2-30 |
| Removal Note page B2-25 | 12. Camshaft pulley | 21. Cylinder head bolt |
| Installation Note | Removal Note page B2-27 | Removal Note page B2-28 |
| page B2-36 | Installation Note | 22. Generator strap |
| 8. Hoses | page B2-32 | 23. Cylinder head |
| Removal Note page B2-25 | 13. Radiator hose, upper | Installation Note |
| Installation Note | 14. No. 3 engine mount bracket | page B2-29 |
| page B2-35 | Removal Note page B2-27 | 24. Cylinder head gasket and O- |
| | Installation Note | ring |
| | page B2-31 | |


**Removal Note
Harness**


Disconnect the harness connectors shown.



Hoses

Disconnect the hoses shown.






Fuel hose

Warning


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.

Plug the disconnected hoses to avoid fuel leakage.




Intake manifold assembly


1. Temporarily install the No.3 engine mount bracket to support the engine.
2. Remove the **SST** installed for the timing belt removal.



3. Remove the intake manifold stay.




4. Loosen the mounting bolts in two or three steps.




Cylinder head cover

1. Remove the cylinder head cover bolts.
2. Disconnect the ventilation pipe (left cylinder head).
3. Remove the cylinder head cover.




Camshaft pulley

1. Hold the camshaft by using a wrench on the cast hexagon as shown, and loosen the camshaft pulley lock bolts.
2. Remove the camshaft pulleys.




No.3 engine mount bracket

1. Install the SST and support the engine.



2. Disconnect the No.3 engine mount bracket from the engine mount rubber.
3. Remove the No.3 engine mount bracket from the engine.




Camshaft cap and oil seal

Caution

- When the front camshaft lobe is pressing on the HLA, removing the camshaft caps can damage the cylinder head thrust journal support.






Perform this same procedure for the right and left cylinder heads.

1. Turn the camshaft clockwise by using a wrench on the cast hexagon and align the camshaft knock pin and cylinder head marks as shown.
2. Loosen the front camshaft cap bolts in five or six steps in the order shown.
3. Remove the front camshaft cap.



Note

- Bolt ⑤ fits only for right cylinder head.



Note

- Before removing the camshaft caps, note their locations.

4. Loosen the camshaft cap bolts in five or six steps in the order shown.
5. Remove the camshaft caps.

Caution


- Remove the thrust cap only after removing all camshaft caps. Otherwise, the thrust cap can be damaged.

Cylinder head bolt

1. Temporarily install the No.3 engine mount bracket to support the engine.

2. Remove the SST.

3. Loosen the cylinder head bolts in two or three steps in the order shown.
4. Remove the cylinder head bolts.




Installation Note

Cylinder head


1. Measure the amount of oil control plug projection from the deck of the cylinder block.

Projection: 8.0–9.0 mm {0.315–0.354 in}

2. Apply clean engine oil to new O-rings and install them to the oil control plugs.




3. Thoroughly remove all dirt, oil, and other material from the decks of the cylinder block.
4. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
5. Place a new cylinder head gasket (marked L) on the left bank.
6. Place a new cylinder head gasket (marked R) on the right bank.



7. Install the cylinder heads to the cylinder block.
8. Tighten the cylinder head bolts as described below.
 - (1) Before installation, measure the length of each bolt. Replace the bolt if it exceeds the maximum length.


Length : 133.7–134.3 mm {5.264–5.287 in}
Maximum: 135.0 mm {5.315 in}




- (2) Apply clean engine oil to the threads and the seat face of each bolt, and install them and the washers.
- (3) Tighten the bolts in two or three steps in the order shown.

Tightening torque:


23.1–25.9 N·m {2.35–2.65 kgf·m, 17.0–19.1ft·lbf}



- (4) Put a paint mark on each bolt head.
- (5) Using the marks as a reference, tighten the bolts by turning each 85°–95° in the sequence shown.
- (6) Further tighten each bolt by turning another 85°–95°.




9. Support the engine by using the **SST**.



10. Disconnect the No.3 engine mount bracket.

11. Remove the No.3 engine mount bracket from the engine.



Camshaft


Caution

- Camshafts must be assembled in the following procedure. Otherwise, camshaft can be broken or damaged because there is little camshaft thrust clearance.

1. Apply a liberal amount of clean engine oil to the journals, cam lobes, and camshaft gears.
2. Align the timing marks of intake camshaft and exhaust camshaft.
3. Install the camshafts on the cylinder head.

Note

- The thrust plate positions for the right and left cylinder head camshafts are different.



Camshaft cap and oil seal


1. Remove the oil, dirt and other foreign material from the mating surfaces between the front camshaft cap and the cylinder head, and degrease.


2. Apply silicone sealant to the shaded areas shown.

Caution


- Install the thrust caps first. Otherwise, camshaft can be broken or damaged.

3. Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the camshaft caps fully seated on the cylinder head.





4. Install the camshaft caps, and hand tighten the camshaft cap bolts.



5. Tighten the camshaft cap bolts gradually in five or six steps in the order shown.

Tightening torque:

11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}

6. Retighten the bolts in the order shown.


Tightening torque:

11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}

7. Install the distributor cap. (LH cylinder head)

Tightening torque:


11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}




8. Apply a light coat of clean engine oil to the new oil seal and the cylinder head.

9. Tap the camshaft oil seal into the cylinder head by using a SST and a hammer.

Protrusion: 0–0.5mm {0–0.019 in}



10. Tap in the new blind cap by using a plastic hammer.




No.3 engine mount bracket


1. Install the No.3 engine mount bracket to the engine.

Tightening torque:


44–60 N·m {4.4–6.2 kgf·m, 32–44 ft·lbf}



2. Temporarily install the No.3 engine mount bracket to the engine mount rubber.




3. Remove the SST.




Camshaft pulley

1. Install the RH camshaft pulley so that the "R" mark can be seen and the timing mark aligns with the camshaft knock pin.




2. Install the LH camshaft pulley so that the "L" mark can be seen and the timing mark aligns with the camshaft knock pin.




3. Apply clean engine oil to the lock bolt threads and temporarily tighten the camshaft pulley lock bolts.
4. Hold the camshaft by using a wrench on the cast hexagon as shown, and tighten the camshaft pulley lock bolts.

Tightening torque:

123–140 N·m {12.5–14.3 kgf·m, 91–103 ft·lbf}

**Cylinder head cover**

1. Remove all old silicone sealant from the cylinder head and cover.
2. Apply silicone sealant to the cylinder head cover as shown.
3. Remove all dirt and other material from the cylinder head, and apply sealant as shown.



4. Install the cylinder head cover and tighten the bolts in two or three steps in the order shown.


Tightening torque:

5.0–8.8 N·m {50–90 kgf·cm, 44–78 in·lbf}

5. Retighten the bolts. (RH ⑤ ⑥, LH ⑥ ⑦)

Tightening torque:



5.0–8.8 N·m {50–90 kgf·cm, 44–78 in·lbf}




6. Install the ventilation pipe to the left cylinder head cover.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Distributor**


1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply clean engine oil to the drive blade.
3. Align the matching marks on the distributor body and the camshaft gear.



4. Install the distributor with the blade fit into the camshaft groove.
5. Hand tighten the distributor mounting bolt.

**Intake manifold assembly**


1. Install a new gasket and the intake manifold. Hand tighten the bolts and nuts.



2. Install the intake manifold stay.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}




3. Tighten the bolts and nuts in two or three steps.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



Hoses

Connect the hoses shown.



Harness

Connect the harness connectors shown.

**Accelerator cable**

1. Install the accelerator cable.
2. Adjust the cable deflection by turning nuts **A**.

Free play: 1–3mm {0.04–0.11in}


Steps After Installation

1. Install the timing belt. (Refer to page B2–13.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E2.)
3. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to pages B2–8,9.)
 - (3) check the operation of the emission control system. (Refer to section F2.)
4. Recheck the engine coolant and oil levels.

HLA

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the timing belt. (Refer to page B2-12.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|--|---|
| 1. Accelerator cable Installation Note page B2-36 | 7. Distributor Installation Note page B2-33 |
| 2. Throttle cable (ATX) Adjustment section K | 8. Camshaft pulley Removal Note page B2-27 Installation Note page B2-32 |
| 3. High-tension leads | 9. Camshaft cap and oil seal Removal Note page B2-27 Installation Note page B2-30 |
| 4. Harness and hoses Removal / Installation Note below | 10. Camshaft Installation Note page B2-30 |
| 5. Intake manifold assembly Removal Note page B2-26 Installation Note page B2-34 | 11. HLA Inspection page B2-80 |
| 6. Cylinder head cover Removal Note page B2-26 Installation Note page B2-33 | |


Removal / Installation Note

Harness and hoses

1. Disconnect the harness connectors and hoses shown.
2. Connect the harness connectors and hoses in the reverse order of disconnection.



HOSES


**Steps After Installation**

1. Install the timing belt. (Refer to page B2-13.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E2.)
3. Start the engine and
 - (1) check the engine oil and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to pages B2-8, 9.)
 - (3) check the operation of the emission control system. (Refer to section F2.)
4. Recheck the engine coolant and oil levels.

FRONT OIL SEAL


Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



- | | |
|------------------------|------------------|
| 1. Timing belt | |
| Removal / Installation | page B2-13 |
| 2. Timing belt pulley | |
| Removal Note | page B2-41 |
| Installation Note | page B2-41 |

- | | |
|-------------------|------------------|
| 3. Oil seal | |
| Removal Note | page B2-41 |
| Installation Note | page B2-41 |




Removal Note

Timing belt pulley

Note


- If necessary, remove the pulley with a steering wheel puller.

1. Remove the timing belt pulley.
2. Remove the crankshaft key.



Oil seal

1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.



Installation Note


Oil seal

1. Apply clean engine oil to the lip of a new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly with a pipe and a hammer.

Protrusion: 0–0.5mm {0–0.019 in}

Note

- Oil seal outer diameter: 48.0 mm {1.89 in}
- Oil seal inner diameter: 34.0 mm {1.34 in}



Timing belt pulley

1. Install the timing belt pulley.
2. Install the crankshaft key with the tapered side toward the oil pump body.

Steps After Installation


Start the engine and check the following.

- Ignition timing (Refer to page B2–8.)

REAR OIL SEAL


Replacement

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.



1. Transaxle
 MTX
 Removal / Installation section J2
 ATX
 Removal / Installation section K
2. Clutch cover, clutch disc (MTX)
 Service section H
3. Flywheel (MTX)
 Removal Note below
 Installation Note page B2-43

4. Drive plate, backing plate, adapter (ATX)
 Removal Note below
 Installation Note page B2-43
5. Oil seal
 Removal Note page B2-43
 Installation Note page B2-43




Removal Note

Flywheel (MTX)


1. Hold the flywheel by using the **SST**.
2. Remove the flywheel mounting bolts.
3. Remove the flywheel.

Drive plate (ATX)

1. Hold the drive plate by using the **SST**.
2. Remove the lock bolts.
3. Remove the backing plate, drive plate, and adapter.


**Oil seal**

1. Cut the oil seal lip with a razor knife.
2. Remove the oil seal by using a screwdriver protected with a rag.

**Installation Note****Oil seal**

1. Apply clean engine oil to the lip of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly with the **SST** and a hammer.


Protrusion: 0–0.7mm {0–0.03 in}

**Flywheel (MTX)**


1. Set the flywheel onto the crankshaft.
2. Hand tighten the lock bolts.
3. Hold the flywheel by using the **SST**.
4. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61–87 N·m {6.2–8.9 kgf·m, 45–49 ft·lbf}

**Drive plate (ATX)**

1. Install the adapter, drive plate and backing plate as shown and hand tighten the lock bolts.



2. Hold the drive plate by using the **SST**.
3. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61–87 N·m {6.2–8.9 kgf·m, 45–49 ft·lbf}

Steps After Installation

Start the engine and perform engine adjustments as necessary.

REMOVAL


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.

PROCEDURE


1. Disconnect the negative battery cable.
2. Drain the engine coolant and transaxle oil.
3. Remove the hood and front wheels.
4. Remove in the order shown in the figure, referring to Removal Note.

Step 1




1. Splash shield
2. Fresh-air duct
3. Air cleaner assembly
4. Coolant reservoir
5. Battery duct
6. Battery and carrier
7. Accelerator cable
8. Radiator hose
9. Oil cooler hose (ATX)
10. Coolant fan motor connector


11. Shroud upper panel
12. Radiator and coolant fan assembly
13. Drive belt
Removal page B2- 7
14. P/S oil pump
Removal Note page B2-45
15. A/C compressor (if equipped)
Removal Note page B2-46
16. Control cable (ATX)

**Removal Note****P/S oil pump**


1. Disconnect the P/S oil pump hose from the engine.
2. Disconnect the steering pressure sensor connector.




3. Remove the bolts shown and secure the P/S oil reservoir away from the engine.




4. Loosen the pulley nut as shown.
5. Remove the pulley.



6. Remove the bolt shown.



7. Remove the bolts shown and remove the P/S oil pump.
8. Position the P/S oil pump away from the engine and secure it with wire.




A/C compressor

1. Remove the A/C compressor with the hoses still connected.
2. Position the compressor away from the engine and secure it with wire.



Step 2

Disconnect the harness connectors shown.



Step 3

Disconnect the hoses shown.



Removal Note
Fuel hose


Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on section F2.


Disconnect the fuel hoses.

Heater hose

Press the heater hose retainer tabs and remove the heater hoses.



Step 4



1. Clutch release cylinder (MTX)

Removal Note below

2. Transverse member

3. Exhaust front pipe

4. Shift control rod (MTX)

5. Extension bar (MTX)

6. Stabilizer control link

7. Tie-rod end ball joint


Removal Note page B2-49

8. Engine mount member

Removal Note page B2-49

9. Drive shaft

Removal Note page B2-49



Removal Note


Clutch release cylinder (MTX)

1. Unbolt the release cylinder pipe brackets from the transaxle.


Caution

• Bending the pipe can cause kinks or cracks.

2. Remove the release cylinder and position it away from the transaxle with the hose still connected.


**Tie-rod end ball joint**

1. Remove the cotter pin and loosen the nut so that it is flush with the end of the ball joint stud.
2. Separate the knuckle arm and ball joint by using the **SST**.

**Engine mount member****Warning**

- Removing the member without first suspending the engine can cause the engine to tilt or fall and cause injury. Suspend the engine properly before removing the member.

1. Suspend the engine by using a chain block.
2. Remove the No.1 and No.2 engine mount nuts.
3. Remove the engine mount member bolts and nuts and remove the engine mount member.


**Drive shaft**

1. Remove the bolts and nuts at the left and right lower arm ball joint.


Caution

- The ball joint dust boots and oil seals are damaged easily if this procedure is not done correctly.

2. Remove the joint shaft.




3. Pry the lower arms downward to separate them from the knuckles.




4. Separate the drive shafts from the transaxle by prying with a bar inserted between the shaft and the case.

Step 5



- 1. No.3 engine mount rubber
- 2. No.4 engine mount rubber and bracket

- 3. Engine and transaxle assembly
Removal Note below




Removal Note

Engine and transaxle assembly

Slowly lift the engine and transaxle assembly as a unit. Keep the engine from swinging or bumping into components in the engine compartment.

Lift the engine and transaxle assembly out as a unit.

Step 6



















1. Starter
2. Throttle cable (ATX)
3. No.2 engine mount rubber and bracket
4. Seal plate
5. Torque converter nuts (ATX)

6. Transaxle mounting bolts
7. Manual transaxle (MTX)
8. Automatic transaxle (ATX)
9. Engine assembly

ENGINE STAND MOUNTING

PREPARATION SST


| | | | |
|---|---|---|---|
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly and assembly of engine</p> | <p>49 L010 1A0 Hanger set, engine stand</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 L011 101 Plate (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> | <p>49 L010 102 Arm (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 L010 103 Hook (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> | <p>49 L010 104 Nut (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 L010 105 Bolt (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> | <p>49 L010 106 Bolt (Part of 49 L010 1A0)</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 E010 1A0 Hanger set, engine</p>  | <p>For disassembly and assembly of engine</p> | <p>49 E010 101 Body (Part of 49 E010 1A0)</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 E010 102 Bolt (Part of 49 E010 1A0)</p>  | <p>For disassembly and assembly of engine</p> | <p>49 E010 1A1 Hanger set, engine</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 E010 103 Hanger (Part of 49 E010 1A1)</p>  | <p>For disassembly and assembly of engine</p> | <p>49 E010 102 Bolt (Part of 49 E010 1A1)</p>  | <p>For disassembly and assembly of engine</p> |
| <p>49 E010 104 Bolt (Part of 49 E010 1A1)</p>  | <p>For disassembly and assembly of engine</p> | | |




PROCEDURE

When using 49 E010 1A0


1. Remove the right exhaust manifold insulator.
2. Remove the EGR valve bolts.




3. Remove the right exhaust manifold and gasket together with the EGR valve and pipe.



4. Install the **SST** at the positions shown.




5. Mount the engine on the **SST**.




When using 49 E010 1A1 and 49 L010 1A0


1. Remove the right exhaust manifold insulator.
2. Remove the right exhaust manifold and gasket.
3. Install the **SST** as shown.




4. Install the **SST** (arms) to the holes as shown, and hand tighten the **SST** (bolts).




5. Assemble the **SST** (bolts, nuts and plate) as shown in the figure.



6. Install the **SST** assembled in step 5 to the **SST** installed in step 4.
 7. Adjust the **SST** (bolts) so that less than 20mm {0.79 in} of thread is exposed.
 8. Make the **SST** (plate and arms) parallel by adjusting the **SST** (bolts and nuts).
 9. Tighten the **SST** (bolts and nuts) to affix the **SST** firmly.




10. Mount the engine on the **SST**.



Coolant Draining

1. After installing the engine to the engine stand, disconnect the oil cooler hoses as shown in the figure (left cylinder head).



















2. Remove the blind cover and drain the engine coolant.
3. After draining the coolant, install a new O-ring to the blind cover.



Tightening torque:

19–25 N·m (1.9–2.6 kgf·m, 14–18 ft·lbf)

DISASSEMBLY

PREPARATION SST

| | | | |
|--|---|---|--|
| <p>49 0636100B</p> <p>Arm, valve spring lifter</p>  | <p>For removal / installation of valves</p> | <p>49 L011 0A0B</p> <p>Tool set, piston pin setting</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 L011 001</p> <p>Body, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 006</p> <p>Installer, piston pin (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 002</p> <p>Screw</p>  | <p>For removal / installation of piston pins</p> | <p>49 D011 002B</p> <p>Head, support block (Part of 49 L011 0A0 B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 001</p> <p>Guide, piston pin</p>  | <p>For removal / installation of piston pins</p> | <p>49 G014 001</p> <p>Wrench, oil filter</p>  | <p>For removal / installation of oil filter</p> |
| <p>49 H018 001</p> <p>Wrench, knock sensor</p>  | <p>For removal / installation of knock sensor</p> | <p>49 S120 170</p> <p>Remover, valve seal</p>  | <p>For removal of valve seals</p> |
| <p>49 E011 1A0</p> <p>Brake set, ring gear</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> | <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of crankshaft rotation</p> |
| <p>49 B012 0A2</p> <p>Pivot</p>  | <p>For removal / installation of valves</p> | <p>49 B012 012</p> <p>Body (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |

| | | | | | |
|---|---|---|--|---|---|
| 49 B012 013 Foot (Part of 49 B012 0A2) |  | For removal / installation of valves | 49 B012 014 Locknut (Part of 49 B012 0A2) |  | For removal / installation of valves |
|---|---|---|--|---|---|

1. Code or arrange all identical parts (such as HLA, pistons, piston rings, connecting rods, and valve springs) so that they can be reinstalled in the cylinder from which they were removed.
2. Clean the parts by using a steam cleaner. Blow dry with compressed air.

Warning


- **Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.**

AUXILIARY PARTS

1. Remove the oil drain plug and drain the engine oil. After draining the engine oil, install the oil drain plug.

Tightening torque: 30–41 N·m {3.0–4.2 kgf·m, 22–30 ft·lbf}


2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- 1. A/C compressor bracket
- 2. Generator
- 3. Bracket and tensioner
- 4. Exhaust manifold insulator(LH)
- 5. Exhaust manifold(LH)
- 6. Distributor and high-tension lead

- 7. Intake manifold assembly
- 8. Engine hanger
- 9. Spark plug
- 10. Oil filter


Disassembly Note page B2-59

**Disassembly Note****Oil filter**

Remove the oil filter by using the **SST**.


TIMING BELT

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- 1. Crankshaft pulley
Disassembly Note page B2-61
- 2. Water pump pulley
- 3. Dipstick and pipe
- 4. Crankshaft position sensor
- 5. Timing belt cover (LH)
- 6. Timing belt cover (RH)
- 7. No.3 engine mount bracket


- 8. Timing belt
Disassembly Note page B2-61
- 9. Timing belt auto tensioner
- 10. Tensioner pulley
- 11. No.2 idler pulley
- 12. No.1 idler pulley
- 13. Timing belt pulley
Disassembly Note page B2-61

**Disassembly Note****Crankshaft pulley**

1. Hold the flywheel (MTX) or drive plate (ATX) by using the **SST**.
2. Remove the pulley bolt.
3. Remove the crankshaft pulley.

**Timing belt**


1. Temporarily install the crankshaft pulley bolt.
2. Turn the crankshaft clockwise to align the timing marks of the pulleys.



3. Mark the timing belt rotation for proper reinstallation.

Caution

- When removing the bolt, hold the tensioner so that the bolt holes are aligned, otherwise the threads can be damaged.




4. Remove the auto tensioner bolts gradually in five or six steps in the order shown.

Caution

- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

5. Remove the timing belt.

**Timing belt pulley**


1. Remove the timing belt pulley.
2. Remove the crankshaft key.

Note

- If necessary, remove the pulley with a steering wheel puller.


CYLINDER HEAD

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- 1. Cylinder head cover
- 2. Camshaft pulley
Disassembly Note page B2-63
Inspection page B2-85
- 3. Seal plate
- 4. Water outlet
- 5. Camshaft cap
Disassembly Note page B2-63
- 6. Blind cap
- 7. Camshaft
Inspection page B2-64
- 8. Camshaft oil seal
- 9. HLA
Disassembly Note page B2-64
Inspection page B2-80

- 10. Cylinder head bolt
Disassembly Note page B2-64
- 11. Cylinder head
Inspection page B2-73
- 12. Cylinder head gasket
- 13. Valve keeper
Disassembly Note page B2-64
- 14. Upper valve spring seat
- 15. Valve spring
Inspection page B2-77
- 16. Lower valve spring seat
- 17. Valve
Inspection page B2-74
- 18. Valve seal
Disassembly Note page B2-65




Disassembly Note Camshaft pulley

1. Hold the camshaft by using a wrench on the cast hexagon.
2. Remove the camshaft pulley bolts.
3. Remove the camshaft pulleys.




Camshaft cap

1. Align the camshaft knock pin as shown to reduce the pressure of the HLA.




Caution

- When the front camshaft lobe is pressing on the HLA, removing the camshaft caps can damage the cylinder head thrust journal support.



2. Loosen the front camshaft cap bolts in five or six steps in the order shown.
3. Remove the front camshaft cap.




4. Loosen the camshaft cap bolts in five or six steps in the order shown.

Caution


- Remove the thrust cap only after removing all camshaft caps. Otherwise, the thrust cap can be damaged.

5. Remove the camshaft caps.



Note

- Before removing the camshaft caps, note their locations. They are identified as follows;
Right head: numbers
Left head: letters



Camshaft

Inspect the following when removing the camshaft.

1. Camshaft end play (Refer to page B2-79.)
2. Camshaft journal oil clearance (Refer to page B2-79.)

HLA


Caution

- The HLA must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.

Note


- Mark the HLA to show their original positions.

1. Remove the HLA from the cylinder head.
2. Store the HLA upside down in an oil-filled container.




Cylinder head bolt

1. Loosen the cylinder head bolts in two or three steps in the order shown in the figure.
2. Remove the cylinder head bolts.



Valve keeper


1. Set the SST against the upper valve spring seat as shown.
2. Compress the spring and remove the valve keepers.

**Valve seal**

Using the **SST**, remove and discard the valve seal.


CYLINDER BLOCK (EXTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- 1. Clutch cover, clutch disc (MTX)
Disassembly Note page B2-67
- 2. Flywheel (MTX)
Disassembly Note page B2-67
- 3. Backing plate, drive plate, and adapter (ATX)
Disassembly Note page B2-67
- 4. Oil cooler and oil filter body
- 5. Water pipe and thermostat housing
Disassembly Note page B2-67
- 6. Knock sensor
Disassembly Note page B2-68


- 7. Oil pan
Disassembly Note page B2-68
- 8. Oil strainer
- 9. Oil baffle
- 10. Water pump
- 11. Oil pump
- 12. Front oil seal
Disassembly Note page B2-68

**Disassembly Note****Clutch cover, clutch disc (MTX)**


1. Hold the flywheel by using the **SST**.
2. Remove the clutch cover bolts in two or three steps.
3. Remove the clutch cover.
4. Remove the clutch cover and disc.

**Flywheel (MTX)**


1. Hold the flywheel by using the **SST**.
2. Remove the flywheel bolts in two or three steps in the order shown.
3. Remove the flywheel.
4. Remove the **SST**.

**Backing plate, drive plate, and adapter (ATX)**


1. Hold the drive plate by using the **SST**.
2. Remove the drive plate bolts in two or three steps.
(Refer to above.)
3. Remove the backing plate, drive plate, and adapter.
4. Remove the **SST**.

**Water pipe and thermostat housing**


1. Disconnect the clip and separate the knock sensor harness from the water pipe.




2. Remove the water pipe and thermostat housing as an assembly.

**Knock sensor**


Remove the knock sensor by using the **SST**.

**Oil pan**

1. Remove the oil pan mounting bolts.
2. Remove the old sealant from the bolt threads.
3. Turn a bolt into the bolt hole as shown to make a small gap between the oil pan and the lower cylinder block.




4. Separate the oil pan from the lower cylinder block by using a screw driver or suitable tool.

**Front oil seal**


Remove the oil seal by using a screwdriver protected with a rag.

CYLINDER BLOCK (INTERNAL PARTS)

Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- | | | | |
|---|------------|---|------------|
| 1. Connecting rod cap Disassembly Note | page B2-70 | 7. Piston Inspection | page B2-81 |
| 2. Lower connecting rod bearing Inspection | page B2-84 | 8. Lower cylinder block Disassembly Note | page B2-71 |
| 3. Piston and connecting rod assembly Disassembly Note | page B2-70 | 9. Lower main bearing and thrust bearing | |
| 4. Piston ring Disassembly Note | page B2-70 | 10. Crankshaft Inspection page | B2-83 |
| Inspection | page B2-82 | 11. Rear oil seal | |
| 5. Piston pin Disassembly Note | page B2-70 | 12. Upper main bearing and thrust bearing | |
| Inspection | page B2-82 | 13. Oil jet Inspection | page B2-84 |
| 6. Connecting rod Disassembly Note | page B2-70 | 14. Cylinder block Inspection | page B2-81 |
| Inspection | page B2-83 | | |




Disassembly Note
Connecting rod cap

Before removing the connecting rod caps, measure the connecting rod side clearance. (Refer to page B2-95.)




Piston and connecting rod assembly

1. Before removing the piston and connecting rod assembly, measure the connecting rod bearing oil clearance by using Plastigage. (Refer to page B2-94.)




2. Remove the Plastigage from the crank pin journals.

3. Use the handle of a hammer to push the piston and connecting rod assembly through the top of the cylinder block.



Piston ring

Remove the piston rings by using a piston ring expander.



Piston pin


Caution

- The connecting rods must be reinstalled in the same positions from which they were removed. If they are not, it can cause premature and uneven wear.


Note

- Mark the connecting rods to show their original positions.


1. Before disassembling the piston and connecting rod, check the oscillation torque as shown. If the large end does not drop by its own weight, replace the piston or the piston pin.




2. Use the following **SSTs** shown in the figure and a press.



3. Insert the **SST** into the piston pin as shown.




4. Verify that the **SST** fits squarely into the piston before pressing.



5. Set the piston and connecting rod on the **SST** as shown.


6. Press out the piston pin.

While removing the piston pin, check the pressure. If it is lower than **4,903 N {500 kgf, 1,100 lbf}**, replace the piston pin or connecting rod.




Lower cylinder block

1. Before removing the lower cylinder block, measure the crankshaft end play. (Refer to page B2-92.)



2. Loosen the cylinder block bolts and crankshaft cap bolts in two or three steps in the order shown in the figure.



3. Insert a screwdriver only at the points shown and pry loose the lower cylinder block.






Caution

- Do not use a scraper to separate the cylinder block sections. It can easily scratch the contact surfaces.


4. Tap the lower cylinder block with a plastic hammer.

INSPECTION / REPAIR

PREPARATION
SST


| | | | |
|--|---|---|---|
| <p>49 B012 005</p> <p>Remover & installer, valve guide</p>  | <p>For removal / installation of valve guides</p> | <p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p>  | <p>For installation of valve guides</p> |
| <p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve guides</p> | <p>49 L012 003</p> <p>Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve guides</p> |
| <p>49 L012 004</p> <p>Nut (Part of 49 L012 0A0)</p>  | <p>For installation of valve guides</p> | | |

1. Clean all parts, being sure to remove all gasket fragments, dirt, oil, etc.
2. Perform the inspections and repairs in the order specified.

**CYLINDER HEAD**


1. Inspect the cylinder head for damage, cracks, and leakage of water and oil. Replace if necessary.
2. Measure the cylinder head for distortion in the six directions shown.

Distortion: 0.10mm {0.004 in} max.



3. Inspect for the following and repair or replace the cylinder head if necessary.
 - (1) Sunken valve seats
 - (2) Damaged intake and exhaust manifold contact surfaces
 - (3) Excessive camshaft oil clearances and end play
4. If the cylinder head distortion exceeds the specification, replace the cylinder head or grind the cylinder head surface.

Grinding: 0.15mm {0.006 in} max.



5. If the cylinder head height is not within the specification, replace it.

Height: 133.4–133.6mm {5.252–5.259 in}

6. Measure the intake and exhaust manifold contact surfaces for distortion in the six directions as shown.


Distortion: 0.10mm {0.004 in} max.

7. If distortion exceeds the specification, grind the surface or replace the cylinder head.

VALVE MECHANISM

Valve and Valve Guide

1. Inspect each valve for the following. Replace or resurface the valve as necessary.
 - (1) Damaged or bent stem
 - (2) Rough or damaged face
 - (3) Damaged or unevenly worn stem tip
2. Measure the valve head margin thickness. Replace the valve if necessary.



Margin thickness

IN: 0.9mm {0.035 in} min.

EX: 1.0mm {0.039 in} min.

3. Measure the valve length. Replace the valve if necessary.

Length


Standard IN: 94.11 mm {3.7051 in}

EX: 95.19mm {3.7476 in}

Minimum IN: 93.61 mm {3.6854 in}

EX: 94.69mm {3.7279 in}

4. Measure the valve stem diameter. Replace the valve if necessary.



Diameter

Standard


IN: 5.970–5.985mm {0.2351–0.2356 in}

EX: 5.965–5.980mm {0.2349–0.2354 in}

Minimum IN: 5.920mm {0.2331 in}

EX: 5.915mm {0.2329 in}


5. Measure the valve guide inner diameter. Replace the guide if necessary.



Inner diameter

IN: 6.01–6.03mm {0.2367–0.2374 in}

EX: 6.01–6.03mm {0.2367–0.2374 in}




6. Calculate the valve stem-to-guide clearance. Subtract the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.

Clearance

IN: 0.025–0.060mm {0.0010–0.0023 in}
 EX: 0.030–0.065mm {0.0012–0.0025 in}
 Maximum: 0.20mm {0.008 in}


7. If the clearance exceeds the maximum, replace the valve and/or valve guide.



8. Measure the valve guide projection height (dimension A). Replace the guide if necessary.

Height A


IN: 14.7–15.3mm {0.579–0.602 in}
 EX: 12.2–12.8mm {0.481–0.503 in}




Replacement of valve guide

Note

- The intake and exhaust valve guides are the same.



1. Remove the valve guide from the combustion chamber side by using the SST.




2. Assemble the SST so that depth L is as specified.


Depth L

IN: 14.7–15.3mm {0.579–0.602 in}
 EX: 12.2–12.8mm {0.481–0.503 in}

3. Tighten the nut.




4. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
5. Verify that the valve guide projection height is within the specification. (Refer to page B2-75.)
6. If not, repeat steps 2-4.




Valve Seat

1. Inspect the contact surface of each valve seat and valve face for the following:
 - (1) Roughness
 - (2) Damage
2. If necessary, resurface the valve seat by using a **45°** valve seat cutter and/or resurface the valve face.




3. Apply a thin coat of Prussian blue to the valve face.
4. Check the valve seating by pressing the valve against the seat.
 - (1) If blue does not appear 360° around the valve face, replace the valve.
 - (2) If blue does not appear 360° around the valve seat, resurface the seat.




5. Measure the seat contact width.

Width: 0.8-1.4mm {0.032-0.055 in}



6. Verify that the valve seating position is at the center of the valve face.
 - (1) If the seating position is too high, correct the valve seat with a **75°** cutter.
 - (2) If the seating position is too low, correct the valve seat with a **45°** cutter.
7. Seat the valve to the valve seat by using lapping compound.




7. Check the sinking of the valve seat.
Measure the protruding length (dimension L) of the valve stem.

Dimension L: 41.5mm {1.634 in}

- (1) If L is as below, it can be used as it is.

41.5–42.0mm {1.634–1.653 in}




- (2) If L is as below, insert a washer onto the spring seat area so that L will be as specified.

42.1–43.0mm {1.658–1.692 in}

- (3) If L is as below or more, replace the cylinder head.

43.1mm {1.697 in}



Valve Spring


1. Inspect the valve springs for cracks and damage.
2. Check the free length of each spring.

Free length

Standard: 46.92mm {1.847 in}






Minimum: 38.7mm {1.524 in}

**with a set load of 233.0–263.6 N
{23.75–26.88 kgf, 52.25–59.14 lbf}**



3. Measure spring pressure when the spring length is compressed to **35.5mm {1.398 in}**. Replace if necessary.
4. Check the out-of-square of the springs. Replace as necessary.

Out-of-square: 1.63mm {0.064 in} max.



CAMSHAFT

1. Visually inspect the helical gears and the friction gear. Replace the camshaft assembly if a problem is found with the helical gear. Replace the friction gear if a problem is found with it.
2. Secure the camshaft cast hexagon in a vise protected with aluminum plates.
3. Loosen the locknut and remove the friction gear.
4. Assemble the friction gear so that the matching marks align.

Tightening torque:

69–78 N·m {7.0–8.0 kgf·m, 51–57 ft·lbf}

5. Set the No.1 and No.5 journals on V-blocks. Measure the camshaft runout. Replace the camshaft if necessary.

Runout: 0.02mm {0.0008 in} max.

6. Check the camshaft for wear and damage. Replace it if necessary.
7. Measure the camshaft lobe height at the two points as shown. Replace the camshaft if necessary.

Height

IN: 42.665mm {1.6797 in}

EX: 43.516mm {1.7132 in}

Minimum

IN: 42.465mm {1.6718 in}

EX: 43.316mm {1.7054 in}


8. Measure the journal diameters in X and Y directions at the two points (A and B) as shown. Replace the camshaft if necessary.

Journal diameter


mm {in}

| Journals | Standard | Minimum |
|---------------------------------|----------------------------------|--------------------|
| No.1 (RH EX, LH IN) and No.5 | 25.940–25.960 {1.0213–1.0220} | 25.890 {1.0193} |
| No.3 (RH IN, LH EX) | 29.975–29.995 {1.1802–1.1809} | 29.925 {1.1781} |
| No.2–No.4 | 25.910–25.930 {1.0201–1.0208} | 25.860 {1.0181} |

9. Measure the camshaft journal oil clearances with the HLA removed.
 - (1) Remove all foreign material and oil from the journals and the camshaft saddles.
 - (2) Install the camshafts on the cylinder head.




- (3) Position Plastigage atop each journal in the journal axial direction.
- (4) Do not rotate the camshaft when measuring the oil clearances.

**Caution**

- Install the thrust caps (RH is 「4」 mark, LH is 「A」 mark) first. Otherwise, camshaft can be broken or damaged.

- (5) Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the thrust caps fully seated on the cylinder heads.



- (6) Install the camshaft caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the camshaft caps fully seated in the cylinder heads.

- (7) Tighten the bolts in the order shown.


Tightening torque:

11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}

- (8) Retighten the bolts in the order shown.


Tightening torque:


11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}

**Caution**



- Remove the thrust cap only after removing all camshaft caps. Otherwise, the thrust cap can be damaged.

- (9) Loosen the camshaft cap bolts in five or six steps in the order shown.





- (10) Loosen the camshaft cap bolts in five or six steps in the order shown.



- (11) Measure the oil clearance.

Oil clearance

No.1, No.5: 0.040–0.081mm {0.0016–0.0031 in}


No.2–No.4: 0.070–0.111 mm {0.0028–0.0043 in}

Maximum

No.1, No.5: 0.120mm {0.0047 in}

No.2–No.4: 0.150mm {0.0059 in}


- (12) If the oil clearance exceeds the maximum, replace the camshaft or the cylinder head.



10. Measure the camshaft end play. If it exceeds the maximum, replace the camshaft or the cylinder head.


End play: 0.05–0.10mm {0.0020–0.0039in}

Maximum: 0.14mm {0.0055 in}




HLA

1. With the HLA filled with engine oil, hold **A** and press **B** by hand. If **B** moves, replace the HLA—do not attempt to repair it.



2. Measure the HLA bores in X and Y directions at two points (A and B) as shown.

Distortion: 30.000–30.025mm {1.1811–1.1820 in}




3. Measure the HLA diameters in X and Y directions at two points (A and B) as shown.

Diameter: 29.959–29.975mm {1.1795–1.1801 in}

4. Calculate the clearance between the HLA diameter and the related HLA bore. Replace the HLA and / or cylinder head if necessary.

Clearance: 0.025–0.066mm {0.00099–0.00259 in}


Maximum: 0.180mm {0.0071 in}



CYLINDER BLOCK

- Check the cylinder block for the following and repair or replace as necessary.
 - Leakage damage
 - Cracks
 - Scoring of wall
- Using a straightedge, measure the cylinder block decks for distortion in six directions as shown.

Distortion: 0.15mm {0.006 in} max.



- If the distortion exceeds the specification, replace the cylinder block.
- Measure the cylinder bores in X and Y directions at three points (A, B, and C) as shown.

Cylinder bore


Base the boring diameter on the diameter of an oversize piston. All cylinders must be of the same diameter.


mm {in}

| Size | Bore | Diameter |
|----------------------|------|-------------------------------|
| Standard | | 75.000–75.022 {2.9528–2.9536} |
| 0.25 {0.01} oversize | | 75.250–75.272 {2.9628–2.9634} |
| 0.50 {0.02} oversize | | 75.500–75.522 {2.9725–2.9733} |

- If the cylinder bore exceeds the standard, replace the cylinder block or rebore the cylinder to oversize.
- If the difference between measurements A and C exceeds the maximum taper, replace the cylinder block or rebore the cylinder to oversize.

Taper: 0.022mm {0.0009 in} max.





- (3) If the difference between measurements X and Y exceeds the maximum out-of-round, rebore the cylinder to oversize.


Out-of-round: 0.020mm {0.0009 in} max.

5. If the upper part of a cylinder wall shows uneven wear, remove the ridge with a ridge reamer.

PISTON, PISTON RING, AND PISTON PIN

Piston

1. Inspect the outer circumferences of all pistons for seizing and scoring. Replace as necessary.
2. Measure the outer diameter of each piston at a right angle (90°) to the piston pin, 16.5mm {0.65 in} below the oil ring land lower edge.




Piston diameter

| | mm {in} | |
|----------------------|---------------|-----------------|
| | Bore | Diameter |
| Standard | 74.953–74.985 | {2.9509–2.9521} |
| 0.25 {0.01} oversize | 75.203–75.235 | {2.9608–2.9620} |
| 0.50 {0.02} oversize | 75.453–75.485 | {2.9706–2.9718} |

3. Measure the piston-to-cylinder clearance.

Clearance: 0.028–0.056mm {0.0011–0.0022 in}
Maximum: 0.13mm {0.005 in}


4. If the clearance exceeds the maximum, replace the piston or rebore the cylinders to fit oversize pistons.
5. If the piston is replaced, the piston rings must also be replaced.




Piston and Piston Rings


1. Measure the piston ring-to-ring land clearance around the entire circumference by using a new piston ring.

Clearance:
 0.020–0.065mm {0.0008–0.0025 in} (Top)
 0.030–0.065mm {0.0012–0.0025 in} (Second)
 0.025–0.052mm {0.0010–0.0020 in} (Oil)
Maximum: 0.15mm {0.006 in}



2. If the clearance exceeds the maximum, replace the piston.
3. Inspect the piston rings for damage, abnormal wear, and breakage. Replace the piston ring if necessary.
4. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.






5. Measure each piston ring end gap by using a feeler gauge. Replace the piston ring if necessary.


End gap

Top: 0.15–0.28mm {0.006–0.011 in}
 Second: 0.25–0.38mm {0.010–0.014 in}
 Oil rail: 0.20–0.70mm {0.008–0.027 in}
 Maximum: 1.0mm {0.039 in}

**Piston and Piston Pin**

1. Measure the piston pin bore diameter in X and Y directions at four points.

Diameter: 18.988–19.000mm {0.7476–0.7480 in}



2. Measure the piston pin diameter in X and Y directions at four points.

Diameter: 18.974–18.980mm {0.7470–0.7472 in}

3. Calculate the piston pin-to-piston clearance.

Clearance: 0.008–0.026mm {0.0004–0.0010 in}

4. If the clearance exceeds the specification, replace the piston and/or piston pin.


CONNECTING ROD

1. Measure each connecting rod small end bore.

Diameter: 18.943–18.961 mm {0.7458–0.7464 in}

2. Calculate the interference between the small end bore and piston pin.


Interference: 0.013–0.037mm {0.0006–0.0014 in}




3. Check each connecting rod for bending. Replace the connecting rod if necessary.

Bending: 0.05mm {0.0020 in}/50mm {1.969 in} max.

If the connecting rod is replaced, the connecting rod cap, bolts, and nuts must also be replaced because they are a matched set.






CRANKSHAFT

1. Check the journals and pins for damage, scoring, and oil hole clogging.
2. Set the crankshaft No.1 and No.4 main journals on V-blocks.
3. Measure the crankshaft runout at No.2 and No.4 journals. Replace the crankshaft if necessary.

Runout: 0.015mm {0.0006 in} max.



4. Measure each journal diameter in X and Y directions at two points (A and B) as shown.

Main journal


Diameter: 61.955mm {2.4385–2.4391 in}

Out-of-round: 0.05mm {0.0020 in} max.

Crank pin journal

Diameter: 47.940–47.955mm {1.8874–1.879 in}

Out-of-round: 0.05mm {0.0020 in} max.



5. If the diameter is less than the specification, grind the journals to match undersize bearings.

Undersize bearing: 0.25mm {0.01 in}

Undersize main journal diameter


mm {in}

| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 61.688–61.705 {2.4287–2.4293} |

Undersize crank pin journal diameter

mm {in}


| Bearing size | Journal diameter |
|-----------------------|-------------------------------|
| 0.25 {0.01} undersize | 47.690–47.705 {1.8776–1.8781} |




BEARING

Main Bearing and Connecting Rod Bearing

Check the main bearings and the connecting rod bearings for peeling, scoring, and other damage.

**OIL JET**


Check the oil jets for clogging by applying compressed air. Replace if necessary.

**TIMING BELT**

1. Replace the timing belt if there is any oil or grease on it.
2. Check the timing belt for damage, wear, peeling, cracks, and hardening. Replace the timing belt if necessary.

Caution



- The following will damage the belt and shorten its life; Forcefully twisting it, turning it inside out, bending it, or allowing oil or grease on it.

**TIMING BELT AUTO TENSIONER, IDLER****Caution**

- Using cleaning fluids or a steam cleaner to clean the tensioner can dissolve the grease in its sealed bearing.

1. Use a clean, soft rag to wipe the tensioner or idler contact surface.
2. If the tensioner or idler does not rotate smoothly, replace it.
3. If there are silicone oil leaks, scratches or abnormal noise when turning the tensioner or idler, replace it.
4. Check the tensioner pulley for rough rotation and abnormal noise. Replace it if necessary.
5. Check the auto tensioner for oil leakage. Replace it if necessary.
6. Check the tensioner rod projection \textcircled{A} . Replace the auto tensioner if necessary.

Projection \textcircled{A} (free length): 14–16 mm {0.56–0.62 in}

**PULLEY****Timing Belt Pulley and Camshaft Pulley**

















Inspect the teeth of each pulley for wear, deformation, and other damage. Replace if necessary.













TIMING BELT COVER

Inspect the timing belt covers for damage and cracks. Replace if necessary.

ASSEMBLY



PREPARATION SST

| | | | |
|---|--|--|---|
| <p>49 L011 0A0B</p> <p>Tool set, piston pin setting</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 001</p> <p>Body, support block (Part of 49 L011 0A0B)</p>  | <p>For removal / Installation of piston pins</p> |
| <p>49 L011 005</p> <p>Bolt, stopper (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 L011 006</p> <p>Puller & installer (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 E011 001</p> <p>Guide (Part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 E011 002</p> <p>Screw</p>  | <p>For removal / installation of piston pins</p> |
| <p>49 D011 001B</p> <p>Head, support block (part of 49 L011 0A0B)</p>  | <p>For removal / installation of piston pins</p> | <p>49 H018 001</p> <p>Wrench, knock sensor</p>  | <p>For removal / installation of knock sensor</p> |
| <p>49 E011 1A0</p> <p>Brake set, ring gear</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 103</p> <p>Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 104</p> <p>Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 105</p> <p>Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 L012 0A0</p> <p>Installer set, valve seal & valve guide</p>  | <p>For installation of valve seals</p> | <p>49 SE01 310A</p> <p>Centering tool, clutch disc</p>  | <p>For installation of clutch disc</p> |
| <p>49 L012 001</p> <p>Installer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> | <p>49 L012 002</p> <p>Body (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> |

| | | | |
|--|---|---|---|
| <p>49 L012 005 Spacer (Part of 49 L012 0A0)</p>  | <p>For installation of valve seals</p> | <p>49 0636 100B Arm, valve spring lifter</p>  | <p>For removal / installation of valves</p> |
| <p>49 B012 0A2 Pivot</p>  | <p>For removal / installation of valves</p> | <p>49 B012 012 Body (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 B012 013 Foot (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> | <p>49 B012 014 Locknut (Part of 49 B012 0A2)</p>  | <p>For removal / installation of valves</p> |
| <p>49 G014 001 Wrench, oil filter</p>  | <p>For removal / installation of oil filter</p> | <p>49 G019 017 Installer, oil seal</p>  | <p>For installation of rear oil seal</p> |
| <p>49 H010 401 Installer, oil seal</p>  | <p>For installation of front oil seal</p> | <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of camshaft oil seals</p> |
| <p>49 F401 331 Body (Part of 49 F401 330B)</p>  | <p>For Installation of camshaft oil seals</p> | <p>49 F401 337A Attachment C (Part of 49 F401 330B)</p>  | <p>For installation of camshaft oil seals</p> |






1. Do not reuse gaskets or oil seals.
2. Clean all parts before reinstallation.
3. Apply clean engine oil to all sliding and rotating parts.
4. Replace plain bearings if they are peeled, burned, or otherwise damaged.
5. Tighten all bolts and nuts to the specified torque.

CYLINDER BLOCK (INTERNAL PARTS) Torque Specifications



Connecting Rod

1. Assemble the **SSTs** (tool set, piston pin setting) to the piston pin.
2. Apply clean engine oil to the piston pin.



3. Set the **SST** (stopper bolt) so that the depth L is as specified.

Depth L: 61.4mm {2.42 in}

4. Tighten the locknut.

5. Assemble the piston and the connecting rod.

6. Insert the **SSTs** (tool set, piston pin setting) assembled in step 1 into the piston pin hole.

7. Mount the piston and connecting rod onto the **SST** (Support block).

8. Verify that the **SSTs** fits squarely into the piston before pressing.

9. Press the piston pin into the piston and connecting rod until the **SST** (piston pin guide) contacts the stopper bolt.

10. While inserting the piston pin, check the pressing force. If it is less than specified, replace the piston pin and/or the connecting rod.

Pressing force:

3,924–12,753 N {400–1,300 kgf, 880–2,860 lbf}

11. Check the connecting rod oscillation torque.
(Refer to page B2-69.)

Piston Ring

Caution






- If reusing an oil ring, it must be reinstalled in the same place and face the same direction as when removed. If this is not done, it can cause premature and uneven wear.

Note

- The upper and lower rails are the same. They can be installed with either face upward.

1. Install the three-piece oil rings on the pistons.

- (1) Apply clean engine oil to the oil ring spacer and rails.
- (2) Install the oil ring spacer so that the opening faces upward.
- (3) Install the upper rail and lower rail.



2. Verify that the spacer tang separates the rails, and that the rails turn smoothly in both directions.
3. Install the rings with the R marks upward.
4. Using a piston ring expander, install the second ring with the scraper face downward.
5. Using a piston ring expander, install the top ring.

6. Apply a liberal amount of clean engine oil to the piston rings.
7. Position the end gap of each ring as shown.

Oil jet

1. Apply thread locking compound to the oil jet threads.
2. Install the oil jets into the upper cylinder block.

Tightening torque:

3.0–4.9 N·m {30–50 kgf·cm, 27–43 in·lbf}

Crankshaft

1. Measure the main bearing oil clearances as described below.

Oil clearance inspection

- (1) Remove any foreign material and oil from the journals and bearings.
- (2) Install the upper main bearings (with oil groove) and the upper thrust bearings.

Note

- No.4 bearing is wider than other bearings.

- (3) Install the lower cylinder block along with the lower main bearings and thrust bearings.

- (4) Measure the length of lower cylinder block bolt. Replace it if the length exceeds the maximum.

Bolt A and B


Length : 135.7–136.3mm {5.343–5.361 in}

Maximum: 138.5mm {5.453 in}

Bolt C

Length : 119.7–120.3mm {4.713–4.736 in}

Maximum: 121.0mm {4.764 in}





- (5) Apply clean engine oil to the bolt threads and seat faces of the lower cylinder block bolts.
- (6) Tighten the bolts in two or three steps in the order shown.

Tightening torque

Bolt A and B : 23.1–25.9 N·m
 {2.35–2.65 kgf·m, 17.0–19.1 ft·lbf}
Bolt C : 18.2–21.0 N·m
 {1.85–2.15 kgf·m, 13.4–15.5 ft·lbf}

Note



- Bolts A have a mark "4" on each bolt head.
- Bolts B have a mark "1" on each bolt head.



- (7) Put paint marks to the lower cylinder block which fit the A, B, C bolt flange marks as shown.
- (8) Using the marks as a reference, further tighten the bolts A, B, and C in the order shown.


Main bolt A (No.4 journals): 75° –85°
Main bolt B (No.1–No.3 journals): 65° –75°
Sub bolt C : 55° –65°

- (9) Tighten the bolts until the mark on each bolt flange aligns with the corresponding paint mark.
- (10) Further tighten each bolt by performing steps (7), (8).



- (11) After tightening, measure the cylinder block No.1–No.4 journal bore diameters.
- (12) Subtract the crankshaft journal diameter from the bore diameter.
- (13) If the oil clearance exceeds the maximum, replace the bearing or grind the crankshaft and install the undersize main bearings. (Refer to page B2–84.)

Oil clearance: 0.037–0.057mm {0.0015–0.0022 in}
Maximum: 0.064mm {0.0025 in}




Main journal diameter

Standard:


61.938–61.955mm {2.4385–2.4391 in}

0.25mm {0.01 in} undersize:

61.688–61.705mm {2.4287–2.4293 in}




- (14) Loosen the lower cylinder block bolts in two or three steps in the order shown.




2. Install the lower cylinder block as follows:

- (1) Install the upper thrust bearings in the upper cylinder block.
- (2) Apply clean engine oil to the main bearings, thrust bearings, and main journals.
- (3) Install the crankshaft in the upper cylinder block.
- (4) Remove any foreign material, oil, and sealant from the contact surfaces of the upper cylinder block and lower cylinder block.
- (5) Apply a continuous bead of silicone sealant to the contact surface as shown.




- (6) Install the lower cylinder block, lower main bearings, and lower thrust bearings within five minutes of applying the silicone sealant.
- (7) Install the lower cylinder block along with the lower main bearings and lower thrust bearings.
- (8) Apply clean engine oil to the threads and seat faces of the bearing cap bolts.
- (9) Tighten the main bolts Ⓐ, Ⓑ and sub bolts Ⓒ as in step 1–(6) through 1–(10).



- (10) Tighten the lower cylinder block bolts Ⓓ in the order shown.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}



3. Measure the crankshaft end play.

End play: 0.080–0.282mm {0.0032–0.0111 in}
Maximum: 0.32mm {0.013 in}

4. If the end play exceeds the maximum, grind the crankshaft and install oversize thrust bearings or replace the crankshaft and thrust bearing.

Thrust bearing width

Standard:


2.000–2.050mm {0.0788–0.0807 in}

0.25mm {0.01 in} oversize:

2.175mm {0.0837–0.0856 in}

0.50mm {0.02 in} oversize:

2.250–2.300mm {0.0886–0.0905 in}




5. Apply a small amount of clean engine oil to the lip of a new rear oil seal.
6. Push the rear oil seal slightly in by hand.
7. Tap the oil seal in evenly by using the **SST** and a hammer.

Protrusion: 0–0.7mm {0–0.021 in}

Note

- Oil seal outer diameter: 93mm {3.66 in}
- Oil seal inner diameter: 75mm {2.87 in}




Piston and Connecting Rod Assembly

1. Rotate the engine as shown.






Note

- Assembly is easier if the pistons are installed with the crankpin at the BDC position.

2. Remove any foreign material and oil from the connecting rod journals and bearings.
3. Install the upper connecting rod bearings in the connecting rods.
4. Apply a liberal amount of clean engine oil to the cylinder walls, pistons, piston rings and connecting rod cap bolts.



5. Check the piston rings for proper end gap positioning.
6. Insert the piston and connecting rod assembly into the cylinder block with the L mark (left bank) and the R mark (right bank) facing the front of the engine. Use a piston installer tool to install.



Connecting Rod Cap

1. Measure the connecting rod bearing oil clearances as follows.

- (1) Measure the oil clearance with the connecting rod in BDC position.
- (2) Do not rotate the crankshaft when measuring the oil clearances.

- (3) Position Plastigage atop the journals in the axial direction.
- (4) Remove any foreign material and oil from the lower connecting rod bearing and connecting rod cap.
- (5) Install the lower connecting rod bearing to the cap.
- (6) Measure the length of connecting rod cap bolt. Replace it if the length exceeds the maximum.

Length: 46.7-47.3mm {1.84-1.86 in}

Maximum: 48.0mm {1.89 in}

- (7) Apply clean engine oil to the threads and seat faces of the connecting rod cap bolts.
- (8) Install the connecting rod caps.
- (9) Tighten the connecting rod cap bolts.

Tightening torque:


22.1-26.9 N·m {2.25-2.75 kgf·m, 16.3-19.8 ft·lbf}

- (10) Put a paint mark on each bolt head.
- (11) Using this mark as a reference, tighten the bolts 83°-97°.
- (12) Remove the connecting rod caps.
- (13) Measure the Plastigage at each journal at the widest point for the smallest clearance, and the narrowest point for the largest clearance.

Oil clearance: 0.023-0.43mm {0.0009-0.0016 in}

Maximum: 0.08mm {0.003 in}

- (14) If the oil clearance exceeds the maximum, grind the crankshaft and install undersize bearings. (Refer to page B2-84.)



2. Install the connecting rod caps as follows.
 - (1) Remove the Plastigage from the journals and bearings.
 - (2) Apply clean engine oil to the connecting rod bearings.
 - (3) Install the connecting rod bearings and caps.
 - (4) Apply engine oil to the threads and seat faces of the cap bolts and tighten them as in step 1.
 - (5) Verify that the crankshaft rotates smoothly by hand.

3. Measure the connecting rod side clearances.

- (1) Measure each connecting rod side clearance.



Side clearance: 0.178–0.330mm {0.0070–0.0129 in}

Maximum: 0.40mm {0.016 in}

- (2) If the clearance exceeds the maximum, replace the connecting rod and cap assembly.

CYLINDER BLOCK (EXTERNAL PARTS)


Torque Specifications



Oil Pump

1. Apply clean engine oil to the new oil seal.
2. Install the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using the SST.


Protrusion: 0-0.7mm {0-0.03 in}



4. Remove any dirt or other material from the contact surfaces.
5. Apply a continuous bead of silicone sealant to the contact surface of the oil pump.
6. Apply clean engine oil to a new O-ring and install it into the pump body.

Caution

- Keep the oil hole free of sealant to prevent engine damage.



7. Apply clean engine oil to the oil seal lip.
8. Install the oil pump within five minutes of applying the sealant, making sure that the O-ring does not come out.


Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lb}

Bolt Ⓐ: 40mm {1.57 in}

Bolt Ⓑ: 25mm {0.98 in}


9. Cut away the portion of the silicone sealant that projects toward the oil pan.

**Water Pump**

1. Remove all dirt, grease, and other material from the water pump mounting surface.
2. Install a new rubber gasket and the water pump.

Tightening torque:


19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lb}

**Oil baffle**

1. Remove any dirt or other material from the oil baffle.
2. Install the oil baffle.

Tightening torque:






19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lb}

**Oil Strainer**

1. Install a new gasket and the oil strainer onto the oil pump body.
2. Tighten bolts Ⓐ, then tighten bolts Ⓑ.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lb}



Oil Pan

1. Remove the sealant from the oil pan bolts and bolt holes in the lower cylinder block.

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening the bolt that has old sealant on it can cause thread damage.

2. Remove any dirt or oil from the contact surfaces.
3. Apply a continuous bead of silicone sealant to the oil pan along the inside of the bolt holes, and overlap the ends.

4. Install the oil pan within five minutes of applying the sealant.

Tightening torque

- Ⓐ : 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}
- Ⓑ : 7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

Knock Sensor

Install the knock sensor by using the SST.

Tightening torque:

- 20–34 N·m {2.0–3.5 kgf·m, 15–25 ft·lbf}


Water Pipe and Thermostat Housing

1. Install a new gasket and install the water pipe and thermostat housing as an assembly.

Tightening torque:

- 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

2. Secure the knock sensor harness to the water pipe with the clip as shown.


**Oil cooler and oil cooler body**

1. Install a new gasket and the oil cooler body.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}


2. Connect the water hoses.

**Flywheel (MTX)**

1. Set the flywheel onto the crankshaft.
2. Hold the flywheel by using the **SST**.
3. Tighten the bolts in two or three steps in the order shown.

Tightening torque:


61–87 N·m {6.2–8.9 kgf·m, 45–49 ft·lbf}

**Clutch Disk and Clutch Cover (MTX)**

- Install the clutch disk and clutch cover by using the **SST**.
(Refer to section H.)

Tightening torque:

18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}

**Drive plate (ATX)****Caution**

- Verify that the adapter and the backing plate are mounted in the directions shown. Incorrect mounting can damage the engine and transaxle.

1. Install the following parts to the crankshaft.

- (1) Adapter
- (2) Drive plate
- (3) Backing plate


2. Hand tighten the lock bolts..

3. Hold the drive plate by using the **SST**.



4. Tighten the bolts in two or three steps in the order shown.

Tightening torque:

61–87 N·m {6.2–8.9 kgf·m, 45–49 ft·lbf}



CYLINDER HEAD Torque Specifications




Valve Seal

1. Assemble the SST so that depth L is as specified.

Depth L

IN: 16.3mm (0.641 in)
EX: 13.8mm (0.54 in)



2. Slide the valve seal onto the valve guide with the **SST**.

Caution

- The intake and exhaust valve seals are different as shown.



| | Ridge | Color |
|---------|-----------|---------------|
| Intake | No or One | Gray |
| Exhaust | Two | Gray or Green |

3. Set the **SST** against the valve seal.

Caution


- Using a hammer will damage the valve seal.

4. Using the **SST**, press the valve seal on by hand until the **SST** contacts the cylinder head.



Valve and Valve Spring


1. Install the lower spring seat.
2. Install the valve.
3. Install the spring with the closer pitch toward the cylinder head.
4. Install the upper spring seat.



5. Compress the valve spring with the **SST**, and install the valve keepers.

6. Remove the **SST**.

7. Tap the end of the valve stem lightly two or three times with a plastic hammer to verify that the keepers are fully seated.




Cylinder Head


1. Measure the amount of oil control plug projection from the deck of the cylinder block.

Projection (A): 8.0–9.0mm {0.315–0.354 in}

2. Apply clean engine oil to new O-rings and install them to the oil control plugs.




3. Thoroughly remove all dirt, oil, and other material from the decks of the cylinder block.
4. Turn the crankshaft clockwise and apply engine oil to the cylinder walls.
5. Place the new cylinder head gaskets on the cylinder block.



6. Install the cylinder heads to the cylinder block.
7. Tighten the cylinder head bolts as described below.
 - (1) Before installation, measure the length of each bolt. Replace a bolt if it exceeds the maximum length.



Length: 133.7-134.3mm {5.264-5.287 in}
Maximum: 135mm {5.31 in}



- (2) Apply clean engine oil to the threads and the seat face of each bolt and install them and new washers.
- (3) Tighten the bolts in two or three steps in the order shown.


Tightening torque:
23.1-25.9 N·m {2.35-2.65 kgf·m, 17.0-19.1 ft·lbf}

- (4) Put a paint mark on each bolt head.
- (5) Using the marks as a reference, tighten the bolts by turning each 85° - 95° in the sequence shown.
- (6) Further tighten each bolt by turning another 85° - 95° .




8. Connect the water pipe to the water pipe elbow and secure to the cylinder head.

Tightening torque:
7.9-10.7 N·m {80-110 kgf·cm, 70-95.4 in·lbf}


**HLA**

1. Apply clean engine oil to the friction surfaces.
2. If the HLA are being reused, install them in the positions from which they were removed.
3. Verify that the HLA move smoothly in their bores.


**Camshaft****Caution**

- Camshafts must be assembled in the following procedure. Otherwise, camshaft can be broken or damaged because there is little camshaft thrust clearance.

1. Apply clean engine oil to the camshaft journals and the supports.
2. Install the camshafts so that the intake camshaft gear mark and exhaust camshaft gear mark align.
3. Remove the oil, dirt from the mating surfaces between the front camshaft cap and the cylinder head, and degrease.
4. Apply a light coat of silicone sealant to the shaded areas as shown.



5. Install the thrust caps onto the cylinder heads. Hand tighten the bolts in five or six steps in the order shown, until the thrust caps fully seated on the cylinder heads.



6. Install the camshaft caps and hand tighten the bolts.
7. Tighten the camshaft cap bolts in five or six steps in the order shown.


Tightening torque:


11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}

8. Retighten the bolts in the order shown.

Tightening torque: 11.3–14.2 N·m

{115–145 kgf·cm, 99.9–125 in·lbf}






9. Install the distributor cap. (LH cylinder head)

Tightening torque:

11.3–14.2 N·m {115–145 kgf·cm, 100–125 in·lbf}




10. Apply clean engine oil to the lip of the new camshaft oil seal.


11. Push the oil seal slightly in by hand.

12. Tap the camshaft oil seal in evenly by using the **SST** and a hammer.

Protrusion: 0–0.5mm {0–0.020 in}



11. Tap in the new blind cap by using a plastic hammer.




Water outlet

Install the water outlet with new O-rings.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}








Seal Plate

Install the seal plate.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



Camshaft Pulley

1. The right and left pulleys are different and must be installed on the same head that they were removed from.

2. Install the camshaft pulley so that the "R" mark can be seen and the timing mark aligns with the camshaft knock pin.

3. Install the camshaft pulley so that the "L" mark can be seen and the timing mark aligns with the camshaft knock pin.

Camshaft Pulley Lock bolt


1. Apply clean engine oil to the lock bolt threads.
2. Hold the camshaft by using a wrench on the cast hexagon as shown, and tighten the bolt.

Tightening torque:

123–140 N·m {12.5–14.3 kgf·m, 91–103 ft·lb}

Cylinder Head Cover

1. Remove all old silicone sealant from the cylinder head and cover.
2. Apply silicone sealant to the cylinder head cover as shown in the figure.
3. Install the new cylinder head cover gasket into the cylinder head cover.



4. Install the cylinder head cover and tighten the bolts in two or three steps in the order shown.


Tightening torque:

5.0–8.8 N·m {50–90 kgf·cm, 44–78 in·lbf}



5. Retighten cylinder head cover bolts. RH ⑤ ⑥ and LH ⑥ ⑦

Tightening torque:

5.0–8.8 N·m {50–90 kgf·cm, 44–78 in·lbf}




TIMING BELT
Torque Specification



Timing Belt Pulley

1. Hold the flywheel (MTX) or drive plate (ATX) by using the SST.
2. Install the crankshaft key and the timing belt pulley on the crankshaft.
3. Temporarily tighten the timing belt pulley bolt.




No.2 Idler Pulley

Install the No.2 idler pulley to the cylinder block.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}




Timing Belt Auto Tensioner

1. Press in the tensioner rod slowly, using a press.

Caution


- Do not press the tensioner rod to more than 9,810 N {1,000 kgf, 2,200 lbf}. It will damage the tensioner.



2. Insert a pin into the second hole in the body as shown to hold the tensioner rod.

Note

- Pin diameter: 1.6 mm {0.063 in}



3. Set the tensioner in place and snugly tighten the tensioner upper bolt.


Note

- This must be done to reduce the timing belt resistance when the idler pulley is installed.

4. Install the tensioner pulley.


Tightening torque:

38–44 N·m {3.8–4.5 kgf·m, 28–32 ft·lbf}




Timing Belt

1. Turn the pulleys clockwise, and align the timing marks.



2. Install the timing belt on the pulleys in the order described below.

- ① Timing belt pulley
- ② No.2 Idler pulley
- ③ LH camshaft pulley
- ④ Tensioner pulley
- ⑤ RH camshaft pulley




3. Verify that the belt has no looseness at the tension side.

4. Install the No.1 idler pulley while applying the pressure on the timing belt.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}




5. Push the auto tensioner in the direction of the arrow and install the lower bolt.

6. Tighten the upper and lower tensioner bolts to the specified torque.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}




7. Remove the pin from the auto tensioner, and apply tension to the belt.

8. Tighten the tensioner pulley.


Tightening torque:

38–44 N·m {3.8–4.5 kgf·m, 28–32 ft·lbf}




9. Turn the crankshaft clockwise twice in the direction of rotation, and align the timing marks.

10. Verify that the timing marks are correctly aligned. If not, repeat the procedure from "Timing Belt Auto Tensioner". (Refer to page B2–108.)



11. Check the timing belt deflection. If it is incorrect, replace the auto tensioner.

Deflection: 6–8mm {0.24–0.31 in}




No.3 Engine Mount Bracket

Install the No.3 engine mount bracket.

Tightening torque:

44–60 N·m {4.4–6.2 kgf·m, 32–44 ft·lbf}




Timing Belt Cover

1. Install the right timing belt cover.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



2. Install the left timing belt cover.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




Crankshaft Position Sensor

Install the crankshaft position sensor.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Dipstick and Pipe**

Install the dipstick and pipe with the clip.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Water Pump Pulley**

Install the water pump pulley.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·m, 70–95.4 in·lbf}

**Crankshaft Pulley**

1. Hold the flywheel (MTX) or drive plate (ATX) by using the SST.
2. Remove the crankshaft pulley bolt.


Caution

- Install the crankshaft pulley carefully. The crankshaft position sensor rotor is on the rear of the pulley, and can be damaged easily.



3. Install the crankshaft pulley onto the crankshaft.
4. Apply clean engine oil to the bolt threads.
5. Tighten the crankshaft pulley.

Tightening torque:

157–166 N·m {16.0–17.0 kgf·m, 116–122 ft·lbf}




AUXILIARY PARTS Torque Specifications



Oil Filter

1. Apply a small amount of clean engine oil to the rubber seal of the new oil filter.
2. Install the filter and tighten it by hand until the rubber seal contacts the mounting base.
3. Tighten the filter 1-1/6 turns by using the **SST**.

**Spark Plug**

Install the spark plugs.

Tightening torque:


15–22 N·m {1.5–2.3 kgf·m, 11–16 ft·lbf}

A/C Compressor Bracket (If equipped)

Install the A/C compressor bracket.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

**Engine Hanger**

1. Install the front engine hanger and the ground harness.


Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

2. Install the rear engine hanger.

Tightening torque:


38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

**Intake Manifold Assembly**

1. Install new gaskets and the intake manifold assembly. Hand tighten the bolts and nuts.
2. Install the intake manifold bracket.

Tightening torque:


19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}




3. Tighten the intake manifold bolts and nuts in two or three steps.

Tightening torque:


19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}




4. Connect the hoses.

**Distributor**

1. Apply clean engine oil to a new O-ring and position it on the distributor.
2. Apply engine oil to the drive blade.
3. Align the groove of the distributor body and shaft gear mark.
4. Install the distributor with the blade fit into the camshaft groove.




5. Hand tighten the distributor mounting bolts.
6. Connect the high-tension leads.

**Exhaust Manifold Assembly (LH)**

1. Place a new gasket in position.
2. Install the left exhaust manifold.

Tightening torque:


19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

**Exhaust Manifold Insulator (LH)**

Install the left exhaust manifold insulator.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

**Bracket and Tensioner**

1. Install the bracket and tensioner.
2. Hand tighten the bolt ①, then bolt ②.
3. Tighten the bolt ②, then bolt ① to the specified torque.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

**Generator**

Install the generator and the bracket.


Tightening torque:

Ⓐ: 38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

Ⓑ: 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

ENGINE STAND DISMOUNTING**PROCEDURE**

1. Remove the engine from the **SST** (Engine stand).
2. Remove the **SST** (Engine hanger) from the engine in the reverse order of installation.
(Refer to page B2-53.)




3. Install a new gasket and the right exhaust manifold (RH) together with the EGR pipe.

Tightening torque:
19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

4. Tighten the EGR pipe.

Tightening torque:
54–68 N·m {5.5–7.0 kgf·m, 40–50 ft·lbf}



5. Install the right exhaust manifold insulator (RH).

Tightening torque:
7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



INSTALLATION

PROCEDURE

Tighten all bolts and nuts to the specified torques.

Step 1

Torque Specifications




Transaxle

1. Join the engine and transaxle.
2. Install the transaxle mounting bolts.
3. Tighten the bolts shown.


Tightening torque:

68-99.0 N·m {6.9-10.1 kgf·m, 50-73.0 ft·lbf}




No.2 engine mount rubber and bracket
Install the mount rubber and bracket.

Tightening torque:
38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}




Starter
Install the starter to the transaxle housing.

Tightening torque:
38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}




Seal plate
Install the seal plate.

Tightening torque:
38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}



Throttle cable (ATX)
Install the throttle cable.

Tightening torque:
6.9–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}



Torque converter nut (ATX)
1. Hold the drive plate by using a screwdriver inserted through the service hole from the converter housing side.
2. Insert a torque wrench through the service hole from the oil pan side. Tighten the nuts evenly and gradually.



Tightening torque:
35–49 N·m {3.5–5.0 kgf·m, 26–36 ft·lbf}

Step 2

Warning

- A vehicle that is lifted but not securely supported on safety stands is dangerous. It can slip or fall, causing death or serious injury. Never work around or under a lifted vehicle if it is not securely supported on safety stands.

Torque Specifications




Engine mount member


Install the engine mount member.

Tightening torque:

64-89 N·m (6.5-9.1 kgf·m, 48-65 ft·lb)

**Engine and transaxle assembly**


1. Suspend the engine and transaxle assembly.
2. Slowly lower the engine and transaxle assembly as a unit. Keep the engine from swinging or bumping into components in the engine compartment.
3. Install the engine and transaxle assembly in the engine compartment.
4. Align the engine mounts with the engine mount member mounting holes.

**Engine mount**

1. Install and tighten the engine mount nuts of the No.1 and No.2 mounts.

Tightening torque:

38–52 N·m {3.8–5.3 kgf·m, 27–38 ft·lbf}




2. Install the No.3 engine mount rubber.

Tightening torque:

Ⓐ: 74–103 N·m {7.5–10.5 kgf·m, 54–75.9 ft·lbf}

Ⓑ: 67–93 N·m {6.8–9.5 kgf·m, 49–68 ft·lbf}



3. Install the No.4 engine mount rubber and bracket, and hand tighten nuts Ⓐ.
4. Install bolts Ⓑ and tighten them in two or three steps in the order shown.

Tightening torque:



44–60 N·m {4.4–8.2 kgf·m, 32–44 ft·lbf}

5. Tighten nuts Ⓐ.

Tightening torque:

67–93 N·m {6.8–9.5 kgf·m, 49–68 ft·lbf}

Step 3
Torque specifications



Drive shaft

1. Apply grease to the end of the drive shafts.

Caution

- The oil seals are damaged easily if this procedure is not done correctly.


2. Install a new clip with the end gap facing upward.
3. Install the drive shaft.
4. Push the drive shaft into the joint shaft.
5. Install the joint shaft.


6. Tighten the bolts in the order shown.

Tightening torque:

43-61 N-m {4.3-6.3 kgf-m, 32-45 ft-lbf}

7. After installation, pull the front hub outward to confirm that the drive shaft is securely held by the clip.






8. Install the lower arm ball joint to the knuckle and tighten the through bolt.

Tightening torque:

44–58 N·m {4.4–6.0 kgf·m, 32–43 ft·lbf}




Tie-rod end ball joint

1. Install the tie-rod ends to the knuckles and tighten.

Tightening torque:

43–56 N·m {4.3–5.8 kgf·m, 32–41 ft·lbf}

2. Install new cotter pins.




Stabilizer control link

Install the stabilizer control link.

Tightening torque:

44–60 N·m {4.4–6.2 kgf·m, 32–44 ft·lbf}



Extension bar (MTX)

Install the extension bar to the transaxle.

Tightening torque:


32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}

Shift control rod (MTX)

Install the shift control rod to the transaxle.

Tightening torque:

16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}




Front exhaust pipe

1. Connect the front exhaust pipe to the exhaust pipe with a new gasket. Hand tighten new nuts.
2. Tighten the nuts.

Tightening torque:


64–89 N·m {6.5–9.1 kgf·m, 48–65 ft·lbf}



4. Install the front exhaust pipe with new gaskets.
5. Tighten new nuts.

Tightening torque:

41–54 N·m {4.1–5.6 kgf·m, 30–40 ft·lbf}




Transverse member

Install the transverse member.

Tightening torque:

94–126 N·m {9.5–12.9 kgf·m, 69–93.3 ft·lbf}



Clutch release Cylinder (MTX)

1. Install the clutch release cylinder.

Tightening torque:

16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}


2. Mount the pipe brackets in position.

Tightening torque:

16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}



Step 4

Connect the hoses shown.



Step 5


1. Connect the harness connectors shown.




2. Install the harness bracket and the fuel filter.

Tightening torque:
 7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lb}

Step 6 Torque Specifications






A/C compressor

Install the A/C compressor to the bracket.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lb}




P/S oil pump and bracket

1. Install the P/S oil pump.

Tightening torque:

Ⓐ: 32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lb}


Ⓑ: 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lb}



2. Tighten the bolt shown.

Tightening torque:

32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lb}




3. Install the P/S oil hose to the engine.

Tightening torque:

7.8–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lb}

4. Connect the steering pressure sensor connector.




5. Install the P/S oil pump pulley to the pump body and hand tighten the nut.

6. Hold the pulley by using a 12mm (0.47 in) socket wrench through the pulley hole, and tighten the pulley nut.

Tightening torque:

63–93 N·m {6.4–9.5 kgf·m, 47–68 ft·lb}




7. Install the P/S oil reservoir and the engine ground.

Tightening torque:

6.9–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}


Drive belt

1. Install the P/S and/or A/C drive belt.
2. Install the generator drive belt.
3. Adjust the drive belt deflection. (Refer to page B2–7.)




Control cable (ATX)

Install the control cable.



Battery duct

Install the battery duct.




Coolant reservoir

Install the coolant reservoir.

Tightening torque:

6.9–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}




Radiator and coolant fan assembly


1. Install the radiator and coolant fan assembly. Secure the shroud upper panel.

Tightening torque:


6.9–9.8 N·m {70–100 kgf·cm, 61–86.8 in·lbf}



2. Connect the upper and lower radiator hoses.
3. Connect the coolant reservoir hose.
4. Connect the coolant fan motor connector.




5. Connect the oil cooler hoses (ATX).



Accelerator cable

1. Install the accelerator cable.
2. Adjust the cable deflection by turning nuts **A**.

Deflection: 1–3mm {0.04–0.11 in}




Battery and carrier


1. Install the battery carrier.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



2. Install the engine harness to the carrier.




3. Install the battery.

Tightening torque:

2.4–5.9 N·m {30–60 kgf·cm, 26–52 in·lbf}

4. Connect the positive battery terminal.



Air cleaner assembly


1. Install the air cleaner assembly.

2. Connect the hoses.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

3. Connect the mass air flow sensor connector.



Fresh-air duct

Install the fresh-air duct.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

Splash shield

Install the splash shield.

Steps After Installation


1. Fill the engine with the specified amount and type of engine oil. (Refer to section D2.)
2. Fill the radiator with the specified amount and type of engine coolant. (Refer to section E2.)
3. If the transaxle oil was drained, fill it with the specified amount and type of transaxle oil. (Refer to section J2, K.)
4. Install the front wheels.
5. Start the engine and
 - (1) check the engine oil, transmission oil, and engine coolant leakage.
 - (2) check the ignition timing and idle speed. (Refer to section F2.)
 - (3) check the operation of the emission control system. (Refer to section F2.)
6. Turn off the engine and check drive belt deflection. (Refer to page B2–6.)
7. Perform a road test.
8. Recheck the oil and coolant levels.

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

LUBRICATION SYSTEM (K8)

| | |
|-------------------------------------|-------|
| INDEX | D2- 2 |
| OUTLINE | D2- 3 |
| SPECIFICATIONS | D2- 3 |
| TROUBLESHOOTING GUIDE | D2- 3 |
| OIL PRESSURE | D2- 4 |
| PREPARATION | D2- 4 |
| INSPECTION | D2- 4 |
| ENGINE OIL | D2- 5 |
| INSPECTION | D2- 5 |
| REPLACEMENT | D2- 5 |
| OIL FILTER | D2- 6 |
| PREPARATION | D2- 6 |
| REPLACEMENT | D2- 6 |
| OIL COOLER | D2- 7 |
| PREPARATION | D2- 7 |
| REMOVAL/INSTALLATION | D2- 7 |
| OIL PAN | D2- 8 |
| REMOVAL/INSTALLATION | D2- 8 |
| INSPECTION | D2- 9 |
| OIL PUMP | D2-11 |
| PREPARATION | D2-11 |
| DISASSEMBLY / ASSEMBLY | D2-11 |
| INSPECTION | D2-12 |

INDEX



| | |
|-------------------|------------|
| 1. Oil pressure | |
| Inspection | page D2- 4 |
| 2. Engine oil | |
| Inspection | page D2- 5 |
| Replacement | page D2- 5 |
| 3. Oil filter | |
| Replacement | page D2- 6 |

| | |
|------------------------------|------------|
| 4. Oil cooler | |
| Removal / Installation | page D2- 7 |
| 5. Oil pan | |
| Removal / Installation | page D2- 8 |
| Inspection | page D2- 9 |
| 6. Oil pump | |
| Disassembly / Assembly | page D2-11 |
| Inspection | page D2-12 |


OUTLINE

SPECIFICATIONS

| Item | | Engine | K8 DOHC |
|--------------------|-------------------------------------|--------------------------------|---|
| Lubrication system | | | Force-fed type |
| Oil pump | Type | | Trochoid gear |
| | Relief pressure | kPa{kgf/cm ² , psi} | 491-588 {5.0-6.0, 72-85} |
| Oil filter | Type | | Full-flow, paper element |
| | Relief pressure differential | kPa{kgf/cm ² , psi} | 79-117 {0.8-1.2, 12-17} |
| Oil capacity | Total (dry engine) | L {US qt, Imp qt} | 4.9 {5.2, 4.3} |
| | Engine oil replacement | L {US qt, Imp qt} | 3.7 {3.9, 3.3} |
| | Engine oil + oil filter replacement | L {US qt, Imp qt} | 4.0 {4.2, 3.5} |
| Engine oil | | | API SG, SH Energy Conserving II (ECII) ILSAC |

D2

Recommended SAE Viscosity



* Anticipated ambient temperature range before succeeding oil change.

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Remedy | Page |
|---|--|---|---|
| Engine hard starting | Improper engine oil Insufficient engine oil | Replace Add oil | D2- 5 D2- 5 |
| Excessive oil consumption | Oil working up or down in cylinder Oil leakage | Refer to section B1 Repair | — |
| Oil pressure drop | Insufficient oil Oil leakage Worn and/or damaged oil pump rotor Worn plunger (inside oil pump) or weak spring Clogged oil strainer Excessive main bearing or connecting rod bearing clearance | Add oil Repair Replace Replace Clean Refer to section B2 | D2- 5 — D2-11, 12 D2-11, 12 — |
| Warning light illuminates while engine is running | Oil pressure drop Malfunction of oil pressure switch Malfunction of electrical system | As described above Refer to section C2* Refer to section C2* | — |


* 1995 MX-3 Body Electrical Troubleshooting Manual





Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.

OIL PRESSURE

PREPARATION
SST

| | |
|---|---|
| <p>49 0187 280</p> <p>Gauge, oil pressure</p>  | <p>For inspection of oil pressure</p> |
|---|---|



INSPECTION

1. Remove the oil pressure switch.

2. Screw the **SST** into the oil pressure switch installation hole.

3. Warm up the engine to normal operating temperature.

4. Run the engine at 1,000 rpm and 3,000 rpm, and note the gauge reading.

Oil pressure

1,000 rpm: 196 kPa {2.0 kgf/cm², 28 psi}

3,000 rpm: 334-490 kPa
{3.4-5.0 kgf/cm², 49-71 psi}

Note

- Oil pressure varies with oil viscosity and temperature.

5. If the pressure is not as specified, check for the cause and repair. (Refer to Troubleshooting Guide, page D2-3.)


6. Apply sealant to the oil pressure switch threads.

7. Remove the **SST** and install the oil pressure switch.

Tightening torque:

11.8-17.6 N·m {120-180 kgf·cm, 105-156 in·lbf}

8. Start the engine and check for oil leaks.



ENGINE OIL


INSPECTION

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil as necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.0 L {1.1 US qt, 0.90 Imp qt}.

D2



REPLACEMENT

Warning

- When the engine and the oil are hot, they can badly burn. Don't burn yourself with either.

1. Warm up the engine to normal operating temperature and stop it.
2. Remove the oil filler cap and the oil pan drain plug.
3. Drain the oil into a container.
4. Install a new gasket and the drain plug.

Tightening torque:


30–41 N·m {3.0–4.2 kgf·m, 22–30 ft·lbf}

5. Refill the engine with the specified type and amount of engine oil.


Oil capacity

L {US qt, Imp qt}

| | |
|-------------------------------------|----------------|
| Total (dry engine) | 4.9 {5.2, 4.3} |
| Engine oil replacement | 3.7 {3.9, 3.3} |
| Engine oil + oil filter replacement | 4.0 {4.2, 3.5} |



6. Refit the oil filler cap.
7. Run the engine and check for leaks.
8. Check the oil level and add oil if necessary.




OIL FILTER

PREPARATION


SST

| | |
|---|--------------------------------------|
| <p>49 G014 001</p> <p>Oil filter wrench</p>  | <p>For replacement of oil filter</p> |
|---|--------------------------------------|



REPLACEMENT

1. Remove the oil filter by using the **SST**.
2. Use a clean rag to wipe off the mounting surface on the oil cooler base.
3. Apply a small amount of clean engine oil to the O-ring of the new filter.



4. Install the oil filter and tighten it by hand until the O-ring contacts the oil cooler base.
5. Tighten the filter 1 and 1/6 turns by using the **SST**.

Tightening torque:


13.8–17.6 N·m {140–180 kgf·cm, 122–156 in·lbf}

6. Start the engine and check for leaks.
7. Check the oil level and add oil if necessary.

Oil filter capacity: 0.3 L {0.32 US qt, 0.26 Imp qt}

OIL COOLER


PREPARATION
SST

| | | |
|-------------------|---|--|
| 49 G014 001 |  | For removal and installation of oil filter |
| Oil filter wrench | | |

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to section E2.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.

D2



- 1. Oil filter
Replacement page D2-6
- 2. Oil cooler hoses
- 3. Oil cooler

- 4. O-ring
- 5. Oil filter body
- 6. Gasket


Steps After Installation

1. Fill with the specified amount and type of engine coolant. (Refer to section E2.)
2. Start the engine and check for leaks.

OIL PAN


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine oil. (Refer to page D2-5.)
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Splash shield
2. Transverse member
3. Front exhaust pipe


4. Oil pan
Removal Note page D2-9
Inspection page D2-9
Installation Note page D2-9
5. Oil strainer

**Removal Note****Oil pan**

1. Remove the oil pan mounting bolts.


Caution

- Pry tools can easily scratch the lower cylinder block and oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.




2. Remove the sealant on the bolt threads.
Screw a bolt into the weld nut to make a gap between the block and oil pan.
3. Insert a screwdriver or a suitable tool.
4. Remove the oil pan.


D2

**INSPECTION****Oil Pan**


Visually check for cracks, deformation and damage. Repair or replace if necessary.

**Installation Note****Oil pan****Caution**


- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause thread damage.



1. Remove all foreign material from the contact surfaces.



2. Apply silicone sealant to the contact surfaces of oil pan as shown in the figure.



3. Install the oil pan within five minutes of applying the sealant.

Tightening torque

- Ⓐ: 7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}
- Ⓑ: 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}


Steps After Installation

1. Fill with the specified amount and type of engine oil. (Refer to page D2-5.)
2. Start the engine and check for leaks.
3. Check the oil level and add oil if necessary.

OIL PUMP


PREPARATION

SST


| | | |
|------------------------------------|---|------------------------------------|
| 49 H010 401 Installer, oil seal |  | For installation of front oil seal |
|------------------------------------|---|------------------------------------|

DISASSEMBLY / ASSEMBLY


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|--|
| 1. Oil seal Disassembly Note page D2-12 Assembly Note page D2-13 | 4. Inner rotor Inspection page D2-12 Assembly Note page D2-13 |
| 2. Pump cover Disassembly Note page D2-12 Assembly Note page D2-13 | 5. Blind plug 6. Spring seat 7. Pressure spring Inspection page D2-12 |
| 3. Outer rotor Inspection page D2-12 Assembly Note page D2-13 | 8. Control plunger 9. Pump body |

**Disassembly Note****Oil seal**

Remove the oil seal with a screwdriver protected with a rag.


**Pump cover**

1. Remove the pump cover mounting bolts with an impact screwdriver.
2. Remove the pump cover.

**INSPECTION****Pressure Spring**

1. Inspect the spring for weakness and damage.
2. Measure the spring free length. Replace the spring if necessary.

Free length: 46.79 mm {1.842 in}


**Rotor Clearance**

Measure the following clearances. Replace the rotor if necessary.

Tooth tip clearance:


0.02–0.18 mm {0.0008–0.0070 in}

Maximum: 0.22 mm {0.0087 in}


**Outer rotor-to-pump body clearance:**

0.113–0.186 mm {0.0045–0.0073 in}

Maximum: 0.20 mm {0.0078 in}




Side clearance: 0.03–0.09 mm {0.0012–0.0035 in}
 Maximum: 0.13 mm {0.0051 in}



Assembly Note
Inner and outer rotor

1. Apply clean engine oil to the friction surface of the pump body and the rotors.
2. Install the inner and outer rotors into the oil pump body with the marks aligned as shown.




Pump cover

1. Install the pump cover.

Tightening torque:

5.9–8.8 N·m {60–90 kgf·cm, 53–78 in·lb}

2. Verify that the oil pump rotates smoothly when turned by hand.



Oil seal

1. Apply clean engine oil to the new oil seal.
2. Install the oil seal into the oil pump body by hand.
3. Press the oil seal into the oil pump body by using a SST.


Protrusion: 0–0.7 mm {0–0.03 in}

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

COOLING SYSTEM (K8)

| | |
|-------------------------------------|-------|
| INDEX | E2- 2 |
| OUTLINE | E2- 3 |
| SPECIFICATIONS | E2- 3 |
| TROUBLESHOOTING GUIDE | E2- 3 |
| ENGINE COOLANT | E2- 4 |
| PREPARATION | E2- 4 |
| INSPECTION | E2- 4 |
| REPLACEMENT | E2- 5 |
| RADIATOR CAP | E2- 6 |
| PREPARATION | E2- 6 |
| INSPECTION | E2- 6 |
| RADIATOR | E2- 7 |
| REMOVAL / INSTALLATION | E2- 7 |
| INSPECTION | E2- 7 |
| THERMOSTAT | E2- 8 |
| REMOVAL / INSTALLATION | E2- 8 |
| INSPECTION | E2- 9 |
| WATER PUMP | E2-10 |
| REMOVAL / INSTALLATION | E2-10 |
| COOLANT FAN SYSTEM | E2-11 |
| SYSTEM CIRCUIT | E2-11 |
| SYSTEM INSPECTION | E2-11 |
| COOLANT FAN MOTOR | E2-12 |
| INSPECTION | E2-12 |
| REPLACEMENT | E2-13 |
| ENGINE COOLANT TEMPERATURE | |
| SENSOR | E2-14 |
| REMOVAL | E2-14 |
| INSPECTION | E2-14 |
| INSTALLATION | E2-14 |
| COOLANT FAN RELAY | E2-14 |
| REMOVAL | E2-14 |
| INSPECTION | E2-14 |

INDEX



- | | | | |
|--------------------------------------|------------|--|--|
| 1. Engine coolant | | | |
| Inspection | page E2- 4 | | |
| Replacement | page E2- 5 | | |
| 2. Radiator cap | | | |
| Inspection | page E2- 6 | | |
| 3. Radiator | | | |
| Removal / Installation | page E2- 7 | | |
| Inspection | page E2- 7 | | |
| 4. Thermostat | | | |
| Removal / Installation | page E2- 8 | | |
| Inspection | page E2- 9 | | |
| 5. Water pump | | | |
| Removal / Installation | page E2-10 | | |
| 6. Coolant fan system | | | |
| System circuit | page E2-11 | | |
| System inspection | page E2-11 | | |
| 7. Coolant fan motor | | | |
| Inspection | page E2-12 | | |
| Replacement | page E2-13 | | |
| 8. Engine coolant temperature sensor | | | |
| Removal | page E2-14 | | |
| Inspection | page E2-14 | | |
| Installation | page E2-14 | | |
| 9. Coolant fan relay | | | |
| Removal / Inspection | page E2-14 | | |

**OUTLINE
SPECIFICATIONS**

| Item | | Engine | MTX | ATX | | |
|------------------|----------------------------|-------------------|----------------------------------|-------------|------------|------|
| Cooling system | | | Water-cooled, forced circulation | | | |
| Coolant capacity | | L {US qt, Imp qt} | 7.5 {7.9, 6.6} | | | |
| Water pump | Type | | Centrifugal | | | |
| | Water seal | | Unified mechanical seal | | | |
| Thermostat | Type | | Wax, bottom-bypass | | | |
| | Opening temperature | °C {°F} | 80-84 {176-183} | | | |
| | Full-open temperature | °C {°F} | 95 {203} | | | |
| | Full-open lift | mm {in} | 8.5 {0.33} | | | |
| Radiator | Type | | Corrugated fin | | | |
| | Cap valve opening pressure | | kPa {kgf/cm ² , psi} | | | |
| | Core size | mm {in} | Width | 690 {27.2} | 647 {25.5} | |
| | | | Height | 350 {13.8} | 390 {15.4} | |
| | | | Depth | 25 {0.98} | | |
| | Fin pitch | | mm {in} | 1.3 {0.051} | | |
| Coolant fan | Type | | Electric | | | |
| | Blade | Outer diameter | mm {in} | | | |
| | | Number | 5 | | | |
| | Motor | Fan speed | | — | Low | High |
| | | Current | A | 11.0 | 12.0 | 16.8 |
| Speed | | rpm | 1,750 | 1,650 | 2,060 | |

E2



TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|--------------------|----------------------------|---------|-------|
| Overheating | Coolant level insufficient | Add | E2- 5 |
| | Coolant leakage | Repair | — |
| | Radiator fins clogged | Repair | E2- 7 |
| | Radiator cap malfunction | Replace | E2- 6 |
| | Coolant fan malfunction | Replace | E2-11 |
| | Thermostat malfunction | Replace | E2- 9 |
| | Water passage clogged | Clean | E2- 5 |
| | Water pump malfunction | Replace | E2-10 |
| Corrosion | Impurities in coolant | Replace | E2- 5 |

ENGINE COOLANT

PREPARATION

SST

| | | | | | |
|---|---|--|--|---|--|
| 49 9200 145 Adapter set, radiator cap tester |  | For inspection of cooling system pressure | 49 9200 146 Adapter A (Part of 49 9200 145) |  | For inspection of cooling system pressure |
|---|---|--|--|---|--|


INSPECTION

Warning


- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.

Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.


When you're sure all the pressure is gone, press down on the cap – still using a cloth – turn it, and remove it.

**Coolant Level (Engine Cold)**

1. Verify that the coolant level is near the filler neck of the radiator.
2. Verify that the coolant level in the coolant reservoir is between the FULL and LOW marks. Add coolant if necessary.

**Coolant Quality**


1. Verify that there is no buildup of rust or scale around the filler cap and filler neck.
2. Verify that the coolant is free of oil. Replace the coolant if necessary.

**Coolant Leakage**

1. Remove the fresh-air duct.
2. Connect a radiator tester and the SST to the radiator filler neck.
3. Apply 103 kPa {1.05 kgf/cm², 15 psi} pressure to the system.
4. Verify that the pressure is held. If not, check for coolant leakage.

Caution

- Applying more than 103 kPa {1.05 kgf/cm², 15 psi} can damage the hoses, fittings and other components, and cause leaks.



Coolant Protection



Caution

- The engine has aluminum parts that can be damaged by alcohol or methanol antifreeze. Do not use alcohol or methanol in the cooling system. Use only ethylene-glycol-based coolant.
- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.

1. Measure the coolant temperature and specific gravity with a thermometer and a hydrometer.
2. Determine the coolant protection by referring to the graph shown.
3. If the coolant protection is not proper, add water or coolant as necessary.

Antifreeze solution mixture percentage

| Coolant protection | Volume percentage | | Gravity at 20°C (68°F) |
|---------------------|-------------------|---------|------------------------|
| | Water | Coolant | |
| Above -16°C (3°F) | 65 | 35 | 1.054 |
| Above -26°C (-15°F) | 55 | 45 | 1.066 |
| Above -40°C (-40°F) | 45 | 55 | 1.078 |



REPLACEMENT

Draining

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.
- Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counter-clockwise to the first stop. Step back while the pressure escapes.
- When you're sure all the pressure is gone, press down on the cap - still using a cloth - turn it, and remove it.

1. Remove the coolant filler cap, radiator cap and loosen the radiator drain plug.
2. Disconnect the oil cooler hoses.
3. Drain the coolant into a container.
4. Flush the cooling system with water until all traces of color are gone.
5. Let the system drain completely.
6. Tighten the drain plug and connect the oil cooler hoses.

Refilling

Use the proper amount and mixture of ethylene-glycol based coolant. (Refer to Coolant Protection, page E2-5.)



1. Slowly pour the coolant into the radiator up to the coolant filler port.


Filling pace:

1.0 L {1.1 US qt, 0.9 Imp qt}/min. max.

2. Fill the coolant reservoir up to the FULL mark.
3. Fully install the coolant filler cap.
4. Start the engine and let it idle until it warms up.
5. If the temperature increases beyond normal, there is excessive air in the system. Stop the engine and allow it to cool; then repeat steps 1-3.
6. Run the engine at 2,200-2,800 rpm for five minutes.
7. Stop the engine and allow it to cool.
8. Repeat steps 1-7; then go to step 9.
9. Remove the filler cap and verify that the engine coolant level is near the filler neck. If not, repeat steps 1-8.
10. Fill the reservoir up to the FULL mark.

RADIATOR CAP**PREPARATION****SST**


| | | | |
|--|---|---|---|
| <p>49 9200 145</p> <p>Adapter set, radiator cap tester</p>  | <p>For inspection of radiator cap valve</p> | <p>49 9200 147</p> <p>Adapter B (Part of 49 9200 145)</p>  | <p>For inspection of radiator cap valve</p> |
|--|---|---|---|

**INSPECTION****Radiator Cap Valve**

1. Remove foreign material (such as water residue) from between the radiator cap valve and the valve seat.
2. Attach the radiator cap to a radiator cap tester with the SST. Apply pressure gradually to 73.5-102 kPa {0.75-1.05 kgf/cm², 10.7-14.9 psi}.
3. Wait about 10 seconds. Verify that the pressure has not decreased.

Negative Pressure Valve


1. Pull the negative pressure valve to open it. Verify that it closes completely when released.
2. Check for damage on the contact surfaces and for cracked or deformed seal packing.
3. Replace the radiator cap if necessary.




RADIATOR

REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Fresh-air duct 2. Coolant fan connector 3. Coolant reservoir hose 4. Upper and lower radiator hoses 5. Oil cooler hoses (ATX) | <ol style="list-style-type: none"> 6. Shroud upper panel 7. Radiator Inspection below 8. Coolant fan and radiator cowling assembly |
|--|---|



INSPECTION

Check for the following and repair or replace if necessary.

1. Cracks, damage, and water leakage.
2. Bent fins (Repair with a screwdriver).
3. Distorted or bent radiator inlet.


Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2-6.)
2. Connect the negative battery cable.
3. Start the engine and check for leaks.

THERMOSTAT



REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.



1. Water inlet pipe
2. Engine harness bracket
3. Thermostat cover
4. Thermostat gasket
Installation Note page E2-9

5. Thermostat
Inspection page E2-9
Installation Note page E2-9

**INSPECTION**

1. Visually check that the thermostat valve is airtight.
2. Place the thermostat and a thermometer in water.
3. Heat the water and check the following.

Initial-opening temperature:

80–84°C {176–183°F}

Full-open temperature: 95°C {203°F}

Full-open lift: 8.5mm {0.33 in} min.

4. Check the thermostat gasket. If damaged, replace the thermostat assembly.

Installation Note**Thermostat**

Install the thermostat into the cylinder head with the jiggle pin at the top.

Thermostat gasket

Install a gasket with the projection facing the same direction as the jiggle pin.

Steps After Installation

1. Fill the radiator with the specified amount and type of engine coolant. (Refer to page E2–6.)
2. Start the engine and check for leaks.


WATER PUMP

REMOVAL / INSTALLATION

Caution

- Applying oil to the water pump rubber seal will damage it.

1. Disconnect the negative battery cable.
2. Drain the engine coolant. (Refer to page E2-5.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.




1. Timing belt
Removal/Installation section B2
2. No.3 engine mount bracket

3. Water pump assembly
Inspect for cracks, damaged mounting surface, bearing condition, and leakage. If the water pump is damaged, replace it. Do not repair it.
4. Water pump rubber seal


COOLANT FAN SYSTEM


SYSTEM CIRCUIT



SYSTEM INSPECTION

1. Turn the ignition switch to OFF.
2. Ground the TEN terminal of the data link connector and open the throttle slightly.
3. Turn the ignition switch on and verify that the fan operates.
4. If the fan does not operate, inspect the coolant fan system components and wire harness.
5. Remove the filler cap and place a thermometer in the filler neck.
6. Start the engine.
7. Verify that the fan operates when the coolant temperature reaches approx. 100°C {212°F}.
8. If it does, check the engine coolant temperature sensor. (Refer to page E2-14.)





COOLANT FAN MOTOR


INSPECTION

MTX (Single-speed type)

1. Check that the battery is fully charged.
2. Disconnect the coolant fan motor connector.
3. Connect the battery and an ammeter to the fan motor connector.
4. Verify that the fan motor operates smoothly at the standard current.

Current: 11.0 A

5. If the fan motor is faulty, replace the fan motor.



ATX (Two-Speed Type)


1. Check that the battery is fully charged.
2. Disconnect the coolant fan motor connector.
3. Connect the battery and an ammeter to the fan motor connector for low-speed inspection.
4. Verify that the fan motor operates smoothly at the standard current.

Current: 12.0 A

5. Connect the battery and an ammeter to the fan motor connector for high-speed inspection.
6. Verify that the fan motor operates smoothly at the standard current.


Current: 16.8 A

7. If the fan motor is faulty, replace the fan motor.





REPLACEMENT

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Fresh-air duct
2. Shroud upper panel
3. Coolant fan connector

4. Radiator cowl
5. Coolant fan
6. Coolant fan motor



ENGINE COOLANT TEMPERATURE SENSOR

REMOVAL

1. Disconnect the engine coolant temperature sensor connector.
2. Remove the engine coolant temperature sensor.

INSPECTION

1. Place the sensor in water with a thermometer and heat the water gradually.
2. Measure resistance of the sensor with an ohmmeter.

| Coolant | Resistance k Ω |
|---------------|-----------------------|
| 91°C {96°F} | 1.70-1.84 |
| 97°C {207°F} | 1.42-1.53 |
| 108°C {226°F} | 1.03-1.11 |

3. If not as specified, replace the engine coolant temperature sensor.


INSTALLATION

1. Install the engine coolant temperature sensor and a new washer.

Tightening torque:

16-23 N·m {1.6-2.4 kgf·m, 12-17 ft·lbf}

2. Connect the engine coolant temperature sensor connector.



COOLANT FAN RELAY

REMOVAL


1. Disconnect the negative battery cable.
2. Remove the coolant fan relay.

INSPECTION

1. Check continuity of the coolant fan relay as shown.

| Terminal | Continuity |
|----------|------------|
| A-C | No |
| B-D | Yes |


2. Apply battery positive voltage between terminals B and D. Check for continuity between terminals A and C.
3. If not as specified, replace the coolant fan relay.




FUEL AND EMISSION CONTROL SYSTEMS (K8)

| | | | |
|--|--------|---|--------|
| INDEX | F2- 2 | POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM | F2-124 |
| OUTLINE | F2- 6 | DESCRIPTION | F2-124 |
| SYSTEM DIAGRAM | F2- 6 | PCV VALVE | F2-124 |
| VACUUM HOSE ROUTING DIAGRAM | F2- 7 | EXHAUST GAS RECIRCULATION (EGR) CONTROL SYSTEM | F2-125 |
| WIRING DIAGRAM | F2- 8 | DESCRIPTION | F2-125 |
| SPECIFICATIONS | F2- 10 | OPERATION | F2-125 |
| COMPONENT DESCRIPTIONS | F2- 11 | SYSTEM INSPECTION | F2-126 |
| TRoubleshooting GUIDE | F2- 14 | EGR SOLENOID VALVE (VACUUM) | F2-126 |
| OUTPUT DEVICES AND ENGINE CONDITION | F2- 14 | EGR SOLENOID VALVE (VENT) | F2-126 |
| RELATIONSHIP CHART | F2- 15 | EGR VALVE | F2-126 |
| USING THIS SECTION | F2- 16 | EVAPORATIVE EMISSION CONTROL SYSTEM | F2-127 |
| DIAGNOSTIC INDEX | F2- 18 | DESCRIPTION | F2-127 |
| SYMPTOM TROUBLESHOOTING | F2- 21 | SYSTEM OPERATION | F2-128 |
| ENGINE TUNE-UP | F2- 69 | PURGE SOLENOID VALVE | F2-128 |
| PREPARATION | F2- 69 | CHARCOAL CANISTER | F2-129 |
| BASIC INSPECTION | F2- 69 | TWO-WAY CHECK VALVE | F2-129 |
| ADJUSTMENT | F2- 70 | CHECK-AND-CUT VALVE | F2-129 |
| ON BOARD DIAGNOSTIC SYSTEM | F2- 72 | SEPARATOR | F2-129 |
| DESCRIPTION | F2- 72 | FUEL-CUT CONTROL SYSTEM | F2-130 |
| PREPARATION | F2- 72 | DESCRIPTION | F2-130 |
| DIAGNOSTIC TROUBLE CODE NUMBER | F2- 73 | PREPARATION | F2-130 |
| AFTER-REPAIR PROCEDURE | F2- 92 | SYSTEM OPERATION | F2-131 |
| SWITCH MONITOR FUNCTION | F2- 92 | CATALYTIC CONVERTER SYSTEM | F2-132 |
| INTAKE-AIR SYSTEM | F2- 95 | DESCRIPTION | F2-132 |
| COMPONENTS | F2- 95 | THREE WAY CATALYTIC CONVERTER | F2-132 |
| THROTTLE BODY | F2- 96 | ELECTRONIC SPARK ADVANCE (ESA) CONTROL SYSTEM | F2-133 |
| AIR INTAKE PIPE/INTAKE MANIFOLD | F2- 96 | DESCRIPTION | F2-133 |
| ACCELERATOR PEDAL | F2- 97 | CONTROL SYSTEM | F2-133 |
| ACCELERATOR CABLE | F2- 97 | DECHOKE CONTROL SYSTEM | F2-134 |
| IDLE AIR CONTROL SYSTEM | F2- 98 | DESCRIPTION | F2-134 |
| DESCRIPTION | F2- 98 | SYSTEM OPERATION | F2-134 |
| PREPARATION | F2- 99 | A/C CUT-OFF CONTROL SYSTEM | F2-135 |
| SYSTEM OPERATION | F2- 99 | DESCRIPTION | F2-135 |
| BAC VALVE | F2- 99 | OPERATION | F2-135 |
| VARIABLE RESONANCE INDUCTION SYSTEM (VRIS) | F2-100 | SYSTEM OPERATION | F2-135 |
| DESCRIPTION | F2-100 | ELECTRICAL COOLANT FAN AND CONDENSER FAN CONTROL SYSTEM | F2-136 |
| SYSTEM OPERATION | F2-101 | ELECTRICAL COOLANT FAN CONTROL | F2-136 |
| COMPONENTS | F2-102 | CONDENSER FAN CONTROL | F2-137 |
| VRIS SHUTTER VALVE ACTUATOR No.1 AND No.2 | F2-103 | SYSTEM OPERATION | F2-138 |
| VRIS SOLENOID VALVE No.1 AND No.2 | F2-103 | CONTROL SYSTEM | F2-139 |
| CHECK VALVE | F2-103 | PREPARATION | F2-139 |
| VACUUM CHAMBER | F2-104 | COMPONENTS | F2-140 |
| FUEL SYSTEM | F2-105 | ENGINE CONTROL MODULE (ECM) | F2-141 |
| DESCRIPTION | F2-105 | VOLUME AIR FLOW SENSOR | F2-150 |
| PREPARATION | F2-106 | THROTTLE POSITION SENSOR | F2-150 |
| SYSTEM OPERATION | F2-107 | ENGINE COOLANT TEMPERATURE SENSOR | F2-152 |
| FUEL TANK | F2-108 | CRANKSHAFT POSITION SENSOR | F2-153 |
| FUEL FILTER | F2-109 | CAMSHAFT POSITION SENSOR | F2-153 |
| FUEL PUMP | F2-110 | HEATED OXYGEN SENSOR | F2-154 |
| FUEL PUMP RELAY | F2-114 | KNOCK SENSOR | F2-156 |
| PRESSURE REGULATOR | F2-114 | MAIN RELAY | F2-157 |
| FUEL INJECTOR | F2-115 | P/S PRESSURE SWITCH | F2-157 |
| PRESSURE REGULATOR CONTROL SYSTEM | F2-119 | CLUTCH SWITCH | F2-157 |
| DESCRIPTION | F2-119 | NEUTRAL SWITCH | F2-158 |
| PRC SOLENOID VALVE | F2-120 | EGR VALVE POSITION SENSOR | F2-158 |
| EXHAUST SYSTEM | F2-121 | OSCILLOSCOPE SIGNAL PATTERN | F2-159 |
| COMPONENT PARTS | F2-121 | | |
| OUTLINE OF EMISSION CONTROL SYSTEM | F2-123 | | |
| DESCRIPTION | F2-123 | | |

INDEX




- | | |
|---|-------------|
| 1. Fresh-air duct | |
| Removal / Inspection / | |
| Installation | page F2- 95 |
| 2. Air cleaner | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2- 70 |
| 3. Volume air flow sensor | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2-150 |
| 4. Resonance duct | |
| Inspection | page F2- 95 |
| 5. Throttle body | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2- 96 |
| 6. BAC valve | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2- 99 |
| 7. Air intake hose | |
| Removal / Installation | page F2- 95 |
| 8. VRIS shutter valve actuator | |
| Inspection | page F2-103 |
| 9. Vacuum chamber | |
| Removal / Installation | page F2-102 |
| Inspection | page F2-104 |
| 10. Check valve | |
| Removal / Installation | page F2-102 |
| Inspection | page F2-103 |
| 11. Intake manifold | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2- 96 |
| 12. Air intake pipe | |
| Removal / Installation | page F2- 95 |
| Inspection | page F2- 96 |
| 13. Accelerator pedal | |
| Removal / Inspection / | |
| Installation | page F2- 97 |
| 14. Accelerator cable | |
| Inspection / Adjustment | page F2- 97 |
| 15. Main silencer | |
| Removal / Inspection / | |
| Installation | page F2-121 |
| 16. Presilencer | |
| Removal / Inspection / | |
| Installation | page F2-121 |
| 17. Three way catalytic converter | |
| Removal / Installation | page F2-121 |
| Inspection | page F2-132 |
| 18. Front pipe | |
| Removal / Inspection / | |
| Installation | page F2-121 |
| 19. Insulator | |
| Removal / Installation | page F2-121 |
| 20. Exhaust manifold | |
| Removal / Inspection / | |
| Installation | page F2-121 |
| 21. EGR pipe | |
| Removal / Inspection / | |
| Installation | page F2-121 |
| 22. Warm up three way catalytic converter | |
| Removal / Inspection / | |
| Installation | page F2-122 |




1. Fuel tank
 - Removal / Inspection / Installation page F2-108
2. Fuel filter (low pressure side)
 - Removal / Installation page F2-110
3. Fuel filter (high pressure side)
 - Replacement page F2-109
4. Fuel pump
 - Inspection page F2-110
 - Disassembly / Assembly page F2-112
5. Fuel pump relay
 - Replacement page F2-114
 - Inspection page F2-114
6. Pressure regulator
 - Inspection page F2-114
 - Removal / Installation page F2-115
7. Fuel injector
 - On-vehicle inspection page F2-115
 - Removal / Installation page F2-115
 - Inspection page F2-115
8. VRIIS solenoid valve No.1 and No.2
 - Removal / Installation page F2-102
 - Inspection page F2-103
9. PCV valve
 - Inspection page F2-124
10. Purge solenoid valve
 - Inspection page F2-128
11. Charcoal canister
 - Inspection page F2-129
12. Check valve (Two-way)
 - Inspection page F2-129
 - Removal / Installation page F2-108
13. Check-and-cut valve
 - Inspection page F2-129
 - Removal / Installation page F2-108
14. Separator
 - Inspection page F2-129
15. Engine control module (ECM)
 - Removal / Installation page F2-141
 - Inspection page F2-141
16. Volume air flow sensor (with intake air temperature sensor)
 - Inspection page F2-150
 - Removal / Installation page F2-95
17. Throttle position sensor (with closed throttle position switch)
 - Inspection page F2-150
 - Replacement page F2-151
18. Engine coolant temperature sensor
 - Removal / Installation page F2-152
 - Inspection page F2-152
19. Crankshaft position sensor (NE signal)
 - Inspection page F2-153
 - Removal / Installation page F2-153
20. Camshaft position sensor (SGC signal, SGT signal)
 - Inspection page F2-153
21. Heated oxygen sensor
 - Inspection page F2-154
 - Replacement page F2-154
22. Knock sensor
 - Removal / Installation page F2-156
23. Main relay
 - Inspection page F2-157
24. P/S pressure switch
 - Inspection page F2-157
25. Clutch switch
 - Inspection page F2-157
 - Replacement page F2-157
26. Neutral switch
 - Inspection page F2-158
 - Replacement page F2-158
27. EGR valve position sensor
 - Inspection page F2-158
28. EGR solenoid valve (vacuum)
 - Inspection page F2-126
29. EGR solenoid valve (vent)
 - Inspection page F2-126
30. PRC solenoid valve
 - Inspection page F2-120

VACUUM HOSE ROUTING DIAGRAM




F2

WIRING DIAGRAM



WIRING DIAGRAM



F2

SPECIFICATIONS

| Item | | Engine | K8 DOHC | | |
|---|--------------------------|--|--|--------------|-------------|
| Idle speed * | | rpm | 670 | | |
| Ignition timing * | | BTDC | 10 | | |
| Throttle body | | | | | |
| Type | | Horizontal draft | | | |
| Throat diameter | | mm {in} | 55 {2.2} | | |
| Fuel pump | | | | | |
| Type | | Impeller (in-tank) | | | |
| Output pressure | | kPa {kgf/cm ² , psi} | 630 {6.5, 92} | | |
| Fuel filter | | | | | |
| Type | Low pressure side | | Nylon element (in fuel pump) | | |
| | High pressure side | | Paper element | | |
| Pressure regulator | | | | | |
| Type | | Diaphragm | | | |
| Regulating pressure | | kPa {kgf/cm ² , psi} | 280 {2.9, 42} | | |
| Fuel injector | | | | | |
| Type | | High-ohmic, side feed | | | |
| Type of drive | | Voltage | | | |
| Resistance | Ω | 20 °C {68°F} | 12–16 | | |
| Idle air control valve | | | | | |
| Solenoid resistance | Ω | 20 °C {68°F} | 10.7–12.3 | | |
| Purge solenoid valve | | | | | |
| Solenoid resistance | Ω | 20 °C {68°F} | 23–27 | | |
| Camshaft position sensor (SGT, SGC signal) | | | | | |
| Type | | Hall element | | | |
| Volume air flow sensor | | | | | |
| Type | | Measuring core type | | | |
| Resistance | Ω | $E_2 \leftrightarrow V_s$ | Closed throttle position 20°C {68°F} | 200–1,000 | |
| | | | Wide open throttle 20°C {68°F} | 20–800 | |
| | Ω | $E_2 \leftrightarrow V_c$ | | 200–400 | |
| | | | $E_2 \leftrightarrow THA$ (Intake air temperature sensor) | 20°C {68°F} | 2,000–3,000 |
| | | | | 60°C {140°F} | 400–700 |
| Engine coolant temperature sensor | | | | | |
| Resistance | $k\Omega$ | 20°C {68°F} | 2.2–2.7 | | |
| | | 80°C {176°F} | 0.29–0.35 | | |
| Fuel Tank | | | | | |
| Capacity | liters {US gal, Imp gal} | | 50 {13.2, 11.0} | | |
| Air cleaner | | | | | |
| Element type | | Oil permeated | | | |
| Accelerator cable | | | | | |
| Free play | mm {in} | | 1.0–3.0 {0.04–0.12} | | |
| Fuel | | | | | |
| Specification | | Unleaded – (R+M) / 2 method 87 or higher | | | |

* TEN terminal of data link connector grounded.

COMPONENT DESCRIPTIONS

| Component | Function | Remarks |
|---|---|--|
| A/C relay | Controls A/C compressor magnetic clutch | — |
| Air cleaner | Filters air entering throttle body | — |
| Air valve | Supplies bypass air into intake manifold (engine cold) | <ul style="list-style-type: none"> • Engine speed increased to shorten warm-up period • Thermowax type • Installed in BAC valve |
| Barometric pressure sensor | Detects barometric pressure; sends signal to ECM | In ECM |
| Brake switch | Detects braking; sends signal to ECM | — |
| Bypass air control (BAC) valve | Supplies bypass air into intake manifold | Consist of air valve and idle air control valve |
| Camshaft position sensor (in distributor) SGC signal SGT signal | Detects No.1 cylinder TDC; sends signal to ECM (SGC signal) Detects crank angle at 60° intervals; sends signal to ECM (SGT signal) | Installed in distributor |
| Charcoal canister | Stores fuel tank fumes (engine stopped) | — |
| Check-and-cut valve | Prevents fuel from flowing into charcoal canister | |
| Check valve (two-way) | Controls pressure in fuel tank | Two-way type |
| Crankshaft position sensor NE signal | Detects crank angle 60° intervals; sends signal to ECM | Installed at crankshaft pulley |
| Data link connector | Concentrated service connector terminals; <ol style="list-style-type: none"> 1. CIS self-diagnosis 2. Initial set 3. Fuel pump check 4. Switch and heated oxygen sensor monitor 5. Engine speed output 6. Supply battery positive voltage 7. Ground | 25-pin (located near left suspension mounting block) <ol style="list-style-type: none"> 1. FEN terminal 2. TEN terminal 3. F/P terminal 4. MEN terminal 5. IG terminal 6. +B terminal 7. GND terminal |
| EGR solenoid valve (vent) | Controls vacuum to EGR control valve (Open air side) | Controlled by duty signal from ECM |
| EGR solenoid valve (vacuum) | Controls vacuum to EGR control valve (Vacuum side) | Controlled by duty signal form ECM |
| Engine control module (ECM) | Controls operation of following: <ol style="list-style-type: none"> 1. A/C (Cut-off) 2. On-board diagnostic function 3. Fuel injection system 4. Idle air control 5. Ignition system (Electronic spark advance) 6. Monitor function 7. Purge control system 8. VRIS control system 9. EGR control system 10. Pressure regulator control system 11. Coolant fan control system 12. Condenser fan control system | <ol style="list-style-type: none"> 1. A/C relay 2. Self-diagnosis Checker 3. Fuel injector 4. Idle air control valve 5. Ignition control module 6. Monitor lamp (Self-Diagnosis Checker) 7. Purge solenoid valve 8. VRIS solenoid valve 9. EGR solenoid valve 10. PRC solenoid valve 11. Coolant fan relay 12. Condenser fan relay |

| Component | Function | Remarks |
|--|---|--|
| Engine control module (ECM) | Detects following: <ol style="list-style-type: none"> 1. A/C operation 2. Air/fuel ratio (oxygen concentration) 3. Atmospheric pressure 4. Braking signal 5. Cranking signal 6. E/L operation 7. Engine coolant temperature 8. Engine speed 9. Ignition ON signal 10. In-gear condition 11. Intake air amount 12. Intake air temperature 13. EGR valve position 14. No.1 piston TDC 15. P/S operation 16. Test mode signal (ignition timing, idle speed, diagnostic trouble code No.) 17. Throttle valve opening angle 18. Closed throttle position 19. Vehicle speed 20. Knocking | <ol style="list-style-type: none"> 1. A/C switch 2. Heated oxygen sensor 3. Barometric pressure sensor 4. Brake switch 5. Ignition switch (START position) 6. Blower motor switch, coolant fan relay, headlight switch, and rear window defroster switch 7. Engine coolant temperature sensor 8. Crankshaft position sensor (NE signal) 9. Ignition switch 10. Neutral / clutch switch (MTX) Transaxle range switch (ATX) 11. Volume air flow sensor 12. Intake air temperature sensor (in volume air flow sensor) 13. EGR valve position sensor 14. Camshaft position sensor (SGC signal) 15. P/S pressure switch 16. Data link connector (TEN terminal) 17. Throttle position sensor 18. Closed throttle position switch (in throttle position sensor) 19. Vehicle speed sensor 20. Knock sensor |
| Engine coolant temperature sensor | Detects engine coolant temperature; sends signal to ECM | Installed on engine |
| Fuel filter | Filters particles from fuel | — |
| Fuel injector | Injects fuel into intake port | Controlled by signals from ECM (side-feed type) |
| Fuel pump | Provides fuel to fuel injectors | <ul style="list-style-type: none"> • Operates while engine running • Installed in fuel tank |
| Fuel pump relay | Voltage for fuel pump while engine running | — |
| Heated oxygen sensor | Detects oxygen concentration; sends signal to ECM | <ul style="list-style-type: none"> • Zirconium and platinum coating • With heater |
| Idle air control valve | Supplies bypass air into intake manifold | <ul style="list-style-type: none"> • Controlled by duty signal from ECM • Installed in BAC valve |
| Ignition control module | Receives spark signal from ECM and generates high voltage in ignition coil | Installed in distributor |
| Ignition switch (START position) | Sends engine cranking signal to ECM | — |
| Intake air temperature sensor | Detects intake air temperature; sends signal to ECM | Installed in volume air flow sensor |
| Intake manifold | Supplies intake air to all cylinders | — |
| Knock sensor | Detects knocking; sends signal to ECM | — |
| Main relay | Supplies current to output devices and ECM | — |
| Neutral/clutch switch (MTX) | Detects in-gear condition; sends signal to ECM | Switch ON in Neutral |
| One-way check valve | Prevents misoperation of VRIS shutter valve No.1 and No.2 and EGR valve during heavy-load operations | For VRIS and EGR |
| PCV valve | Controls blowby gas introduced into engine | — |
| PRC solenoid valve | Controls vacuum to pressure regulator | — |
| Pressure regulator | Adjusts fuel pressure supplied to fuel injectors | — |
| P/S pressure switch | Detects P/S operation | P/S ON when steering wheel turned |
| Purge solenoid valve | Controls evaporative fumes from charcoal canister to intake manifold | Controlled by duty signal from ECM |

| Component | Function | Remarks |
|---|---|--|
| Resonance chamber | Reduces intake air noise | — |
| Separator | Prevents fuel from flowing into charcoal canister | — |
| Three-way catalytic converter | Reduces HC, CO, and NOx by chemical reaction | Monolith type |
| Throttle body | Controls intake air amount | — |
| Transaxle range switch (ATX) | Detects in-gear condition; send signal to ECM | Switch ON in Park or Neutral position |
| Vehicle speed sensor | Detects vehicle speed; sends signal to ECM | Installed on instrument cluster |
| Volume air flow sensor | Detects intake air amount; sends signal to ECM | Intake air temperature sensor included |
| VRIS shutter valve actuator No.1 and No.2 | Closes/opens VRIS shutter valve No.1 and No.2 to improve torque characteristics | For variable resonance induction system (VRIS) |
| VRIS solenoid valve No.1 and No.2 | Controls vacuum to VRIS shutter valve actuator No.1 and No.2 | — |

TROUBLESHOOTING GUIDE

OUTPUT DEVICES AND ENGINE CONDITION

| ENGINE CONDITION | | CRANKING (COLD ENGINE) | WARMING UP (DURING IDLE) | MEDIUM LOAD | | ACCELERATION | HEAVY LOAD | DECELERATION | IDLE | IG: ON (ENGINE NOT RUNNING) | REMARK | |
|-------------------------|------------------------|------------------------------------|---------------------------------------|-----------------|--------|-----------------------|------------|--|--|-----------------------------|---|--|
| | | | | COLD | WARM | | | | | | | |
| FUEL INJECTOR | FUEL INJECTION AMOUNT | Rich | | Normal | | Rich | | Fuel cut* | Normal | No injection | * Engine speed: Above 1,500 rpm (ATX) / 1,200 rpm (MTX) | |
| FUEL PUMP RELAY | | ON | | | | | | | | OFF | | |
| IGNITION CONTROL MODULE | | Fixed at BTDC 7° | Advanced: depends on engine condition | | | | | | OFF | | | |
| SOLENOID VALVE | PURGE CONTROL | OFF | | ON (Purge) | | OFF | | | | | | |
| | EGR | VENT | OFF | | ON | | OFF | | System operates: Amount of EGR changes | | | |
| | | VACUUM | OFF | | ON | | OFF | | | | | |
| | PRC | OFF (Vacuum to pressure regulator) | | | | | | ON* | OFF | * During hot start only | | |
| | VRIS No. 1 | OFF | | | ON* | | | OFF | * Engine speed: 1,900-2,600 rpm 3,900-6,300 rpm | | | |
| VRIS No. 2 | OFF | | | ON* | | | OFF | * Engine speed: 1,900-2,600 rpm 4,700-6,300 rpm | | | | |
| BAC VALVE | IDLE AIR CONTROL VALVE | ON (Closed loop duty) | | ON (Fixed duty) | | ON (Closed loop duty) | | OFF | | | | |
| | AIR VALVE | OPEN | | | CLOSED | | | | | — | | |
| A/C RELAY | | OFF (A/C cut) | ON | | | OFF (A/C cut) | ON | | OFF | A/C operating | | |

RELATIONSHIP CHART

| INPUT DEVICE | | OUTPUT DEVICE | | | | | | | | | | | | | |
|---|---------------------------------|---------------|-----------------|-------------------------|---|------------------------------------|----------------------------|--|---------------|---------------------------------------|-------------|----------------------------|---|--|---------------------------------------|
| | | FUEL INJECTOR | FUEL PUMP RELAY | IGNITION CONTROL MODULE | A/C RELAY (A/C CUT-OFF) AND CONDENSER FAN LOW RELAY | BAC VALVE (IDLE AIR CONTROL VALVE) | ELECTRIC COOLANT FAN RELAY | CONDENSER FAN HIGH RELAY NO.1 AND NO.2 | PURGE CONTROL | VRIS (NO.1 AND NO.2) SOLENOID CONTROL | EGR CONTROL | PRESSURE REGULATOR CONTROL | TCM (TORQUE REDUCTION EXECUTED SIGNAL/ ENGINE COOLANT TEMPERATURE SIGNAL) | SELF-DIAGNOSIS CHECKER (DIAGNOSTIC TROUBLE CODE) | SELF-DIAGNOSIS CHECKER (MONITOR LAMP) |
| CAMSHAFT POSITION SENSOR | SGT SIGNAL | ○ | ○ | ○ | | | | | | | | | | ○ | |
| | SGC SIGNAL | | | ○ | | | | | | | | | | ○ | |
| CRANKSHAFT POSITION SENSOR (NE SIGNAL) | | ○ | ○ | ○ | | ○ | | | ○ | ○ | ○ | ○ | | ○ | |
| THROTTLE POSITION SENSOR | CLOSED THROTTLE POSITION SWITCH | ○ | | ○ | | ○ | ○ | | ○ | | ○ | | | | ○ |
| | THROTTLE POSITION SENSOR | ○ | | ○ | ○ | ○ | | | | ○ | ○ | ○ | ○ | ○ | |
| ENGINE COOLANT TEMPERATURE SENSOR | | ○ | | ○ | ○ | ○ | ○ | ○ | ○ | | ○ | ○ | ○ | ○ | |
| INTAKE AIR TEMPERATURE SENSOR | | ○ | | | | ○ | | | ○ | | | ○ | | ○ | |
| HEATED OXYGEN SENSOR | | ○ | | | | | | | ○ | | | | | ○ | ○ |
| KNOCK SENSOR | | | | ○ | | | | | | | | ○ | | ○ | |
| A/C AMPLIFIER | | | | | ○ | ○ | ○ | | | | | | | | ○ |
| P/S PRESSURE SWITCH | | | | | ○ | ○ | | | | | | | | | |
| IGNITION SWITCH (START SIGNAL) | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | ○ | | | |
| BRAKE SWITCH | | ○ | | | | | | | | ○ | | | | | ○ |
| E/L* | | | | | | ○ | | | | | | | | | ○ |
| NEUTRAL / CLUTCH SWITCH | | ○ | | ○ | ○ | ○ | | | ○ | | | ○ | | | ○ |
| DATA LINK CONNECTOR (TERMINAL TEN) | | | | ○ | | ○ | ○ | | | | | ○ | | ○ | ○ |
| EGR VALVE POSITION SENSOR | | | | ○ | | | | | | | ○ | | | ○ | |
| BAROMETRIC PRESSURE SENSOR | | ○ | | | | ○ | | | ○ | | | | | ○ | |
| VEHICLE SPEED SENSOR | | | | | | ○ | | | | ○ | | | | | |
| VOLUME AIR FLOW SENSOR | | ○ | | ○ | | | | | ○ | | ○ | | ○ | ○ | |
| PARK / NEUTRAL POSITION SIGNAL (TCM) | | ○ | | ○ | ○ | | | | ○ | | | ○ | | | ○ |
| TORQUE REDUCTION REQUEST SIGNAL 1,2 (TCM) | | ○ | | ○ | | | | | | | | ○ | | | |


* E/L: Fan switch ON at 2nd position or higher, headlights ON, fog lights ON, or rear window defroster switch ON.

USING THIS SECTION


Introduction

Most of the fuel and emission control systems are electrically controlled, often making it difficult to diagnose problems, especially intermittent problems. Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a drivability complaint. The customer is often a good source of information on such problems, especially the intermittent ones. Through a talk with the customer, you will usually find out what the symptoms are and under what conditions they occur.


Work flow



Diagnostic index



Troubleshooting chart

| TROUBLESHOOTING GUIDE | | F2 | |
|---|--|---|---|
| 6 CHANKS NORMALLY BUT HARD TO START — WHEN ENGINE COLD | | | |
| DESCRIPTION | | <ul style="list-style-type: none"> • Engine cranks at normal speed but requires excessive cranking time before starting • Battery in normal condition • Restarts OK after warm-up • Engine runs normally at idle (If idle condition is not OK, refer to "Rough idle" [Nos. 6-12]) | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ⊙ Air/Fuel mixture too rich <ul style="list-style-type: none"> • Volume airflow sensor stuck • Air cleaner housing element clogged • Idle-speed control malfunction | | <ul style="list-style-type: none"> ⊙ Air/Fuel mixture too lean <ul style="list-style-type: none"> • Fuel injection control malfunction (connection for coolant temperature) ⊙ Poor atomization | |
| STEP | INSPECTION | ACTION | |
| 1 | Is "00" displayed on Self-Diagnosis Checker ignition switch ON? SELF-DIAGNOSIS CHECKER  | Yes No | Go to next step Diagnostic trouble Code No. displayed Check for cause (Refer to specified check sequence) |
| 2 | Are PCM/E terminal voltages OK? 1C-Starter signal 17-Engine coolant temperature sensor or ground | Yes No | Go to next step |

DESCRIPTION:

Further describes the system. Confirm that the chart addresses the actual symptom before beginning troubleshooting.

TROUBLESHOOTING HINTS:

This describes the possible point of malfunction.

STEP:

This shows the order of troubleshooting. Proceed with troubleshooting as indicated.

INSPECTION:


This describes an inspection to quickly determine the malfunction of parts. If a detailed procedure is necessary to perform the INSPECTION, refer to the page specified by the "page" mark.




ACTION:

This recommends the appropriate action to take as a result (Yes/No) of the INSPECTION. How to perform the ACTION is described on the reference page specified by the "page" mark.

DIAGNOSTIC INDEX

| NO. | TROUBLESHOOTING ITEM | DESCRIPTION | PAGE |
|-----|---|--|-----------|
| 1 | Will not crank or cranks slowly | Refer to Engine Electrical System | section G |
| 2 | Crank normally but will not start | (No combustion) | F2-21 |
| 3 | | (Partial combustion) - When engine cold | F2-23 |
| 4 | | (Partial combustion) - After warm-up | F2-25 |
| 5 | Crank normally but hard to start | Always | F2-27 |
| 6 | | When engine cold | F2-29 |
| 7 | | After warm-up | F2-31 |
| 8 | Rough idle/ Low idle speed/ Engine stalls at idle | Always | F2-33 |
| 9 | | Before warm-up | F2-35 |
| 10 | | After warm-up | F2-37 |
| 11 | | When A/C, P/S, or E/L ON | F2-39 |
| 12 | Rough idle/Engine stalls just after starting | Engine stalls or vibrates excessively just after starting (acceleration from idle) | F2-40 |
| 13 | High idle speed after warm-up | Idle speed excessively high after warm-up | F2-41 |
| 14 | Idle moves up and down/idle hunting | Engine speeds up and down at idle | F2-43 |
| 15 | Engine stalls on deceleration | Engine unexpectedly stops running during or after deceleration | F2-45 |
| 16 | Engine stalls suddenly (Intermittent) | Engine intermittently stops running | F2-47 |
| 17 | Hesitates/Stumbles on acceleration | Flat spot occurs just after accelerator is depressed, or mild jerking occurs during acceleration | F2-48 |
| 18 | Surges while cruising | Unexpected change in engine speed that is usually repetitive | F2-50 |
| 19 | Lack of power | Engine performance poor under load when throttle valve is fully open Maximum speed reduced | F2-52 |
| 20 | Poor acceleration | Engine performance poor during acceleration | F2-56 |
| 21 | Runs rough during deceleration/Backfire | Engine runs rough during deceleration, and abnormal combustion occurs in exhaust system | F2-60 |
| 22 | Knocking | Abnormal combustion accompanied by audible "pinging" noise | F2-62 |
| 23 | Fuel odor | Gasoline odor in cabin | F2-64 |
| 24 | Exhaust sulfur odor | Exhaust gas has unusual odor | F2-65 |
| 25 | High oil consumption | Oil consumption excessive | F2-65 |
| 26 | Poor fuel economy | Fuel economy unsatisfactory | F2-66 |
| 27 | A/C does not work | Blower fan operates, but magnetic clutch does not | F2-68 |

Description of Drivability**STUMBLE** : Mild jerking during acceleration.**HESITATION** : Flat spot occurring just after the accelerator pedal is depressed.**SURGE** : Continuous soft jerking during cruise.



Fuel Pressure and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".

Fuel Line Safety Procedures

A. Release the fuel pressure before disconnecting a fuel line.

1. Start the engine.
2. Remove the fuel pump relay.
3. After the engine stalls, turn the ignition switch to OFF.
4. Install the fuel pump relay.

B. Avoid leakage.


1. When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
2. Plug the hose after removal.




C. Install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose.

Pinching Hose



When pinching an air hose or a fuel hose with pliers, wrap the hose with a rag to prevent damage.




B+: Battery positive voltage




| STEP | INSPECTION | ACTION | |
|------|--|--|---|
| 4 | Does B+ exist at fuel pump connector terminal with ignition switch ON?  | Yes | Check continuity of fuel pump page F2-110 |
| | | No | Check fuel pump relay page F2-113 |
| 5 | Is there fuel injector operating sound while engine is being cranked? | Yes | Go to step 7 |
| | | No | Go to next step |
| 6 | Does B+ exist at fuel injector connector with ignition switch ON? | Yes | Check ECM fuel injector terminals 3U, 3V, 3W, 3X, 3Y and 3Z voltages page F2-141 |
| | | No | Check for open circuit in wiring between main relay (FUEL INJ relay) and fuel injector page F2-8 |
| 7 | Connect data link connector terminals F/P and GND by using jumper wire; Is fuel line pressure correct with the ignition switch ON? page F2-107 Fuel line pressure: 260–310 kPa {2.6–3.2 kgf/cm ² , 37–45 psi} | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator ⇨ If pressure gradually increase, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure page F2-110 |
| | | High pressure Is fuel return hose clogged or restricted? ⇨ If it is not, replace pressure regulator page F2-115 ⇨ If it is, repair or replace it | |
| 8 | Is engine compression correct? Engine compression: 981 kPa {10.0 kgf/cm ² , 142 psi}-300 rpm | Yes | Go to next step |
| | | No | Check engine condition <ul style="list-style-type: none"> • Worn piston, piston rings, or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve stuck in guide |
| 9 | Are all spark plugs OK? section G WEAR AND CARBON BUILDUP PLUG GAP: 1.0–1.1mm (0.040–0.043 in) | Yes | Go to next step |
| | | No | Clean or replace spark plug section G |
| 10 | Try a known good ECM; and check if condition improves page F2-141 | | |



| | | | |
|---|--|----------------------|---|
| 3 | CRANKS NORMALLY BUT WILL NOT START (PARTIAL COMBUSTION) — WHEN ENGINE COLD | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine cranks at normal speed but shows only partial combustion and will not continue to run • Battery in normal condition • Fuel in tank | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Air/fuel mixture too rich</p> <ul style="list-style-type: none"> • Air cleaner element clogged • Volume air flow sensor stuck <p>② Air/fuel mixture too lean</p> <ul style="list-style-type: none"> • Fuel injection control malfunction (correction for coolant temperature) • Low fuel line pressure • Air leakage of intake-air system <p>③ Low engine compression</p> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>Is "00" displayed on SST with Ignition switch ON?</p> <p style="text-align: right;">☞page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  | <p>Yes</p> <p>No</p> | <p>"00" displayed</p> <p>Go to next step</p> <p>Diagnostic trouble Code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">☞page F2-74</p> |
| 2 | <p>Is strong blue spark visible at each disconnected high-tension lead?</p> <p style="text-align: right;">☞page F2-113</p>  | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check distributor cap and rotor</p> <p style="text-align: right;">☞section G</p> |
| 3 | <p>Connect data link connector terminals F/P and GND by using jumper wire; is fuel line pressure correct with ignition switch ON?</p> <p style="text-align: right;">☞page F2-107</p> <p>Fuel line pressure: 260-310 kPa (2.6-3.2 kgf/cm², 37-45 psi)</p> <p>PRESSURE GAUGE</p>  | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Low pressure</p> <p>Check fuel line pressure while pinching fuel return hose</p> <ul style="list-style-type: none"> ⇨ If pressure quickly increases, check pressure regulator ⇨ If pressure gradually increases, check for clogging between fuel pump and pressure regulator <p>If not clogged, check fuel pump maximum pressure</p> <p style="text-align: right;">☞page F2-113</p> <p style="text-align: right;">☞page F2-110</p> <p>High pressure</p> <p>Is fuel return hose clogged or restricted?</p> <ul style="list-style-type: none"> ⇨ If it is not, replace pressure regulator ⇨ If it is, repair or replace it <p style="text-align: right;">☞page F2-115</p> |




B+: Battery positive voltage




| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 4 | Are ECM terminal voltages OK? ☞page F2-141 • 1C (Start signal) | Yes | Go to next step |
| | | No | Check for cause ☞page F2-141 |
| 5 | Is there air leakage of intake-air system components? | Yes | Repair or replace |
| | | No | Go to next step |
| 6 | Does engine start when engine coolant temperature sensor is disconnected? | Yes | Check engine coolant temperature sensor ☞page F2-152 |
| | | No | Go to next step |
| 7 | Does volume air flow sensor move smoothly from fully closed to fully open? MEASURING CORE ☞page F2-150  | Yes | Go to next step |
| | | No | Repair or replace volume air flow sensor |
| 8 | Is engine compression correct? Engine compression (Minimum): 981 kPa {10.0 kgf/cm ² , 142 psi}·300 rpm | Yes | Go to next step |
| | | No | Check engine condition <ul style="list-style-type: none"> • Worn piston, piston rings, or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve stuck in guide |
| 9 | Are spark plugs OK? ☞section G WEAR AND CARBON BUILDUP PLUG GAP 1.0-1.1 mm {0.040-0.043 in}  | Yes | Go to next step |
| | | No | Clean or replace spark plug ☞section G |
| 10 | Try a known good ECM: and check if condition improves ☞page F2-141 | | |


| | | |
|--|---|--|
| 4 | CRANKS NORMALLY BUT WILL NOT START (PARTIAL COMBUSTION) — AFTER WARM-UP | |
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine cranks at normal speed and shows partial combustion but will not start after running and being hot soaked • Battery is in normal condition • Engine starts normally when cold | |
| [TROUBLESHOOTING HINTS] | | |
| ① Air/fuel mixture too rich <ul style="list-style-type: none"> • Insufficient fuel injection control (correction for coolant temperature) • Fuel injector fuel leakage | ② Vapor lock <ul style="list-style-type: none"> • Fuel pressure is not held in fuel line after engine stopped • Pressure regulator control system malfunction | |
| STEP | INSPECTION | ACTION |
| 1 | Warm up engine to normal operating temperature and stop it Connect data link connector terminals F/P and GND by using jumper wire for 3 minutes with ignition switch ON. Does engine start?  <p style="text-align: center;">GND F/P</p> | Yes Change to another brand of fuel |
| | | No Go to next step |
| 2 | Remove vacuum hose from pressure regulator and plug it; Does engine start?  | Yes Check pressure regulator control system ↗ page F2-120 |
| | | No Go to next step |
| 3 | Connect data link connector terminals F/P and GND with jumper wire; is fuel line pressure correct by using ignition switch ON? ↗ page F2-107 Fuel line pressure: 260–310 kPa {2.6–3.2 kgf/cm ² , 37–45 psi} INSTALL CLAMPS  <p style="text-align: center;">PRESSURE GAUGE GND F/P</p> | Yes Go to next step |
| | | No Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator ↗ page F2-113 ⇨ If pressure gradually increases, check fuel line and filter for clogging If hose is not clogged, check fuel pump maximum pressure ↗ page F2-110 |
| | | High pressure Is fuel return hose clogged or restricted? ↗ page F2-115 ⇨ If it is not, replace pressure regulator ⇨ If it is, repair or replace it |
| 4 | In the same condition as step 2, is fuel line pressure held after ignition switch is turned OFF? ↗ page F2-107 Fuel line pressure: More than 150 kPa {1.5 kgf/cm², 21 psi} for 5 min. | Yes Go to step 6 |
| | | No Go to next step |




| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 5 | Pinch fuel delivery hose: is fuel line pressure held after ignition switch is turned OFF? ↳page F2-114 Fuel line pressure: More than 150 kPa (1.5 kg/cm ² , 21 psi) for 5 min.  | Yes | Replace pressure regulator ↳page F2-115 |
| | | No | Check fuel pump hold pressure ↳page F2-111 ↳ If OK, check fuel injector for fuel leakage ↳page F2-116 ↳ If not OK, replace fuel pump ↳page F2-112 |
| 6 | Disconnect engine coolant temperature sensor connector; does engine start?  | Yes | Check engine coolant temperature sensor ↳page F2-152 ↳ If OK, check connectors of engine coolant temperature sensor and ECM 2E terminal ↳page F2-141 ↳ If not OK, replace engine coolant temperature sensor |
| | | No | Go to next step |
| 7 | Is "00" displayed on SST with ignition switch ON? ↳page F2-73 SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble Code No. displayed Check for cause (Refer to specified check sequence) ↳page F2-74 |
| 8 | Are ECM terminal voltages OK? 1B-Main relay 2B-Volume air flow sensor 2E-Engine coolant temperature sensor ↳page F2-141 | Yes | Go to next step |
| | | No | Check for cause ↳page F2-141 |
| 9 | Try a known good ECM; does condition improve? ↳page F2-141 | Yes | Replace ECM ↳page F2-141 |
| | | No | Change to another brand of fuel |


| 5 | CRANKS NORMALLY BUT HARD TO START — ALWAYS | | |
|--|--|-----|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine cranks at normal speed but requires excessive cranking time before starting • Battery is in normal condition • Engine runs normally at idle (If idle condition not OK, refer to "Rough Idle" [No. 8-1]) | | |
| [TROUBLESHOOTING HINTS] <ul style="list-style-type: none"> ① Air/Fuel mixture too lean <ul style="list-style-type: none"> • Fuel injection control malfunction (correct for coolant temperature) • Low fuel line pressure • Air leakage ② Air/Fuel mixture too rich <ul style="list-style-type: none"> • Air cleaner housing element clogged • Volume air flow sensor stuck ③ Poor ignition spark | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "00" displayed on SST with ignition switch ON? ↳page F2-73 SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble Code No. displayed Check for cause (Refer to specified check sequence) ↳page F2-74 |
| 2 | Is intake manifold vacuum at idle? Vacuum: More than 450 mmHg {17.7 inHg} | Yes | Go to next step |
| | | No | Check for air leakage of intake-air system components |
| 3 | Is air cleaner element clean? ↳page F2-70 | Yes | Go to next step |
| | | No | Replace air cleaner element |
| 4 | Does engine start easily when throttle valve is quarterly open? | Yes | Check throttle valve for carbon deposit then go to step 6 |
| | | No | Go to next step |
| 5 | Is fuel line pressure at idle correct? ↳page F2-113 Fuel line pressure: 260-310 kPa {2.6-3.2 kgf/cm², 37-45 psi} (Vacuum hose to pressure regulator disconnected) INSTALL CLAMPS PRESSURE GAUGE  | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator ↳page F2-113 ⇨ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure ↳page F2-110 |



| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 6 | Disconnect idle air control valve connector at idle: Does engine speed increase?  ↗page F2-99 IDLE AIR CONTROL VALVE | Yes | Go to next step |
| | | No | Replace idle air control valve ↗page F2-95 |
| 7 | Are ECM terminal voltages OK? 1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground ↗page F2-141 | Yes | Go to next step |
| | | No | Check for cause ↗page F2-141 |
| 8 | Connect data link connector terminals F/P and GND by using jumper wire; does engine start normally?  GND F/P | Yes | Check fuel pump relay ↗page F2-113 ⇨ If OK, repair or replace wire harness ⇨ If not OK, replace relay |
| | | No | Go to next step |
| 9 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ↗page F2-70 Ignition timing (BTDC): 9-11° (10 ± 1°)  TEST SWITCH | Yes | Go to next step |
| | | No | Adjust ignition timing ↗page F2-70 |
| 10 | Is engine compression correct? Engine compression (Minimum): 981 kPa (10.0 kgf/cm ² , 142 psi)-300 rpm | Yes | Go to next step |
| | | No | Check engine condition <ul style="list-style-type: none"> • Worn piston, piston rings, or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve sticking in guide |
| 11 | Try a known good ECM and check if condition improves ↗page F2-141 | | |




| 6 | CRANKS NORMALLY BUT HARD TO START — WHEN ENGINE COLD | | |
|---|---|----------------------|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine cranks at normal speed but requires excessive cranking time before starting • Battery in normal condition • Restarts OK after warm-up • Engine runs normally at idle (If idle condition is not OK, refer to "Rough idle" [Nos. 8–12]) | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Air/Fuel mixture too rich</p> <ul style="list-style-type: none"> • Volume air flow sensor stuck • Air cleaner element clogged • Idle air control malfunction <p>② Air/Fuel mixture too lean</p> <ul style="list-style-type: none"> • Fuel injection control malfunction (correction for coolant temperature) <p>③ Poor atomization</p> | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Is "00" displayed on Self-Diagnosis Checker ignition switch ON?</p> <p>SELF-DIAGNOSIS CHECKER  49 B019 9A0</p> <p>SYSTEM SELECTOR</p> <p>SELECT SW: A 49 H018 9A1</p> <p>MONITOR LIGHT</p> <p><i>page F2-73</i></p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) <i>page F2-74</i></p> |
| 2 | <p>Are ECM terminal voltages OK?</p> <p>1C-Starter signal</p> <p>2E-Engine coolant temperature sensor</p> <p>3D-Sensor ground <i>page F2-141</i></p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check for cause <i>page F2-141</i></p> |
| 3 | <p>Does engine start easily when throttle valve is quarterly open?</p>  | <p>Yes</p> <p>No</p> | <p>Is idle air control valve OK? <i>page F2-99</i></p> <p>⇨ If it is, check air valve <i>page F2-99</i></p> <p>⇨ If it is not, replace idle air control valve <i>page F2-95</i></p> <p>Go to next step</p> |
| 4 | <p>Is intake manifold vacuum correct at idle?</p> <p>Vacuum: More than 450 mmHg {17.7 inHg}</p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Check for air leakage of intake-air system components</p> |
| 5 | <p>Is air cleaner element clean? <i>page F2-70</i></p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Replace air cleaner element</p> |
| 6 | <p>Disconnect idle air control valve connector at idle. Does engine speed increase? <i>page F2-99</i></p>  <p>IDLE AIR CONTROL VALVE</p> | <p>Yes</p> <p>No</p> | <p>Go to next step</p> <p>Replace idle air control valve <i>page F2-99</i></p> |



| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 7 | Connect data link connector terminals F/P and GND by using jumper wire; is fuel line pressure correct with ignition switch ON? <small>page F2-107</small> Fuel line pressure: 260-310 kPa (2.6-3.2 kgf/cm ² , 37-45 psi) INSTALL CLAMPS PRESSURE GAUGE  | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator <small>page F2-113</small> ⇨ If pressure gradually increases, check fuel line for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure <small>page F2-110</small> |
| | | | High pressure Is fuel return hose clogged or restricted? ⇨ If it is not, replace pressure regulator <small>page F2-115</small> ⇨ If it is, repair or replace it |
| 8 | Try a known good ECM; does condition improve? <small>page F2-141</small> | Yes | Replace ECM <small>page F2-141</small> |
| | | No | Change to another brand of fuel |



| | | | |
|---|--|---------------|--|
| 7 | CRANKS NORMALLY BUT HARD TO START — AFTER WARM-UP | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine cranks at normal speed but requires excessive cranking time before starting after running and being hot soaked • Battery in normal condition • Engine starts normally when cold • Engine runs normally at idle (If idle condition is not OK, refer to "Rough Idle" (No. 8-12)) | | |
| <p>[TROUBLESHOOTING HINTS]</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>① Air/fuel mixture too rich</p> <ul style="list-style-type: none"> • Fuel injection control malfunction • Fuel injector fuel leakage </div> <div style="width: 45%;"> <p>② Vapor lock</p> <ul style="list-style-type: none"> • Fuel pressure not held in fuel line after engine stopped • Pressure regulator control system malfunction </div> </div> | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">↗page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  | Yes | <p>"00" displayed</p> <p>Go to next step</p> |
| | | No | <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">↗page F2-74</p> |
| 2 | <p>Remove vacuum hose from pressure regulator and plug it.</p> <p>Does engine start normally?</p>  | Yes | <p>Check pressure regulator control system</p> <p style="text-align: right;">↗page F2-113</p> |
| | | No | <p>Go to next step</p> |
| 3 | <p>Are ECM terminal voltages OK?</p> <p>1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground</p> <p style="text-align: right;">↗page F2-141</p> | Yes | <p>Go to next step</p> |
| | | No | <p>Check for cause</p> <p style="text-align: right;">↗page F2-141</p> |
| 4 | <p>Run engine at idle; does fuel line pressure held after ignition switch is turned OFF?</p> <p>Fuel line pressure: More than 150 kPa {1.5 kgf/cm², 21 psi} for 5 min.</p> <p style="text-align: center;">INSTALL CLAMPS</p> <p>PRESSURE GAUGE</p>  | Yes | <p>Go to next step</p> |
| | | No | <p>Plug outlet of pressure regulator outlet; is fuel line pressure held after ignition switch is turned OFF?</p> <p style="text-align: right;">↗page F2-108</p> <p>⇨ If it does, replace pressure regulator ↗page F2-115</p> <p>⇨ If it does not, check fuel pump hold pressure ↗page F2-111</p> <p>If fuel pump is OK, check fuel injectors for fuel leakage ↗page F2-116</p> |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 5 | <p>Warm up engine to normal operating temperature and stop it Connect data link connector terminals F/P and GND by using jumper wire for 3 minutes with ignition switch ON; does engine start easily?</p>  | Yes | Change to another brand of fuel |
| | | No | Go to next step |
| 6 | <p>Try a known good ECM; does condition improve?</p> <p style="text-align: right;">↖ page F2-141</p> | Yes | Replace ECM ↖ page F2-141 |
| | | No | Change to another brand of fuel |




| 8 | ROUGH IDLE/ENGINE STALLS AT IDLE — ALWAYS | | |
|--|---|--------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine starts normally but stalls or vibrates excessively at idle in every condition | | |
| <p>[TROUBLESHOOTING HINTS]</p> <ul style="list-style-type: none"> ① Air/fuel mixture too lean <ul style="list-style-type: none"> • Air leakage • Fuel injection control malfunction • Low fuel line pressure ② One or more fuel injectors clogged or not operating ③ Low intake air amount ④ Incorrect idle speed <ul style="list-style-type: none"> • Idle speed misadjustment • Idel air control malfunction ⑤ One or more spark plugs not firing ⑥ Low engine compression ⑦ Volume air flow sensor stuck | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">↗page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  <p>MONITOR LIGHT</p> | Yes | <p>"00" displayed</p> <p>Go to next step</p> |
| | | No | <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence) ↗page F2-74</p> |
| 2 | <p>Are ECM terminal voltage OK?</p> <p>1C-Starter signal</p> <p>2E-Engine coolant temperature sensor</p> <p>3D-Sensor ground</p> <p style="text-align: right;">↗page F2-141</p> | Yes | Go to next step |
| | | No | Check for cause ↗page F2-141 |
| 3 | <p>Disconnect high-tension lead at idle; does engine speed decrease equally at each cylinder?</p> | Yes | Go to step 8 |
| | | No | Go to next step |
| 4 | <p>Is there fuel injector operating sound at idle?</p> | Yes | Go to step 6 |
| | | No | Go to next step |
| 5 | <p>Does battery positive voltage exist at fuel injector connector terminal A wire?</p> | Yes | <p>Is fuel injector resistance OK? ↗page F2-117</p> <p>Resistance: 12-16 Ω [20°C (68°F)]</p> <p>↔ If it is, check wiring between ECM and fuel injector</p> <p>↔ If it is not, replace fuel injector ↗page F2-115</p> |
| | | No | Check wiring between ECM and fuel injector |
| 6 | <p>Is strong blue spark visible at disconnected high-tension lead?</p> <p style="text-align: right;">↗section G</p>  | Yes | Go to next step |
| | | No | <p>Check high-tension lead ↗section G</p> <p>↔ If OK, check distributor cap and rotor</p> <p>↔ If not OK, replace high-tension lead</p> |

| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 7 | Are spark plugs OK? WEAR AND CARBON BUILDUP PLUG GAP 1.0–1.1mm {0.040–0.043 in}  | Yes | Is engine compression correct? ↔section B2 ⇨ If OK, replace fuel injector ↔page F2–115 ⇨ If not OK, check for cause ↔section B2 |
| | | No | Clean or replace spark plug ↔section G |
| 8 | Is fuel line pressure correct at idle? ↔page F2–113 Fuel line pressure: 260–310 kPa (2.6–3.2 kgf/cm², 37–48 psi) (Vacuum hose to pressure regulator disconnected)  | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator ↔page F2–113 ⇨ If pressure gradually increases, check for clogging between fuel pump and pressure regulator ⇨ If hose is not clogged, check fuel pump maximum pressure ↔page F2–110 |
| 9 | Does volume air flow sensor move smoothly from closed throttle position to wide open throttle? ↔page F2–149 MEASURING CORE  | Yes | Go to next step |
| | | No | Repair or replace volume air flow sensor |
| 10 | Is there air leakage at intake-air system components? | Yes | Repair or replace |
| | | No | Go to next step |
| 11 | Is engine compression correct? ↔section B2 Engine compression (Minimum): 981 kPa (10.0 kgf/cm², 142 psi)-300 rpm | Yes | Go to next step |
| | | No | Check for cause ↔section B2 |
| 12 | Connect System Selector to data link connector and set Test Switch to “SELF TEST”; is ignition timing correct at idle after warm-up? ↔page F2–71 Ignition Timing (BTDC): 9–11° {10 ± 1°} | Yes | Try a known good ECM and check if condition improves ↔page F2–141 |
| | | No | Adjust ignition timing ↔page F2–71 |




| | | | |
|---|--|-----|--|
| 9 | ROUGH IDLE/ENGINE STALLS AT IDLE — BEFORE WARM-UP | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine speed low or engine stalls or vibrates excessively at idle during warm-up | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Low intake air amount</p> <ul style="list-style-type: none"> • Volume air flow sensor stuck • Air cleaner element clogged • Air valve <p>② Low fuel injection control</p> <ul style="list-style-type: none"> • Fuel injection control malfunction (Correction for coolant temperature) <p>③ Poor atomization</p> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">↖ page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  | Yes | <p>"00" displayed</p> <p>Go to next step</p> |
| | | No | <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">↖ page F2-74</p> |
| 2 | <p>Is intake manifold vacuum correct at idle after warm-up?</p> <p>Vacuum: More than 450 mmHg (17.7 inHg)</p> | Yes | Go to next step |
| | | No | Check for air leakage of intake-air system components |
| 3 | <p>Is air cleaner element clean?</p> <p style="text-align: right;">↖ page F2-70</p> | Yes | Go to next step |
| | | No | Replace air cleaner housing element |
| 4 | <p>Are ECM terminal voltages OK?</p> <p>1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground</p> <p style="text-align: right;">↖ page F2-141</p> | Yes | Go to next step |
| | | No | Check for cause ↖ page F2-141 |
| 5 | <p>Disconnect idle air control valve connector</p> <p>Does engine speed increase after warm-up?</p>  | Yes | Go to next step |
| | | No | Replace IAC valve ↖ page F2-95 |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 6 | <p>Is engine coolant temperature sensor resistance correct?</p> <p>RESISTANCE ☞ page F2-152</p>  <p>COOLANT TEMPERATURE °C {°F}</p> | Yes | Go to next step |
| | | No | Replace engine coolant temperature sensor |
| 7 | <p>Connect System Selector to data link connector and set Test Switch to "SELF TEST" when engine is cold.</p> <p>Does engine speed decrease as engine warms up?</p> | Yes | Go to next step |
| | | No | Check air valve ☞ page F2-99 |
| 8 | <p>Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up?</p> <p>☞ page F2-70</p> <p>Ignition timing (BTDC): 9-11° (10 ± 1°)</p>  <p>TEST SWITCH</p> | Yes | Go to next step |
| | | No | Adjust ignition timing ☞ page F2-70 |
| 9 | <p>Try a known good ECM; does condition improve?</p> <p>☞ page F2-141</p> | Yes | Replace ECM ☞ page F2-141 |
| | | No | Change to another brand of fuel |




| 10 | ROUGH IDLE/ENGINE STALLS AT IDLE — AFTER WARM-UP | | |
|---|---|---|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine runs normally at idle during warm-up but stalls or vibrates excessively after warm-up | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> ① Idle-speed control system malfunction ② Air/fuel mixture too lean <ul style="list-style-type: none"> • Air leakage • Low fuel line pressure | | <ul style="list-style-type: none"> ③ Air/fuel mixture too rich <ul style="list-style-type: none"> • Fuel injection control malfunction (Correction for coolant temperature) ④ Poor ignition ⑤ Low engine compression | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">☞ page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  <p>SYSTEM SELECTOR 49 B019 9A0</p> <p>SELECT SW: A 49 H018 9A1</p> <p>MONITOR LIGHT</p> | Yes | <p>"00" displayed</p> <p>Go to next step</p> |
| | | No | <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">☞ page F2-74</p> |
| 2 | <p>Are ECM terminal voltages OK?</p> <p>1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground</p> <p style="text-align: right;">☞ page F2-141</p> | Yes | Go to next step |
| | | No | Check for cause ☞ page F2-141 |
| 3 | <p>Disconnect high-tension lead at idle; does engine speed decrease equally at all cylinders?</p> | Yes | Go to next step |
| | | No | Go to step 9 |
| 4 | <p>Is intake manifold vacuum at idle correct?</p> <p>Vacuum: More than 450 mmHg {17.7 inHg}</p> | Yes | Go to next step |
| | | No | Check for air leakage of intake-air system components ☞ page F2-95 |
| 5 | <p>Is air cleaner element clean?</p> <p style="text-align: right;">☞ page F2-70</p> | Yes | Go to next step |
| | | No | Replace air cleaner element |
| 6 | <p>Disconnect idle air control valve connector at idle; does engine speed increase?</p>  <p>IDLE AIR CONTROL VALVE</p> | Yes | Go to next step |
| | | No | Replace idle air control valve ☞ page F2-95 |

| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 7 | Is fuel line pressure correct at idle? <small>↗ page F2-113</small> Fuel line pressure: 260–310 kPa (2.6–3.2 kgf/cm ² , 37–45 psi) (Vacuum hose to pressure regulator disconnected) PRESSURE GAUGE INSTALL CLAMPS  | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator <small>↗ page F2-113</small> ⇨ If pressure gradually increases, check for clogging between fuel pump and pressure regulator ⇨ If hose is not clogged, check fuel pump maximum pressure <small>↗ page F2-110</small> |
| 8 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? <small>↗ page F2-70</small> Ignition timing (BTDC): 9–11° (10 ± 1°) | Yes | Go to next step |
| | | No | Adjust ignition timing <small>↗ page F2-70</small> |
| 9 | Disconnect engine coolant temperature sensor connector; does engine condition improve? | Yes | Replace engine coolant temperature sensor |
| | | No | Try a known good ECM; and check if condition improves <small>↗ page F2-141</small> |
| 10 | Is there fuel injector operating sound at idle?  | Yes | Go to next step |
| | | No | Is fuel injector resistance OK? <small>↗ page F2-117</small> Resistance: 12–16 Ω [20°C (68°F)] ⇨ If it is, check wiring between ECM and fuel injector ⇨ If it is not, replace fuel injector <small>↗ page F2-115</small> |
| 11 | Is engine compression correct? <small>↗ section B2</small> Engine compression (Minimum): 981 kPa (10.0 kgf/cm ² , 142 psi)-300 rpm | Yes | Go to next step |
| | | No | Check engine <small>↗ section B2</small> |
| 12 | Is strong blue spark visible at disconnected high-tension lead? <small>↗ section G</small>  | Yes | Go to next step |
| | | No | Check high-tension lead <small>↗ section G</small> ⇨ If OK, check distributor cap and rotor ⇨ If not OK, replace high-tension lead |
| 13 | Are spark plugs OK? <small>↗ section G</small> | Yes | Try a known good ECM; and check if condition improves <small>↗ page F2-141</small> |
| | | No | Repair or replace spark plug <small>↗ section G</small> |


B+: Battery positive voltage




| | | | |
|---------------------------------------|---|---|--|
| 11 | ROUGH IDLE/ENGINE STALLS AT IDLE — WHEN A/C, P/S, OR E/L ON | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Engine stalls or vibrates excessively at idle when A/C, P/S, or E/L ON • A/C, P/S, headlights, blower fan, and electric coolant fan operate normally • Idle condition is normal when A/C, P/S, and E/L are OFF | | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Idle air control system malfunction | | | |
| STEP | INSPECTION | ACTION | |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">☞ page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  <p style="text-align: right;">SYSTEM SELECTOR 49 B019 9A0</p> <p style="text-align: center;">SELECT SW: A 49 H018 9A1</p> <p>MONITOR LIGHT</p> | <p>Yes</p> <p>00" displayed</p> <p>Go to next step</p> | |
| | | <p>No</p> <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">☞ page F2-74</p> | |
| 2 | <p>Does SST Monitor Light show that switches operate correctly with ignition switch ON?</p> <p style="text-align: right;">☞ page F2-92</p> <p>SELF-DIAGNOSIS CHECKER</p>  <p style="text-align: right;">SYSTEM SELECTOR 49 B019 9A0</p> <p style="text-align: center;">SELECT SW: A 49 H018 9A1</p> <p>MONITOR LIGHT</p> | <p>Yes</p> <p>Go to next step</p> | |
| | | <p>No</p> <p>Light does not turn ON or OFF with specified switch</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">☞ page F2-93</p> | |
| | | <p>Light always ON</p> <p>Check wiring between ECM terminal 1D and SST</p> | |
| 3 | <p>Is ECM terminal 1I voltage OK?</p> <p style="text-align: right;">☞ page F2-141</p> <p>Voltage: Battery positive voltage (at idle)</p>  | <p>Yes</p> <p>Try known good ECM; and check if condition improves</p> <p style="text-align: right;">☞ page F2-141</p> | |
| | | <p>No</p> <p>Check for short circuit in wiring between data link connector terminal TEN and ground</p> | |



| 12 | ROUGH IDLE/ENGINE STALLS JUST AFTER STARTING | | | | | | | | |
|---|---|---|---|--------------------|-----|--------------------|----|-----|-----------------|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine starts normally, but vibrates excessively or stalls just after starting (acceleration from idle) • Idle conditions are normal in the other conditions | | | | | | | | |
| [TROUBLESHOOTING HINTS] ① Fuel injection control system <ul style="list-style-type: none"> • Start signal not input to ECM ② Ignition timing misadjustment | | | | | | | | | |
| STEP | INSPECTION | | ACTION | | | | | | |
| 1 | Is "00" displayed on SST with ignition switch ON? ⚡ page F2-73 SELF-DIAGNOSIS CHECKER  SYSTEM SELECTOR 49 B019 9A0 SELECT SW: A 49 H018 9A1 MONITOR LIGHT | Yes | "00" displayed Go to next step | | | | | | |
| | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ⚡ page F2-74 | | | | | | | |
| 2 | Are ECM terminal voltages OK (especially 2B)? ⚡ page F2-141 | Yes | Go to next step | | | | | | |
| | | No | Check for cause ⚡ page F2-141 | | | | | | |
| 3 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ⚡ page F2-70 Ignition timing (BTDC): 9-11° {10 ± 1°} | Yes | In same condition as step 3 inspection and apply parking brake. Is idle speed correct? ⚡ page F2-71 Idle speed: 640-700 {670 ± 30} rpm ⇨ If OK, go to next step ⇨ If not OK, adjust idle speed ⚡ page F2-71 | | | | | | |
| | | No | Adjust ignition timing ⚡ page F2-70 | | | | | | |
| 4 | Check for continuity between throttle position sensor terminals C and D ⚡ page F2-150  <table border="1" data-bbox="273 2142 971 2341"> <thead> <tr> <th>Clearance between throttle lever and stopper</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>0.15 mm {0.006 in}</td> <td>Yes</td> </tr> <tr> <td>0.50 mm {0.020 in}</td> <td>No</td> </tr> </tbody> </table> | Clearance between throttle lever and stopper | Continuity | 0.15 mm {0.006 in} | Yes | 0.50 mm {0.020 in} | No | Yes | Go to next step |
| | | Clearance between throttle lever and stopper | Continuity | | | | | | |
| 0.15 mm {0.006 in} | Yes | | | | | | | | |
| 0.50 mm {0.020 in} | No | | | | | | | | |
| No | Adjust throttle position sensor ⚡ page F2-151 | | | | | | | | |
| 5 | Try a known good ECM; and check if condition improves ⚡ page F2-141 | | | | | | | | |


| 13 | HIGH IDLE SPEED AFTER WARM-UP | | |
|---|---|--------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Idle speed excessively high after warm-up | | |
| <p>[TROUBLESHOOTING HINTS] Excessive intake air supplied to engine</p> <ul style="list-style-type: none"> ① Throttle valve not fully closed ② Idle-air control malfunction <ul style="list-style-type: none"> • All valve not closed • Idle air control valve stuck <ul style="list-style-type: none"> • A/C, E/L signal sent to ECM • P/S pressure switch always ON | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is throttle valve fully closed when accelerator is released?  | Yes | Go to step 3 |
| | | No | Is throttle linkage correctly installed and does it operate freely? ☞page F2-96 ⇨ If OK, go to next step ⇨ If not OK, clean, adjust, or replace linkage ☞page F2-96 |
| 2 | Is "00" displayed on SST with ignition switch ON? ☞page F2-73 SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ☞page F2-74 |
| 3 | Does SST Monitor light show that switches operate correctly with ignition switch ON? ☞page F2-92 SELF-DIAGNOSIS CHECKER  | Yes | Go to next step |
| | | No | Light does not turn ON or OFF with specified switch Check for cause (Refer to specified check sequence) ☞page F2-93 |
| | | | Light always ON Check wiring between ECM terminal 1D and Self-Diagnosis Checker |
| 4 | Are ECM terminal voltages OK (especially 2E)? ☞page F2-141 | Yes | Go to next step |
| | | No | Check for cause |


| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 5 | Does engine speed decrease as engine warms up? | Yes | Go to next step |
| | | No | Check air valve ↗page F2-99 |
| 6 | Is idle air control valve OK? ↗page F2-99 | Yes | Go to next step |
| | | No | Repair or replace |
| 7 | Pinch PCV hose with pliers; does engine speed decrease? | Yes | Check PCV valve ↗page F2-124 |
| | | No | Go to next step |
| 8 | Are ECM terminal voltages OK? 1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground ↗page F2-141 | Yes | Try a known good ECM and check if condition improves ↗page F2-141 |
| | | No | Check for cause ↗page F2-141 |



| 14 | IDLE MOVES UP AND DOWN/IDLE HUNTING | | |
|---|--|-----|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine speeds up and down at idle | | |
| [TROUBLESHOOTING HINTS] ① Closed throttle position switch (built-in throttle position sensor) OFF at idle ② Air leakage ③ Fuel injection amount inconstant <ul style="list-style-type: none"> • Poor contact point inside volume air flow sensor ④ Poor ignition | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "00" displayed on SST with ignition switch ON? ⚙️ page F2-73 SELF-DIAGNOSIS CHECKER | Yes | "00" displayed Go to next step |
| |  SYSTEM SELECTOR 49 H018 9A0 SELECT SW: A 49 H018 9A1 MONITOR LIGHT | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ⚙️ page F2-74 |
| 2 | Is intake manifold vacuum correct at idle? Intake manifold vacuum: More than 450 mmHg {17.7 inHg} | Yes | Go to next step |
| | | No | Low vacuum Check for air leakage of intake-air system components |
| 3 | Is air cleaner element clean? ⚙️ page F2-70 | Yes | Go to next step |
| | | No | Replace air cleaner element |
| 4 | Disconnect high-tension lead at idle; does engine speed decrease equally at each cylinder? | Yes | Go to next step |
| | | No | Go to step 8 |
| 5 | Are ECM terminal voltage OK? 1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground ⚙️ page F2-141 | Yes | Go to next step |
| | | No | Check for cause ⚙️ page F2-141 |
| 6 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ⚙️ page F2-70 | Yes | Go to next step |
| | Ignition timing (BTDC): 9-11° {10 ± 1°} | No | Adjust ignition timing ⚙️ page F2-70 |



| STEP | INSPECTION | ACTION | |
|------|--|--------|--|
| 7 | Is volume air flow sensor OK? <small>☞ page F2-150</small>  | Yes | Go to step 13 |
| | | No | Replace volume air flow sensor |
| 8 | Is there fuel injector operating sound at idle? | Yes | Go to step 10 |
| | | No | Go to next step |
| 9 | Does battery positive voltage exist at fuel distributor (RH) terminal A? Does battery positive voltage exist at fuel distributor (LH) terminal D? | Yes | Is fuel injector resistance OK? <small>☞ page F2-117</small> Resistance: 12–16 Ω [20°C (68°F)] ☞ If it is, check wiring between ECM and fuel injector ☞ If it is not, replace fuel injector <small>☞ page F2-115</small> |
| | | No | Check wiring between ECM and fuel injector |
| 10 | Is strong blue spark visible at disconnected high-tension lead? <small>☞ section G</small>  | Yes | Go to next step |
| | | No | Check high-tension lead ☞ If OK, check distributor cap and rotor <small>☞ section G</small> ☞ If not OK, replace high-tension lead |
| 11 | Are spark plugs OK? <small>☞ section G</small>  | Yes | Is engine compression correct? <small>☞ section B2</small> Compression (Minimum): 981 kPa (10.0 kgf/cm ² , 142 psi)-300 rpm ☞ If OK, go to next step ☞ If not OK, check for cause |
| | | No | Clean or replace spark plug <small>☞ section G</small> |
| 12 | Check for fuel injector leakage <small>☞ page F2-116</small> | Yes | Replace fuel injector <small>☞ page F2-115</small> |
| | | No | Go to next step |
| 13 | Try a known good ECM and check if condition improves <small>☞ page F2-140</small> | | |



| 15 | ENGINE/STALLS ON DECELERATION | | |
|--|--|--------|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine unexpectedly stops running during or after deceleration • Idle condition normal | | |
| <p>[TROUBLESHOOTING HINTS] Engine speed drops too much when accelerator is released because of a poor connector connection that has been disconnected by the force of deceleration ① Idle speed misadjustment ② Fuel cut control malfunction</p> | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is idle condition normal? Idle speed: 640–700 rpm {670 ± 30} rpm | Yes | Go to next step |
| | | No | Adjust or perform troubleshooting No. 8–11 "ROUGH IDLE" page F2–33 |
| 2 | Is "00" displayed on SST with ignition switch ON? page F2–73  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) page F2–74 |
| 3 | Does SST Monitor Light show that switches operate correctly with ignition switch ON? page F2–92  | Yes | Go to next step |
| | | No | Light not ON or OFF with specified switch Check for cause (Refer to specified check sequence) page F2–93 |
| | | | Light always ON Check wiring between ECM terminal 1D and Self-Diagnosis Checker |
| 4 | Are ECM terminal voltages OK (especially 1 R, 2B, 3D, 3U, 3V, 3W, 3X, 3Y, and 3Z)? page F2–141 | Yes | Go to next step |
| | | No | Check for cause page F2–141 |
| 5 | Check for poor connection of the following parts <ul style="list-style-type: none"> • Ignition coil • Ignition control module • Distributor • High-tension lead • Fuel injector • Fuel pump relay • ECM | Yes | Repair or replace |
| | | No | Go to next step |



| STEP | INSPECTION | ACTION | |
|------|---|--------|--|
| 6 | Disconnect idle air control valve connector at idle: does engine speed increase?  IDLE AIR CONTROL VALVE | Yes | Go to next step |
| | | No | Replace idle air control valve ↔ page F2-95 |
| 7 | Try a known good ECM and check if condition improves ↔ page F2-141 | | |




| 16 | ENGINE STALLS SUDDENLY (INTERMITTENT) | | |
|--|--|----------------------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • Engine intermittently stops running • Before stalling, engine condition is OK | | |
| <p>[TROUBLESHOOTING HINTS]</p> <p>① Intermittently no spark or no fuel injection caused by vehicle vibration, acceleration, or deceleration</p> <ul style="list-style-type: none"> • Poor connection in wire harness | | | |
| STEP | INSPECTION | | ACTION |
| 1 | <p>Is "00" displayed on SST with ignition switch ON?</p> <p style="text-align: right;">↪ page F2-73</p> <p>SELF-DIAGNOSIS CHECKER</p>  <p>MONITOR LIGHT</p> | <p>Yes</p> <p>No</p> | <p>"00" displayed</p> <p>Go to next step</p> <p>Diagnostic trouble code No. displayed</p> <p>Check for cause (Refer to specified check sequence)</p> <p style="text-align: right;">↪ page F2-74</p> |
| 2 | <p>Check for poor connection of the following parts</p> <ul style="list-style-type: none"> • Ignition coil • Ignition control module • Distributor • High-tension lead • Fuel injector • Fuel pump relay • ECM | <p>Yes</p> <p>No</p> | <p>Repair or replace</p> <p>Go to next step</p> |
| 3 | <p>Are ECM terminal voltages OK (especially 1 B, 3A, 3B, and 3C)?</p> <p style="text-align: right;">↪ page F2-141</p> <p>Note</p> <ul style="list-style-type: none"> • When checking voltages, tap, move, and wiggle harness and connector to recreate problem | <p>Yes</p> <p>No</p> | <p>Go to Troubleshooting No.2: "CRANKS NORMALLY BUT WILL NOT START (NO COMBUSTION)"</p> <p style="text-align: right;">↪ page F2-21</p> <p>Check for cause</p> <p style="text-align: right;">↪ page F2-141</p> |



| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 7 | <p>Is fuel line pressure correct at idle? ↳ page F2-113</p> <p>Fuel line pressure: 260-310 kPa (2.6-3.2 kgf/cm², 37-45 psi) (Vacuum hose to pressure regulator disconnected)</p>  <p>PRESSURE GAUGE INSTALL CLAMPS</p> | Yes | <p>Does fuel line pressure decrease quickly acceleration? ↳ If it does, check fuel line and filter for clogging ↳ If it does not, go to next step</p> |
| | | No | <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <p>↳ If pressure quickly increases, check pressure regulator ↳ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure</p> <p>↳ page F2-113 ↳ page F2-110</p> |
| 8 | <p>Connect System Selector to data link connector and set test switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ↳ page F2-70</p> <p>Ignition timing (BTDC): 9-11° (10 ± 1°)</p>  <p>TEST SWITCH</p> | Yes | <p>Does ignition timing advance during acceleration? ↳ If it does, go to next step ↳ If not, replace ECM</p> <p>↳ page F2-141</p> |
| | | No | <p>Adjust ignition timing</p> <p>↳ page F2-70</p> |
| 9 | <p>Are air duct and air hoses correctly installed?</p> | Yes | Go to next step |
| | | No | Repair |
| 10 | <p>Is exhaust system restricted? ↳ page F2-120</p> | Yes | Repair or replace |
| | | No | Go to next step |
| 11 | <p>Is variable resonance induction system (VRIS) OK? ↳ page F2-102</p> | Yes | Go to next step |
| | | No | Repair or replace |
| 12 | <p>Try a known good ECM and check if condition improves ↳ page F2-141</p> | | |

| 18 | SURGES WHILE CRUISING | | |
|---|--|-----|--|
| DESCRIPTION | <ul style="list-style-type: none"> • Unexpected change in engine speed that is usually repetitive | | |
| [TROUBLESHOOTING HINTS] ① Air/fuel mixture too lean ② Misfire ③ Poor connection in wiring harness | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "00" displayed on SST with ignition switch ON? ☞ page F2-73 SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ☞ page F2-74 |
| 2 | Does SST Monitor Light show that switches operate correctly with ignition switch ON? ☞ page F2-92 SELF-DIAGNOSIS CHECKER  | Yes | Go to next step |
| | | No | Light does not turn ON or OFF with specified input switch Check for cause (Refer to specified check sequence) ☞ page F2-93 |
| | | | Light always ON Check ECM terminal 1D voltage ☞ page F2-141 |
| 3 | Is throttle position sensor OK? ☞ page F2-150 | Yes | Go to next step |
| | | No | Adjust ☞ page F2-151 |
| 4 | Disconnect heated oxygen sensor connector; does condition improve? | Yes | Check heated oxygen sensor ☞ page F2-154 |
| | | No | Go to next step |
| 5 | Are ECM terminal 2C and 2D voltages OK? ☞ page F2-141 | Yes | Go to next step |
| | | No | Check for cause ☞ page F2-141 |



| STEP | INSPECTION | ACTION | |
|------|---|--|--|
| 6 | Is throttle linkage correctly installed and does it operate freely? ☞ page F2-96 | Yes | Go to next step |
| | | No | As required, correct, clean, or replace any binding or damaged linkage, and adjust cable deflection at throttle body ☞ page F2-96 |
| 7 | Is intake manifold vacuum correct at idle? Vacuum: More than 450 mmHg (17.7 inHg) | Yes | Go to next step |
| | | No | Check for air leakage of intake air system components |
| 8 | Is air cleaner element clean? ☞ page F2-70 | Yes | Go to next step |
| | | No | Replace air cleaner element |
| 9 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ☞ page F2-70 Ignition timing (BTDC): 9-11° (10 ± 1°)  TEST SWITCH | Yes | Does ignition timing advance during acceleration? ☞ If it does, go to next step ☞ If it does not, replace ECM ☞ page F2-141 |
| | | No | Adjust ignition timing ☞ page F2-70 |
| 10 | Is fuel line pressure correct at idle? ☞ page F2-113 Fuel line pressure: 260-310 kPa (2.6-3.2kgf/cm ² , 37-45 psi) (vacuum hose to pressure regulator disconnected)  INSTALL CLAMPS PRESSURE GAUGE | Yes | Does fuel line pressure decrease during quick acceleration? ☞ If it does, check for fuel pump maximum pressure If pressure is OK, check fuel line and filter for clogging ☞ If it does not, go to next step ☞ page F2-110 |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ☞ If pressure quickly increases, check pressure regulator ☞ page F2-113 ☞ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure ☞ page F2-110 |
| | | High pressure Is fuel return line clogged? ☞ If it is not, replace pressure regulator ☞ page F2-115 ☞ If it is, replace it | |
| 11 | Check if exhaust system is restricted ☞ page F2-121 | Yes | Repair or replace |
| | | No | Go to next step |
| 12 | Try a known good ECM and check if condition improves ☞ page F2-141 | | |



| 19 | | LACK OF POWER | |
|---|---|---|---|
| DESCRIPTION | | <ul style="list-style-type: none"> • Performance poor under load when throttle valve is fully open • Reduced maximum speed • Idle condition normal | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Factors other than engine malfunction <ul style="list-style-type: none"> • Clutch slipping • Brake dragging • Low tire pressure • Incorrect tire size • Over-loaded ② Low intake air amount <ul style="list-style-type: none"> • Throttle valve not open fully • Clogged intake-air system ③ Air/fuel mixture too lean <ul style="list-style-type: none"> • Fuel line pressure decreases • Fuel injection malfunction ④ Poor ignition ⑤ Low engine compression ⑥ Alcohol-blended fuel used | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check factors other than engine <ul style="list-style-type: none"> • Clutch slipping • Brake dragging • Low tire pressure • Incorrect tire size | Yes | Go to next step |
| | | No | Repair or replace |
| 2 | Is throttle valve fully opened when accelerator is fully depressed? | Yes | Go to next step |
| | | No | Is accelerator cable correctly installed? ↔page F2-97 ⇨ If it is, check throttle body ↔page F2-96 ⇨ If it is not, install it correctly ↔page F2-97 |
| 3 | Is "00" displayed on SST with ignition switch ON? ↔page F2-73 SELF-DIAGNOSIS CHECKER  MONITOR LIGHT | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ↔page F2-74 |
| 4 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ↔page F2-70 Ignition timing (BTDC): 9-11° (10 ± 1°)  TEST SWITCH | Yes | Ignition timing advances when accelerating ⇨ If advances, go to next step ⇨ If not advances, check ECM terminal voltages ↔page F2-141 |
| | | No | Adjust ignition timing ↔page F2-70 |
| 5 | Are ECM terminal voltages OK? ↔page F2-141 (Especially 2F) | Yes | Go to next step |
| | | No | Check for cause ↔page F2-141 |




| STEP | INSPECTION | | ACTION | | | | | | | | | | | |
|---------------------------------|--|--------------------|--|--|--------------------------|--------------------|---------------------------------|----------|--------|---------------------------------|---------|--|----|--|
| 6 | Is intake manifold vacuum correct at idle? Intake manifold vacuum: More than 450 mmHg (17.7 inHg) | Yes | Go to next step | | | | | | | | | | | |
| | | No | Check for air leakage of intake air system components | | | | | | | | | | | |
| 7 | Is air cleaner element clean? ⇨ page F2-70 | Yes | Go to next step | | | | | | | | | | | |
| | | No | Replace air cleaner element | | | | | | | | | | | |
| 8 | Is fuel line pressure correct at idle? ⇨ page F2-113 Fuel line pressure: 260-310 kPa (2.6-3.2kgf/cm ² , 37-45 psi) (Vacuum hose to pressure regulator disconnected) | Yes | Does fuel line pressure decrease during quick acceleration? ⇨ If it does, check fuel pump maximum pressure ⇨ page F2-110 ⇨ If pressure is OK, check fuel line and filter for clogging ⇨ If it does not, go to next step | | | | | | | | | | | |
| |  | No | Low pressure Check fuel line pressure while pinching fuel return hose ⇨ If pressure quickly increases, check pressure regulator ⇨ page F2-113 ⇨ If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure ⇨ page F2-110 | | | | | | | | | | | |
| | | | High pressure Is fuel return line clogged? ⇨ If it is not, replace pressure regulator ⇨ page F2-115 ⇨ If it is, replace it | | | | | | | | | | | |
| 9 | Is volume air flow sensor OK? ⇨ page F2-150 I. Does measuring core move smoothly? MEASURING CORE | Yes | Go to next step | | | | | | | | | | | |
| |  II. Check resistance  <table border="1" data-bbox="589 1942 1048 2256"> <thead> <tr> <th rowspan="2">Terminal</th> <th colspan="2">Resistance (Ω)</th> </tr> <tr> <th>Closed throttle position</th> <th>Wide open throttle</th> </tr> </thead> <tbody> <tr> <td>E₂ ↔ V_s</td> <td>200-1000</td> <td>20-800</td> </tr> <tr> <td>E₂ ↔ V_c</td> <td colspan="2">200-400</td> </tr> </tbody> </table> | Terminal | Resistance (Ω) | | Closed throttle position | Wide open throttle | E ₂ ↔ V _s | 200-1000 | 20-800 | E ₂ ↔ V _c | 200-400 | | No | Repair or replace volume air flow sensor |
| Terminal | Resistance (Ω) | | | | | | | | | | | | | |
| | Closed throttle position | Wide open throttle | | | | | | | | | | | | |
| E ₂ ↔ V _s | 200-1000 | 20-800 | | | | | | | | | | | | |
| E ₂ ↔ V _c | 200-400 | | | | | | | | | | | | | |

| STEP | INSPECTION | | ACTION |
|------|--|-----|---|
| 10 | Are spark plugs OK? ↗ section G  | Yes | Go to next step |
| | | No | Clean or replace spark plug |
| 11 | Is resistance of high-tension leads OK? Resistance: 16 kΩ per 1 m (3.28 ft)  | Yes | Go to next step |
| | | No | Replace high tension lead |
| 12 | Is resistance of ignition coil OK? ↗ section G Resistance [at 20°C (68°F)]: Primary coil winding 0.49–0.73 Ω Secondary coil winding 20–31 kΩ | Yes | Go to next step |
| | | No | Replace distributor ↗ section G |
| 13 | Is engine compression correct? ↗ section B2 Engine compression: 981 kPa {10.0 kgf/cm ² , 142 psi}–300 rpm | Yes | Go to next step |
| | | No | Check engine condition ↗ section B2 <ul style="list-style-type: none"> • Worn piston, piston rings, or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve stuck in guide |
| 14 | Change to another brand of fuel; does condition improve? | Yes | Change to another brand of fuel |
| | | No | Go to next step |



| STEP | INSPECTION | | ACTION |
|------|---|-----|-------------------|
| 15 | Is variable resonance induction system (VRIS) OK? ↔ page F2-101 | Yes | Go to next step |
| | | No | Repair or replace |
| 16 | Try a known good ECM and check if condition improves ↔ page F2-141 | | |




| 20 | | POOR ACCELERATION | | | | | | | |
|--|--|---|--|--------------------|-----|--------------------|----|--|--|
| DESCRIPTION | | <ul style="list-style-type: none"> • Performance poor during acceleration • Idle condition normal | | | | | | | |
| [TROUBLESHOOTING HINTS] | | | | | | | | | |
| ① Factors other than engine malfunction <ul style="list-style-type: none"> • Clutch slipping • Brake dragging • Low tire pressure • Incorrect tire size • Over-loaded ② Low intake air amount <ul style="list-style-type: none"> • Throttle valve not open fully • Clogged intake-air system ③ Air/fuel mixture too lean <ul style="list-style-type: none"> • Fuel line pressure decreases • Fuel injection malfunction ④ Poor ignition | | | | | | | | | |
| ⑤ Low engine compression ⑥ Alcohol-blended fuel used | | | | | | | | | |
| STEP | INSPECTION | ACTION | | | | | | | |
| 1 | Check factors other than engine <ul style="list-style-type: none"> • Clutch slipping • Brake dragging • Low tire pressure • Incorrect tire size | Yes | Go to next step | | | | | | |
| | | No | Repair | | | | | | |
| 2 | Does throttle valve fully open when accelerator is fully depressed? | Yes | Go to next step | | | | | | |
| | | No | Is accelerator cable correctly installed? ↔page F2-97 ⇨ If it is, check throttle body ↔page F2-96 ⇨ If it is not, install it correctly | | | | | | |
| 3 | Is "00" displayed on SST with ignition switch ON? ↔page F2-73 SELF-DIAGNOSIS CHECKER  SYSTEM SELECTOR 49 B019 9A0 SELECT SW: A 49 H018 9A1 MONITOR LIGHT | Yes | "00" displayed Go to next step | | | | | | |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ↔page F2-74 | | | | | | |
| 4 | Check continuity between throttle position sensor terminals C and D ↔page F2-149  | Yes | Go to next step | | | | | | |
| | | No | Adjust throttle position sensor ↔page F2-151 | | | | | | |
| <table border="1"> <thead> <tr> <th>Clearance between throttle lever and stopper</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>0.15 mm {0.006 in}</td> <td>Yes</td> </tr> <tr> <td>0.50 mm {0.020 in}</td> <td>No</td> </tr> </tbody> </table> | | Clearance between throttle lever and stopper | Continuity | 0.15 mm {0.006 in} | Yes | 0.50 mm {0.020 in} | No | | |
| Clearance between throttle lever and stopper | Continuity | | | | | | | | |
| 0.15 mm {0.006 in} | Yes | | | | | | | | |
| 0.50 mm {0.020 in} | No | | | | | | | | |



| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 5 | <p>Connect System Selector to data link connector and set Test Switch to "SELF TEST" Is ignition timing at idle correct after warm-up? ☞ page F2-70</p> <p>Ignition timing (BTDC): 9-11° {10 ± 1°}</p>  <p>TEST SWITCH</p> | Yes | <p>Does ignition timing advance during acceleration?</p> <p>☞ If it does, go to next step ☞ if it does not, check ECM terminal voltages ☞ page F2-141</p> |
| | | No | <p>Adjust ignition timing ☞ page F2-70</p> |
| 6 | <p>Are ECM terminal voltages OK? 1C-Starter signal 2E-Engine coolant temperature sensor 3D-Sensor ground ☞ page F2-141</p> | Yes | <p>Go to next step</p> |
| | | No | <p>Check for cause ☞ page F2-141</p> |
| 7 | <p>Is intake manifold vacuum correct at idle? Intake manifold vacuum: More than 460 mmHg (17.7 inHg)</p> | Yes | <p>Go to next step</p> |
| | | No | <p>Check for air leakage of intake-air system components</p> |
| 8 | <p>Is fuel line pressure correct at idle? ☞ page F2-113</p> <p>Fuel line pressure: 260-310 kPa (2.6-3.2kgf/cm², 37-45 psi) (vacuum hose to pressure regulator disconnected)</p> <p>INSTALL CLAMPS</p> <p>PRESSURE GAUGE</p>  | Yes | <p>Does fuel line pressure decrease during quick acceleration?</p> <p>☞ If it does, check fuel pump maximum pressure ☞ If pressure is OK, check fuel line and filter for clogging ☞ If it does not decrease, go to next step</p> |
| | | No | <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <p>☞ If pressure quickly increases, check pressure regulator ☞ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure ☞ page F2-113</p> |
| | | | <p>High pressure Is fuel line clogged?</p> <p>☞ If it is not, replace pressure regulator ☞ If it is, replace fuel line ☞ page F2-115</p> |


| STEP | INSPECTION | | ACTION | | | | | | | | | | | |
|--------------------------|--|----------|--|----------------|--------------------------|--------------------|---------------------|----------|--------|---------------------|---------|--|-----|-----------------|
| 9 | <p>Is volume air flow sensor OK? ☞ page F2-150</p> <p>I. Does measuring core move smoothly?</p>  <p>MEASURING CORE</p> <p>II. Check resistance</p>  <table border="1" data-bbox="541 650 1006 947"> <thead> <tr> <th rowspan="2">Terminal</th> <th colspan="2">Resistance (Ω)</th> </tr> <tr> <th>Closed throttle position</th> <th>Wide open throttle</th> </tr> </thead> <tbody> <tr> <td>E2 ↔ V_S</td> <td>200-1000</td> <td>20-800</td> </tr> <tr> <td>E2 ↔ V_C</td> <td colspan="2">200-400</td> </tr> </tbody> </table> | Terminal | Resistance (Ω) | | Closed throttle position | Wide open throttle | E2 ↔ V _S | 200-1000 | 20-800 | E2 ↔ V _C | 200-400 | | Yes | Go to next step |
| | | | Terminal | Resistance (Ω) | | | | | | | | | | |
| Closed throttle position | Wide open throttle | | | | | | | | | | | | | |
| E2 ↔ V _S | 200-1000 | 20-800 | | | | | | | | | | | | |
| E2 ↔ V _C | 200-400 | | | | | | | | | | | | | |
| No | Repair or replace volume air flow sensor | | | | | | | | | | | | | |
| 10 | <p>Are spark plugs OK? ☞ section G</p>  <p>WEAR AND CARBON BUILDUP</p> <p>PLUG GAP 1.0-1.1 mm {0.040-0.043 in}</p> <p>BURNS</p> <p>DAMAGE AND DETERIORATION</p> <p>DAMAGE</p> | Yes | Go to next step | | | | | | | | | | | |
| | | No | Clean or replace spark plug | | | | | | | | | | | |
| 11 | <p>Is resistance of ignition coil OK? ☞ section G</p> <p>Resistance [at 20°C (68°F)] :</p> <p>Primary coil winding 0.49-0.73 Ω</p> <p>Secondary coil winding 20-31 kΩ</p> | Yes | Go to next step | | | | | | | | | | | |
| | | No | Replace distributor | | | | | | | | | | | |
| 12 | <p>Is engine compression correct? ☞ section B2</p> <p>Engine compression (minimum): 981 kPa {10.0 kgf/cm², 142 psi}-300 rpm</p> | Yes | Go to next step | | | | | | | | | | | |
| | | No | <p>Check engine condition ☞ section B2</p> <ul style="list-style-type: none"> • Worn piston, piston rings, or cylinder wall • Defective cylinder head gasket • Distorted cylinder head • Improper valve seating • Valve stuck in guide | | | | | | | | | | | |




| STEP | INSPECTION | | ACTION |
|------|---|-----|---------------------------------|
| 13 | Change to another brand of fuel; does condition improve? | Yes | Change to another brand of fuel |
| | | No | Go to next step |
| 14 | Is A/C cut-off control system OK? ☞ page F2-135 | Yes | Go to next step |
| | | No | Repair or replace |
| 15 | Is variable resonance induction system (VRIS) OK? ☞ page F2-101 | Yes | Go to next step |
| | | No | Repair or replace |
| 16 | Try a known good ECM and check if condition improves ☞ page F2-141 | | |

| 21 | RUNS ROUGH DURING DECELERATION/BACKFIRE | | |
|---|---|-----|--|
| DESCRIP-TION | <ul style="list-style-type: none"> • Engine runs rough during deceleration, and abnormal combustion occurs in exhaust system • Transaxle in normal condition | | |
| [TROUBLESHOOTING HINTS] ① Air/fuel mixture too rich <ul style="list-style-type: none"> • Air cleaner element clogged • Fuel injection control malfunction (Fuel-cut control) • Fuel injector fuel leakage ② Throttle position sensor (terminal IDL) malfunction | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Is "00" displayed on SST with ignition switch ON? ☞ page F2-73 SELF-DIAGNOSIS CHECKER  SYSTEM SELECTOR 49 B019 9A0 SELECT SW: A 49 H018 9A1 MONITOR LIGHT | Yes | "00" displayed Go to next step |
| 2 | Does Self-Diagnosis Checker Monitor Light show that switches operate correctly with ignition switch ON? ☞ page F2-92 SELF-DIAGNOSIS CHECKER  SYSTEM SELECTOR 49 B019 9A0 SELECT SW: A 49 H018 9A1 MONITOR LIGHT | Yes | Go to next step |
| 3 | Is intake manifold vacuum correct at idle? Vacuum: More than 450 mmHg {17.7 inHg} | Yes | Go to next step |
| 4 | Is air cleaner element clean? ☞ page F2-70 | Yes | Go to next step |
| 5 | Are ECM terminal voltages OK (especially 2F, 3A, 3U, 3V, 3W, 3X, 3Y and 3Z)? ☞ page F2-141 | Yes | Go to next step |
| | | No | Check for cause ☞ page F2-141 |



| STEP | INSPECTION | ACTION | | | | | | | | | | | | |
|--------------------------|---|----------|---|----------------|--------------------------|--------------------|---------|----------|--------|---------|---------|--|-----|-----------------|
| 6 | Is fuel cut operation OK? ☞ page F2-131 | Yes | Go to next step | | | | | | | | | | | |
| | | No | Try a known good ECM and check if condition improves ☞ page F2-141 | | | | | | | | | | | |
| 7 | Is volume air flow sensor OK? ☞ page F2-150 I. Does measuring core move smoothly? MEASURING CORE  THA E2 E2 Vc Vs II. Check resistance  <table border="1" data-bbox="622 899 1070 1185"> <thead> <tr> <th rowspan="2">Terminal</th> <th colspan="2">Resistance (Ω)</th> </tr> <tr> <th>Closed throttle position</th> <th>Wide open throttle</th> </tr> </thead> <tbody> <tr> <td>E2 ↔ Vs</td> <td>200-1000</td> <td>20-800</td> </tr> <tr> <td>E2 ↔ Vc</td> <td colspan="2">200-400</td> </tr> </tbody> </table> | Terminal | Resistance (Ω) | | Closed throttle position | Wide open throttle | E2 ↔ Vs | 200-1000 | 20-800 | E2 ↔ Vc | 200-400 | | Yes | Go to next step |
| | | | Terminal | Resistance (Ω) | | | | | | | | | | |
| Closed throttle position | Wide open throttle | | | | | | | | | | | | | |
| E2 ↔ Vs | 200-1000 | 20-800 | | | | | | | | | | | | |
| E2 ↔ Vc | 200-400 | | | | | | | | | | | | | |
| No | Repair or replace volume air flow sensor | | | | | | | | | | | | | |
| 8 | Check continuity between throttle position sensor terminals C and D ☞ page F2-150 | Yes | Go to next step | | | | | | | | | | | |
| | | No | Adjust throttle position sensor ☞ page F2-151 | | | | | | | | | | | |
| 9 | Check fuel injector for fuel leakage ☞ page F2-117  FUEL MAIN HOSE FUEL RETURN HOSE | Yes | Replace fuel injector | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | |
| 10 | Try a known good ECM and check if condition improves ☞ page F2-141 | | | | | | | | | | | | | |


| 22 | | KNOCKING | |
|--|--|--|---|
| DESCRIPTION | | ● Abnormal combustion accompanied by audible "pinging" noise | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Incorrect ignition timing (Too advanced) | | ④ Air/Fuel mixture too lean | |
| ② Carbon deposits in cylinder | | ● Fuel injection amount not correct | |
| ③ Overheating | | ● Fuel line pressure decreases during acceleration | |
| STEP | INSPECTION | ACTION | |
| 1 | Connect System Selector to data link connector and set Test Switch to "SELF TEST"; is ignition timing at idle correct after warm-up? ☞ page F2-70 Ignition timing (BTDC): 9-11° (10 ± 1°)  | Yes | Go to next step |
| | | No | Adjust ignition timing ☞ page F2-70 |
| 2 | Is "00" displayed on SST with ignition switch ON? ☞ page F2-73 SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) ☞ page F2-74 |
| 3 | Is intake manifold vacuum correct at idle? Vacuum: More than 450 mmHg (17.7 inHg) | Yes | Go to next step |
| | | No | Check for air leakage of intake air system components |
| 4 | Is engine compression correct? ☞ section B2 Engine compression (minimum): 981 kPa (10.0 kgf/cm², 142 psi)-300 rpm | Yes | Go to next step |
| | | No | High compression Check engine condition ● Carbon deposits ☞ section B2 |

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 5 | <p>Is fuel line pressure correct at idle? ↳ page F2-113</p> <p>Fuel line pressure: 260–310 kPa (2.5–3.2 kgf/cm², 37–45 psi) (Vacuum hose disconnected from pressure regulator)</p>  | Yes | <p>Does fuel line pressure decrease during quick acceleration?</p> <p>⇒ If it does, check for clogging between fuel pump and pressure regulator</p> <p>⇒ If it does not, go to next step</p> |
| | | No | <p>Low pressure Check fuel line pressure while pinching fuel return hose</p> <p>⇒ If pressure quickly increases, check pressure regulator ↳ page F2-113</p> <p>⇒ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure ↳ page F2-110</p> |
| 6 | Is cooling system OK? | Yes | Go to next step |
| | | No | <p>Repair or replace</p> <ul style="list-style-type: none"> • Thermostat ↳ section E • Electric coolant fan • Radiator |
| 7 | <p>Try a known good ECM; does condition improve? ↳ page F2-141</p> | Yes | Replace ECM ↳ page F2-141 |
| | | No | Change to another brand of fuel or use a higher-octane fuel |




| 23 | | FUEL ODOR | |
|---|--|--------------------------|--|
| DESCRIPTION | | • Gasoline odor in cabin | |
| [TROUBLESHOOTING HINTS] | | | |
| ① Poor connection or damaged fuel system | | | |
| ② Charcoal canister overflow due to evaporative emission control system malfunction | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is there fuel leakage or damage of fuel system and evaporative emission control system? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is "00" displayed on SST with ignition switch ON? SELF-DIAGNOSIS CHECKER  MONITOR LIGHT | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) page F2-74 |
| 3 | Is vacuum felt at purge solenoid valve with engine running and throttle valve opened? (Neutral switch connector disconnected)  | Yes | Go to step 5 |
| | | No | Check for solenoid valve operating sound ⇒ If OK, check vacuum hoses for clogging ⇒ If not OK, go to next step |
| 4 | Apply battery positive voltage and ground to purge solenoid valve Is vacuum felt at solenoid valve at idle?  | Yes | Check ECM terminal voltages page F2-141 |
| | | No | Replace purge solenoid valve |
| 5 | Try a known good ECM and check if condition improves page F2-141 | | |


| | | |
|--|---------------------------------|--------|
| 24 | EXHAUST SULFUR ODOR | |
| DESCRIP-TION | • Exhaust gas has unusual odor | |
| [TROUBLESHOOTING HINTS] High sulfur content fuel used | | |
| STEP | INSPECTION | ACTION |
| 1 | Change to another brand of fuel | |

| | | | |
|--|---|--------|--|
| 25 | HIGH OIL CONSUMPTION | | |
| DESCRIP-TION | • Oil consumption excessive | | |
| [TROUBLESHOOTING HINTS] ① PCV system malfunction ① Engine malfunction (Oil working up, working down, or leaking) | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is PCV hose, ventilation hose, or attaching nipples separated, damaged, clogged, or restricted? ☞ page F2-124 | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Is there air pressure or oil at ventilation hoses?  | Yes | Go to next step |
| | | No | Check engine condition • Oil leakage • Worn valve seal • Worn valve stem • Worn valve guide ☞ section B2 |
| 3 | Is vacuum felt at PCV valve at idle? ☞ page F2-124  | Yes | Check engine condition • Worn piston ring groove • Stuck piston rings • Worn piston or cylinder ☞ section B2 |
| | | No | Replace PCV valve |

| 26 | POOR FUEL ECONOMY | | |
|--|---|-----|---|
| DESCRIPTION | <ul style="list-style-type: none"> Fuel economy unsatisfactory | | |
| <p>[TROUBLESHOOTING HINTS] Although fuel consumption is drastically increased by such operation as city driving, short-runs, stop-and-go driving, and extended winter warm-up periods, as opposed to "trip" mileage, an attempt should be made to determine if any of these factors were an influence when confronted with "poor mileage". However, since the operator and driving conditions are not always at fault, the following suggestions are offered as possible other reasons for poor mileage.</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>① Operator depressing accelerator pedal more than usual because of low engine power</p> <ul style="list-style-type: none"> Poor ignition Low intake air amount Electronic spark advance control system malfunction Clutch slipping Exhaust component restricted </div> <div style="width: 48%;"> <p>② Air/fuel mixture too rich</p> <ul style="list-style-type: none"> High fuel line pressure <p>③ Alcohol-blended fuel used</p> <p>④ High vehicle load</p> <ul style="list-style-type: none"> Low tire pressure Incorrect tire size Brake dragging </div> </div> | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Check factors other than engine <ul style="list-style-type: none"> Low tire pressure Unrecommended tire size Clutch slipping Brake dragging Exhaust component restricted | Yes | Go to next step |
| | | No | Repair or replace |
| 2 | Are air hoses connected correctly? <small>☞ page F2-95</small> | Yes | Go to next step |
| | | No | Repair |
| 3 | Is "00" displayed on SST with ignition switch ON? <small>☞ page F2-73</small> SELF-DIAGNOSIS CHECKER  | Yes | "00" displayed Go to next step |
| | | No | Diagnostic trouble code No. displayed Check for cause (Refer to specified check sequence) <small>☞ page F2-74</small> |
| 4 | Is intake manifold vacuum correct? Vacuum: More than 450 mmHg {17.7 inHg} | Yes | Go to next step |
| | | No | Check for air leakage of intake-air system components |
| 5 | Is air cleaner element clean? <small>☞ page F2-70</small> | Yes | Go to next step |
| | | No | Replace air cleaner element |

| STEP | INSPECTION | | ACTION |
|------|---|-----|--|
| 6 | Are ECM terminal voltages OK? (especially 2B, 2C, 2D 2E, 3U, 3V, 3W, 3X, 3Y, and 3Z) ⇨ page F2-141 | Yes | Go to next step |
| | | No | Check for cause ⇨ page F2-141 |
| 7 | Connect System Selection to data link connector and set Test Switch to "SELF- TEST"; is ignition timing at idle correct after warm-up? ⇨ page F2-70 Ignition timing (BTDC): 9-11° (10 ± 1°) | Yes | Go to next step |
| | | No | Adjust ignition timing ⇨ page F2-70 |
| 8 | Is fuel line pressure correct at idle? ⇨ page F2-107 Fuel line pressure: 210-260 kPa (2.1-2.7 kgf/cm², 30-38 psi) | Yes | Go to next step |
| | | No | High pressure Is vacuum hose to pressure regulator damaged or poorly connected? ⇨ If it is not, replace pressure regulator ⇨ If it is, repair or replace vacuum hose ⇨ page F2-115 |
| 9 | Run engine at idle; does fuel line pressure held after ignition switch is turned off? ⇨ page F2-107 Fuel line pressure: More than 150 kPa (1.5 kgf/cm², 21 psi) for 5 min. | Yes | Go to next step |
| | | No | Check fuel injectors for fuel leakage ⇨ page F2-116 |
| 10 | Change to another brand of fuel | | |




| | | | |
|---|---|---------------|---|
| 27 | A/C DOES NOT WORK | | |
| DESCRIPTION | <ul style="list-style-type: none"> • Blower fan operates, but magnetic clutch does not | | |
| [TROUBLESHOOTING HINTS] | | | |
| <ul style="list-style-type: none"> • Open or short circuit in wiring harness • A/C relay, A/C switch, or magnetic clutch malfunction • ECM malfunction | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is ECM 10 terminal voltage OK?  | Yes | Is ECM 1 L terminal voltage OK? page F2-141 ⇨ If it is, check A/C system '95 MX-3 ⇨ If it is not, replace ECM BETM page F2-141 |
| | | No | Check for cause page F2-141 |


ENGINE TUNE-UP

PREPARATION
SST

49 B019 9A0
System Selector




For
Inspection of
ignition timing
and idle speed



BASIC INSPECTION

Engine Oil

1. Remove the dipstick and check the engine oil level and condition.
2. Add or change oil as necessary.



Coolant (engine cold)


Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system.

Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes.

When you're sure all the pressure is gone, press down on the cap—still using a cloth—turn it, and remove it.

1. Verify that the coolant level is near the radiator filler neck.
2. Verify that the coolant level in the coolant reservoir is between the FULL and LOW marks.
3. Add coolant if necessary.




Battery

Removing the label on the top of the battery or removing the vent caps will void the battery's warranty.

1. Remove any corrosion on the clamps or battery posts.
2. Verify that the battery top is clean. If necessary, clean with baking soda and water.
3. Verify that cables are in good condition and not frayed or corroded. Repair or replace if necessary.
4. Verify that cable clamps are tight.

Note

- Because this is a maintenance-free battery, it is not necessary to check the fluid level.



Air Cleaner Element Inspection

1. Check the air cleaner element for excessive dirt and for oil and damage.


Caution

- Cleaning the element with compressed air will reduce the element's ability to filter the air. Don't use compressed air to clean the element.

2. Replace the element if necessary.

**ADJUSTMENT****Preparation**




1. Warm up the engine to normal operating temperature.
2. Turn all electrical loads off.
 - Headlight switch
 - Blower switch
 - Rear window defroster switch
 - P/S
 - A/C
3. Connect the **SST** to the data link connector.
4. Connect a timing light.
5. Connect a tachometer to the data link connector terminal **IG-** as shown.

**Ignition Timing**

1. Perform "Preparation". (Refer to above.)
2. Verify that the coolant fan does not operate.
3. Make sure the idle speed is within the specification. If not, adjust the idle speed (Refer to page F2-71).

Idle speed (Neutral or P range):
550-950 rpm {750 ± 200 rpm}

4. Set switch A to position 1.
5. Set TEST SW to SELF TEST

**Note**

- If the SST is not used, connect a jumper wire between the terminal TEN and the terminal GND of the data link connector.

6. Make sure the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition timing: BTDC 9–11° {10 ± 1°}

7. If the marks are not aligned, loosen the distributor lock bolts and turn the distributor to make the adjustment.
8. Tighten the distributor lock bolts to the specified torque.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lb}

9. Disconnect the SST.
10. Check if the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition Timing: BTDC 6–18°

Idle Speed

1. Perform "Preparation". (Refer to page F2–70.)
2. With the coolant fan off, verify that the idle speed is within the specification.

Idle speed: 640–700 rpm {670 ± 30 rpm}

3. If not within the specification, adjust the idle speed by turning the air adjusting screw.

ON BOARD DIAGNOSTIC SYSTEM

DESCRIPTION



When trouble occurs in the main input or output devices, check for the cause by using the **SST**. Failures of each input and output device are indicated and retrieved from the engine control module (ECM) as diagnostic trouble code numbers.




Note

- For input devices, the ECM continuously checks for malfunctions. For output devices, it checks for malfunctions only in a three-second period after the ignition switch is turned to ON, or the terminal TEN of the data link connector is grounded.

PREPARATION













SST










| | | | |
|---|----------------------|--|----------------------|
| <p>49 B019 9A0 System Selector</p>  | <p>For diagnosis</p> | <p>49 H018 9A1 Self-Diagnosis Checker</p>  | <p>For diagnosis</p> |
|---|----------------------|--|----------------------|

**DIAGNOSTIC TROUBLE CODE NUMBER****Inspection Procedure**

1. Connect the **SST** to the data link connector.
2. Set switch A to position 1.
3. Set TEST SW to SELF TEST.
4. Connect the **SST** to the System Selector and a ground.
5. Set the select switch to position A.
6. Turn the ignition switch to ON.
7. Verify that 88 flashes on the digital display and the buzzer sounds for **3 sec.** after turning the ignition switch ON.
8. If 88 does not flash, check the main relay (FUEL INJ relay) (Refer to page F2-157), power supply circuit, and data link connector wiring.
9. If 88 flashes and the buzzer sounds continuously for more than **20 sec.**, check for a short circuit between the engine control module terminal tE and the data link connector. Replace the engine control module if necessary, and perform steps 3-7 again.
10. Note any code numbers and check for the causes by referring to the check sequences shown on pages F2-74 through F2-91. Repair as necessary.
11. After repairs, cancel the code numbers by performing the "After-repair procedure". (Refer to page F2-92.)

Diagnostic Trouble Code Numbers

| No. | Indicator flashing pattern | Diagnosed circuit | Condition | Point | Memorized | Page |
|-----|---|--------------------------------------|---|---|---|-------|
| 02 | ON  OFF | NE signal crankshaft position sensor | No NE signal | <ul style="list-style-type: none"> • Crankshaft position sensor connector • Wiring from crankshaft position sensor to ECM • Crankshaft position sensor | Yes | F2-76 |
| 03 | ON  OFF | SGC signal camshaft position sensor | No SGC signal input while a specified number of SGT or NE signal pulses are input | <ul style="list-style-type: none"> • Distributor connector • Wiring from main relay to distributor • Wiring from distributor to ECM • Camshaft position sensor | Yes | F2-77 |
| 04 | ON  OFF | SGT signal camshaft position sensor | No SGT signal | | Yes | F2-78 |
| 05 | ON  OFF | Knock sensor | Open or short circuit | <ul style="list-style-type: none"> • Knock sensor connector • Wiring from knock sensor to ECM • Knock sensor | Yes | F2-79 |
| 08 | ON  OFF | Volume air flow sensor | | <ul style="list-style-type: none"> • Volume air flow sensor connector • Wiring from volume air flow sensor to ECM • Volume air flow sensor | Yes | F2-80 |
| 09 | ON  OFF | Engine coolant temperature sensor | | <ul style="list-style-type: none"> • Engine coolant temperature sensor connector • Wiring from engine coolant temperature sensor to ECM • Engine coolant temperature sensor resistance | Yes | F2-81 |
| 10 | ON  OFF | Intake air temperature sensor | | <ul style="list-style-type: none"> • Volume air flow sensor connector • Wiring from volume air flow sensor to ECM • Intake air temperature sensor resistance | Yes | F2-82 |
| 12 | ON  OFF | Throttle position sensor | | <ul style="list-style-type: none"> • Throttle position sensor connector • Wiring from throttle position sensor to ECM • Throttle position sensor | Yes | F2-83 |
| 14 | ON  OFF | Barometric pressure sensor | | <ul style="list-style-type: none"> • ECM | Yes | F2-84 |
| 15 | ON  OFF | Heated oxygen sensor (Left side) | | Sensor output continues less than 0.55V 100 sec. after engine speed exceeds 1,500 rpm | <ul style="list-style-type: none"> • Heated oxygen sensor connector • Wiring from heated oxygen sensor to ECM • Heated oxygen sensor | Yes |
| 16 | ON  OFF | EGR valve position sensor | Open or short circuit | <ul style="list-style-type: none"> • EGR valve position sensor connector • Wiring from EGR valve position sensor to ECM • EGR valve position sensor | Yes | F2-85 |
| 17 | ON  OFF | Closed loop system (Left side) | Sensor output not changed 50 sec. after engine speed exceeds 1,500 rpm | <ul style="list-style-type: none"> • Fuel pressure • Injection fuel leakage • Ignition system • Air leakage • ECM | Yes | F2-86 |

| No. | Indicator flashing pattern | Diag-nosed circuit | Condition | Point | Memo-rized | Page |
|-----|---|---|---|--|------------|-------|
| 23 | ON  OFF | Heated oxygen sensor (Right side) | Sensor output continues less than 0.55V 100 sec. after engine speed exceeds 1,500 rpm | <ul style="list-style-type: none"> • Heated oxygen sensor connector • Wiring from heated oxygen sensor to ECM • Heated oxygen sensor | Yes | F2-86 |
| 24 | ON  OFF | Closed loop system (Right side) | Sensor output not changed 50 sec. after engine speed exceeds 1,500 rpm | <ul style="list-style-type: none"> • Fuel pressure • Injection fuel leakage • Ignition system • Air leakage • ECM | Yes | F2-86 |
| 25 | ON  OFF | PRC solenoid valve (pressure regulator control) | Open circuit | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-88 |
| 26 | ON  OFF | Purge solenoid valve (purge control) | | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-88 |
| 28 | ON  OFF | EGR solenoid valve (vacuum) | | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-89 |
| 29 | ON  OFF | EGR solenoid valve (vent) | | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-89 |
| 34 | ON  OFF | Idle air control valve | | <ul style="list-style-type: none"> • Idle air control valve connector • Wiring from idle air control valve to ECM • Idle air control valve continuity | No | F2-90 |
| 41 | ON  OFF | VRIS solenoid valve No.1 | | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-91 |
| 46 | ON  OFF | VRIS solenoid valve No.2 | | <ul style="list-style-type: none"> • Solenoid valve connection • Wiring from solenoid valve to ECM • Solenoid valve continuity | No | F2-91 |

Note

- If more than one failure is present, the code numbers will be indicated in numerical order.


After repairs, cancel the code numbers by performing the "After-repair procedure". (Refer to page F2-92.)

Troubleshooting

If a diagnostic trouble code number is shown on the SST, check for the cause by using the chart related to the code number shown.


| CODE No. | | 02 (CRANKSHAFT POSITION SENSOR NE SIGNAL) | |
|----------|--|---|--|
| STEP | INSPECTION | | ACTION |
| 1 | Is there poor connection in crankshaft position sensor circuit? | Yes | Repair or replace |
| | | No | Go to next step |
| 2 | Disconnect connector from ECM; Is resistance of connector between terminals 3F and 3H OK? Resistance: 520-580 Ω | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Is there continuity between terminal 3F or 3H of connector and ground (At harness side) ? | Yes | Check for short circuit in wiring from camshaft position sensor to terminal 3F or 3H |
| | | No | Replace ECM |
| 4 | Is resistance of camshaft position sensor OK? Resistance: 520-580 Ω | Yes | Check for open circuit in wiring from ECM to crankshaft position sensor |
| | | No | Replace crankshaft position sensor |

Circuit Diagram




| CODE No. | 03 (CAMSHAFT POSITION SENSOR SGC SIGNAL) | | |
|----------|--|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Is there poor connection in distributor circuit? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is code No. 04 also present? | Yes | Go to next step |
| | | No | Go to step 5 |
| 3 | Is there continuity between distributor terminal A (6-pin) and ground? | Yes | Go to next step |
| | | No | Check for open circuit in wiring from distributor to ground |
| 4 | Is there battery positive voltage at distributor terminal B (6-pin)? | Yes | Go to next step |
| | | No | Check for open circuit in wiring from distributor to main relay |
| 5 | Is there approx. 5V at distributor harness-side connector terminal B (3-pin)? (With distributor connector disconnected) | Yes | Replace distributor |
| | | No | Go to next step |
| 6 | Is there approx. 5V at ECM terminal 3G? (With distributor connector disconnected) | Yes | Check for short or open circuit in wiring from distributor to ECM terminal 3G |
| | | No | Replace ECM |

Circuit Diagram




| CODE No. | 04 (CAMSHAFT POSITION SENSOR SGT SIGNAL) | | |
|----------|--|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Is there poor connection in distributor circuit? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is code No. 03 also present? | Yes | Go to next step |
| | | No | Go to step 5 |
| 3 | Is there continuity between distributor terminal A (6-pin) and ground? | Yes | Go to next step |
| | | No | Check for open circuit in wiring from distributor to ground |
| 4 | Is there battery positive voltage at distributor terminal B (6-pin)? | Yes | Go to next step |
| | | No | Check for open circuit in wiring from distributor to main relay |
| 5 | Is there approx. 5V at distributor harness-side connector terminal B (3-pin)? (With distributor connector disconnected) | Yes | Replace distributor |
| | | No | Go to next step |
| 6 | Is there approx. 5V at ECM terminal 3E? (With distributor connector disconnected) | Yes | Check for short or open circuit in wiring from distributor to ECM terminal 3E |
| | | No | Replace ECM |

Circuit Diagram




| CODE No. | | 05 (KNOCK SENSOR) | |
|----------|---|-------------------|--|
| STEP | INSPECTION | | ACTION |
| 1 | Does knock sensor circuit have a poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Does wire harness between knock sensor and ECM have a continuity? | Yes | Repair or replace harness |
| | | No | Check continuity between ECM terminal 2M and ground ⇒ If continuity, repair or replace harness ⇒ If no continuity, go to next step |
| 3 | Try known good knock sensor. Does same code No. present? | Yes | Replace ECM |
| | | No | Replace knock sensor |

Circuit Diagram




| CODE No. | | 08 (VOLUME AIR FLOW SENSOR) | | | | | | | | | | |
|----------|---|---|---|---------------------------------|---------------------------------------|---------------------------------|-----|----------|--------|-----|---------|--|
| STEP | INSPECTION | ACTION | | | | | | | | | | |
| 1 | Does volume air flow sensor circuit have a poor connection? | Yes | Repair or replace connector | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | |
| 2 | Is Code No. 10 also present? | Yes | Check for open circuit in wiring from volume air flow sensor terminal C to ground | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | |
| 3 | Is resistance of volume air flow sensor OK? | Yes | Go to next step | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Volume air flow sensor</th> <th>Closed throttle position (Ω)</th> <th>Wide open throttle (Ω)</th> </tr> </thead> <tbody> <tr> <td>B-A</td> <td>200-1000</td> <td>20-800</td> </tr> <tr> <td>B-D</td> <td colspan="2">200-400</td> </tr> </tbody> </table> | | Volume air flow sensor | Closed throttle position (Ω) | Wide open throttle (Ω) | B-A | 200-1000 | 20-800 | B-D | 200-400 | |
| | | Volume air flow sensor | Closed throttle position (Ω) | Wide open throttle (Ω) | | | | | | | | |
| B-A | 200-1000 | 20-800 | | | | | | | | | | |
| B-D | 200-400 | | | | | | | | | | | |
| No | Replace volume air flow sensor | | | | | | | | | | | |
| 4 | Does wire harness between volume air flow sensor and ECM have continuity? | Yes | Go to next step | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Volume air flow sensor</th> <th>ECM</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>2I</td> </tr> <tr> <td>A</td> <td>2B</td> </tr> </tbody> </table> | | Volume air flow sensor | ECM | B | 2I | A | 2B | | | |
| | | Volume air flow sensor | ECM | | | | | | | | | |
| B | 2I | | | | | | | | | | | |
| A | 2B | | | | | | | | | | | |
| No | Repair or replace wire harness | | | | | | | | | | | |
| 5 | Are ECM terminal 3D, 2I, and 2B voltages OK? ☞ page F2-141 | Yes | Replace ECM ☞ page F2-140 | | | | | | | | | |
| | | No | Check for a short circuit in wiring from volume air flow sensor to ECM | | | | | | | | | |

Circuit Diagram




| CODE No. | 09 (ENGINE COOLANT TEMPERATURE SENSOR) | | | | | | | | |
|--------------|--|-----------------------------------|---|-------------|---------|--------------|-----------|-----|-----------------|
| STEP | INSPECTION | ACTION | | | | | | | |
| 1 | Does engine coolant temperature sensor circuit have a poor connection? | Yes | Repair or replace connector | | | | | | |
| | | No | Go to next step | | | | | | |
| 2 | Does wire harness between engine coolant temperature sensor and ECM have continuity? <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Engine coolant temperature sensor</th> <th>ECM</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>2E</td> </tr> <tr> <td>B</td> <td>3D</td> </tr> </tbody> </table> | Engine coolant temperature sensor | ECM | A | 2E | B | 3D | Yes | Go to next step |
| | | Engine coolant temperature sensor | ECM | | | | | | |
| A | 2E | | | | | | | | |
| B | 3D | | | | | | | | |
| No | Repair or replace | | | | | | | | |
| 3 | Is resistance of engine coolant temperature sensor OK? <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Coolant temperature</th> <th>Resistance (kΩ)</th> </tr> </thead> <tbody> <tr> <td>20°C (68°F)</td> <td>2.2-2.7</td> </tr> <tr> <td>80°C (176°F)</td> <td>0.29-0.35</td> </tr> </tbody> </table> | Coolant temperature | Resistance (kΩ) | 20°C (68°F) | 2.2-2.7 | 80°C (176°F) | 0.29-0.35 | Yes | Go to next step |
| | | Coolant temperature | Resistance (kΩ) | | | | | | |
| 20°C (68°F) | 2.2-2.7 | | | | | | | | |
| 80°C (176°F) | 0.29-0.35 | | | | | | | | |
| No | Replace engine coolant temperature sensor | | | | | | | | |
| 4 | Is same code No. present following "After-repair procedure" ? ⚡ page F2-94 | Yes | Go to next step | | | | | | |
| | | No | Engine coolant temperature sensor and circuit OK | | | | | | |
| 5 | Are ECM terminal 2E and 3D voltages OK? ⚡ page F2-141 | Yes | Replace ECM ⚡ page F2-140 | | | | | | |
| | | No | Check for a short circuit in wiring from engine coolant temperature sensor to ECM | | | | | | |

Circuit Diagram




| CODE No. | 10 (INTAKE AIR TEMPERATURE SENSOR — IN VOLUME AIR FLOW SENSOR) | | | | | | | | |
|--|--|---|---|--------------|-------------|---------------|---------|--|--|
| STEP | INSPECTION | | ACTION | | | | | | |
| 1 | Does intake air temperature sensor circuit have a poor connection? | Yes | Repair or replace connector | | | | | | |
| | | No | Go to next step | | | | | | |
| 2 | Is code No. 08 also present? | Yes | Check for an open circuit in wiring from volume air flow sensor terminal C or D to ground | | | | | | |
| | | No | Go to next step | | | | | | |
| 3 | Does wire harness between intake air temperature sensor and ECM have continuity? | Yes | Go to next step | | | | | | |
| | | No | Repair or replace | | | | | | |
| <table border="1"> <thead> <tr> <th>Intake air temperature sensor (In volume air flow sensor)</th> <th>ECM</th> </tr> </thead> <tbody> <tr> <td>D</td> <td>3D</td> </tr> <tr> <td>E</td> <td>2K</td> </tr> </tbody> </table> | | Intake air temperature sensor (In volume air flow sensor) | ECM | D | 3D | E | 2K | | |
| Intake air temperature sensor (In volume air flow sensor) | ECM | | | | | | | | |
| D | 3D | | | | | | | | |
| E | 2K | | | | | | | | |
| 4 | Is resistance of volume air flow sensor between terminals C and G OK? | Yes | Go to next step | | | | | | |
| | | No | Replace volume air flow sensor | | | | | | |
| <table border="1"> <thead> <tr> <th>Temperature</th> <th>Resistance (Ω)</th> </tr> </thead> <tbody> <tr> <td>20°C (68° F)</td> <td>2,000-3,000</td> </tr> <tr> <td>60°C (140° F)</td> <td>400-700</td> </tr> </tbody> </table> | | Temperature | Resistance (Ω) | 20°C (68° F) | 2,000-3,000 | 60°C (140° F) | 400-700 | | |
| Temperature | Resistance (Ω) | | | | | | | | |
| 20°C (68° F) | 2,000-3,000 | | | | | | | | |
| 60°C (140° F) | 400-700 | | | | | | | | |
| 5 | Is same code No. present following "After-repair procedure"? ☞ page F2-92 | Yes | Replace ECM | | | | | | |
| | | No | Intake air temperature sensor and circuit OK | | | | | | |
| 6 | Are ECM terminal 2K and 3D voltages OK? ☞ page F2-141 | Yes | Replace ECM ☞page F2-141 | | | | | | |
| | | No | Look for a short circuit in wiring from intake air temperature sensor to ECM | | | | | | |

Circuit Diagram



| CODE No. | | No. t2 (THROTTLE POSITION SENSOR) | |
|----------|---|-----------------------------------|---|
| STEP | INSPECTION | | ACTION |
| 1 | Does throttle position sensor circuit have a poor connection? | Yes | Repair or replace connector |
| 2 | Is ECM terminal 2F voltage OK? <small>see page F2-37</small> | Yes | Go to next step |
| | | No | Go to step 4 |
| 3 | Is voltage increase linear according to the throttle valve opening angle? | Yes | Go to step 7 |
| | | No | Replace throttle position sensor |
| 4 | Disconnect throttle position sensor connector. Turn ignition switch to ON. Is there 5V at connector terminal A? | Yes | Go to next step |
| | | No | Check for open or short circuit in wiring harness. (ECM terminal 2I-throttle sensor terminal A) |
| 5 | Is there continuity between connector terminal D and ECM terminal 2F? | Yes | Go to next step |
| | | No | Replace or replace wiring harness |
| 6 | Is there continuity between connector terminal D and ECM terminal 3D? | Yes | Replace throttle position sensor |
| | | No | Repair or replace wiring harness |
| 7 | Do throttle position sensor connector and ECM connector have poor connection? | Yes | Replace ECM <small>see page F2-141</small> |
| | | No | Intermittent poor connection of harness or connector (Repair connector and / or harness) |


Circuit Diagram



| | | |
|----------|--|--------------|
| CODE No. | 14 (BAROMETRIC PRESSURE SENSOR — IN ECM) | |
| STEP | ACTION | |
| 1 | Replace ECM | ☞page F2-140 |


| | | | |
|--|--|--------|--|
| CODE No. | 15 and/or 23 (HEATED OXYGEN SENSOR-INACTIVATED) | | |
| Note • If code No. 15 and 17 are both present, first perform the checking procedure for code No. 17. | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Does heated oxygen sensor circuit have a poor connection? | Yes | Repair or replace connector |
| | | No | Go to next step |
| 2 | Is heated oxygen sensor output voltage OK? | Yes | Go to next step |
| | | No | Replace heated oxygen sensor |
| 3 | Does wire harness between heated oxygen sensor and ECM terminal (left bank 2D, right bank 2C) have continuity? | Yes | Go to next step |
| | | No | Repair or replace |
| 4 | Is ECM terminal (left bank 2D, right bank 2d) voltage OK? ☞ page F2-141 | Yes | Go to next step |
| | | No | Check for a short circuit in wiring from heated oxygen sensor to ECM |
| 5 | Is sensitivity of heated oxygen sensor OK? ☞ page F2-154 | Yes | Replace ECM ☞page F2-141 |
| | | No | Try a known good heated oxygen sensor and check if condition improves ☞page F2-154 |

Circuit Diagram




| CODE No. | 16 (EGR VALVE POSITION SENSOR) | | | | | | | | | | |
|----------|--|---------------------------|---|---|----|---|----|---|----|-----|-----------------|
| STEP | INSPECTION | | ACTION | | | | | | | | |
| 1 | Does EGR valve position sensor circuit have a poor connection? | Yes | Repair or replace connector | | | | | | | | |
| | | No | Go to next step | | | | | | | | |
| 2 | Is EGR valve OK? <i>see page F2-126</i> | Yes | Go to next step | | | | | | | | |
| | | No | Replace EGR valve | | | | | | | | |
| 3 | Is resistance of EGR valve position sensor OK? <i>see page F2-158</i> | Yes | Go to next step | | | | | | | | |
| | | No | Replace EGR valve | | | | | | | | |
| 4 | Is there continuity between EGR valve position sensor and ECM? <table border="1" data-bbox="360 842 1037 1051"> <thead> <tr> <th>EGR valve position sensor</th> <th>ECM</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>2J</td> </tr> <tr> <td>B</td> <td>3D</td> </tr> <tr> <td>C</td> <td>2I</td> </tr> </tbody> </table> | EGR valve position sensor | ECM | A | 2J | B | 3D | C | 2I | Yes | Go to next step |
| | | EGR valve position sensor | ECM | | | | | | | | |
| A | 2J | | | | | | | | | | |
| B | 3D | | | | | | | | | | |
| C | 2I | | | | | | | | | | |
| No | Check for open circuit in wiring from EGR valve position sensor to ECM | | | | | | | | | | |
| 5 | Is there 4.5-5.5V at EGR valve position sensor connector terminal C? <i>see page F2-158</i> | Yes | Go to next step | | | | | | | | |
| | | No | Check for short circuit in wiring from EGR valve position sensor terminal C to ECM | | | | | | | | |
| 6 | Is ECM terminal 2J voltage OK? | Yes | Replace ECM | | | | | | | | |
| | | No | Check for short circuit in wiring harness EGR valve position sensor terminal A to ECM | | | | | | | | |

Circuit Diagram



| CODE No. | 17 and/or 24 (CLOSED LOOP SYSTEM) | |
|----------|--|---|
| STEP | INSPECTION | ACTION |
| 1 | Is same code No. present following "After-repair procedure"? <i>↔</i> page F2-92 | Yes Go to next step |
| | | No Does heated oxygen sensor circuit have a poor connection? ↔ If not, perform troubleshooting for code No. 15 |
| 2 | Does Self-Diagnosis Checker monitor lamp illuminate at idle after engine has been warmed up to 2,500-3,000 rpm for 3 min. | Yes Go to next step Note • A/F mixture is rich |
| | | No Go to step 5 Note • A/F mixture is lean or misfire is occurring |
| 3 | Is fuel line pressure correct at idle? <i>↔</i> page F2-113 Fuel line pressure: 260-310 kPa (2.5-3.2 kgf/cm ² , 37-45 psi) (Vacuum hose to pressure regulator disconnected) | Yes Go to next step |
| | | No High pressure Is fuel return hose clogged or restricted? ↔ If not, replace pressure regulator <i>↔</i> page F2-115 |
| 4 | Check fuel injector for fuel leakage Is leakage observed? <i>↔</i> page F2-116 | Yes Replace fuel injector |
| | | No Is engine coolant temperature sensor OK? <i>↔</i> page F2-152 ↔ If it is, replace ECM ↔ If not, replace engine coolant temperature sensor |
| 5 | Disconnect each high-tension lead at idle; does engine speed decrease equally at each cylinder? | Yes Go to next step |
| | | No Go to step 8 |

Circuit Diagram




| STEP | INSPECTION | | ACTION |
|------|--|-----|--|
| 6 | Is fuel line pressure correct at idle? ☞ page F2-113 Fuel line pressure: 260-310 kPa (2.6-3.2kgf/cm ² , 37-45 psi) (Vacuum hose from pressure regulator disconnected) | Yes | Go to next step |
| | | No | Low pressure Check fuel line pressure while pinching fuel return hose ☞ If pressure quickly increases, check pressure regulator ☞ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure ☞ page F2-113 ☞ page F2-110 |
| 7 | Check intake-air system components for air leakage Is leakage observed? | Yes | Go to step 11 |
| | | No | Replace |
| 8 | Is there a misfire or a dead cylinder found in inspection step 5? | Yes | Repair or replace ignition system |
| | | No | Go to next step |
| 9 | Is fuel injector operating sound heard at dead cylinder during idle in inspection step 5? | Yes | Go to next step |
| | | No | Is there battery positive voltage at fuel injector connector? ☞ If there is, replace fuel injector ☞ If there is not, look for a short or open circuit in wire harness |
| 10 | Replace fuel injector at dead cylinder found in inspection step 5 Is same code No. present following "After-repair procedure"? ☞ page F2-82 | Yes | Go to next step |
| | | No | Removed fuel injector at fault |
| 11 | Try a known good ECM and check if condition improves ☞ page F2-141 | | |

| CODE No. | | 25 (PRC SOLENOID VALVE) | |
|----------|---|-------------------------|--|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect connector from ECM; is battery positive voltage at ECM terminal 3M with ignition switch ON? | Yes | Does ECM terminal connector have a poor connection? ⇒ If not, repair or replace ECM page F2-141 ⇒ If it does, repair or replace connector |
| | | No | Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at PRC solenoid valve connector terminal wire? | Yes | Repair or replace wire |
| | | No | Go to next step |
| 3 | Is PRC solenoid valve OK? page F2-120 | Yes | Look for a short or open circuit in wiring from main relay (FUEL INJ relay) to solenoid valve |
| | | No | Replace PRC solenoid valve |

| CODE No. | | 26 (PURGE SOLENOID VALVE) | |
|----------|---|---------------------------|--|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect connector from ECM. Is there battery positive voltage at ECM terminal 20 with ignition switch ON? | Yes | Does ECM terminal connector have a poor connection? ⇒ If not, replace ECM page F2-141 ⇒ If it does, repair or replace connector |
| | | No | Go to next step |
| 2 | In same condition as step 1; is there battery positive voltage at purge solenoid valve connector terminal wire? | Yes | Repair or replace wire |
| | | No | Go to next step |
| 3 | Is purge solenoid valve OK? page F2-128 | Yes | Look for a short or open circuit in wiring from the main relay (FUEL INJ relay) to the solenoid valve |
| | | No | Replace purge solenoid valve |


Circuit Diagram



| CODE No. | 28 (EGR SOLENOID VALVE — VACUUM) | |
|----------|---|--|
| STEP | INSPECTION | ACTION |
| 1 | Disconnect connector from ECM; is there battery positive voltage at ECM terminal 3O with ignition switch ON? | Yes Does ECM terminal connector have a poor connection? ⇨ If not, replace ECM ⇨ If it does, repair or replace the connector page F2-141 |
| | | No Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at EGR solenoid valve (vacuum) connector terminal? | Yes Repair or replace wire |
| | | No Go to next step |
| 3 | Is EGR solenoid valve (vacuum) OK? page F2-126 | Yes Look for a short or open circuit in wiring from main relay (FUEL INJ relay) to solenoid valve |
| | | No Replace EGR solenoid valve (vacuum) |


| CODE No. | 29 (EGR SOLENOID VALVE — VENT) | |
|----------|--|--|
| STEP | INSPECTION | ACTION |
| 1 | Disconnect connector from ECM; is there battery positive voltage at ECM terminal 3P with ignition switch ON? | Yes Does ECM terminal have a poor connection? ⇨ If not, replace ECM ⇨ If it does, repair or replace the connector page F2-141 |
| | | No Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at EGR solenoid valve (vent) connector terminal wire? | Yes Repair or replace wire No Go to next step |
| | | No Go to next step |
| 3 | Is EGR solenoid valve (vent) OK? page F2-126 | Yes Look for a short or open circuit in wiring from main relay (FUEL INJ relay) to solenoid valve |
| | | No Replace EGR solenoid valve(vent) |

Circuit Diagram



| CODE No. | 34 (IDLE AIR CONTROL VALVE) | | |
|----------|---|-----|--|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect connector from ECM; is there battery positive voltage at ECM terminal 3Q with ignition switch ON? | Yes | Check ECM terminal for poor connection ⇒ If OK, replace ECM ⇒ If not OK, repair or replace connector ↔ page F2-141 |
| | | No | Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at idle-up solenoid valve connector terminal? | Yes | Repair or replace wire |
| | | No | Go to next step |
| 3 | Does idle air control valve have correct resistance? ↔ page F2-99 Resistance: 10.7–12.3 Ω [at 20°C {68°F}] | Yes | Look for a short or open circuit in wiring from main relay (FUEL INJ relay) to idle air control valve |
| | | No | Replace idle air control valve |


Circuit Diagram




| CODE No. | | 41 (VRIS SOLENOID VALVE No.1) | |
|----------|--|-------------------------------|---|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect connector from ECM; is there battery positive voltage at ECM terminal 3I with Ignition switch ON? | Yes | Check ECM terminal connector for poor connection ⇒ If OK, replace ECM page F2-141 ⇒ If not OK, repair or replace connector |
| | | No | Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at VRIS solenoid valve No.1 connector terminal A? | Yes | Repair or replace wire |
| | | No | Go to next step |
| 3 | Is VRIS solenoid valve No.1 OK? page F2-103 | Yes | Look for a short or open circuit in wiring from main relay to solenoid valve |
| | | No | Replace VRIS solenoid valve No.1 |

| CODE No. | | 46 (VRIS SOLENOID VALVE No.2) | |
|----------|--|-------------------------------|---|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect connector from ECM; is there battery positive voltage at ECM terminal 3J with Ignition switch ON? | Yes | Check ECM terminal connector for poor connection ⇒ If OK, replace ECM page F2-141 ⇒ If not OK, repair or replace connector |
| | | No | Go to next step |
| 2 | In same condition as step 1, is there battery positive voltage at VRIS solenoid valve No.2 connector terminal A? | Yes | Repair or replace wire |
| | | No | Go to next step |
| 3 | Is VRIS solenoid valve No.2 OK? page F2-103 | Yes | Look for a short or open circuit in wiring from main relay (FUEL INJ relay) to solenoid valve |
| | | No | Replace VRIS solenoid valve No.2 |

Circuit Diagram





AFTER-REPAIR PROCEDURE

1. Cancel the memory of diagnostic trouble code number by disconnecting the negative battery cable and depressing the brake pedal for **at least 20 seconds**. Reconnect the negative battery cable.
2. Connect the **SST** to the data link connector.
3. Verify that no diagnostic trouble code numbers are displayed.


SWITCH MONITOR FUNCTION

Individual switches can be inspected by using the **SST** (Self-Diagnosis Checker).

Preparation

Ground the data link connector terminal TEN and turn the ignition switch to ON (engine off). If any switch remains activated, the monitor light will be illuminated.


| Switch | Self-Diagnosis Checker (Monitor light) | | Remarks |
|---------------------------------|--|----------------------------|-------------------------------|
| | Light ON | Light OFF | |
| Clutch switch (MTX) | Clutch pedal released | Clutch pedal depressed | In gear |
| Neutral switch (MTX) | In gear | Neutral | Clutch pedal released |
| Transaxle range switch (ATX) | ON | OFF | — |
| Closed throttle position switch | Accelerator pedal depressed | Accelerator pedal released | — |
| Brake switch | Brake pedal depressed | Brake pedal released | — |
| Headlight switch | ON | OFF | Headlight ON |
| DRL (CANADA) | ON | OFF | ON: parking lever released |
| Fan switch | ON | OFF | At 2nd or higher position |
| A/C switch (if equipped) | ON | OFF | Blower switch at 1st position |
| Rear window defroster switch | ON | OFF | — |




Inspection Procedure

1. Connect the **SST** (System Selector) to the data link connector.
2. Set switch A to position 1.
3. Set TEST SW to SELF TEST.
4. Connect the **SST** (Self-Diagnosis Checker) to the System Selector and a ground.
5. Set the select switch of the Self-Diagnosis Checker to position A.
6. Turn the ignition switch to ON.
7. Pull the parking brake lever.
8. Verify that the monitor light illuminates when each switch is made to function as described.


Procedure




Neutral and Clutch switches (MTX)




Transaxle range switch (ATX)




Closed throttle position switch (In throttle position sensor)




Brake switch




Headlight switch




DRL (CANADA)




Fan switch



A/C switch



Rear window defroster switch




INTAKE-AIR SYSTEM


COMPONENTS

Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to Removal Note.
2. Check the components for damage and repair or replace as necessary.
3. Install in the reverse order of removal, referring to Installation Note.




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Strut bar 2. Fresh-air duct Inspect for damage or cracks 3. Air cleaner Inspection page F2-70 4. Resonance duct Inspect for damage or cracks 5. Volume air flow sensor Inspection page F2-150 6. Air intake hose Inspect for damage | <ol style="list-style-type: none"> 7. Accelerator cable Inspection / Adjustment page F2-97 8. Throttle body Inspection page F2-96 9. Spacer Inspect for damage 10. BAC valve Inspection page F2-99 11. Intake manifold Inspection page F2-96 12. Air intake pipe Inspection page F2-96 |
|---|--|


**Removal Note****Fuel hose**

Before disconnecting the delivery pipe, release the fuel pressure from the fuel system to reduce the possibility of injury or fire.


(Refer to page F2-106)

**Water hose**

1. Before disconnecting the water hose from BAC valve, drain the coolant from the drain plug as shown in figure.
2. After installing the throttle body, fill up the coolant to the radiator.

**Installation Note****Air intake pipe**


1. Apply small amount of clean engine oil to O-rings.
2. Install the air intake pipe carefully without damaging the O-rings.
3. Tighten the bolts in the order shown in the figure.

**THROTTLE BODY****Inspection**

1. Check the throttle body for wear, coolant leakage, and deposit.
2. Verify that the throttle valve moves smoothly when the throttle lever is moved from fully closed to fully open.
3. Replace the throttle body if necessary.

Removal / Installation

(Refer to page F2-95.)


**AIR INTAKE PIPE / INTAKE MANIFOLD****Inspection**

1. Check for damage and cracks.
2. Check the air intake pipe and intake manifold contact surface for distortion as shown in the figure.
3. Replace the air intake pipe/intake manifold if necessary.


ACCELERATOR PEDAL

Removal / Inspection / Installation

1. Remove in the order shown in figure.
2. Visually check the accelerator pedal and retainer for cracks and damage. Repair or replace as necessary.
3. Install in the reverse order of removal.



- | | |
|---|--|
| 1. Accelerator cable Inspection / Adjustment below | 4. Return spring |
| 2. Retainer | 5. Accelerator pedal Inspect for damage |
| 3. Clip | |



**ACCELERATOR CABLE
Installation / Adjustment**


1. Depress the accelerator pedal fully. Check if the throttle valve is fully opened.
2. Inspect the accelerator cable play.

Play 1.0-3.0 mm {0.04-0.11in}.


3. Loosen nut (A) to adjust the play if necessary.

IDLE AIR CONTROL SYSTEM

DESCRIPTION



Idle air control system controls the bypass air amount that passes through the throttle body and improve stability, quick warm-up, idle stability and drivability. This system consists of the idle air control valve, air valve, ECM, and input devices.



SYSTEM OPERATION


1. Warm up the engine to normal operating temperature.
2. Shift the selector lever to neutral (MTX) or P (ATX).
3. Turn all electric loads OFF.
4. Connect a tachometer to the data link connector terminal IG- as shown.
5. Verify that the coolant fan is turned off.
6. Verify that the idle speed is within the specification.

Idle speed (Neutral or P range)
:640–700 rpm {670 ± 30 rpm}

7. If not within the specification, adjust the idle speed.
 (Refer to page F2–71.)
8. Verify that the idle speed is within the specification under the conditions below.

| Condition | Idle speed {rpm} |
|--------------------|------------------|
| No load | 640–700 |
| Electrical load ON | 640–700 |
| Air Conditioner ON | 720–780 |
| P/S operating | 640–700 |

9. If not as specified, check the related wiring harness, switches and sensors.



BAC VALVE

Inspection

Air valve

1. Connect the data link connector terminals TEN and GND with a jumper wire.
2. Connect a tachometer to the data link connector terminal IG-.
3. Start the engine.
4. The idle speed should decrease gradually as the engine warms up.

Idle air control valve


1. Disconnect the idle air control valve connector.
2. Measure the resistance of the idle air control valve with an ohmmeter.

Resistance: 10.7–12.3Ω (at 20°C {68°F})

3. If not as specified, replace the idle air control valve.

Removal / Installation

(Refer to page F2–95.)




VARIABLE RESONANCE INDUCTION SYSTEM (VRIS)

DESCRIPTION

The inside of the dynamic chamber is divided into two, and two shutter valves are equipped on the connecting pipes for variable resonance induction system.


This system opens and closes the shutter valves according to the engine speed to improve the charging efficiency by utilizing the pressure waves of the intake air.

There are two vacuum chambers under the left bank of the intake manifold in order to supply constant vacuum to the VRIS shutter valve actuators during wide-open throttle operation and other low-vacuum, low-speed situations.




Operation

| Engine speed (rpm) | -1,900 | 1,900-2,600 | 2,600-3,900 | 3,900-4,700 | 4,700-6,300 | 6,300- |
|-------------------------|--------|-------------|-------------|-------------|-------------|--------|
| VRIS shutter valve No.1 | closed | open | closed | open | open | closed |
| VRIS shutter valve No.2 | closed | open | closed | closed | open | closed |




SYSTEM OPERATION

1. Start the engine and run it at idle.
2. Connect a tachometer to the data link connector IG- terminal as shown.




3. Open the throttle valve.



4. Verify that the rod is pulled into the shutter valve actuator 1 and 2 when the engine speed is as shown.

Note


- The operation of the shutter valve actuator cannot be checked unless load condition while the engine speed is within 1,900–2,600 rpm as shown in the figure.



COMPONENTS

Removal / Inspection / Installation


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



7.9-10.7 N·m (80-110 kgf·cm, 69-95 in·lbf)

- | | |
|--|-------------|
| 1. VRIS solenoid valve No.1 | |
| Inspection | page F2-103 |
| 2. VRIS solenoid valve No.2 | |
| Inspection | page F2-103 |
| 3. VRIS shutter valve actuator No.1 and No.2 | |
| Inspection | page F2-103 |



- | | |
|---------------------|-------------|
| 4. Intake manifold | |
| Removal/ Inspection | |
| Installation | page F2- 95 |
| 5. Vacuum chamber | |
| Inspection | page F2-104 |
| 6. Check valve | |
| Inspection | page F2-103 |



VRIS SHUTTER VALVE ACTUATOR No.1 AND No.2

Inspection

1. Disconnect the vacuum hose from the shutter valve actuator.
2. Connect a vacuum pump tester to the actuator.
3. Apply vacuum and verify that the rod is pulled into the actuator.




VRIS SOLENOID VALVE No.1 AND No.2

Inspection


1. Disconnect the solenoid valve.
2. Verify that air flows between each port as below.

| Port | Airflow |
|------|---------|
| A-B | No |
| A-C | No |
| B-C | Yes |



3. Connect battery positive voltage and a ground to the terminals of the solenoid valve.
4. Verify that air flows between each port as below.


| Port | Airflow |
|------|---------|
| A-B | Yes |
| A-C | No |
| B-C | No |



CHECK VALVE

Inspection


1. Remove the check valve.
2. Blow through A and verify that air flows from B.
3. Blow through B and verify that air does not flow from A.

**VACUUM CHAMBER****Inspection**

1. Visually check the vacuum chamber for clogging, damage, or cracks.
2. Replace if necessary.


FUEL SYSTEM





DESCRIPTION



This system supplies the necessary fuel to the fuel injectors for combustion at a constant pressure. Fuel is metered and injected into the engine intake ports according to injection control signals from the engine control module. The system consists of the fuel tank, fuel pump, fuel filters, fuel distributor, pressure regulator, fuel injectors, and fuel pump relay.

PREPARATION SST

| | |
|---|--|
| <p>49 E018 9A0 Injector checker</p>  | <p>For inspection of fuel injector</p> |
|---|--|



Fuel Pressure and Servicing Fuel System

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.

Fuel in the fuel system is under high pressure when the engine is not running.

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the following "Fuel Line Safety Procedures".

Fuel Line Safety Procedures

A. Release the fuel pressure before disconnecting a fuel line.

1. Start the engine.
2. Remove the fuel pump relay.
3. After the engine stalls, turn the ignition switch to OFF.
4. Install the fuel pump relay.

B. Avoid leakage.





1. When disconnecting a fuel line hose, wrap a rag around it to protect against fuel leakage.
2. Plug the hose after removal.

C. Install hose clamps to secure the fuel pressure gauge to the fuel filter and the main hose.

Priming Fuel System

After the fuel pressure has been released for repairs or inspection, the system must be primed to avoid excessive cranking when the engine is first started. Follow the steps below.

1. Connect the data link connector terminals F/P and GND by using a jumper wire.
2. Turn the ignition switch to ON for approximately 10 sec. and check for fuel leaks.
3. Turn the ignition switch to OFF and remove the jumper wire.



SYSTEM OPERATION

Fuel Pressure Hold Inspection

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge as shown in the figure.
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON for 10 sec. to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Observe the fuel pressure after 5 min.

Fuel pressure:

More than 150 kPa {1.5 kgf/cm², 21 psi}

8. If not as specified, perform the following inspections.
 - Fuel pump hold pressure (Refer to page F2-111.)
 - Pressure regulator hold pressure (Refer to page F2-114.)
 - Fuel injector fuel leakage (Refer to page F2-116.)

Fuel Line Pressure Inspection

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.

1. Disconnect the negative battery cable.
2. Install a fuel pressure gauge as shown in the figure.
3. Connect the negative battery cable.

4. Connect data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON.
6. Measure the fuel line pressure.

Fuel line pressure:

260–310 kPa {2.6–3.2 kgf/cm², 37–45 psi}

- Pressure low – Measure fuel pump maximum pressure. (Refer to Page F2-110.) If as specified, the fuel line or fuel filter might be clogged or restricted.
- Pressure high – Replace the pressure regulator.


FUEL TANK

Removal / Inspection / Installation

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.
- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.
- Repairing a fuel tank that has not been properly steam cleaned can be dangerous. Explosion or fire may cause death or serious injury. Always properly steam clean a fuel tank before repairing it.

1. Remove in the order shown in the figure.
2. Inspect the fuel tank components visually and repair or replace if necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



1. Rear seat cushion

2. Fuel pump cover

3. Fuel pump connector

4. Fuel hose

Installation Note page F2-109

5. Evaporative hose

Installation Note page F2-109

6. Insulator

7. Fuel tank strap


8. Fuel tank

Inspect for cracks and corrosion

9. Protector

10. Separator

Inspect for cracks and corrosion



Installation Note

1. Push the ends of the main fuel hose, fuel return hose, and evaporative hoses onto the fuel tank fittings at least 25 mm {1.0 in}.
2. Push the fuel filler hose onto the fuel tank pipe and filler pipe at least 35 mm {1.4 in}.


FUEL FILTER

Replacement

High pressure side


The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

1. Before removing the fuel filter, release the fuel pressure from the fuel system.
2. Remove in the order shown in figure.
3. Install in the reverse order of removal.
4. Verify that the fuel hoses are pushed fully onto the fuel filter nozzles.




1. Negative battery cable
2. Fuel hose
3. Fuel pipe

4. Bracket
5. Fuel filter (High pressure side)




Low pressure side (In-tank filter)
(Refer to page F2-112.)



FUEL PUMP
Inspection
Fuel pump maximum pressure


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.



1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge to the fuel main pipe and plug the outlet of the gauge as shown. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Connect data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON to operate the fuel pump.
6. Measure the fuel pump maximum pressure.


Fuel pump maximum pressure:
500–630 kPa {5.0–6.5 kgf/cm², 72–92 psi}




7. Turn the ignition switch to OFF and disconnect the jumper wire.
8. If not as specified, replace the fuel pump.

Continuity

1. Remove the rear seat cushion.
2. Disconnect the fuel pump connector.
3. Check for continuity between the fuel pump connector terminals B and H.
4. If there is none, replace the fuel pump.





Fuel pump fuel pressure hold inspection

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.

1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and main hose.
3. Connect the negative battery cable.
4. Connect the data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON for approx. 10 sec. to operate the fuel pump.
6. Turn off the ignition switch. Wait for 5 min., and observe the fuel pressure.

Specification:

More than 150 kPa {1.5 kgf/cm², 21 psi}


7. If not as specified, replace the fuel pump.
(Refer to page F2-112.)

Disassembly / Assembly


Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F-106.

1. Remove the rear seat cushion.
2. Disassemble in the order shown in the figure.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|-------------------------------------|------------------------------------|
| 1. Fuel pump cover | 5. Fuel pump connector |
| 2. Fuel gauge sender unit connector | 6. Bracket |
| 3. Fuel hose | 7. Rubber mount |
| 4. Fuel gauge | 8. Fuel pump |
| | 9. Fuel filter (Low pressure side) |




Assembly Note

1. Do not apply excessive side force when pushing the fuel hose onto the fuel pump nipple.
2. Install the cramps as shown.



FUEL PUMP


1. After installing the fuel pump to the bracket, pull the pump down so that it is tight against the bracket.



FUEL PUMP RELAY

Replacement


1. Remove the passenger side wall.
2. Disconnect the relay connector.
3. Remove the relay from the ECM bracket.
4. Install in the reverse order of removal.



Inspection

Operation check

Listen for operational sound of the fuel pump relay while the starter operating.



Continuity

1. Check continuity between the terminals of the relay by using an ohmmeter.

B+: Battery positive voltage

| Terminal A-B | Terminal C-D |
|--------------|---------------|
| Apply B+ | Continuity |
| Not apply B+ | No continuity |


PRESSURE REGULATOR

Inspection


Fuel line pressure

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.



1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery cable.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.



Fuel line pressure:

210-260 kPa {2.1-2.7 kgf/cm², 30-38 psi}

6. Disconnect the vacuum hose from the pressure regulator and measure the fuel line pressure.

Fuel line pressure:


260-310 kPa {2.6-3.2 kgf/cm², 37-45 psi}

Hold pressure


Perform this inspection if the fuel pressure hold inspection is not as specified. (Refer to page F2-107.)

Warning

- **Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.**



1. Disconnect the negative battery cable.
2. Connect a fuel pressure gauge between the fuel filter and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery cable.




4. Connect the data link connector terminals F/P and GND by using a jumper wire.
5. Turn the ignition switch to ON for 10 sec. to operate the fuel pump.
6. Turn the ignition switch to OFF and disconnect the jumper wire.
7. Pinch the fuel delivery hose with pliers.
8. Observe the fuel pressure for 5 min.

Fuel pressure:

More than 150 kPa { 1.5 kgf/cm², 21 psi }

9. If not as specified, replace the pressure regulator.



FUEL INJECTOR

Inspection (On-vehicle)

1. Warm up the engine and run it at idle.
2. Listen for the operational sound of each fuel injector by using a screwdriver or a soundscope.

Note:


- The best way to judge the performance of a fuel injector is to compare its sound with the sound of other fuel injectors.

Removal / Installation

Warning

- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.


1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to Installation Note.



1. Negative battery cable
2. Air intake hose
3. Fuel injector connector
4. Fuel hose
5. Vacuum hose
6. Fuel distributor (Right bank)
7. Fuel distributor (Left bank)

8. Harness
9. Spacer
10. Fuel injector
11. Insulator
12. Pressure regulator



Inspection page F2-114



Installation Note


Fuel Injector

1. Use new O-rings.
2. Apply a small amount of clean engine oil to the O-rings before installing them.
3. Check the inside of the fuel distributors for fuel deposits, and clean them with gasoline if necessary.
4. Fit the fuel injector squarely into the fuel distributor, and gradually screw and install it.
5. Fit the injector tab into the fuel distributor notch.
6. Install the harness in the reverse order of removal.




Fuel leakage test

1. Install the fuel hoses shown in the figure.








2. Connect the data link connector terminals F/P and GND by using a jumper wire.
3. Turn the ignition switch to ON and check for fuel leaks from the fuel distributor.
4. If fuel leaks, check the fuel injector O-ring and fuel distributor.



Fuel distributor

1. Use new injector insulators.
2. Install the insulators, making sure that each is pressed in fully, and that it is not twisted or bent. Incorrectly installed insulators can cause rough idle.



Inspection

Note

- It is not necessary to remove the fuel injectors to perform the following procedures.

Fuel injector resistance

1. Disconnect the fuel injector connectors as shown in the figure.
2. Measure the resistance of the fuel injector with an ohmmeter.

| Harness | Terminal | Injector No. |
|------------|----------|--------------|
| Right bank | a-b | 1 |
| | a-c | 5 |
| | a-d | 3 |
| Left bank | d-c | 2 |
| | d-b | 4 |
| | d-a | 6 |

Resistance: 12-16 Ω [20°C {68°F}]

3. If not as specified, check the connectors for continuity and poor connection.
4. If the harness is OK, replace the fuel injector.


Fuel leakage test

1. Remove the fuel injector together with fuel distributor from intake manifold as shown in figure.
2. Connect the fuel hose and fuel return hose.

3. Connect the data link connector terminals F/P and GND by using a jumper wire.
4. Turn the ignition switch to ON and check for fuel leaks from the fuel injector.

Fuel leakage: Less than 1 drop/2 min.


5. If not as specified, check the fuel injector O-ring and fuel distributor contact face.
6. Install the fuel injector.
7. Turn the ignition switch to ON and check for fuel leaks from the fuel injector.
8. If not as specified, replace the fuel injector.

**Volume Test**

1. Remove the fuel injectors together with the fuel distributor.
2. Connect the **SST** as shown in figure.

Warning

- Fuel vapor is hazardous. It can very easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel.



3. Check the injection volume with a graduated container.

Injection volume


32–40 cc {1.95–2.44 cu. in} / 15 sec.

4. If not as specified, replace the fuel injector.


PRESSURE REGULATOR CONTROL SYSTEM

DESCRIPTION


To prevent percolation of the fuel during hot restart idle, vacuum to the pressure regulator is momentarily cut and the fuel injection pressure is increased to slightly more than 284 kPa {2.9 kgf/cm², 41.2 psi}. Pressure in the fuel line at idle is approx. 226 kPa {2.3 kgf/cm², 32.7 psi}.




| Operating condition | | | Operating time (sec) |
|---------------------|------------------------|-----------------------------------|----------------------|
| Coolant temperature | Intake air temperature | Engine condition | |
| Above 70°C {158°F} | Above 75°C {167°F} | Engine speed lower than 1,500 rpm | Approx. 120 |

**PRC SOLENOID VALVE****Inspection****On-vehicle**


1. Start the engine and run it at idle.
2. Disconnect the vacuum hose from the pressure regulator. Verify that vacuum is felt.



3. Ground the PRC solenoid valve terminal A with a jumper wire. Verify that no vacuum is felt.
4. If vacuum exists, check the PRC solenoid valve.

**Solenoid valve**

1. Disconnect the vacuum hose from the PRC solenoid valve and vacuum pipe.
2. Blow through the PRC solenoid valve from port A.
3. Verify that air flows from port B.



4. Disconnect the PRC solenoid valve connector.
5. Connect battery positive voltage and a ground to the terminals of the PRC solenoid valve.
6. Blow through the PRC solenoid valve from port A.
7. Verify that air flows from the valve air filter.
8. If not as specified, replace the PRC solenoid valve.

EXHAUST SYSTEM


COMPONENT PARTS

Inspection (On-vehicle)

Start the engine and verify that there is no exhaust gas leakage from the exhaust system components.

Removal / Inspection / Installation


1. Remove in the order shown in the figure.
2. Check the exhaust component parts and repair or replace as necessary.
3. Install in the reverse order of removal.



1. Main silencer
Inspect for deterioration and restriction
2. Presilencer
Inspect for deterioration and restriction
3. Three way catalytic converter
Inspect for deterioration and restriction
4. Transverse member

5. Front pipe
Inspect for deterioration and cracks
6. Exhaust manifold insulator
7. EGR pipe
Inspect for deterioration and cracks
8. Exhaust manifold
Inspect for deterioration and cracks
9. Insulator

CALIFORNIA



1. Main silencer
Inspect for deterioration and restriction
2. Presilencer
Inspect for deterioration and restriction
3. Three way catalytic converter
Inspect for deterioration and restriction
4. Transverse member

5. Front pipe
Inspect for deterioration and cracks
6. Exhaust manifold insulator
7. EGR pipe
Inspect for deterioration and cracks
8. Warm up three way catalytic converter
Inspect for deterioration and cracks
9. Insulator


OUTLINE OF EMISSION CONTROL SYSTEM

DESCRIPTION

To reduce HC (hydrocarbon) emission, the positive crankcase ventilation (PCV) system and evaporative system are adopted.

This system consists of the deceleration control system, evaporative emission control system, EGR control system, and PCV system.

The purpose of these system is to reduce CO, HC and NOx emissions.





POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

DESCRIPTION

The PCV valve is operated by the intake manifold vacuum.

When the engine is running at idle, the PCV valve is slightly open and a small amount of blowby gas is drawn into the dynamic chamber to be burned.


As the engine speed rises, the PCV valve is opened further, allowing a larger amount of blowby gas to be drawn into the dynamic chamber.







PCV VALVE

Inspection

1. Start the engine and let it idle.
2. Disconnect the PCV valve together with the ventilation hose from the cylinder head cover.
3. Block the PCV valve opening.
4. Verify that vacuum is felt.
5. Remove the PCV valve.
6. Blow through the valve from port Ⓐ and verify that air comes out from port Ⓑ.
7. Blow through the valve from port Ⓑ and verify that no air comes out from port Ⓐ.
8. Replace the PCV valve if not as specified.





SYSTEM INSPECTION

1. Connect the **SSTs** (Engine Signal Monitor and Adaptor Harness) to the ECM as shown (Refer to page F2-141.)
2. Start the engine.
3. Accelerate the engine and verify that ECM terminal 3O and 3P voltages are battery positive voltage while the engine is still cold.
4. Warm up the engine to normal operating temperature.
5. Drive the vehicle and verify that Engine Signal Monitor green and red lights flash at ECM terminals 3O and 3P.
6. Disconnect the EGR solenoid valve (Vacuum) connector.
7. Apply battery positive voltage and a ground to the solenoid valve as shown.
8. Verify that the engine runs roughly or stalls at idle.

EGR SOLENOID VALVE (VACUUM)

Inspection

1. Disconnect the vacuum hoses.
2. Blow through the vacuum hose and verify that air does not flow.
3. Disconnect the solenoid valve connector.
4. Apply battery positive voltage and a ground to the solenoid valve as shown.
5. Blow through the vacuum hose and verify that air flows.
6. If not as specified, replace the solenoid valves.

EGR SOLENOID VALVE (VENT)

Inspection

1. Disconnect the vacuum hoses.
2. Blow through the vacuum hose and verify that air flows.
3. Disconnect the solenoid valve connector.
4. Apply battery positive voltage and a ground to the solenoid valve as shown.
5. Blow through the vacuum hose and verify that air does not flow.
6. If not as specified, replace the solenoid valves.


EGR VALVE

Inspection

1. Start the engine and run it at idle.
2. Connect a vacuum pump as shown and apply vacuum.
3. Verify that the engine runs roughly or stalls at more than the specified vacuum.

Specification: 40–60 mmHg { 1.6–2.4 inHg }

4. If not as specified, replace the EGR valve.




Replacement

Plug the water hoses after disconnecting them.

1. Remove the EGR control valve in the order shown below.
 - (1) Battery and battery tray
 - (2) EGR hoses
 - (3) Vacuum hose
 - (4) EGR valve position sensor connector
 - (5) EGR valve and gasket
2. Install a new gasket, and then install the EGR valve in the reverse order of removal.

EVAPORATIVE EMISSION CONTROL SYSTEM

DESCRIPTION




The evaporative emission control system consists of the separator, check-and-cut valve, two-way check valve, charcoal canister, purge solenoid valve, engine control module (ECM), and input devices. The amount of evaporative fumes introduced into the engine and burned is controlled by the solenoid valve to correspond to the engine's operating conditions. To maintain best engine performance, the solenoid valve is controlled by the ECM.


Operation

The purge solenoid valve is controlled by duty signals from the ECM to perform purging of the charcoal canister. Purging is done when these conditions are met:


- (1) After warm-up
- (2) Driving in gear
- (3) Accelerator pedal depressed (closed throttle position switch OFF)
- (4) Heated oxygen sensor functioning normally

**SYSTEM OPERATION**


1. Warm up the engine to normal operation temperature.
2. Run the engine at idle.
3. Disconnect the vacuum hose from the purge solenoid valve.
4. Check that no vacuum's felt.




5. Disconnect the neutral switch connector. (MTX)
Position the vehicle on the chassis roller and shift the selector lever to D (ATX).



6. Connect a tachometer and increase the engine speed to 1200 rpm.
7. Check that vacuum is felt approx. 10 sec. after.


**PURGE SOLENOID VALVE****Inspection**

1. Remove the solenoid valve.
2. Blow through the solenoid valve from hose A and check that air dose not flow from B.




3. Apply battery positive voltage to solenoid valve and check that air dose flow from hose A to B.
4. If not as specified, measure the resistance of the solenoid valve.

Resistance: 23-27 Ω [20°C (68°F)]

**CHARCOAL CANISTER****Inspection**


1. Remove the charcoal canister.
2. Visually check the charcoal canister for damage or crack.
3. Blow through each port and check that air flows.

**TWO-WAY CHECK VALVE****Inspection**

1. Remove the valve.
2. Check the operation of the valve by using a vacuum pump.


| | |
|---|---------|
| Apply approx. 2.0kPa {1.5 mmHg, 0.6 in Hg} vacuum at port A | Airflow |
| Apply approx. 5.9kPa {4.4 mmHg, 1.7 in Hg} vacuum at port B | Airflow |

3. If not as specified, replace the two-way check valve.

**CHECK-AND-CUT VALVE****Inspection**

1. Remove the valve and plug port C.
2. Check operation of the valve by using a vacuum pump.

| | |
|---|---------|
| Apply approx. 1.0—4.90 kPa {7.4—36.7 mmHg, 0.3—1.44 in Hg} vacuum at port A | Airflow |
| Apply approx. 6.4—8.3 kPa {48—62mmHg, 1.9—2.4 in Hg} vacuum at port B | Airflow |


**SEPARATOR****Inspection**





1. Remove the left side trim.
2. Remove the separator.
3. Visually check the separator for damage. Replace it if necessary.

FUEL-CUT CONTROL SYSTEM

DESCRIPTION

This system is used to improve fuel economy, to prevent engine bucking during deceleration, and to protect the engine from overspeeding.





SYSTEM OPERATION

1. Connect a tachometer to the data link connector IG- terminal.
2. Connect the **SSTs** (Engine Signal Monitor and Adapter) to the ECM (Refer to page F2-141.)
3. Warm-up the engine to normal operating temperature and run it at idle.
4. Set the **SST** to terminal 3U to 3Z and make sure the green and red lights flash alternately.
5. Increase the engine speed to **4,000 rpm**; then suddenly release the throttle.
6. Verify that the red indicator light illuminates while the engine speed is above approximately **1,200 rpm (MTX)**, **1,500 rpm (ATX)** on deceleration.
7. Increase the engine speed and verify that the maximum rpm does not exceed specification.

Specifications: Approx. 7,500 rpm


Caution

- Holding the maximum rpm for more than 3 seconds can damage the engine.



CATALYTIC CONVERTER SYSTEM

DESCRIPTION

The three way catalytic converter reduces CO, HC and NOx by chemical reaction. The catalytic converter contains platinum and rhodium compounds.



CALIFORNIA



THREE WAY CATALYTIC CONVERTER Inspection

Note


- The insulator cannot be removed.

Remove the three way catalytic converter and visually check for deterioration and cracks.

ELECTRONIC SPARK ADVANCE (ESA) CONTROL SYSTEM

DESCRIPTION

The ignition timing is determined and set within ECM by signals from the various sensors and switches to obtain the best engine performance.



CONTROL SYSTEM

The ECM provides the most suitable ignition timing according to data sent from various sensors and switches.



The ignition timing is separated into two types, the basic ignition timing and the changeable ignition timing.

Ignition timing

| Engine condition | Ignition timing (BTDC) |
|------------------|---|
| Cranking | 6-8° |
| Idling | 9-11° {10 ± 1°} |
| Driving | Ignition timing advanced according to engine speed and intake manifold vacuum (calculated by engine speed and intake air amount). |

DECHOKE CONTROL SYSTEM**DESCRIPTION**

To facilitate starting the engine when the spark plugs become fouled, such as when the engine is flooded, fuel injection is cut if the throttle valve is held fully open during cranking and engine coolant temperature is 0°C {32°F} or below. This allows the spark plugs to dry and purges excess fuel from the cylinders.


**SYSTEM OPERATION**

1. Turn the ignition switch to START and verify that the fuel injector operating sound is heard.
2. Depress the accelerator pedal fully and turn the ignition switch to START. Verify that no fuel injector operating sound is heard.
3. If fuel injector operating sound is heard, check ECM terminal 1C and 2F voltages (Refer to page F2-141, 149).

A/C CUTOFF CONTROL SYSTEM


DESCRIPTION

An A/C cut-off control system is used to improve idle smoothness just after starting the engine and to improve acceleration performance.



OPERATION

| Engine condition | Purpose | Cut-off period |
|---|----------------------------------|--|
| After engine started | Improved idle smoothness | Approx. 5 sec. |
| Throttle valve fully open | Improved drivability | Approx. 5 sec. |
| Engine coolant temperature over 113°C {235°F} | Prevents engine from overheating | Cycled ON/OFF (10sec.) until engine coolant temperature reduced to 107°C {225°F} |



SYSTEM OPERATION

1. Turn the ignition switch to ON.
2. Turn the blower switch and A/C switch ON.
3. Verify that the condenser fan stops.
4. Turn the ignition switch to START and verify that the condenser fan stops for approx. 5 sec.


Note

- The magnetic clutch and the additional fan operate together.

F2 ELECTRICAL COOLANT FAN AND CONDENSER FAN CONTROL SYSTEM

ELECTRICAL COOLANT FAN AND CONDENSER FAN CONTROL SYSTEM


ELECTRICAL COOLANT FAN CONTROL



To improve engine reliability, the electric coolant fan is controlled by ECM. MX-3 models employ a LOW/HIGH control of the coolant fan. These controls operation under the conditions below.

| Engine condition | Fan relay No.1 | Fan relay No.2 | Fan relay No.3 | LOW/HIGH operation |
|---|----------------|----------------|----------------|--------------------|
| Engine coolant temperature above 100°C {212°F} | OFF | ON | OFF | LOW |
| A/C switch ON | OFF | ON | OFF | LOW |
| TEN terminal grounded and closed throttle position switch OFF | ON | ON | ON | HIGH |
| Engine coolant temperature above 108°C {226°F} | ON | ON | ON | HIGH |
| Engine coolant temperature sensor malfunction | ON | ON | ON | HIGH |


CONDENSER FAN CONTROL (A/C EQUIPPED ONLY)



To improve A/C efficiency, the condenser fan is operated at three speeds: low, medium and high. There are three relays (High No.1, No.2 and low) which control the condenser fan operation. These controls operation under the conditions below.


| Engine condition | A/C operation | A/C relay | Condenser fan low relay | Condenser fan high relay No.1 | Condenser fan high relay No.2 | Fan control operation |
|--|---------------|-----------|-------------------------|-------------------------------|-------------------------------|-----------------------|
| Engine coolant temperature below 108°C {226°F} | YES | ON | ON | OFF | OFF | LOW |
| Engine coolant temperature above 108°C {226°F} | NO | OFF | OFF | ON | ON | MEDIUM |
| Engine coolant temperature above 108°C {226°F} | YES | ON | ON | ON | ON | HIGH |
| Engine coolant temperature sensor malfunction | NO | OFF | OFF | ON | ON | MEDIUM |
| Engine coolant temperature sensor malfunction | YES | ON | ON | ON | ON | HIGH |

F2 ELECTRICAL COOLANT FAN AND CONDENSER FAN CONTROL SYSTEM



SYSTEM OPERATION








1. Connect the data link connector terminals TEN and GND by using a jumper wire.
2. Turn the ignition switch to ON.




4. Rotate the throttle link by hand and verify that the coolant fan operates.

CONTROL SYSTEM

PREPARATION
SST

| | | | |
|---|---|--|---|
| <p>49 9200 162A Engine Signal Monitor</p>  | <p>For inspection of ECM</p> | <p>49 T018 902 Adapter harness</p>  | <p>For inspection of ECM</p> |
| <p>49 H018 9A1 Self-Diagnosis Checker</p>  | <p>For inspection of heated oxygen sensor</p> | <p>49 B019 9A0 System Selector</p>  | <p>For inspection of heated oxygen sensor</p> |
| <p>49 G018 906 Sheet, 64 pin</p>  | <p>For inspection of ECM</p> | <p>49 H018 001 Wrench, knock sensor</p>  | <p>For replacement of knock sensor</p> |
| <p>49 D088 008 Harness adapter, Power</p>  | <p>For inspection of ECM</p> | | |


COMPONENTS



- | | |
|--|---|
| 1. Engine control module (ECM) Removal / Installation page F2-141 Inspection page F2-141 | 7. Heated oxygen sensor Inspection page F2-154 Removal / Installation page F2-154 |
| 2. Volume air flow sensor Inspection page F2-150 | 8. Knock sensor Removal / Installation page F2-156 |
| 3. Throttle position sensor Inspection page F2-150 Replacement page F2-151 | 9. Main relay Inspection page F2-157 |
| 4. Engine coolant temperature sensor Removal / Installation page F2-152 Inspection page F2-152 | 10. P/S pressure switch Inspection page F2-157 |
| 5. Crankshaft position sensor Inspection page F2-153 Removal / Installation page F2-153 | 11. Clutch switch Inspection page F2-157 Replacement page F2-157 |
| 6. Camshaft position sensor Inspection page F2-153 | 12. Neutral switch Inspection page F2-158 Replacement page F2-158 |
| | 13. EGR valve position sensor ... page F2-158 |


ENGINE CONTROL MODULE (ECM)**Removal / Installation**

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.




1. Negative battery cable
2. Side wall

3. Fuel pump relay
4. ECM

**Inspection**

1. Disconnect the ECM connector.
2. Connect the **SSTs** (Engine Signal Monitor and Adapter) to the ECM as shown.

Use connector A of the Adaptor to check the voltages at terminals 1A through 1V and at terminals 3A through 3Z. Use connector B to check the voltages at terminals 2A through 2P.



3. Place the **SST** (Sheet) on the Engine Signal Monitor.
4. Measure the voltage at each terminal.
(Refer to pages F2-142 through F2-149.)
5. If any ECM terminal voltage is incorrect, check the related input or output devices and wiring. If no problem is found, replace the ECM.

Terminal Voltage

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remarks |
|----------|-------|--------|------------------------------------|---|-----------------|--|
| 1A | ○ | | Battery | Constant | B+ | For backup |
| 1B | ○ | | Main relay (FUEL INJ relay) | Ignition switch OFF | 0V | — |
| | | | | ON | B+ | |
| 1C | ○ | | Ignition switch (START) | While cranking | 10V | — |
| | | | | Ignition switch ON | Below 1.0V | |
| 1D | | ○ | Data link connector (MEN terminal) | Test switch at "SELF-TEST" Light illuminated for 3 sec. after ignition switch OFF→ON | 4.5–5.5V | With Self-Diagnosis Checker and System Selector |
| | | | | Light not illuminated after 3 sec. | B+ | |
| | | | | Test switch at "O2 MONITOR" at idle Monitor light illuminated | 4.5–5.5V | |
| | | | | Test switch at "O2 MONITOR" at idle Monitor light not illuminated | B+ | |
| 1E | | ○ | Malfunction indicator lamp (MIL) | Lamp illuminated for 3 sec. after ignition switch OFF→ON | Below 2.5V | With System Selector test switch at "SELF-TEST" |
| | | | | Lamp not illuminated after 3 sec. | B+ | |
| | | | | Lamp illuminated | Below 2.5V | |
| | | | | Lamp not illuminated | B+ | |
| | | | Data link connector (FEN terminal) | Buzzer sounded for 3 sec. after ignition switch OFF→ON | Below 2.5V | <ul style="list-style-type: none"> • With Self-Diagnosis Checker and System Selector • With System Selector test switch at "SELF-TEST" |
| | | | | Buzzer not sounded after 3 sec. | B+ | |
| | | | | Buzzer sounded | Below 2.5V | |
| | | | | Buzzer not sounded | B+ | |
| 1F | — | — | — | — | — | — |
| 1G | | ○ | Ignition control module | Ignition switch ON | Approx. 0V | — |
| | | | | Idle | Approx. 0.6 | |
| 1H | ○ | | Headlight switch | Head light ON | B+ | — |
| | | | | Head light OFF | 0V | |
| 1I | ○ | | Data link connector (TEN terminal) | System Selector test switch at "O ₂ MONITOR" | B+ | <ul style="list-style-type: none"> • With Self-Diagnosis Checker and System Selector • Ignition switch ON |
| | | | | System Selector test switch at "SELF-TEST" | Below 1.0V | |
| 1J | ○ | | Rear window defroster relay | Rear window defroster switch OFF | B+ | Ignition switch ON |
| | | | | Rear window defroster switch ON | Below 1.5V | |
| 1K | | ○ | TCM | Engine coolant temperature below 60°C {140°F} | Below 1.0V | Ignition switch ON |
| | | | | Engine coolant temperature above 60°C {140°F} | B+ | |
| 1L | | ○ | A/C relay | A/C switch ON | Below 2.5V | Ignition switch ON |
| | | | | A/C switch OFF | B+ | |

B+: Battery positive voltage

| Terminal | Incorrect voltage | | Possible cause |
|----------|----------------------------------|---|--|
| 1A | Always 0V | | <ul style="list-style-type: none"> • Open circuit in wiring from Battery to ECM terminal 1A |
| 1B | Always 0V | | <ul style="list-style-type: none"> • Main relay malfunction (Refer to page F2-157) • Open or short circuit in wiring from main relay to ECM terminal 1B • ROOM 15A fuse burned |
| 1C | Always 0V (starter turns) | | <ul style="list-style-type: none"> • Open or short circuit in wiring from ignition switch to ECM terminal 1C |
| 1D | Always 0V | | <ul style="list-style-type: none"> • Main relay (FUEL INJ relay) malfunction (Refer to page F2-157) • Open circuit in wiring from ignition switch to data link connector terminal +B • Open or short circuit in wiring from data link connector terminal MEN to ECM terminal 1D |
| | Always approx. B+ | | <ul style="list-style-type: none"> • Poor connection at ECM connector • ECM malfunction |
| | Always approx. 5V | | <ul style="list-style-type: none"> • ECM malfunction |
| 1E | Always below 2.5V | MIL always ON | <ul style="list-style-type: none"> • Short circuit in wiring from instrument cluster to ECM terminal 1E • ECM malfunction |
| | | MIL never ON | <ul style="list-style-type: none"> • Open circuit in wiring from instrument cluster to ECM terminal 1E |
| | Always approx. B+ | | <ul style="list-style-type: none"> • Poor connection at ECM connector • ECM malfunction |
| | Always below 2.5V | No display on Self-Diagnosis Checker | <ul style="list-style-type: none"> • Main relay (FUEL INJ relay) malfunction (Refer to page F2-157) • Open circuit in wiring from ignition switch to data link connector terminal +B |
| | | "88" displayed and buzzer sounds continuously | <ul style="list-style-type: none"> • Open or short circuit in wiring from data link connector terminal FEN to ECM terminal 1E |
| | Always approx. B+ | | <ul style="list-style-type: none"> • Poor connection at ECM connector • ECM malfunction |
| 1F | — | | — |
| 1G | Always 0V | | <ul style="list-style-type: none"> • Short circuit in wiring from ignition control module to ECM terminal 1G |
| 1H | Always below 1.0 (Headlights OK) | | <ul style="list-style-type: none"> • Open or short circuit in wiring from headlight relay to ECM terminal 1H |
| 1I | Always below 1.0V | | <ul style="list-style-type: none"> • Short circuit in wiring from data link connector terminal TEN to ECM terminal 1I |
| | Always approx. B+ | | <ul style="list-style-type: none"> • Open circuit in wiring from data link connector terminal TEN to ECM terminal 1I • Open circuit in wiring from data link connector terminal GND to ground |
| 1J | Always 0V | | <ul style="list-style-type: none"> • Short circuit in wiring from rear window defroster switch to ECM terminal 1J |
| | Always B+ | | <ul style="list-style-type: none"> • Open circuit in wiring from rear window defroster switch to ECM terminal 1J |
| 1K | Always below 1.0V | | <ul style="list-style-type: none"> • Open or short circuit in wiring from ECM terminal 1K to TCM terminal 1N |
| 1L | Always below 2.5V | A/C does not operate | <ul style="list-style-type: none"> • A/C relay malfunction • Open circuit in wiring from ignition switch to A/C relay • Open circuit in wiring from A/C relay to ECM terminal 1L |
| | | A/C switch OFF but A/C operates | <ul style="list-style-type: none"> • Short circuit in wiring from A/C relay to ECM terminal 1L • ECM malfunction |
| | Always B+ | | <ul style="list-style-type: none"> • Poor connection at ECM connector • ECM malfunction |

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remarks |
|----------|-------|-----------|--|--|--------------------|--|
| 1M | ○ | | Vehicle speed sensor | Ignition switch ON | 0V or approx. 5.0V | — |
| | | | | Driving | Approx. 2.5V | |
| 1N | ○ | | P/S pressure switch | Ignition switch ON | B+ | — |
| | | | | P/S ON at idle | Below 1.0V | |
| | | | | P/S OFF at idle | B+ | |
| 1O | ○ | | A/C switch | A/C switch ON | 1.5–3.5V | Ignition switch ON and blower motor ON |
| | | | | A/C switch OFF | 4.5–5.5V | |
| 1P | ○ | | Fan switch | Fan speed control 2nd–4th position | Below 1.0V | Ignition switch ON and blower motor ON |
| | | | | Fan speed control 1st position or fan switch OFF | B+ | |
| 1Q | ○ | | Brake switch | Brake pedal released | Below 1.0v | — |
| | | | | Brake pedal depressed | B+ | |
| 1R | ○ | | Neutral/Clutch switch (MTX) | Neutral position or clutch pedal depressed | Below 1.0V | Ignition switch ON |
| | | | | Others | B+ | |
| | | TCM (ATX) | N or P range | Below 1.0V | — | |
| | | | Others | B+ | | |
| 1S | ○ | | TCM (ATX) | At shifting | Approx. 2.5V | — |
| | | | | Others | B+ | |
| 1T | ○ | | Throttle position sensor (Closed throttle position switch) | Accelerator pedal released | Below 1.0V | Ignition switch ON |
| | | | | Accelerator pedal depressed | B+ | |
| 1U | ○ | | Ground (MTX) | Constant | 0V | — |
| 1V | ○ | | TCM | At shifting | 0V | — |
| | | | | Others | B+ | |
| 2A | — | — | — | — | — | — |
| 2B | ○ | | Volume air flow sensor | Ignition switch ON | Approx. 4V | — |
| | | | | Idle | Approx. 2.6V | |
| 2C | ○ | | Heated oxygen sensor (RH) | Ignition switch ON | 0V | — |
| | | | | Idle (After warm-up) | 0–1.0V | |
| 2D | ○ | | Heated oxygen sensor (LH) | Acceleration (After warm-up) | 0.5–1.0V | — |
| | | | | Deceleration | 0–0.4V | |
| 2E | ○ | | Engine coolant temperature sensor | Engine coolant temperature 20°C (68°F) | Approx. 3.1V | Ignition switch ON |
| | | | | After warm-up | Approx. 0.9V | |
| 2F | ○ | | Throttle position sensor | Closed throttle position | 0.1–1.1V | Ignition switch ON |
| | | | | Wide open throttle | 2.8–4.5V | |

B+: Battery positive voltage

| Terminal | Incorrect voltage | Possible cause |
|----------|---|---|
| 1M | Always 0V | <ul style="list-style-type: none"> • Open or short circuit in wiring from speedometer to ECM terminal 1M |
| 1N | Always below 1.0V | <ul style="list-style-type: none"> • P/S pressure switch malfunction (Refer to page F2-157) • Short circuit in wiring from P/S pressure switch to ECM terminal 1N • ECM malfunction |
| | Always B+ | <ul style="list-style-type: none"> • P/S pressure switch malfunction (Refer to page F2-157) • Open circuit in wiring from P/S pressure switch to ECM terminal 1N • Open circuit in wiring from P/S pressure switch to ground |
| 1O | Always below 1.5V | <ul style="list-style-type: none"> • Short circuit in wiring from A/C amplifier to ECM terminal 1O • A/C amplifier malfunction • ECM malfunction |
| | Always 4.5–5.5V | <ul style="list-style-type: none"> • Open circuit in wiring from A/C amplifier to ECM terminal 1O • A/C amplifier malfunction |
| 1P | Always below 1.0V | <ul style="list-style-type: none"> • Short circuit in wiring from A/C amplifier to ECM terminal 1P • A/C amplifier malfunction • ECM malfunction |
| | Always B+ | <ul style="list-style-type: none"> • Open circuit in wiring from A/C amplifier to ECM terminal 1P • A/C amplifier malfunction |
| 1Q | Always below 1.0V (Stoplight OK) | <ul style="list-style-type: none"> • Open circuit in wiring from brake switch to ECM terminal 1Q |
| 1R | Always below 1.0V (Neutral/clutch switch OK) | <ul style="list-style-type: none"> • Short circuit in wiring from neutral/clutch switch to ECM terminal 1R |
| | Always B+ | <ul style="list-style-type: none"> • Open circuit in wiring from neutral/clutch switch to ECM terminal 1R |
| | Always below 1.0V (Transaxle range switch OK) | <ul style="list-style-type: none"> • Short circuit in wiring from ECM terminal 1R to TCM terminal 1D |
| | Always B+ | <ul style="list-style-type: none"> • Open circuit in wiring from ECM terminal 1R to TCM terminal 1D |
| 1S | Always 0V | <ul style="list-style-type: none"> • Open or short circuit in wiring from ECM terminal 1S to TCM terminal 2M |
| 1T | Always below 1.0 V | <ul style="list-style-type: none"> • Short circuit in wiring from throttle position sensor to ECM terminal 1T • ECM malfunction • Throttle position sensor misadjusted |
| | Always B+ | <ul style="list-style-type: none"> • Open circuit in wiring from throttle position sensor to ECM terminal 1T • ECM malfunction |
| 1U | — | — |
| 1V | Always B+ | <ul style="list-style-type: none"> • Open circuit in wiring from ECM terminal 1V to TCM terminal 1A |
| | Always 0V | <ul style="list-style-type: none"> • Short circuit in wiring from ECM terminal 1V to TCM terminal 1A |
| 2A | — | — |
| 2B | Always below 2.0 V or Approx. 4V | <ul style="list-style-type: none"> • Refer to code No. 08 Troubleshooting (Refer to page F2-80) |
| 2C | 0V after warm-up | <ul style="list-style-type: none"> • Refer to code No. 23 Troubleshooting (Refer to page F2-84) |
| | Always approx. 1V after warm-up | <ul style="list-style-type: none"> • Refer to code No. 24 Troubleshooting (Refer to page F2-86) |
| 2D | 0V after warm-up | <ul style="list-style-type: none"> • Refer to code No. 15 Troubleshooting (Refer to page F2-84) |
| | Always approx. 1V after warm-up | <ul style="list-style-type: none"> • Refer to code No. 17 Troubleshooting (Refer to page F2-86) |
| 2E | Always approx. 0V or approx. 5V | <ul style="list-style-type: none"> • Refer to code No. 09 Troubleshooting (Refer to page F2-81) |
| 2F | Always constant | <ul style="list-style-type: none"> • Open circuit in wiring from ECM terminal to throttle position sensor |
| | Always above 4V | <ul style="list-style-type: none"> • Throttle position sensor misadjusted |

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remarks | |
|----------|-------|--------|---|---|------------------------------------|-----------------------------|------------|
| 2H | ○ | | — | Constant | Approx. 5V | — | |
| | | | Ground (California) | Constant | 0V | — | |
| 2I | | ○ | Throttle position sensor Volume airflow sensor EGR valve position sensor TCM | Ignition switch ON | 5V | | |
| 2J | ○ | | EGR valve position sensor | Ignition switch ON | Approx. 0.8V | — | |
| | | | | Engine running | Approx. 0.8–4.5V | | |
| 2K | ○ | | Intake air temperature sensor (Volume air flow sensor) | Ambient air temperature 20°C (68°F) | Approx. 2.5V | Ignition switch ON | |
| 2L | ○ | | DRL relay (Canada) | Parking brake pulled with ignition switch ON (DRL OFF) | B+ | DRL: Daytime Running Lights | |
| | | | | Idle (DRL ON) | Below 2.5V | | |
| 2M* | ○ | | Knock sensor | Ignition switch ON | Approx. 0.7V | — | |
| | | | | Idle | Approx. 0.7V | | |
| 2N | — | — | — | — | — | — | |
| 2O | | ○ | Purge solenoid valve | Ignition switch ON or idle | B+ | | |
| 2P | | ○ | Coolant fan relay (ATX) | Engine coolant temp. 108°C (226°F) | Below 2V | — | |
| | | | | Others | B+ | | |
| 3A | — | — | Ground (Output) | Constant | 0V | — | |
| 3B | — | — | Ground (Fuel injector) | Constant | 0V | — | |
| 3C | — | — | Ground (CPU) | Constant | 0V | — | |
| 3D | — | — | Ground (Input) | Constant | 0V | — | |
| 3E | ○ | | Camshaft position sensor (in distributor) (SGT signal) | Ignition switch ON | Approx. 0V or 5V | — | |
| | | | | Idle | Approx. 2.5 V | | |
| 3F | ○ | | Crankshaft position sensor (Crankshaft pulley) (Ground) | Constant | 0V | — | |
| 3G | ○ | | Camshaft position sensor (in distributor) (SGC signal) | Ignition switch ON | Approx. 0V or 5V | — | |
| | | | | Idle | Approx. 2.5V | | |
| 3H | ○ | | Crankshaft position sensor (Crankshaft pulley) (NE signal) | Ignition switch ON | 0V | | |
| | | | | Idle | Approx. 0V | | |
| 3I | | ○ | VRIS solenoid valve No.1 | Engine speed 3,900–6,300 rpm | Approx. 1.2V | — | |
| | | | | Others | B+ | | |
| 3J | | ○ | VRIS solenoid valve No.2 | Engine speed 4,700–6,300 rpm | Approx. 1.2V | — | |
| | | | | Others | B+ | | |
| 3K | — | — | — | — | — | — | |
| 3L | | ○ | Coolant fan relay | Engine coolant temp. 100°C (212°F) | Below 1.0V | — | |
| | | | | Others | B+ | | |
| 3M | | ○ | PRC solenoid valve | Hot condition: Engine coolant temp. above 70°C (158°F) and intake air temp. above 75°C (158°F) for 120 sec. after engine starting | Approx. 1.2V | — | |
| | | | | Others | B+ | | |
| 3N | | ○ | Condenser fan relay | Ignition switch ON | B+ | — | |
| | | | | Idle | Engine coolant temp. 108°C (226°F) | | Below 2.0V |
| | | | | | Others | | B+ |

*: Diagnostic trouble code No. 05 may be memorized by ECM when the Engine Signal Monitor is set to position 2M.

B+: Battery positive voltage

| Terminal | Incorrect voltage | Possible cause |
|----------|---------------------------------|--|
| 2H | — | — |
| 2I | Always approx. 0V | • Short circuit in wiring from ECM |
| 2J | Always approx. 0V or approx. 5V | • Refer to code No. 16 Troubleshooting (Refer to page F2-85) |
| 2k | Always 0V | • Refer to code No. 10 Troubleshooting (Refer to page F2-82) |
| 2L | Always 0V (DRL system OK) | • Open or short circuit in wiring from DRL relay to ECM terminal 2L |
| 2M | Always 0V or B+ | • Refer to code No. 05 Troubleshooting (Refer to page F2-79) |
| 2N | — | — |
| 2O | Always 0V or approx. 5V | • Refer to code No. 26 Troubleshooting (Refer to page F2-88) |
| 2P | Always below 2V or B+ | • Open or short circuit in wiring from coolant fan relay to ECM terminal 2P • ECM malfunction |
| 3A | Above 0V | • Poor connection at ground terminal • Open circuit in wiring from ECM |
| 3B | | |
| 3C | | |
| 3D | | |
| 3E | Always approx. 0V or approx. 5V | • Refer to code No. 04 Troubleshooting (Refer to page F2-78) |
| 3F | Above 0V | • Poor connection at ground terminal • Open circuit in wiring from ECM |
| 3G | Always approx. 0V or approx. 5V | • Refer to code No. 03 Troubleshooting (Refer to page F2-77) |
| 3H | 0V | • Refer to code No. 02 Troubleshooting (Refer to page F2-76) |
| 3I | Always approx. 0V or B+ | • Refer to code No. 41 Troubleshooting (Refer to page F2-91) |
| 3J | Always approx. 0V or B+ | • Refer to code No. 46 Troubleshooting (Refer to page F2-91) |
| 3K | — | — |
| 3L | Always below 1.0V or B+ | • Open or short circuit in wiring from coolant fan relay to ECM terminal 3L • ECM malfunction |
| 3M | Always below 1.0V or B+ | • Refer to code No. 26 Troubleshooting (Refer to page F2-88) |
| 3N | Always below 2.0V | • Open or short circuit in wiring from condenser fan relay to ECM terminal 3N • ECM malfunction |

B+: Battery positive voltage


| Terminal | Input | Out-put | Connection to | Test condition | Correct voltage | Remarks |
|----------|-------|---------|-----------------------------|-----------------------------|-----------------|---|
| 3O | | ○ | EGR solenoid valve (vent) | Idle | B+ | * Engine Signal Monitor: Green and red light flash |
| | | | | Initial acceleration * | B+ | |
| 3P | | ○ | EGR solenoid valve (vacuum) | Idle | B+ | |
| | | | | Initial acceleration* | B+ | |
| 3Q | | ○ | Idle air control valve | Ignition switch ON | Approx. 7V | --- |
| | | | | Idle | Approx. 9V | |
| 3R | — | — | — | — | — | — |
| 3S | — | — | — | — | — | — |
| 3T | | ○ | Fuel pump relay | Ignition switch ON | B+ | --- |
| | | | | Idle | Below 1.0V | |
| 3U | | ○ | Fuel injector No.1 | Ignition switch ON or Idle* | B+ | * Engine Signal Monitor: Green and red lights flash |
| 3V | | ○ | Fuel injector No.2 | | | |
| 3W | | ○ | Fuel injector No.3 | | | |
| 3X | | ○ | Fuel injector No.4 | | | |
| 3Y | | ○ | Fuel injector No.5 | | | |
| 3Z | | ○ | Fuel injector No.6 | | | |

Control Unit Connector (Control Unit Side)

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 3Y | 3W | 3U | 3S | 3Q | 3O | 3M | 3K | 3I | 3G | 3E | 3C | 3A | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 3Z | 3X | 3V | 3T | 3R | 3P | 3N | 3L | 3J | 3H | 3F | 3D | 3B | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

B+: Battery positive voltage

| Terminal | Incorrect voltage | Possible cause |
|----------|-------------------------|--|
| 3O | Always 0V | • Refer to code No. 28 Troubleshooting (Refer to page F2-89) |
| 3P | Always 0V | • Refer to code No. 29 Troubleshooting (Refer to page F2-89) |
| 3Q | Always approx. 0V or B+ | • Refer to code No. 34 Troubleshooting (Refer to page F2-90) |
| 3R | — | — |
| 3S | — | — |
| 3T | Always below 1.0V | • Open or short circuit in wiring from fuel pump relay to ECM terminal 3T |
| 3U | Always 0V | <ul style="list-style-type: none"> • Open or short circuit in wiring from fuel injector to ECM terminal 3U, 3V, 3W, 3X, 3Y or 3Z • Main relay malfunction (Refer to page F2-157) |
| 3V | | |
| 3W | | |
| 3X | | |
| 3Y | | |
| 3Z | | |



VOLUME AIR FLOW SENSOR

Inspection

1. Check the volume air flow sensor body for cracks or damage.
2. Verify that the measuring core opens smoothly.
3. Measure the resistance of the sensor by using a circuit tester.

| Terminal | Resistance (Ω) |
|--|---|
| $E_2 \leftrightarrow V_S$ | 200–1,000 (Closed; 20°C {68°F}) 20–800 (Open; 20°C {68°F}) |
| $E_2 \leftrightarrow V_C$ | 200–400 (Closed \leftrightarrow Open; 20°C {68°F}) |
| $E_2 \leftrightarrow THA$ (Intake air temperature sensor) | 20°C {68°F}: 2,000–3,000 60°C {140°F}: 400–700 |

Removal / Installation


(Refer to page F2-95.)

THROTTLE POSITION SENSOR

Inspection

Idle switch


1. Turn the ignition switch to OFF and the throttle valve to the closed throttle position.
2. Disconnect the throttle position sensor connector.
3. Check continuity between the throttle position sensor terminals C and D.



Specification

| Terminals | Throttle valve closed throttle position |
|-----------|---|
| C–D | Continuity |

4. If no continuity, adjust the throttle position sensor. (Refer to page F2-151.)
5. Insert a feeler gauge of 0.5 mm {0.020 in} between the stopper and the throttle lever.
6. Verify that there is no continuity between the throttle position sensor terminals C and D.
7. If continuity, adjust the throttle position sensor. (Refer to page F2-151.)




Variable resister





1. Remove the ECM. (Refer to page F2-141.)
2. Connect the SSTs (Engine Signal Monitor and Adapter Harness) to the ECM.
3. Set the SST (Engine Signal Monitor) to position 2F.
4. Turn the ignition switch to ON.
5. Rotate the throttle link by hand and verify that voltage is within the specification.

Specification

| ECM terminal | Throttle valve position | |
|--------------|--------------------------|--------------------|
| | Closed throttle position | Wide open throttle |
| 2F | 0.1–1.1V | 2.8–4.5V |

6. If not as specified, adjust the throttle position sensor. (Refer to page F2-151.)





Adjustment

Note

- The throttle adjusting screw is set at the factory and must not be adjusted. Any adjustment will negatively effect the engine performance.

Closed throttle position switch

- Turn the ignition switch to OFF and the throttle valve to the closed throttle position.
- Disconnect the throttle position sensor connector.
- Loosen the throttle position sensor screws.
- Rotate the throttle position sensor and adjust continuity between the sensor terminals C and D as shown.

Specification

| Clearance | Continuity |
|--------------------|------------|
| 0.15 mm {0.006 in} | Yes |
| 0.50 mm {0.020 in} | No |

- Tighten the throttle position sensor screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—20 in·lbf}

Variable resistor

- Remove the ECM. (Refer to page F2-141.)
- Connect the SSTs to the ECM connector as shown.
- Verify that the throttle valve is at the closed throttle position.
- Loosen the attaching screws.
- Turn the ignition switch to ON.
- Measure the ECM terminal 2F voltage.
- Adjust the voltage to the specification.

Specification

Closed throttle position: 0.1—1.1V

Wide open throttle: 2.8—4.5V

(Verify that the voltage increase is directly proportioned to the throttle valve opening angle.)

- Tighten the attaching screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—20 in·lbf}

- If not adjusted, replace the throttle position sensor.

Replacement

- Disconnect the throttle position sensor connector.
- Remove the attaching screws.
- Remove the throttle position sensor.
- Verify that the throttle valve is at the closed throttle position.

5. Open the throttle valve slightly and catch the tang of the throttle body on the throttle position sensor plastic tabs. Adjust tang A on the throttle body with tab A on the throttle position sensor. Note tangs on the throttle body mate with the tab on the throttle position sensor on the side of the tab without a slot.
6. Position the throttle position sensor on the throttle body so that the mounting holes align.
7. Install and hand tighten the attaching screws.
8. Release the throttle.
9. Adjust the throttle position sensor output voltage and closed throttle position switch.

Replacement

1. Turn the ignition switch OFF.
2. Remove the throttle position sensor screws.
3. Remove the throttle position sensor.
4. Replace a new throttle position sensor and adjust it. (Refer to page F2-151.)
5. Tighten the throttle position sensor screws.

Tightening torque:

1.6—2.3 N·m {16—24 kgf·cm, 14—20 in·lbf}

ENGINE COOLANT TEMPERATURE SENSOR

Removal / Installation

Warning

- Removing the radiator cap or the coolant filler cap while the engine is running, or when the engine and radiator are hot is dangerous. Scalding coolant and steam may shoot out and cause serious injury. It may also damage the engine and cooling system. Turn off the engine and wait until it is cool. Even then, be very careful when removing the cap. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap – still using a cloth – turn it, and remove it.

1. Remove the radiator cap.
2. Disconnect the engine coolant temperature sensor connector.
3. Remove the engine coolant temperature sensor.
4. Install in the reverse order of removal.

Tighting torque:



16–23 N·m {1.6–2.4 kgf·m, 12–17 ft·lbf}


Inspection

1. Place the sensor in water with a thermometer and heat the water gradually.
2. Measure resistance of the sensor by using an ohmmeter.

| Coolant temperature | Resistance (k Ω) |
|---------------------|--------------------------|
| 20°C {68°F} | 2.2–2.7 |
| 80°C {176°F} | 0.29–0.35 |

3. If not as specified, replace the engine coolant temperature sensor.



**CRANKSHAFT POSITION SENSOR****Inspection**



1. Disconnect the crankshaft position sensor connector.
2. Measure the resistance between terminals A and B.

Resistance: 520–580 Ω [20°C {68°F}]


3. Replace the crankshaft position sensor if not as specified.

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the idler pulley bracket.
3. Remove the dipstick pipe.
4. Remove the crankshaft position sensor.
5. Install in the reverse order of removal.
6. Adjust the drive belt deflection. (Refer to section B2.)

**CAMSHAFT POSITION SENSOR (IN DISTRIBUTOR)****Inspection**

1. Remove the distributor. (Refer to section G.)
2. Verify that the distributor connector (3-pin) is disconnected.
3. Connect the distributor connector (6-pin) as shown in the figure.
4. Disconnect the fuel injector connector.
5. Turn the ignition switch ON.
6. Connect the SSTs (Engine Signal Monitor and Adapter Harness) to the ECM.
7. Rotate the distributor drive by hand and measure the output voltage.

**Specification**

| Terminal | Voltage |
|-----------------|-----------------------|
| 3E (SGT signal) | Approx. 5V (6 pulses) |
| 3G (SGC signal) | Approx. 5V (1 pulse) |


8. After the inspection, install the distributor. (Refer to section G.)
9. Start the engine and adjust the ignition timing. (Refer to page F2-70.)


Ignition timing: BTDC 9–11° {10 ± 1°}

10. Tighten the distributor lock bolts to the specified torque.

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}






HEATED OXYGEN SENSOR (Right bank, Left bank)

Inspection

1. Warm up the engine to normal operating temperature and run it at idle.
2. Disconnect the heated oxygen sensor connector.
3. Connect a voltmeter between the heated oxygen sensor and a ground.
4. Run the engine at 4,500 rpm until voltmeter indicates approx. 0.7V.
5. Measure the voltage while increasing and decreasing the engine speed suddenly several times.

Specification

| Engine condition | Voltage (V) |
|--------------------|-------------|
| While deceleration | Below 0.4 |
| While acceleration | Above 0.5 |




6. Connect the **SSTs** (System Selector and Self-Diagnosis Checker) to the data link connector as shown.

7. Set switch A to position 1.
8. Set TEST SW to O₂ MONITOR.

Note

- With the brake pedal depressed, the monitor lamp shows operation of the right heated oxygen sensor.
- With the brake pedal released, the monitor lamp shows operation of the left heated oxygen sensor.

9. Increase the engine speed to 2,000–3,000 rpm, and verify that the monitor light flashes for 10 sec. If not as specified, replace the heated oxygen sensor.




Heater

1. Measure resistance between terminals C and D of the heater connector.

Resistance: Approx. 13 Ω [20°C {68°F}].

2. Replace the heater if not as specified.





Replacement

1. Disconnect the heated oxygen sensor connector.
2. Remove the heated oxygen sensor.
3. Install in the reverse order of removal.

Tightening torque:

30–49 N·m {3.0–5.0 kgf·m, 22–36 ft·lbf}






KNOCK SENSOR Removal / Installation

Warning


- Fuel line spills and leaks are dangerous. Fuel can ignite and cause serious injuries or death and damage. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedures" on page F2-106.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect the fuel tank components visually and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



1. Air hose
2. Intake manifold
3. Bypass pipe


4. Water pipe
5. Knock sensor




Removal / Installation Note

Engine coolant

1. Drain the engine coolant into a container before removing the intake manifold.
2. Use the **SST** to remove / install the knock sensor.

**MAIN RELAY****Inspection****Operation check**

Listen for operational sound of the fuel pump relay while starter operating.


**Continuity inspection**

1. Check continuity between the terminals by using an ohmmeter.

B+: Battery positive voltage

| Terminal A-B | Terminal C-D |
|--------------|---------------|
| Apply B+ | Continuity |
| No Apply B+ | No continuity |


2. Replace the main relay if necessary.

**P/S PRESSURE SWITCH****Inspection**

1. Disconnect the P/S pressure switch connector.
2. Start the engine, and check continuity of the switch by using an ohmmeter.

| Steering wheel | Continuity |
|----------------|------------|
| Turned | Yes |
| Straight ahead | No |

3. Replace the P/S pressure switch if not as specified.

**CLUTCH SWITCH****Inspection**

1. Disconnect the clutch switch connector.
2. Connect the ohmmeter to the switch.
3. Check continuity of the switch.

| Pedal | Continuity |
|-----------|------------|
| Depressed | Yes |
| Released | No |


4. If not as specified, replace the clutch switch.


Replacement

1. Loosen the nuts and remove the clutch switch.
2. Install the clutch switch.
3. Adjust the clutch pedal height. (Refer to section H.)
4. Tighten the nuts to the specified torque.

Tightening torque:

14-17 N·m {1.4-1.8 kgf·m, 11-13 ft·lbf}






NEUTRAL SWITCH

Inspection

1. Disconnect the neutral switch connector shown in the figure.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

| Transaxle | Continuity |
|--------------|------------|
| Neutral | Yes |
| Other ranges | No |

4. If not as specified, replace the neutral switch.




Replacement

1. Disconnect the neutral switch connector.
2. Remove the bracket.
3. Remove the neutral switch.
4. Install in the reverse order of removal.

Tightening torque:

20–29 N·m (2.0–3.0 kgf·m, 15–21 ft·lbf)



EGR VALVE POSITION SENSOR

Inspection of Output Voltage

1. Disconnect the ECM connector.
2. Connect the SSTs (Engine Signal Monitor and Adapter) to the ECM as shown and connect a vacuum pump.
3. Turn the ignition switch to ON.
4. Measure voltage at the terminals as shown in the table.


| Terminal | ECM | Vacuum | |
|----------|-----|-----------------|---------------------|
| | | 0 mmHg (0 inHg) | 150 mmHg (5.9 inHg) |
| C | 2I | 4.5–5.5V | |
| B | 3D | Below 1.5V | |
| A | 2J | Approx. 0.7V | Approx. 4.7V |


5. If not correct at terminals A and B, check the wiring harness and terminals 2I and 3D of the ECM.
6. If not correct at terminal C, measure the sensor resistance, then the wiring harness and terminal 2F of the ECM.

Inspection of Resistance

1. Disconnect the EGR valve position sensor connector, and connect an ohmmeter.
2. Disconnect the vacuum hose from the EGR valve, and connect a vacuum pump.
3. Measure the resistance between terminals as shown in the table.

| Terminal | ECM | Vacuum | |
|----------|-------|-----------------|---------------------|
| | | 0 mmHg (0 inHg) | 150 mmHg (5.9 inHg) |
| C–B | 2I–3D | 4.6 KΩ | |
| A–B | 2J–3D | Approx. 2.3 KΩ | Approx. 5.8 KΩ |
| A–C | 2J–2I | Approx. 5.3 KΩ | Approx. 1.2 KΩ |






OSCILLOSCOPE SIGNAL PATTERN Fuel Injector Control Signal

Condition: At Idle after warm-up

Fuel injector ON time increases during warm-up, acceleration, and heavy load condition to supply fuel in relation to the engine requirement.



Idle Air Control Valve Signal

Condition: At idle after warm-up

Signal pattern changes depends on load condition.


Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

ENGINE ELECTRICAL SYSTEM

| | |
|---------------------------------------|------|
| INDEX | G- 2 |
| OUTLINE | G- 4 |
| SPECIFICATIONS | G- 4 |
| TROUBLESHOOTING GUIDE | G- 5 |
| DIAGNOSTIC INDEX | G- 5 |
| SYMPTOM TROUBLESHOOTING | G- 5 |
| CHARGING SYSTEM | G- 8 |
| PREPARATION | G- 8 |
| CIRCUIT DIAGRAM | G- 8 |
| SYSTEM INSPECTION | G- 9 |
| BATTERY | G-10 |
| GENERATOR | G-12 |
| DRIVE BELT | G-18 |
| IGNITION SYSTEM | G-20 |
| CIRCUIT DIAGRAM | G-20 |
| SYSTEM INSPECTION | G-22 |
| IGNITION TIMING | G-23 |
| HIGH-TENSION LEAD | G-24 |
| SPARK PLUG | G-25 |
| IGNITION COIL | G-26 |
| DISTRIBUTOR | G-27 |
| IGNITION CONTROL MODULE | G-32 |
| STARTING SYSTEM | G-33 |
| PREPARATION | G-33 |
| CIRCUIT DIAGRAM | G-33 |
| STARTER | G-34 |
| STARTER INTERLOCK SWITCH | G-43 |


INDEX

K8 DOHC



- | | | | |
|------------------------------------|------------|--|--|
| 1. Battery | | | |
| Inspection | page G-10 | | |
| Recharging | page G-11 | | |
| 2. Generator | | | |
| Removal / Installation | page G-13 | | |
| Disassembly / Assembly | page G-15 | | |
| Inspection | page G-16 | | |
| 3. Drive belt | | | |
| Inspection | page G-18 | | |
| Adjustment | page G-19 | | |
| Replacement | section B2 | | |
| 4. High-tension lead | | | |
| Removal / Installation | page G-24 | | |
| Inspection | page G-24 | | |
| 5. Spark plug | | | |
| Removal / Installation | page G-25 | | |
| Spark test | page G-25 | | |
| Inspection | page G-25 | | |
| 6. Ignition coil | | | |
| Inspection | page G-27 | | |
| Replacement | page G-27 | | |
| 7. Distributor | | | |
| Spark test | page G-27 | | |
| Electronic spark advance | | | |
| inspection | page G-28 | | |
| Removal / Installation | page G-29 | | |
| Disassembly / Assembly | page G-30 | | |
| Inspection | page G-31 | | |
| 8. Ignition control module | | | |
| Inspection | page G-32 | | |
| Replacement | page G-32 | | |
| 9. Starter | | | |
| Inspection (On-vehicle) | page G-34 | | |
| Removal / Installation | page G-35 | | |
| Performance inspection | page G-36 | | |
| Disassembly / Assembly | page G-37 | | |
| Inspection | page G-40 | | |
| 10. Starter interlock switch (MTX) | | | |
| Inspection | page G-43 | | |

B6 DOHC



| | | |
|------------------------------------|------------|--|
| 1. Battery | | |
| Inspection | page G-10 | |
| Recharging | page G-11 | |
| 2. Generator | | |
| Removal / Installation | page G-12 | |
| Disassembly / Assembly | page G-14 | |
| Inspection | page G-16 | |
| 3. Drive belt | | |
| Inspection | page G-18 | |
| Adjustment | page G-19 | |
| Replacement | section B1 | |
| 4. High-tension lead | | |
| Removal / Installation | page G-24 | |
| Inspection | page G-24 | |
| 5. Spark plug | | |
| Removal / Installation | page G-25 | |
| Spark test | page G-25 | |
| Inspection | page G-25 | |
| 6. Ignition coil | | |
| Inspection | page G-26 | |
| Replacement | page G-27 | |
| 7. Distributor | | |
| Spark test | page G-27 | |
| Electronic spark advance | | |
| inspection | page G-28 | |
| Removal / Installation | page G-29 | |
| Disassembly / Assembly | page G-31 | |
| Inspection | page G-31 | |
| 8. Ignition control module | | |
| Inspection | page G-32 | |
| Replacement | page G-32 | |
| 9. Starter | | |
| Inspection (On-vehicle) | page G-34 | |
| Removal / Installation | page G-34 | |
| Performance Inspection | page G-36 | |
| Disassembly / Assembly | page G-39 | |
| Inspection | page G-40 | |
| 10. Starter interlock switch (MTX) | | |
| Inspection | page G-43 | |

OUTLINE

SPECIFICATIONS

| Item | | Engine / Transaxle | | B6 DOHC | | K8 DOHC | | |
|--|-------------------------------------|-----------------------------|--------------------------------|---|---------------------|---|---|--|
| | | | | MTX | ATX | MTX | ATX | |
| Battery | Voltage | V | | 12 | | | | |
| | Type and capacity (5-hour rate A·h) | | | 55D23L (48) 50D20L (40) | | 65D23L (43) 50D20L (40) | | |
| Dark current *1 | | mA | | 20 or less | | | | |
| Generator | Type | | | A.C. | | | | |
| | Output | V-A | | 12-70 | | 12-90 | | |
| | Regulator type | | | Transistorized (built-in voltage regulator) | | | | |
| | Regulated voltage | V | | 14.1-14.7 | | | | |
| | Brush length | mm {in} | Standard | | 20.0 {0.79} | | 21.5 {0.85} | |
| | | | Minimum | | 5.0 {0.20} | | 8.0 {0.32} | |
| | Drive belt deflection | mm {in}/9.8N {10kgf, 22lbf} | New | | 5.5-7.0 {0.22-0.27} | | 5.5-6.5 {0.22-0.25} (with A/C) 6.0-7.0 {0.24-0.27} (without A/C) | |
| Used | | | | 6.0-7.5 {0.24-0.29} | | 6.5-7.5 {0.26-0.29} (with A/C) 7.0-8.0 {0.28-0.31} (without A/C) | | |
| Starter | Type | | | Direct | | Coaxial reduction | Eccentric reduction | |
| | Output | V-kW | | 12-0.8 | | 12-1.4 12-1.7*3 | 12-1.4 12-1.6*3 | |
| | Brush length | mm {in} | Standard | | 16 {0.7} | | 17.5 {0.69} | |
| | | | Minimum | | 10 {0.4} | | 12 {0.5} | |
| Distributor | Spark advance type | | Electronic spark advance (ESA) | | | | | |
| Ignition timing (TEN terminal of data link connector grounded) | | BTDC | | 10° | | | | |
| Ignition coil | Resistance [at 20°C {68°F}] | Primary coil winding | Ω | 0.49-0.73 | | | | |
| | | Secondary coil winding | kΩ | 20-31 | | | | |
| Spark plug | Type | NGK | | BKR5E-11 *2 BKR6E-11 | | | | |
| | | NIPPON-DENSO | | K16PR-U11 *2 K20PR-U11 | | | | |
| Plug gap | | mm {in} | | 1.0-1.1 {0.040-0.043} | | | | |
| Firing order | | | | 1-3-4-2 | | 1-2-3-4-5-6 | | |

*1 Dark current is the constant flow of current present when the ignition switch is OFF (i.e., audio unit, clock, etc.).

*2 Standard plug



*3 Cold area

TROUBLESHOOTING GUIDE


DIAGNOSTIC INDEX


| No. | Troubleshooting Items | Page |
|-----|--|-------|
| 1 | Will not crank—starter motor does not operate | below |
| 2 | Will not crank—starter motor spins | below |
| 3 | Cranks slowly | G-6 |
| 4 | Generator warning light illuminates while engine running | G-6 |
| 5 | Discharged battery | G-6 |
| 6 | Misfire | G-7 |

SYMPTOM TROUBLESHOOTING


| 1 | | Will not crank—starter motor does not operate | |
|------|--|---|---|
| STEP | INSPECTION | ACTION | |
| 1 | Does engine crank with fully charged battery? | Yes | Check charging system page G-9 |
| | | No | Go to next step |
| 2 | Starter interlock switch OK? (MTX) | Yes | Go to next step |
| | | No | Check starter interlock switch page G-43 |
| 3 | Is battery positive voltage present at terminal B?  | Yes | Go to next step |
| | | No | Check wiring harness |
| 4 | Is battery positive voltage present at terminal S with ignition switch in START position?  | Yes | <ul style="list-style-type: none"> • Check magnetic switch page G-40 • Check yoke page G-41 • Check armature page G-41 |
| | | No | <ul style="list-style-type: none"> • Check transaxle range switch (ATX) section K • Check ignition switch • Check wiring harness |

G

| 2 | | Will not crank—starter motor spins | |
|------|--|------------------------------------|---|
| STEP | INSPECTION | ACTION | |
| 1 | Is drive pinion pushed out while cranking (click is heard when pushed out)?  | Yes | Remove starter and check flywheel ring gear teeth and starter drive pinion teeth |
| | | No | <ul style="list-style-type: none"> • Check magnetic switch page G-40 • Check yoke page G-41 |

| 3 Cranks slowly | | | |
|-----------------|---|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Does engine crank normally with fully charged battery? | Yes | Check charging system page G-9 |
| | | No | Go to next step |
| 2 | Are starter cable connections loose or corroded?  | Yes | Repair or replace connection |
| | | No | Check starter for binding (brush, armature, etc.) |

| 4 Generator warning light illuminates while engine running | | | |
|--|---|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Is battery positive voltage correct at idle? Specification: 14.1–14.7V | Yes | Check wiring harness between generator terminal L and generator warning light |
| | | No | Check charging system page G-9 |

| 5 Discharged battery | | | |
|----------------------|---|-----|---|
| STEP | INSPECTION | | ACTION |
| 1 | Check charging system; is it OK? page G-9 | Yes | Turn ignition switch off and measure dark current as shown  Dark current: Below 20mA |
| | | No | Repair or replace parts as necessary |

B+: Battery positive voltage


| 6 | | Misfire | |
|------|---|---------|---|
| STEP | INSPECTION | | ACTION |
| 1 | Disconnect high-tension lead from each spark plug. Does strong blue spark occur while cranking? | Yes | Check spark plugs ↗page G-26 |
| | | No | Go to next step |
| 2 | Are resistance of high-tension leads OK? Specification: 16 kΩ per 1 m (3.28 ft) [at 20°C (68°F)] ↗page G-24 | Yes | Go to next step |
| | | No | Replace high-tension leads |
| 3 | Are there corrosion, damage, or cracks on the distributor cap and rotor? ↗page G-31 | Yes | Replace cap or rotor |
| | | No | Go to next step |
| 4 | Is ignition coil normal? ↗page G-26 | Yes | Go to next step |
| | | No | Replace distributor |
| 5 | Are distributor connector and PCM or ECM connector connected? | Yes | Go to next step |
| | | No | Connect connectors |
| 6 | Measure voltage at terminal A (3-pin) of distributor (harness side connector); is it correct? Voltage: B+ (Ignition switch ON) | Yes | Go to next step |
| | | No | Check main fuse, ignition switch and wiring harness |
| 7 | Is PCM or ECM normal? | Yes | Replace distributor |
| | | No | Replace PCM or ECM |

G


CHARGING SYSTEM

PREPARATION

SST

| | | |
|------------------------------|---|--------------------------------------|
| 49 9200 020A |  | For inspection of drive belt tension |
| Tension gauge, V-ribbed belt | | |

CIRCUIT DIAGRAM





The generator has a self-diagnostic function to warn the operator of the following problems in the charging system. If a problem arises, the generator warning light illuminates.

1. Terminal S circuit open
2. No voltage output
3. Field coil circuit open
4. Terminal B circuit open
5. Voltage output too high

SYSTEM INSPECTION

B+: Battery positive voltage

| STEP | INSPECTION | | ACTION | | | | | | | | | | | | |
|------|---|-----------|---|----------|---|----|-----------|---|-----------|-----------|---|----|-----------|-----|---|
| 1 | Check battery positive voltage; is it correct? Specification: Above 12.4V | Yes | Go to next step | | | | | | | | | | | | |
| | | No | Check battery page G-10 | | | | | | | | | | | | |
| 2 | Turn ignition switch on; does generator warning light illuminate? | Yes | Go to step 3 | | | | | | | | | | | | |
| | | No | Check generator warning light bulb and wiring harness between warning light and terminal L | | | | | | | | | | | | |
| 3 | Start engine; does generator warning light go out? | Yes | Go to step 5 | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |
| 4 | Is voltage at generator terminals correct? Specification: <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Terminal</th> <th>Ign : ON (V)</th> <th>Idle (V)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;">B+</td> <td style="text-align: center;">14.1-14.7</td> </tr> <tr> <td style="text-align: center;">L</td> <td style="text-align: center;">Approx. 1</td> <td style="text-align: center;">14.1-14.7</td> </tr> <tr> <td style="text-align: center;">S</td> <td style="text-align: center;">B+</td> <td style="text-align: center;">14.1-14.7</td> </tr> </tbody> </table> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>B6 DOHC</p> </div> <div style="text-align: center;">  <p>K8 DOHC</p> </div> </div> | Terminal | Ign : ON (V) | Idle (V) | B | B+ | 14.1-14.7 | L | Approx. 1 | 14.1-14.7 | S | B+ | 14.1-14.7 | Yes | Check wiring harness between battery and terminal B |
| | | Terminal | Ign : ON (V) | Idle (V) | | | | | | | | | | | |
| B | B+ | 14.1-14.7 | | | | | | | | | | | | | |
| L | Approx. 1 | 14.1-14.7 | | | | | | | | | | | | | |
| S | B+ | 14.1-14.7 | | | | | | | | | | | | | |
| No | <ul style="list-style-type: none"> • Check wiring harness • Replace generator page G-12 | | | | | | | | | | | | | | |
| 5 | 1. Connect an ammeter (90A min.) between terminal B and harness 2. Start engine and turn all electrical loads OFF. 3. Hold engine speed at 2,500-3,000 rpm. 4. Does output current increase when electrical loads are applied? Caution • Grounding terminal B can damage generator internal circuit | Yes | Charging system normal | | | | | | | | | | | | |
| | | No | Go to next step | | | | | | | | | | | | |
| 6 | Is drive belt tension OK? page G-18 | Yes | Replace generator page G-12 | | | | | | | | | | | | |
| | | No | <ul style="list-style-type: none"> • Adjust drive belt tension • Replace drive belt | | | | | | | | | | | | |

G

BATTERY

Inspection


Battery discharge test

Warning

- Hydrogen gas is produced during normal battery operation. A battery-related explosion can cause serious injury. Keep all flames (including cigarettes), heat, and sparks away from the top and surrounding area of open battery cells.

Caution

- To prevent damage to electrical components or the battery, turn all accessories off and stop the engine before performing maintenance or recharging the battery.




Test load

| Battery | Load (A) |
|---------|----------|
| 50D20L | 150 |
| 55D23L | 180 |
| 65D23L | 165 |


Battery positive voltage with load

| Approximate battery temp. | Minimum voltage (V) |
|---------------------------|---------------------|
| 21°C {70°F} | 9.6 |
| 15°C {60°F} | 9.5 |
| 10°C {50°F} | 9.4 |
| 4°C {40°F} | 9.3 |
| -1°C {30°F} | 9.1 |
| -7°C {20°F} | 8.9 |
| -12°C {10°F} | 8.7 |
| -18°C {0°F} | 8.5 |



Terminal and cable

1. Check the tightness of the terminals to ensure good electrical connections.
2. Check for corroded or frayed battery cables.
3. Check the rubber protector on the positive terminal for proper coverage.
4. Clean the terminals if necessary, and coat them with grease.



Recharging

Warning

- Hydrogen gas is produced during normal battery operation. A battery-related explosion can cause serious injury. Keep all flames (including cigarettes), heat, and sparks away from the top and surrounding area of open battery cells.

Caution

- To prevent damage to electrical components or the battery, turn all accessories off and stop the engine before performing maintenance or recharging the battery.
- When disconnecting the battery, remove the negative cable first and install it last to prevent damage to electrical components or the battery.
- Do not quick charge for over 30 minutes. It will damage the battery.

| Battery | Slow charge (A) | Quick charge (A) |
|---------|-----------------|------------------|
| 50D20L | 4.0-5.0 | 25 |
| 55D23L | 4.5-5.5 | 30 |
| 65D23L | | |

Slow charging

It is not necessary to remove the vent caps to perform a slow charge.

Quick charging

Remove the battery from the vehicle and remove the vent caps to perform a quick charge.

Place the battery in a pan of water to prevent it from overheating. The water level should come up about halfway on the battery. Keep water off of the top of the battery.

GENERATOR

Removal / Installation

Warning

- When the battery cables are connected, touching the vehicle body with generator terminal B will generate sparks. This can cause personal injury, fire, and damage to the electrical components. Always disconnect the battery before performing the following operation.

Caution


- Reversing the battery connections or using high-voltage testers will damage the rectifier.
- Do not start the engine while the connector is disconnected from terminals L and S. It can damage the generator.

Note

- Battery positive voltage is always present at generator terminal B when the battery is connected.

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Inspect all parts and repair or replace as necessary.
4. Install in the reverse order of removal.


B6 DOHC



1. Connector
2. Generator terminal B wire
Inspect for damage and corrosion

3. Drive belt
 Inspection page G-18
 Adjustment page G-19
 Replacement section B1
4. Generator
 Disassembly / Assembly page G-14
 Inspection page G-16

K8 DOHC




1. Fresh-air duct
2. Radiator upper bracket
3. Condenser fan (if equipped)
4. Generator terminal B wire
Inspect for damage and corrosion
5. Connector

6. Splash shield
7. Belt tensioner
8. Drive belt
Inspection page G-18
Adjustment page G-19
Replacement section B2
9. Generator
Disassembly / Assembly page G-15
Inspection page G-16

Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly / Assembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Disassembly / Assembly Note**.


B6 DOHC



- 1. Pulley
- 2. Front bracket
- 3. Rotor
Inspection page G-16
- 4. Rear bracket
Disassembly / Assembly Note . page G-15
- 5. Stator
Disassembly / Assembly Note . page G-15
Inspection page G-16


- 6. Rectifier
Disassembly / Assembly Note . page G-15
Inspection page G-17
- 7. Brush holder assembly
Disassembly / Assembly Note . page G-15
Inspection
(Brush and brush spring) page G-17
- 8. Bearing
Inspection page G-16

K8 DOHC



- 1. Pulley
- 2. Front bracket
- 3. Rotor
Inspection page G-16
- 4. Rear bracket
Assembly / Disassembly Note below
- 5. Stator
Assembly / Disassembly Note below
Inspection page G-16

- 6. Rectifier
Assembly / Disassembly Note below
Inspection page G-17
- 7. Brush holder assembly
Assembly / Disassembly Note below
Inspection
(Brush and brush spring) page G-17
- 8. Bearing
Inspection page G-16




Disassembly / Assembly Note
Rear bracket, Stator lead wire

Use a soldering iron to remove the solder from the rear bracket and the stator lead wire.

Caution

- The rectifier can be damaged when overheated. Do not hold the soldering gun to the rectifier contact for more than 5 seconds.




Brush holder


Use a soldering iron to remove the solder from the brush holder.

Caution


- The rectifier can be damaged when overheated. Do not hold the soldering gun to the rectifier contact for more than 5 seconds.

**Inspection****Rotor**


1. Check continuity between the slip rings with an ohmmeter.
2. Replace the rotor if there is no continuity.




3. (1) Check continuity between each slip ring and the core with an ohmmeter.
- (2) Replace the rotor if there is continuity.
4. Check if the slip ring surface is rough. Use fine sandpaper to repair it if necessary.

**Stator**





1. Check continuity between the stator coil leads with an ohmmeter.
2. Replace the stator if there is no continuity.



3. Check continuity between the stator coil leads and the core with an ohmmeter.
4. Replace the stator if there is continuity.

**Bearing**

1. Check for abnormal noise, looseness, and sticking.
2. Replace the bearing(s) if necessary.



Rectifier

1. Check continuity of the diodes with an ohmmeter.

| Negative | Positive | Continuity |
|----------------|----------------|------------|
| E | Pn, P1, P2, P3 | Yes |
| B | | No |
| T | | No |
| Pn, P1, P2, P3 | E | No |
| | B | Yes |
| P1, P2, P3 | T | Yes |
| Pn | | No |

2. Replace the rectifier if not as specified.

Brush


If a brush is worn almost to or beyond the limit, replace all the brushes.

- Standard:** 21.5 mm {0.85 in} (K8 DOHC)
20.0 mm {0.79 in} (B6 DOHC)
- Minimum:** 8.0 mm {0.32 in} (K8 DOHC)
5.0 mm {0.20 in} (B6 DOHC)

Brush spring

1. Using a spring pressure gauge, measure the brush spring pressure with the brush tip projecting 2 mm {0.079 in}.
2. Replace the spring if necessary.

- Standard force:**
3.2–4.3 N {0.32–0.44 kgf, 0.71–0.96 lbf} (K8 DOHC)
4.7–5.8 N {0.47–0.60 kgf, 1.04–1.29 lbf} (B6 DOHC)
- Minimum:**
1.6–2.3 N {0.16–0.24 kgf, 0.36–0.52 lbf} (K8 DOHC)
2.4–3.1 N {0.24–0.32 kgf, 0.53–0.70 lbf} (B6 DOHC)




DRIVE BELT

Inspection

1. Check the drive belts and pulleys for wear, cracks, and fraying. Replace if necessary.
2. Measure the drive belt tension with a **SST**, and measure the deflection by applying moderate pressure 98 N {10 kgf, 22 lbf} midway between the pulleys. Adjust the belt if necessary.


Tension (B6 DOHC)

| Drive belt | N {kgf, lbf} | | |
|-------------------|-----------------------------|-----------------------------|-----------------|
| | New* | Used | Limit |
| Generator | 500-740 {50-76, 110-160} | 500-700 {50-72, 110-150} | 340 {35, 77} |
| P/S, P/S + A/C | 500-580 {50-60, 110-130} | 430-490 {43-50, 95-110} | 250 {25, 55} |
| A/C | 500-580 {50-60, 110-130} | 430-490 {43-50, 95-110} | 250 {25, 55} |




Deflection (B6 DOHC)

| Drive belt | mm {in} | | |
|-------------------|------------------------|-------------------------|----------------|
| | New* | Used | Limit |
| Generator | 5.5-7.0 {0.22-0.27} | 6.0-7.5 {0.24-0.29} | 8.0 {0.31} |
| P/S, P/S + A/C | 8.0-9.0 {0.32-0.35} | 9.0-10.0 {0.36-0.39} | 11.5 {0.45} |
| A/C | 8.0-9.0 {0.32-0.35} | 9.0-10.0 {0.36-0.39} | 11.5 {0.45} |




Tension (K8 DOHC)

| Drive belt | N {kgf, lbf} | | |
|--------------------|-----------------------------|-----------------------------|-----------------|
| | New* | Used | Limit |
| Generator | 690-880 {70-90, 160-190} | 500-680 {50-70, 110-150} | 440 {45, 99} |
| Generator + A/C | 690-880 {70-90, 160-190} | 500-680 {50-70, 110-150} | 440 {45, 99} |
| P/S | 540-680 {55-70, 130-150} | 400-540 {40-55, 88-120} | 340 {35, 77} |




Deflection (K8 DOHC)

| Drive belt | mm {in} | | |
|--------------------|------------------------|------------------------|---------------|
| | New* | Used | Limit |
| Generator | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} | 9.0 {0.35} |
| Generator + A/C | 5.5-6.5 {0.22-0.25} | 6.5-7.5 {0.26-0.29} | 8.0 {0.32} |
| P/S | 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} | 9.0 {0.35} |



*: A belt that has been on a running engine for less than five minutes.




**Adjustment
B6 DOHC**

1. Loosen the generator mounting bolt and adjusting bolt.
2. Tighten the generator adjusting bolt.
3. Tighten the generator mounting bolts and recheck the tension.


Tightening torque

Mounting bolt:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}



4. If adjustment is not possible, replace the drive belt.
(Refer to section B1.)



K8 DOHC


1. Loosen tensioner lock nut (A).
2. Tighten adjuster bolt (B).
3. Tighten tensioner lock nut (A).

Tightening torque

(A): 32–46 N·m {3.2–4.7 kgf·m, 24–33 ft·lbf}



4. If adjustment is not possible, replace the drive belt.
(Refer to section B2.)

B6 DOHC







SYSTEM INSPECTION

B+: Battery positive voltage

| STEP | INSPECTION | ACTION | |
|------|--|--------|---|
| 1 | Disconnect high-tension lead from each spark plug. Does strong blue spark occur while cranking engine?  ↗page G-25 | Yes | • Check spark plugs ↗page G-25 ⇨ Ignition system normal |
| | | No | Go to next step |
| 2 | Are resistance of high-tension leads OK? ↗page G-24 Specification: 16 kΩ per 1 m {3.28 ft} [at 20°C {68°F}] | Yes | Go to next step |
| | | No | Replace high-tension leads |
| 3 | Are there corrosion, damage or cracks on distributor cap and rotor? ↗page G-31 | Yes | Replace cap and rotor |
| | | No | Go to next step |
| 4 | Is ignition coil OK? ↗page G-26 | Yes | Go to next step |
| | | No | Replace distributor |
| 5 | Are distributor connector and PCM or ECM connector connected? | Yes | Go to next step |
| | | No | Connect connectors |
| 6 | Measure voltage at terminal A (3-pin) of distributor (harness side connector). Is it correct? Voltage: B+ (ignition switch ON)  | Yes | Go to next step |
| | | No | Check main fuse, ignition switch and wiring harness |
| 7 | Is PCM or ECM normal? | Yes | Replace distributor |
| | | No | Replace PCM or ECM |

IGNITION TIMING**Adjustment**

1. Warm up the engine to normal operating temperature and run it at idle (P range [ATX] or neutral [MTX]).
2. Turn all electrical loads OFF.
3. Turn the A/C switch OFF.
4. Verify that the coolant fan does not operate.

**K8 DOHC**

1. Connect a tachometer to the data link connector terminal IG-. Connect a timing light as shown.

2. Connect the data link connector terminals TEN and GND with a jumper wire.

3. Check the idle speed.

Specification: 550–950 rpm

4. If necessary, adjust the idle speed. (Refer to section F2.)

5. Check the ignition timing.

Ignition timing: BTDC 9–11° (10 ± 1°)

6. If the ignition timing is not as specified, loosen the distributor lock bolts and turn the distributor to make the adjustment.

7. Tighten the distributor lock bolts to the specified torque.




Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

8. Disconnect a jumper wire.

9. Check if the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition timing: BTDC 6–18°

**B6 DOHC**

1. Connect a tachometer to the data link connector terminal IG-. Connect a timing light as shown.

2. Connect the data link connector terminals TEN and GND with a jumper wire.
3. Check the idle speed.

Specifications (Neutral): 650–750 (700 ± 50) rpm[MTX]
(P range): 700–800 (750 ± 50) rpm[ATX]

4. If necessary, adjust the idle speed. (Refer to section F1.)
5. Check the ignition timing.


Ignition timing: BTDC 9–11° (10 ± 1°)

6. If the ignition timing is not as specified, loosen the distributor lock bolts and turn the distributor to make the adjustment.
7. Tighten the distributor lock bolts to the specified torque.

Tightening torque:
 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

8. Disconnect a jumper wire.
9. Check if the timing mark (yellow) on the crankshaft pulley and the mark on the timing belt cover are aligned.

Ignition timing: 6–18°

**HIGH-TENSION LEAD
Removal / Installation****Caution**





- Reinstall the high-tension leads to their original positions. Incorrect installation can damage the leads and cause power loss, and negatively effect electronic components.

Inspection

1. Measure resistance of the high-tension leads.

Specification: 16 k Ω per 1 m {3.28 ft} [at 20°C {68°F}]

- If not as specified, replace the high-tension lead.



SPARK PLUG

Removal / Installation

- Remove and install the high-tension leads carefully.

Caution

- Pulling on the wire part of the spark plug lead may break it. To remove the lead, pull only on the boot.

- Remove and install the spark plug with a plug socket.

Caution

- To avoid breaking the spark plug, be sure to fit the socket squarely over it.

- Apply anti-seize compound or molybdenum-based lubricant to the spark plug threads.
- Tighten the spark plug to the specified torque.

Tightening torque:


15–22 N·m {1.5–2.3 kgf·m, 11–16 ft·lbf}

Spark Test

Warning

- High voltage in the ignition device system can cause strong electrical shock. Avoid direct contact to the vehicle body during the following spark test.

- Remove the spark plug.
- Connect the spark plug to a high-tension lead.
- Hold the high-tension lead with insulated pliers 5–10 mm {0.20–0.39 in} from a ground.
- Crank the engine and verify that there is a strong blue spark. If not, replace the spark plug or high-tension lead as necessary.

**Inspection**


Check the following points. If a problem is found, replace the spark plug.

- Damaged insulation
- Worn electrodes
- Carbon deposits

If cleaning is necessary, use a plug cleaner or a wire brush. Clean the upper insulator also.

- Damaged gasket
- Burnt condition


Plug gap: 1.0–1.1 mm {0.040–0.043 in}

**IGNITION COIL****Inspection****(B6 DOHC)****Primary coil winding**

1. Disconnect the 3-pin connector from the distributor.
2. Use an ohmmeter and measure resistance of the primary coil winding.

Specification: 0.49–0.73 Ω [at 20°C {68°F}]

3. If not within the specification, replace the distributor.

**Secondary coil winding**


1. Disconnect the 3-pin connector from the distributor.
2. Remove the distributor cap.
3. Use an ohmmeter and measure resistance of the secondary coil winding.

Specification: 20–31 k Ω [at 20°C {68°F}]

4. If not within the specification, replace the distributor.

Replacement


1. Replace the distributor. (Refer to page G-29.)
2. Adjust the ignition timing. (Refer to page G-24.)

**(K8 DOHC)****Primary coil winding**

1. Disconnect the 3-pin connector from the distributor.
2. Use an ohmmeter and measure resistance of the primary coil winding.

Specification: 0.49–0.73 Ω [at 20°C {68°F}]

3. If not within the specification, replace the distributor.

**Secondary coil winding**


1. Disconnect the 3-pin connector from the distributor.
2. Remove the distributor cap.
3. Use an ohmmeter and measure resistance of the secondary coil winding.

Specification: 20–31 k Ω [at 20°C {68°F}]

4. If not within the specification, replace the distributor.


Replacement

1. Replace the distributor. (Refer to page G-29.)
2. Adjust the ignition timing. (Refer to page G-23.)


**DISTRIBUTOR****Spark Test****Warning**

- High voltage in the ignition device system can cause strong electrical shock. Avoid direct contact to the vehicle body during the following spark test.

1. Disconnect the high-tension lead from a spark plug.
2. Hold the lead with insulated pliers 5–10 mm {0.20–0.39 in} from a ground.
3. Crank the engine and verify that a strong blue spark is visible.

**Electronic Spark Advance Inspection**


Verify that the ignition timing advances with engine acceleration.




Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Adjust the ignition timing. (Refer to page G-23.)

K8 DOHC



B6 DOHC




1. Resonance duct (K8)
2. High-tension lead
Inspection page G-24
3. Connector

4. Distributor
Disassembly / Assembly page G-30
Inspection page G-31

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.


K8 DOHC



- 1. Cap
Inspection page G-31
- 2. Rotor
Inspection page G-31


- 3. Packing
- 4. Distributor

B6 DOHC




- 1. Cap
Inspection below
- 2. Rotor
Inspection below

- 3. Cover
- 4. Packing
- 5. Distributor



Inspection
Cap and rotor
B6 DOHC

- 1. Check for corrosion, damage, and cracks.
- 2. Replace if necessary.



K8 DOHC

- 1. Check for corrosion, damage, and cracks.
- 2. Replace if necessary.

IGNITION CONTROL MODULE**Inspection**


1. Check the PCM or ECM. (Refer to sections F1, F2.)
2. Check the condition of the connector, distributor, ignition coil, and high-tension leads.
3. If all are normal but misfire still occurs, replace the distributor.

Replacement


1. Replace the distributor. (Refer to page G-29.)
2. Adjust the ignition timing. (Refer to page G-23.)

STARTING SYSTEM


PREPARATION
SST

| | | |
|---------------------------------------|---|---|
| <p>49 E301 144 Removing plate</p> |  | <p>For installation of overrunning clutch</p> |
|---------------------------------------|---|---|

CIRCUIT DIAGRAM



Note
 • K8 DOHC uses a reduction starter.



STARTER

Inspection (On-vehicle)

1. Measure the battery positive voltage.


Specification: Above 12.4V

2. Crank the engine, and verify that the starter turns smoothly.
3. If the starter does not turn, check the voltage of terminal S.
4. If the voltage is more than 8V, remove and inspect the starter. If the voltage is less than 8V, check the wiring harness, ignition switch, starter interlock switch (MTX) and transaxle range switch (ATX).

Removal / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.


B6 DOHC



1. Battery
2. Intake manifold bracket
3. Terminal S wire
4. Terminal B wire

5. Starter
 Disassembly / Assembly page G-39
 Inspection page G-40


K8 DOHC
(MTX)



- 1. Negative battery cable
- 2. Strat bar
- 3. Intake air hose
- 4. Terminal S wire

- 5. Terminal B wire
 - 6. Starter
- Disassembly / Assembly page G-37
 Inspection page G-40


(ATX)



- 1. Negative battery cable
- 2. Intake air hose
- 3. Terminal S and B wire

- 4. Fuel filter (High pressure side)
- 5. Starter

Disassembly / Assembly page G-38
 Inspection page G-40



Performance Inspection

Magnetic switch


Disconnect the terminal S wire, and perform the following tests.

Pull-in test

Connect battery positive voltage as shown and verify that the pinion is ejected.


Caution

- Applying power continuously for more than 10 seconds will damage the starter.



Hold-in test

After completing the pull-in test, disconnect the wire from terminal M (with the pinion left ejected) and verify that the pinion does not return.




Adjustment of pinion gap

1. Disconnect the wiring from terminal M.
2. When the battery is connected between terminal S and the starter body, the pinion will be ejected and then stop. Measure the clearance (pinion gap) between the pinion and the stopper.

Caution

- Applying power continuously for more than 10 seconds will damage the starter.

Pinion gap: 0.5–2.0 mm {0.020–0.078 in}



3. If the pinion gap is not within the specification, make adjustment by increasing or decreasing the number of washers between the magnetic switch and the drive housing. (The gap becomes smaller as the number of washers is increased.)

No load test

1. Connect the circuit as shown.
2. Measure voltage, current, and speed as shown.


| | B6 DOHC | K8 DOHC (MTX) | K8 DOHC (ATX) |
|-------------|----------------|-------------------------------------|-------------------------------------|
| Voltage(V) | 11 | 11 | 11 |
| Current (A) | below 50 | below 90 | below 70 |
| Speed (rpm) | 5000 or higher | 3000 or higher 2900 or higher *1 | 2000 or higher 2200 or higher *1 |

*1: cold area

Disassembly / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.

K8 DOHC (MTX)



- | | |
|--|---|
| 1. Magnetic switch Inspection page G-40 | 6. Internal gear |
| 2. Rear bracket | 7. Lever |
| 3. Brush holder assembly Inspection page G-40 | 8. Front bracket |
| 4. Yoke Inspection page G-41 | 9. Pinion gear and planetary gears Disassembly Note page G-39 Assembly Note page G-39 Inspection page G-42 |
| 5. Armature Inspection page G-41 | 10. Shaft |


(ATX)




- 1. Magnetic switch
Inspection page G-40
- 2. Washer
- 3. Lever
- 4. Rear bracket
- 5. Yoke
Inspection page G-41
- 6. Brush holder assembly
Inspection page G-40
- 7. Armature
Inspection page G-41

- 8. Center bracket
- 9. Internal gear
- 10. Pinion shaft assembly (overrunning clutch)
Disassembly Note page G-39
Assembly Note page G-39
Inspection page G-42
- 11. Bearing
- 12. Front bracket

B6 DOHC




- | | |
|--|--|
| 1. Magnetic switch Inspection page G-40 | 5. Front bracket |
| 2. Rear bracket | 6. Lever |
| 3. Brush holder assembly Inspection page G-40 | 7. Drive pinion Disassembly Note below Assembly Note below |
| 4. Yoke Inspection page G-41 | 8. Armature Inspection page G-41 |
| | 9. Bearing (if equipped) |



Disassembly Note

Drive pinion


Remove the stopper for the overrunning clutch with a pipe as shown in the figure.




Assembly Note

Drive pinion


1. Set the drive pinion onto the armature (B6 DOHC) or gear shaft (K8 DOHC MTX), and install the ring.
2. Install the stopper with the **SST** and press as shown in the figure.

**Inspection****Magnetic switch**


1. Continuity (Terminal S—Terminal M)
Check for continuity between terminals S and M.
Replace the magnetic switch if there is no continuity.




2. Continuity (Terminal S—Body)
Check for continuity between terminal S and the body.
Replace the magnetic switch if there is no continuity.



3. Grounding
Check continuity between terminals M and B. Replace the magnetic switch if there is continuity.

**Brush and brush holder**

1. Check continuity between each insulated brush and the plate. Replace the brush holder if there is continuity.




2. Measure the brush spring force with a spring balance.

| Type | B6 DOHC | K8 DOHC | |
|--------------------------|-------------------|--|-------------------|
| | | MTX | ATX |
| Standard N {kgf, lbf} | 18.6 {1.89, 4.16} | 20.6 {2.10, 4.62} 19.6 {2.00, 4.40}*1 | 19.2 {1.95, 4.29} |
| Minimum N {kgf, lbf} | 11.8 {1.20, 2.64} | 6.86 {0.70, 1.54} 9.32 {0.95, 2.09}*1 | 8.83 {0.90, 1.98} |

*1: Cold area


3. Replace the spring if not as specified.



Brush


If a brush is worn almost to or beyond the wear limit, replace all the brushes.

| Type | B6 DOHC | K8 DOHC | |
|------------------|----------|------------|-------------|
| | | MTX | ATX |
| Standard mm {in} | 16 {0.7} | 17.5{0.69} | 17.0{0.67} |
| Minimum mm {in} | 10 {0.4} | 12 {0.5} | 11.5 {0.46} |




Yoke

1. Check for continuity between terminal M wire and brushes. Replace the yoke assembly if there is no continuity.




2. Check continuity between terminal M wire and yoke. Replace the yoke assembly if there is continuity.

3. Check if the field coil is loose. Replace the yoke assembly if it is.




Armature

1. Check continuity between the commutator and the core. Replace the armature if there is continuity.




2. Check continuity between the commutator and the shaft. Replace the armature if there is continuity.




- Place the armature on V-blocks, and measure the runout with a dial indicator.
If the runout exceeds the maximum, repair it with a lathe or replace the armature.

Runout: 0.05 mm {0.002 in}
Maximum: 0.1 mm {0.004 in} (K8-DOHC)
0.4 mm {0.015 in} (B6-DOHC)




- Replace the armature if the outer diameter of the commutator is almost at or less than the minimum.
- If the commutator surface is dirty, wipe it with a cloth; if it is rough, repair it with a lathe or fine sandpaper.

| Type | B6 DOHC | K8 DOHC (MTX) | K8 DOHC (ATX) |
|--------------------------|-------------|---------------|---------------|
| Minimum diameter mm {in} | 27.0 {1.07} | 28.8 {1.14} | 31.4 {1.24} |



- Measure the segment groove depth.
If the depth of the mold between segments is almost at or less than the minimum, undercut the grooves to the standard depth.

Depth: 0.4–0.8 mm {0.02–0.03 in} (B6-DOHC)
0.4–0.6 mm {0.016–0.023 in} (K8-DOHC)
Minimum: 0.2 mm {0.008 in}




Overrunning Clutch

Turn the pinion shaft by hand and hold the overrunning clutch. Replace the overrunning clutch if the pinion turns in both directions or in neither direction.


Caution

- Using cleaning fluids or a steam cleaner to clean the overrunning clutch can dissolve the grease in its sealed bearing.



Internal Gear and Planetary Gears (K8 DOHC MTX)

- Internal gear
Check for wear or damage. Replace if necessary.
- Planetary gears
Check for wear or damage. Replace if necessary.

**STARTER INTERLOCK SWITCH****Inspection**

1. Disconnect the starter interlock switch connector.
2. Connect an ohmmeter to the switch.
3. Check the continuity.

| Clutch pedal | Continuity |
|--------------|------------|
| Depressed | Yes |
| Released | No |

4. Replace the starter interlock switch if not as specified.

GENERAL INFORMATION

| | |
|---|-------|
| SAFETY INFORMATION | GI- 2 |
| LUBRICANTS | GI- 2 |
| JACKING POSITIONS | GI- 2 |
| SAFETY STAND POSITIONS | GI- 2 |
| VEHICLE LIFT POSITIONS | GI- 3 |
| DYNAMOMETER | GI- 3 |
| COMPRESSED AIR | GI- 3 |
| HOW TO USE THIS MANUAL | GI- 4 |
| ADVISORY MESSAGES | GI- 4 |
| PREPARATION | GI- 4 |
| REPAIR PROCEDURE | GI- 4 |
| SYMBOLS | GI- 5 |
| IDENTIFICATION NUMBER LOCATIONS ... | GI- 6 |
| UNITS | GI- 7 |
| ABBREVIATIONS | GI- 8 |
| SAE STANDARDS | GI- 9 |
| FUNDAMENTAL PROCEDURES | GI-11 |
| PROTECTION OF THE VEHICLE | GI-11 |
| PREPARATION OF TOOLS AND MEASURING EQUIPMENT | GI-11 |
| SPECIAL TOOLS | GI-11 |
| REMOVAL OF PARTS | GI-11 |
| DISASSEMBLY | GI-11 |
| REASSEMBLY | GI-12 |
| ADJUSTMENTS | GI-13 |
| RUBBER PARTS AND TUBING | GI-13 |
| HOSE CLAMPS | GI-13 |
| TORQUE FORMULAS | GI-13 |
| VISE | GI-13 |
| ELECTRICAL TROUBLESHOOTING | |
| TOOLS | GI-14 |
| TEST LIGHT | GI-14 |
| JUMPER WIRE | GI-14 |
| VOLTMETER | GI-14 |
| OHMMETER | GI-14 |
| ELECTRICAL PARTS | GI-15 |
| BATTERY CABLE | GI-15 |
| CONNECTORS | GI-15 |
| TERMINALS | GI-16 |
| SENSORS, SWITCHES, AND RELAYS ... | GI-16 |
| WIRING HARNESS | GI-17 |
| MAIN FUSE | GI-17 |
| FUSE | GI-17 |
| INSTALLATION OF RADIO SYSTEM | GI-18 |
| TOWING | GI-19 |

SAFETY INFORMATION

LUBRICANTS

Avoid prolonged and repeated contact with petroleum-based oils. Used oil may irritate the skin, and can cause skin cancer and other skin disorders.

Wash thoroughly after working with oil. We recommend water soluble hand cleaners. Do not use kerosene, gasoline, or any other solvent, to remove oil from your skin.

If repeated or prolonged contact with oil is necessary, wear protective clothing. Soiled clothing, particularly those soiled with used oils and greases containing lead, should be cleaned at regular intervals.

JACKING POSITIONS


Warning

- **Improperly jacking a vehicle is dangerous. The vehicle can slip off the jack and cause serious injury. Use only the correct front and rear jacking positions and block the wheels.**

Use safety stands to support the vehicle after it has been lifted.


Front

At the center of the crossmember



Rear


At the center of the crossmember



SAFETY STAND POSITIONS


Front

Both sides of the vehicle




Rear

Both sides of the vehicle




VEHICLE LIFT POSITIONS**Front**

Both sides of the side sill

**Rear**

Both sides of the side sill



GI

DYNAMOMETER

When test-running a vehicle on a dynamometer:

- place a fan, preferably a vehicle-speed proportional type, in front of the vehicle.
- Connect an exhaust gas ventilation unit.
- Cool the exhaust pipes with a fan.
- Keep the area around the vehicle uncluttered.
- Watch the water temperature gauge.

COMPRESSED AIR

When using compressed air to clean or remove parts:

- Wear protective eye wear.
- Hold a rag over the opening to prevent parts from shooting out.
- Take precautions so that people around you are not struck by flying debris.

HOW TO USE THIS MANUAL

ADVISORY MESSAGES

You'll find several **Warnings**, **Cautions**, and **Notes** in this manual.

Warning

- A **Warning** indicates a situation in which serious injury or death could result if the warning is ignored.

Caution

- A **Caution** indicates a situation in which damage to the vehicle could result if the caution is ignored.


Note

- A **Note** provides added information that will help you to complete a particular procedure.

PREPARATION

This points out the needed **SSTs** for the service operation. It is best to gather all necessary **SSTs** before beginning work.


Example:



REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

Example:



* 1: The numbers (①, etc.) refer to part identification and servicing procedures.


SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.


| Symbol | Meaning | Kind |
|--------|---------------------------------|---|
| | Apply oil | New engine oil or gear oil as appropriate |
| | Apply brake fluid | FMVSS116: DOT-3 |
| | Apply automatic transaxle fluid | Dexron [®] II or M-III |
| | Apply grease | Appropriate grease |
| | Apply sealant | Appropriate sealant |
| | Apply petroleum jelly | Appropriate petroleum jelly |

IDENTIFICATION NUMBER LOCATIONS

VEHICLE IDENTIFICATION NUMBER (VIN)




AUTOMATIC TRANSAXLE MODEL AND NUMBER




ENGINE MODEL AND NUMBER

K8 DOHC



B6 DOHC



UNITS

| | |
|--------------------|---|
| Electrical current | A (ampere) |
| Electric potential | V (volt) |
| Electric power | W (watt) |
| Length | mm (millimeter) in (inch) |
| Negative pressure | kPa (kilo Pascal) mmHg (millimeters of mercury) inHg (inches of mercury) |
| Positive pressure | kPa (kilo Pascal) kgf/cm ² (kilogram force per square centimeter) psi (pounds per square inch) |
| Resistance | Ω (ohm) |
| Torque | N·m (Newton meter) kgf·m (kilogram force per meter) kgf·cm (kilogram force per centimeter) ft·lbf (foot pound) in·lbf (inch pound) |
| Volume | L (liter) US qt (U.S. quart) Imp qt (Imperial quart) ml (milliliter) cc (cubic centimeter) cu in (cubic inch) fl oz (fluid ounce) |
| Weight | g (gram) oz (ounce) |

Conversion to SI Units (Système International d' Unités)

All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

Rounding off

Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

Upper and lower limits

When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7kgf/cm² in the following specifications:

- 210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}
- 270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

The actual converted values for 2.7 kgf/cm² are 264 kPa and 38.4 psi. In the top specification, 2.7 is used as an upper limit, so its converted values are rounded down to 260 and 38. In the bottom specification, 2.7 is used as a lower limit, so its converted values are rounded up to 270 and 39.

ABBREVIATIONS

| | |
|-------|---|
| AAS | Air adjusting screw |
| ABDC | After bottom dead center |
| ABS | Antilock brake system |
| ACC | Accessories |
| ATDC | After top dead center |
| ATX | Automatic transaxle |
| ATF | Automatic transaxle fluid |
| BBDC | Before bottom dead center |
| BTDC | Before top dead center |
| CM | Control Module |
| CPU | Central processing unit |
| D | Drive |
| DOHC | Double overhead camshaft |
| DRL | Daytime running lights |
| EC-AT | Electronically controlled automatic transaxle |
| E/L | Electrical load |
| EX | Exhaust |
| H | High |
| HLA | Hydraulic lash adjuster |
| HU | ABS hydraulic unit |
| IGN | Ignition |
| IN | Intake |
| INT | Intermittent |
| L | Low |
| LH | Left hand |
| LO | Low |
| M | Motor |
| M/S | Manual steering |
| MTX | Manual transaxle |
| N | Neutral |
| OFF | Switch off |
| ON | Switch on |
| P | Park |
| PCV | Positive crankcase ventilation |
| PRC | Pressure regulator control |
| P/S | Power steering |
| R | Reverse |
| RH | Right hand |
| RTS | Reduce torque signal |
| S | Slope |
| SR | Sensor rotor |
| SST | Special service tool |
| SW | Switch |
| TNS | Tail-, parking, and licence plate lights |
| TRS | Torque reduced signal |
| VICS | Variable inertia charging system |
| VRIS | Variable resonance induction system |
| WSS | Wheel speed sensor |

SAE STANDARDS

In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

| Previous Standard | | SAE Standard | | |
|-------------------|--------------------------------------|--------------|---|--------|
| Abbreviation | Name | Abbreviation | Name | Remark |
| — | Accelerator Pedal | AP | Accelerator Pedal | |
| — | Air Cleaner | ACL | Air Cleaner | |
| — | Air Conditioning | A/C | Air Conditioning | |
| — | Airflow Meter | VAF | Volume Air Flow Sensor | |
| — | Airflow Sensor | MAF | Mass Air Flow Sensor | |
| — | Alternator | GEN | Generator | |
| — | ATF Thermosensor | — | Transmission (Transaxle) Fluid Temperature Sensor | |
| — | Atmospheric Pressure | BARO | Barometric Pressure | |
| Vb | Battery Voltage | B+ | Battery Positive Voltage | |
| — | Catalytic Converter | OC | Oxidation Catalytic Converter | |
| | | TWC | Three Way Catalytic Converter | |
| | | WU-TWC | Warm Up Three Way Catalytic Converter | #1 |
| — | Circuit Opening Relay | FPR | Fuel Pump Relay | #2 |
| — | Clutch Position | CPP | Clutch Pedal Position | |
| — | Crank Angle Sensor | CMP | Camshaft Position Sensor | |
| — | Crank Angle Sensor 2 | CKP | Crankshaft Position Sensor | |
| — | Diagnosis Connector | DLC | Data Link Connector | |
| — | Diagnosis/Self-Diagnosis | OBD | On-Board Diagnostic | |
| — | Direct Ignition | DLI | Distributorless Ignition | |
| — | EC-AT Control Unit | TCM | Transmission (Transaxle) Control Module | |
| EGI | Electronic Gasoline Injection System | CIS | Continuous Fuel Injection System | |
| — | Electronic Spark Ignition | EI | Electronic Ignition | #3 |
| ECU | Engine Control Unit | PCM | Powertrain Control Module | #4 |
| | | ECM | Engine Control Module | |
| — | Engine Modification | EM | Engine Modification | |
| — | Engine RPM Signal | — | Engine Speed Input Signal | |
| — | Engine Speed | RPM | Engine Speed | |
| — | Evaporative Emission | EVAP | Evaporative Emission | |
| — | Exhaust Gas Recirculation | EGR | Exhaust Gas Recirculation | |
| — | Fan Control | FC | Fan Control | |
| — | Feedback System | CLS | Closed Loop System | |
| — | Flexible Fuel | FF | Flexible Fuel | |
| — | Fuel Pump | FP | Fuel Pump | |
| — | Fully Closed | CTP | Closed Throttle Position | |
| — | Fully Open | WOT | Wide Open Throttle | |
| — | Ground/Earth | GND | Ground | |

#1: Directly connected to exhaust manifold


#2: In some models, there is a fuel pump relay that controls pump speed. That relay is now called the fuel pump relay (speed).

#3: Controlled by the ECM (PCM)

#4: Device that controls engine and powertrain

| Previous Standard | | SAE Standard | | |
|-------------------|--------------------------------|--------------|--------------------------------------|------------------------|
| Abbreviation | Name | Abbreviation | Name | Remark |
| — | IC Regulator | VR | Voltage Regulator | |
| — | Idle Speed Control | IAC | Idle Air control | |
| — | Idle Switch | — | Closed Throttle Position Switch | |
| — | Igniter | ICM | Ignition Control Module | |
| — | Inhibitor Position | TR | Transmission (Transaxle) Range | |
| — | Intake Air Pressure | MAP | Manifold Absolute Pressure | |
| — | Intake Air Thermo | IAT | Intake Air Temperature | |
| — | Intercooler | CAC | Charge Air Cooler | |
| — | Knock Sensor | KS | Knock Sensor | |
| — | Line Pressure Solenoid Valve | — | Pressure Control Solenoid | |
| — | Lock-up Position | TCC | Torque Converter Clutch | |
| — | Malfunction Indicator Light | MIL | Malfunction Indicator Lamp | |
| — | Multiport Fuel Injection | MFI | Multiport Fuel Injection | |
| — | Open Loop | OL | Open Loop | |
| — | Overdrive | 4GR | Fourth Gear | |
| — | Oxygen Sensor | HO2S | Heated Oxygen Sensor | With heater |
| | | O2S | Oxygen Sensor | |
| — | Park/Neutral Range | PNP | Park/Neutral Position | |
| — | Power Steering Pressure | PSP | Power Steering Pressure | |
| — | Pulse Generator | — | Input/Turbine Speed Sensor | |
| — | Reed Valve | SAPV | Secondary Air Pulse Valve | |
| — | Secondary Air Injection System | PAIR | Pulsed Secondary Air Injection | Pulsed injection |
| | | AIR | Secondary Air Injection | Inject with compressor |
| — | Sequential Fuel Injection | SFI | Sequential Multipoint Fuel Injection | |
| — | Service Code(s) | DTC | Diagnostic Trouble Code (s) | |
| — | Spark Ignition | DI | Distributor Ignition | |
| — | Stoplight Switch | — | Brake Switch | |
| — | Test Mode | DTM | Diagnostic Test Mode | #5 |
| — | Throttle Body | TB | Throttle Body | |
| — | Throttle Sensor | TP | Throttle Position Sensor | |
| — | Turbocharger | TC | Turbocharger | |
| — | Vehicle Speed Sensor | VSS | Vehicle Speed Sensor | |
| — | Vehicle Speed Sensor 1 | — | Output Speed Sensor | |
| — | Water Thermo | ECT | Engine Coolant Temperature | |
| — | 1-2 Shift Solenoid Valve | — | Shift Solenoid A | |
| — | 2-3 shift Solenoid Valve | — | Shift Solenoid B | |
| — | 3-4 Shift Solenoid Valve | — | Shift Solenoid C | |
| — | 3rd Gear | 3GR | Third Gear | |
| — | — | — | Incorrect Gear Ratio | |

#5: Diagnostic trouble codes depend on the diagnostic test mode




FUNDAMENTAL PROCEDURES

PROTECTION OF THE VEHICLE


Always be sure to cover fenders, seats, and floor areas before starting work.

GI




PREPARATION OF TOOLS AND MEASURING EQUIPMENT

Be sure that all necessary tools and measuring equipment are available before starting any work.




SPECIAL TOOLS

Use special tools when they are required.




REMOVAL OF PARTS

While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair. After removing the part, plug all holes and ports to prevent foreign material from entering.




DISASSEMBLY

If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



1. Inspection of parts


When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.



2. Arrangement of parts

All disassembled parts should be carefully arranged for reassembly.

Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.




3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.



REASSEMBLY


Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.


If removed, these parts should be replaced with new ones:

- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:


1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.






ADJUSTMENTS

Use suitable gauges and testers when making adjustments.




RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.



HOSE CLAMPS

When reinstalling, position the hose clamp in the original location on the hose, and squeeze the clamp lightly with large pliers to ensure a good fit.




TORQUE FORMULAS

When using a torque wrench-SST combination, the written torque must be recalculated due to the extra length that the SST adds to the torque wrench. Recalculate the torque by using the following formulas. Choose the formula that applies to you.


| Torque Unit | Formula |
|-------------|-------------------------------------|
| N·m | $N \cdot m \times [L / (L + A)]$ |
| kgf·m | $kgf \cdot m \times [L / (L + A)]$ |
| kgf·cm | $kgf \cdot cm \times [L / (L + A)]$ |
| ft·lbf | $ft \cdot lbf \times [L / (L + A)]$ |
| in·lbf | $in \cdot lbf \times [L / (L + A)]$ |

A = The length of the SST past the torque wrench drive.
L = The length of the torque wrench.



WISE

When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




ELECTRICAL TROUBLESHOOTING TOOLS

TEST LIGHT

The test light, as shown in the figure, uses a 12V bulb. The two lead wires should be connected to probes. The test light is used for simple voltage checks and for checking for short circuits.

Caution

- Using a bulb over 3.4W when checking the control module may damage the control module.




JUMPER WIRE

A jumper wire is used to create a temporary circuit. Connect the jumper wire between the terminals of a circuit to bypass a switch.


Caution

- Do not connect a jumper wire from the power source line to a body ground. This may cause burning or other damage to wiring harnesses or electronic components.



VOLTMETER

The DC voltmeter is used to measure circuit voltage. A voltmeter with a range of 15V or more is used by connecting the positive (+) probe (red lead wire) to the point where voltage is to be measured and the negative (-) probe (black lead wire) to a body ground.




OHMMETER

The ohmmeter is used to measure the resistance between two points in a circuit, and to check for continuity and short circuits.

Caution


- Do not connect the ohmmeter to any circuit to which voltage is applied. This will damage the ohmmeter.



ELECTRICAL PARTS

BATTERY CABLE

Before disconnecting connectors or removing electrical parts, disconnect the negative battery cable.




CONNECTORS

Data Link Connector

Insert the probe into the service hole when connecting a jumper wire to the data link connector.


Caution

- Inserting a jumper wire probe into the data link connector terminal may damage the terminal.




Disconnecting Connectors

When disconnecting two connectors, grasp the connectors, not the wires.




Connectors can be disconnected by pressing or pulling the lock lever as shown.




Locking Connector

When locking connectors, listen for a click that will indicate they are securely locked.

**Inspection**


1. When a tester is used to check for continuity or to measure voltage, insert the tester probe from the wiring harness side.




2. Check the terminals of waterproof connectors from the connector side, as they cannot be accessed from the wiring harness side.

Caution

- To prevent damage to the terminal, wrap a thin wire around the lead before inserting it into the terminal.


**TERMINALS****Inspection**

Pull lightly on individual wires to check that they are secured in the terminal.


**Replacement**

Use the appropriate tools to remove a terminal as shown. When installing a terminal, be sure to insert it until it locks securely.

Insert a thin piece of metal from the terminal side of the connector, and then, with the terminal locking tab pressed down, pull the terminal out from the connector.

**SENSORS, SWITCHES, AND RELAYS**


Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.



WIRING HARNESS Wiring Color Codes

Two-color wires are indicated by a two-color code symbol. The first letter indicates the base color of the wire and the second the color of the stripe.


| CODE | COLOR | CODE | COLOR |
|------|-------------|------|--------|
| B | Black | O | Orange |
| BR | Brown | P | Pink |
| G | Green | R | Red |
| GY | Gray | V | Violet |
| L | Blue | W | White |
| LB | Light Blue | Y | Yellow |
| LG | Light Green | — | — |



MAIN FUSE

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the main fuse block mounting nuts.
3. Open the main fuse block lid and remove the main fuse mounting bolts.
4. Remove the main fuse.
5. Install in the reverse order of removal.



FUSE (PLATE TYPE)

Removal / Installation

1. Use the puller found on the back of the fuse block cover to remove the fuses. If one or more of the fuses are burnt, check for a short in the harness.

Caution

- Determine and correct the cause of the burnt fuse before replacing it. If the fuse is replaced before doing this, it may burn again.


2. Install in the reverse order of removal.



INSTALLATION OF RADIO SYSTEM

If a radio system is installed improperly or if a high-powered type is used, the CIS and other systems may be affected.

When the vehicle is to be equipped with a radio, observe the following precautions:

1. Install the antenna at the farthest point from control modules.
2. Install the antenna feeder as far as possible from the control module harnesses (at least 30 cm {11.8 in}).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered radio system.





TOWING

Proper towing equipment is necessary to prevent damage to the vehicle. Laws and regulations applicable to vehicles in tow must always be observed.

As a general rule, towed vehicles should be pulled with the driving wheels off the ground. If excessive damage or other conditions prevent towing the vehicle with the driving wheels off the ground, use wheel dollies.

With either automatic or manual transaxle:

1. Set the ignition switch in the ACC position.
2. Place the selector lever or shift lever in N (Neutral).
3. Release the parking brake.

Caution

- Do not tow the vehicle backward with driving wheels on the ground. This may cause internal damage to the transaxle.



Caution

- Don't use the hook loops under the front and rear for towing. They are designed ONLY for tying down the vehicle when it's being transported. Using them for towing will damage the bumper.

TIE-DOWN HOOKS

FRONT

REAR



Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

CLUTCH


- INDEX H- 2
- OUTLINE H- 4
 - SPECIFICATIONS H- 4
- TROUBLESHOOTING GUIDE H- 4
- CLUTCH FLUID H- 5
 - PREPARATION H- 5
 - REPLACEMENT H- 5
- CLUTCH PEDAL H- 6
 - ADJUSTMENT H- 6
 - REMOVAL / INSTALLATION H- 7
- CLUTCH MASTER CYLINDER H- 8
 - PREPARATION H- 8
 - REMOVAL / INSTALLATION H- 8
 - AIR BLEEDING H- 9
 - OVERHAUL H-11
- CLUTCH RELEASE CYLINDER H-13
 - PREPARATION H-13
 - REMOVAL / INSTALLATION H-13
 - AIR BLEEDING (REFER TO PAGE H-9) H-14
 - OVERHAUL H-14
- CLUTCH UNIT H-15
 - PREPARATION H-15
 - REMOVAL / INSTALLATION H-16
- CLUTCH COVER H-18
 - INSPECTION H-18
- CLUTCH DISC H-19
 - INSPECTION H-19
- CLUTCH RELEASE COLLAR H-20
 - INSPECTION H-20
- PILOT BEARING H-20
 - INSPECTION H-20
- FLYWHEEL H-20
 - INSPECTION H-20

H

INDEX


K8 DOHC

TRANSAXLE SERVICE,
SECTION J2



B6 DOHC

TRANSAXLE SERVICE,
SECTION J1



-
1. Clutch pedal
 - Adjustment page H- 6
 - Removal / Installation page H- 7
 2. Clutch master cylinder
 - Removal / Installation page H- 8
 - Air bleeding page H- 9
 - Overhaul page H-11
 3. Clutch release cylinder
 - Removal / Installation page H-13
 - Air bleeding page H- 9
 - Overhaul page H-14
 4. Clutch release collar
 - Removal / Installation page H-16
 - Inspection page H-20
 5. Clutch release fork
 - Removal / Installation page H-16
 6. Clutch cover
 - Removal / Installation page H-16
 - Inspection page H-18
 7. Clutch disc
 - Removal / Installation page H-16
 - Inspection page H-19
 8. Pilot bearing
 - Removal / Installation page H-16
 - Inspection page H-20
 9. Flywheel
 - Removal / Installation page H-16
 - Inspection page H-20

OUTLINE

SPECIFICATIONS


| Item | Model | | B6 DOHC | K8 DOHC | |
|------------------|----------------------|---------------------|---------------------|-------------|--|
| | | | F25M-R | G25M-R | |
| Clutch control | | | Hydraulic | | |
| Clutch cover | Type | Diaphragm Spring | | | |
| | Set load | N {kgf, lbf} | 4,316 {440, 968} | | |
| Clutch disc | Outer diameter | mm {in} | 200 {7.87} | 225 {8.86} | |
| | Inner diameter | mm {in} | 130 {5.12} | 150 {5.91} | |
| | Thick-ness | Pressure plate side | mm {in} | 3.8 {0.150} | |
| | | Flywheel side | mm {in} | 3.5 {0.138} | |
| Clutch pedal | Type | Suspended | | | |
| | Pedal ratio | 6.31 | | | |
| | Full stroke | mm {in} | 130 {5.12} | | |
| | Height (with carpet) | mm {in} | 199-204 {7.83-8.03} | | |
| Master cylinder | Inner diameter | mm {in} | 15.87 {0.625} | | |
| Release cylinder | Inner diameter | mm {in} | 19.05 {0.750} | | |
| Clutch fluid | | | FMVSS116 DOT-3 | | |

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Action | Page |
|---------------------------------------|---|------------------------------|-------------------------|
| Slipping | Clutch disc facing worn excessively | Replace | H-16 |
| | Clutch disc facing surface hardened or oil on surface | Repair or replace | H-16, 19 |
| | Pressure plate damaged | Replace | H-16 |
| | Diaphragm spring damaged or weakened | Replace | H-16 |
| | Insufficient clutch pedal play | Adjust | H-6 |
| | Clutch pedal sticking | Repair or replace | H-7 |
| | Flywheel damaged | Repair or replace | H-16, 20 |
| Poor disengagement | Excessive runout or damaged clutch disc | Replace | H-16 |
| | Clutch disc splines rusted or worn | Remove rust or replace | H-16 |
| | Oil on facing | Repair or replace | H-16, 19 |
| | Diaphragm spring weakened | Replace | H-16 |
| | Excessive clutch pedal play | Adjust | H-6 |
| | Insufficient clutch fluid | Add fluid | H-5 |
| | Leakage of clutch fluid | Locate and repair or replace | — |
| Vibration of clutch when accelerating | Oil on facing | Repair or replace | H-16, 19 |
| | Torsion dampers weakened | Replace | H-16 |
| | Clutch disc facing hardened or damaged | Repair or replace | H-16, 19 |
| | Clutch disc facing rivets loose | Replace | H-16 |
| | Pressure plate damaged or has excessive runout | Replace | H-16 |
| | Flywheel surface hardened or damaged | Repair or replace | H-16, 20 |
| | Loose or worn engine mount | Tighten or replace | — |
| Clutch pedal sticking | Pedal shaft not properly lubricated | Lubricate or replace | H-7 |
| Abnormal noise | Clutch release collar damaged | Replace | H-16 |
| | Poor lubrication of release collar sleeve | Lubricate or replace | H-16 |
| | Torsion dampers weakened | Replace | H-16 |
| | Excessive crankshaft end play | Repair | Refer to section B1, 82 |
| | Pilot bearing worn or damaged | Replace | H-16, 20 |
| | Worn pivot points of release fork | Replace | H-16 |

CLUTCH FLUID

PREPARATION
SST

| | |
|--|-----------------------------|
| <p>49 0259 770B</p> <p>Wrench, flare nut</p>  | <p>For air bleeding</p> |
|--|-----------------------------|

REPLACEMENT


Note

- A common reservoir is used for the clutch and brake system fluids.

Caution

- **Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.**

1. Remove the fluid from the reservoir by using a suction pump, and fill the reservoir with new fluid of the specified type.
2. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.




3. Insert the other end of the vinyl hose into a clear container.
4. Working with another person, have the person depress the clutch pedal several times, then hold it down.
5. With the clutch pedal depressed, loosen the bleeder screw by using the **SST** to let the fluid escape. Close the bleeder screw.
6. Repeat steps 4 and 5 until only clean fluid is seen. Make sure the reservoir is always 3/4 full or more during this procedure.
7. Modify the bleeder screw tightening torque to allow for a torque wrench-**SST** combination. (Refer to section GI "Torque Formulas".)
8. Tighten the bleeder screw by using the **SST**.

Tightening torque:

5.9–8.8 N·m {60–90 kgf·cm, 53–78 in·lbf}

9. Fill the reservoir to MAX with new fluid of the specified type.
10. Slowly pump the clutch pedal several times. Verify that there is no fluid leakage.
11. Check operation of the clutch system.
12. Check operation of the brake system.



CLUTCH PEDAL

ADJUSTMENT

Height

Inspection

1. Measure the distance from the upper surface of the pedal pad to the carpet.

**Pedal height: 199–204 mm {7.83–8.03 in}
(with carpet)**

2. If necessary, adjust the pedel height

Adjustment

1. Disconnect the clutch switch connector.
2. Loosen locknut **A** and turn clutch switch **B** until the height is correct.
3. Tighten locknut **A**.

Tightening torque:

13.8–17.6 N·m {140–180 kgf·cm, 122–156 in·lbf}

4. After adjustment, measure the pedal free play.

Free Play

Inspection

1. Depress the clutch pedal by hand until clutch resistance is felt.

Pedal free play: 0.6–3.2 mm {0.02–0.12 in}

Total pedal free play: 5–16 mm {0.19–0.63 in}

2. If necessary, adjust the pedal free play.

Adjustment

1. Loosen locknut **C** and turn push rod **D** until the pedal free play is correct.
2. Verify that the disengagement height (from the upper surface of the pedal pad to the carpet) is correct when the pedal is fully depressed.

**Minimum disengagement height: 39.5 mm {1.56 in}
(with carpet)**

3. Tighten locknut **C**.


Tightening torque:

11.8–16.6 N·m {120–170 kgf·cm, 105–147 in·lbf}

4. After adjustment, measure the pedal height.


REMOVAL / INSTALLATION

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.




1. Nut
2. Clutch switch connector
3. Clutch switch
4. Nut
5. Nut
6. Starter interlock switch


7. Clip
8. Pin
9. Bushing
10. Nut
11. Push rod
Inspect for damage and bending
12. Clevis
13. Pedal pad
14. Clutch pedal
Adjustment page H-6

**Removal Note****Clutch pipe**

1. Disconnect the clutch pipe by using the **SST**.




2. Disconnect the clutch hose from the reservoir.
3. Plug the outlet of the reservoir.

**Installation Note****Clutch pipe**

1. Modify the clutch pipe tightening torque to allow for a torque wrench-**SST** combination. (Refer to section GI "Torque Formulas".)
2. Tighten the clutch pipe by using the **SST**.

Tightening torque:


12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lb}

**AIR BLEEDING**

The clutch hydraulic system must be bled to remove air introduced whenever a hydraulic line is disconnected.

Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.



1. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.
2. Insert the other end of the vinyl hose into a clear container.
3. Working with another person, have the person depress the clutch pedal several times, then hold it down.
4. With the clutch pedal depressed, loosen the bleeder screw by using the **SST** to let fluid and air escape. Close the bleeder screw.
5. Repeat steps 3 and 4 until no air bubbles are seen. Make sure the reservoir is always 3/4 full or more during this procedure.

6. Modify the bleeder screw tightening torque to allow for a torque wrench-**SST** combination. (Refer to section GI "Torque Formulas".)
7. Tighten the bleeder screw by using the **SST**.

Tightening torque:

5.9–8.8 N·m {60–90 kgf·cm, 52–78 in·lbf}

8. Fill the reservoir to MAX with new fluid of the specified type.
9. Slowly pump the clutch pedal several times. Verify that there is no fluid leakage.
10. Check operation of the clutch system.
11. Check operation of the brake system.


OVERHAUL

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. **Wear protective eye wear whenever using compressed air.**

3. Wipe all parts, and clean all parts, passages, and inner parts with compressed air.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Clip 2. Hose 3. Joint 4. Bushing 5. Snap ring Disassembly Note below Assembly Note page H-12 6. Piston and secondary cup assembly Disassembly Note page H-12 Assembly Note page H-12 Inspect for wear, scoring and cracks | <ol style="list-style-type: none"> 7. Spacer 8. Primary cup Inspect for wear and cracks 9. Return spring 10. Master cylinder body Inspect cylinder bore for scoring and corrosion |
|---|---|



Disassembly Note

Snap ring

While holding the piston down with a cloth-wrapped pin punch, remove the snap ring.




Piston and secondary cup assembly

Warning

- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.


Remove the piston and secondary cup assembly, spacer, and primary cup by applying compressed air through the clutch pipe installation hole.



Assembly Note

Piston and secondary cup assembly

1. Apply new fluid of the specified type to the cylinder bore and all internal parts.
2. Verify that all parts are completely free of dirt, dust, and other small particles.
3. Install the spring, primary cup, spacer, and piston and secondary cup assembly into the master cylinder body.




Snap ring

While holding the piston down with a cloth-wrapped pin punch, install the snap ring.

CLUTCH RELEASE CYLINDER

PREPARATION
SST


| | |
|--|--|
| <p>49 0259 770B</p> <p>Wrench, flare nut </p> | <p>For disconnecting/ connecting clutch pipe</p> |
|--|--|

REMOVAL / INSTALLATION


Caution

- Clutch fluid will damage painted surfaces. If clutch fluid does get on a painted surface, wipe it off immediately.

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, bleed the clutch system. (Refer to page H-9.)




- | | |
|--|--|
| <p>1. Clutch pipe Removal Note below Installation Note page H-14</p> | <p>3. Clutch release cylinder Remove boot and check for fluid leakage Overhaul page H-14</p> |
|--|--|



Removal Note

Clutch pipe

Disconnect the clutch pipe by using the **SST**, and plug the clutch pipe immediately.



Installation Note

Clutch pipe

1. Modify the clutch pipe tightening torque to allow for a torque wrench-SST combination. (Refer to section GI "Torque Formulas".)
2. Tighten the clutch pipe by using the SST.

Tightening torque

12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lbf}


OVERHAUL

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.

Warning


- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.

3. Wipe all parts, and clean all ports, passages, and inner parts with compressed air.
4. Assemble in the reverse order of disassembly.



1. Boot
2. Push rod
3. Piston and cup assembly
Disassembly Note page H-15
Inspect for wear, scoring and cracks
4. Return spring
5. Bleeder cap

6. Bleeder screw
7. Steel ball
8. Release cylinder body
Inspect cylinder bore for scoring and corrosion
Replace clutch release cylinder assembly if necessary.



Disassembly Note Piston and cup assembly

Warning








- Applying compressed air to the cylinder assembly can make the contents suddenly pop out, possibly causing injury. Hold a rag over the cylinder opening when using compressed air.

Remove the piston and cup assembly by applying compressed air through the clutch pipe installation hole.

CLUTCH UNIT

PREPARATION

SST


| | | | |
|---|--|--|--|
| <p>49 SE01 310A Centering tool, clutch disc</p>  | <p>For Support of clutch disc</p> | <p>49 1285 071 Puller, bearing</p>  | <p>For removal of pilot bearing</p> |
| <p>49 1285 073 Chuck (Part of 49 1285 071)</p>  | <p>For removal of pilot bearing</p> | <p>49 E011 1A0 Brake, ring gear</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 103 Shaft (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | <p>49 E011 105 Stopper (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> |
| <p>49 E011 104 Collar (Part of 49 E011 1A0)</p>  | <p>For prevention of engine rotation</p> | | |

REMOVAL / INSTALLATION

Note

- The clutch release cylinder can be removed from the transaxle with the clutch pipe connected.


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.




1. Clutch release cylinder
2. Transaxle
Service sections J1, J2
3. Boot
4. Clutch release collar
Inspection page H-20
5. Clutch release fork
6. Clutch cover
Removal Note page H-17
Inspection page H-18
Installation Note page H-18

7. Clutch disc
Removal Note page H-17
Inspection page H-19
Installation Note page H-18
8. Pilot bearing
Inspection page H-20
Removal Note page H-17
Installation Note page H-18
9. Flywheel
Removal Note page H-17
Inspection page H-20
Installation Note page H-17

N·m [kgf·m, ft·lbf]


**Removal Note****Clutch cover and clutch disc**

1. Support the clutch disc by using the **SST**.
2. Install the **SST** or equivalent.
3. Loosen each bolt one turn at a time in a crisscross pattern until spring tension is released. Then remove the clutch cover and disc.


**Pilot bearing****Note**

- The pilot bearing does not have to be removed unless you are replacing it.

If removing the pilot bearing, use the **SST**.

**Flywheel**


1. Hold the flywheel by using the **SST** or equivalent.
2. Remove the bolts evenly and gradually in the figure shown.
3. Remove the flywheel.
4. Inspect for oil leakage from the crankshaft rear oil seal. If there is any such leakage or if the oil seal is damaged, refer to sections B1 or B2 and replace the crankshaft oil seal.

**Installation Note****Flywheel**

1. Wipe the bolts clean and apply sealant to the bolt threads.
2. Install the flywheel and the **SST** or equivalent.
3. Tighten the bolts in the pattern shown.


Tightening torque:

97–102 N·m {9.8–10.5 kgf·m, 71–75 ft·lbf} (B6 DOHC)
61–67 N·m {6.2–6.9 kgf·m, 45–49 ft·lbf} (K8 DOHC)


**Pilot bearing**

Install a new pilot bearing by using a suitable pipe.

Pipe outer diameter: 35 mm {1.378 in}
Depth of press: 0–0.4 mm {0–0.016 in}

**Clutch disc**


1. Clean the clutch disc splines and primary shaft gear splines.
2. Apply molybdenum sulfide to the splines.
3. Hold the clutch disc in position by using the **SST**.

**Clutch cover**

1. Align the dowel holes with the flywheel dowels.
2. Install the **SST** or equivalent.
3. Tighten the bolts evenly and gradually in the pattern shown.


Tightening torque:

18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}

**CLUTCH COVER****INSPECTION**


1. Measure wear of the diaphragm spring fingers.

Depth: 0.6 mm {0.024 in} max.





2. Inspect the flatness of the pressure plate contact surface with a straightedge and a feeler gauge.

Maximum: 0.5 mm {0.020 in}



3. The K8 DOHC engine is made of aluminum, so the magnet will not hold the dial indicator to the block as it would for the B6 DOHC engine. Therefore, use the **SST** to hold the dial indicator when checking the runout of the diaphragm spring fingers for the K8 DOHC engine.
4. Rotate the flywheel and check for misaligned diaphragm spring fingers. Replace the clutch cover if not as specified.


Maximum: 0.6 mm {0.024 in}



CLUTCH DISC


INSPECTION

1. Inspect the lining surface for burning and oil contamination. Remove minor scoring or burning with emery paper. Replace the clutch disc if it is badly burned or oil soaked.
2. Inspect for loose facing rivets and damper rubbers. Replace the clutch disc if either is loose.




3. Measure the thickness of the lining at a rivet head on both sides with vernier calipers. Replace the clutch disc if its thickness is less than minimum.

Thickness: 0.3 mm {0.012 in} min.



4. Measure the clutch disc runout with a dial indicator. Replace the clutch disc if runout is excessive.

Runout: 0.7 mm {0.027 in} max.




CLUTCH RELEASE COLLAR

INSPECTION

Caution

- Cleaning the clutch release collar with cleaning fluids or a steam cleaner can wash the grease out of the sealed bearing.

1. Turn the bearing while applying force in the axial direction.
2. If the collar sticks or has excessive resistance, replace it.




PILOT BEARING

INSPECTION

Note

- The pilot bearing can be inspected while it is the flywheel.


Turn the bearing while applying force in the axial direction. If the bearing sticks or has excessive resistance, replace it.



FLYWHEEL

INSPECTION

1. Inspect the contact surface of the clutch disc for scoring, cracks and burning. Remove minor scoring or burning with emery paper. Repair or replace as necessary.



2. Inspect the ring gear teeth for wear and damage. If necessary, replace the ring gear.
3. Measure the flywheel runout with a dial indicator. Replace the flywheel if runout is excessive.


Runout: 0.2 mm {0.008 in} max.

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

MANUAL TRANSAXLE (G25M-R)

| | |
|--|-------|
| INDEX | J2- 2 |
| OUTLINE | J2- 3 |
| SPECIFICATIONS | J2- 3 |
| STRUCTURAL VIEW | J2- 4 |
| POWER FLOW | J2- 5 |
| TROUBLESHOOTING GUIDE | J2- 6 |
| TRANSAXLE OIL | J2- 7 |
| INSPECTION | J2- 7 |
| REPLACEMENT | J2- 7 |
| OIL SEAL (DIFFERENTIAL) | J2- 8 |
| PREPARATION | J2- 8 |
| REPLACEMENT | J2- 8 |
| OIL SEAL (CHANGE ROD ASSEMBLY) | J2- 9 |
| REPLACEMENT | J2- 9 |
| TRANSAXLE | J2-10 |
| PREPARATION | J2-10 |
| REMOVAL | J2-12 |
| DISASSEMBLY | J2-15 |
| INSPECTION | J2-27 |
| ASSEMBLY | J2-30 |
| INSTALLATION | J2-46 |
| DIFFERENTIAL | J2-50 |
| PREPARATION | J2-50 |
| DISASSEMBLY / INSPECTION / | |
| ASSEMBLY | J2-51 |
| SHIFT MECHANISM | J2-54 |
| OVERHAUL | J2-54 |

INDEX



GRADE : API SERVICE GL-4 or GL-5
 VISCOSITY : ALL-SEASON SAE75W-90
 ABOVE 10°C {50°F} SAE 80W-90
 CAPACITY : 2.70 L (2.85 US qt, 2.38 Imp qt)

BACK-UP LIGHT SWITCH SERVICE,
 1885 MX-3 BODY ELECTRICAL
 TROUBLESHOOTING MANUAL

| | |
|--------------------------|------------|
| 1. Transaxle | |
| Removal | page J2-12 |
| Disassembly | page J2-15 |
| Inspection | page J2-27 |
| Assembly | page J2-30 |
| Installation | page J2-46 |
| 2. Differential | |
| Disassembly / Inspection | |
| Assembly | page J2-51 |


| | |
|-----------------------------------|------------|
| 3. Shift mechanism | |
| Overhaul | page J2-54 |
| 4. Transaxle oil | |
| Inspection | page J2- 7 |
| Replacement | page J2- 7 |
| 5. Oil seal (differential) | |
| Replacement | page J2- 8 |
| 6. Oil seal (change rod assembly) | |
| Replacement | page J2- 9 |

OUTLINE

SPECIFICATIONS

| Item | | Engine/Transaxle | K8 DOHC |
|--------------------|-----------|-------------------|--|
| | | | G25M-R |
| Transaxle control | | | Floor shift |
| Synchromesh system | | | Forward: Synchromesh Reverse: Selective sliding and synchromesh |
| Gear ratio | 1st | | 3.307 |
| | 2nd | | 1.833 |
| | 3rd | | 1.310 |
| | 4th | | 1.030 |
| | 5th | | 0.795 |
| | Reverse | | 3.166 |
| Final gear ratio | | | 4.388 |
| Oil | Grade | | API service GL-4 or GL-5 |
| | Viscosity | All-season | SAE 75W-90 |
| | | Above 10°C {50°F} | SAE 80W-90 |
| | Capacity | L {US qt, Imp qt} | 2.70 {2.85, 2.38} |

STRUCTURAL VIEW









- 1. 1st gear
- 2. 2nd gear
- 3. 3rd gear
- 4. 4th gear
- 5. 5th gear

- 6. Reverse gear
- 7. 1st gear
- 8. 2nd gear
- 9. Secondary 3rd gear
- 10. Secondary 4th gear

- 11. Secondary 5th gear
- 12. Clutch hub sleeve
(reverse gear)
- 13. Reverse idler gear
- 14. Differential





POWER FLOW



J2

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|--|---|---------------------------------------|---------------|
| Shift lever does not shift smoothly or is hard to shift | Seized shift lever ball seat | Replace | J2-54 |
| | Seized change control rod joint | Replace | J2-54 |
| | Bent change control rod | Replace | J2-54 |
| Too much play in shift lever | Worn change control rod bushing | Replace | J2-54 |
| | Weak shift lever ball spring | Replace | J2-54 |
| | Worn shift lever ball bushing | Replace | J2-54 |
| Difficult to shift | Bent change control rod | Replace | J2-54 |
| | No grease in transaxle control | Lubricate with grease | J2-54 |
| | Insufficient oil | Add oil | J2-7 |
| | Deterioration of oil quality | Replace with oil of specified quality | J2-7 |
| | Wear or play of shift fork or shift rod | Replace | J2-16 |
| | Worn synchronizer ring | Replace | J2-22, 24 |
| | Worn synchronizer cone of gear | Replace | J2-22, 24 |
| | Bad contact of synchronizer ring and cone of gear | Replace | J2-22, 24 |
| | Excessive longitudinal play of gears | Replace | J2-22, 24 |
| | Worn bearing | Replace | J2-22, 24 |
| | Worn synchronizer key spring | Replace | J2-22, 24 |
| | Excessive primary shaft gear bearing preload | Adjust | J2-36 |
| | Improperly adjusted change guide plate | Adjust | J2-19 |
| Does not stay in gear | Bent change control rod | Replace | J2-54 |
| | Worn change control rod bushing | Replace | J2-54 |
| | Weak shift lever ball spring | Replace | J2-54 |
| | Improperly installed extension bar | Tighten | J2-54 |
| | Worn shift fork | Replace | J2-16 |
| | Worn clutch hub | Replace | J2-22, 24 |
| | Worn clutch hub sleeve | Replace | J2-22, 24 |
| | Worn gear sliding surface of shaft gears | Replace | J2-22, 24 |
| | Worn gear sliding surface of gear | Replace | J2-22, 24 |
| | Worn steel sliding groove of control end | Replace | J2-16 |
| | Weak spring pressing against steel ball | Replace | J2-16 |
| | Excessive thrust clearance | Replace | J2-16, 22, 24 |
| | Worn bearing | Replace | J2-22, 24 |
| | Improperly installed or loose engine mount | Tighten | J2-46 |
| Abnormal noise | Insufficient oil | Add oil | J2-7 |
| | Deterioration of oil quality | Replace with oil of specified quality | J2-7 |
| | Worn bearing | Replace | J2-22, 24 |
| | Worn sliding surfaces of gears or shafts | Replace | J2-22, 24 |
| | Excessive gear backlash | Replace | J2-22, 24 |
| | Damaged gear teeth | Replace | J2-22, 24 |
| | Foreign material in gears | Replace | J2-22, 24 |
| | Damaged differential gear or excessive backlash | Replace | J2-51 |



TRANSAXLE OIL

INSPECTION

1. Park the vehicle on level ground.
2. Remove the oil level plug and washer.
3. Verify that the oil level is near the bottom of the plug port.
4. If the oil level is low, add the specified amount and type of oil through oil level plug hole.

5. Install a new washer and the oil level plug.

Tightening torque:

40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}

REPLACEMENT

1. Remove the drain plug and the washer.
2. Drain the oil into a suitable container.
3. Install a new washer and the drain plug.

Tightening torque:

40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}

4. Remove the oil level plug and the washer. Add the specified amount and type of oil through the oil level plug hole until the level reaches the bottom of the oil level plug hole.

Specified oil

Grade: API Service GL-4 or GL-5

Viscosity: All-season SAE 75W–90

Above 10°C {50°F} SAE 80W–90

Capacity: 2.70 L {2.85 US qt, 2.38 Imp qt}

5. Install a new washer and the oil level plug.



Tightening torque:

40–58 N·m {4.0–6.0 kgf·m, 29–43 ft·lbf}

OIL SEAL (DIFFERENTIAL)


PREPARATION

SST




REPLACEMENT


1. Remove the drain plug and washer. (Refer to Replacement, page J2-7.)
2. Drain the oil into a suitable container.
3. Separate the drive shaft and joint shaft from the transaxle. (Refer to page J2-12.)




4. Remove the oil seal by using a screwdriver.



5. Using the **SST** and a hammer, tap the new oil seal in evenly until the **SST** contacts the transaxle case.
6. Coat the lip of the oil seal with transaxle oil.




7. Insert the drive shaft and joint shaft to the transaxle. (Refer to page J2-46.)
8. Add the specified amount and type of oil. (Refer to page J2-7.)




OIL SEAL (CHANGE ROD ASSEMBLY)

REPLACEMENT

1. Remove the drain plug and washer.
(Refer to Replacement page J2-7.)
2. Drain the oil into a suitable container.
3. Disconnect the change control rod from the transaxle.
4. Remove the joint and boot from the change rod assembly.




5. Remove the oil seal.



6. Install a new oil seal by using a 26 mm {1.024 in} diameter pipe.
7. Coat the lip of the oil seal with transaxle oil.

J2



8. Install the boot and joint to the change rod assembly so that the drain hole is facing downward.


Tightening torque:

13.8–18.6 N·m {140–190 kgf·m, 122–164 in·lbf}

9. Connect the change control rod to the change rod assembly.

Tightening torque:

















16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}


















10. Add the specified amount and type of oil.
(Refer to page J2-7.)

TRANSAXLE


PREPARATION SST

| | | | |
|---|---|---|---|
| <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> | <p>49 T028 3A0 Puller set, ball joint</p>  | <p>For removal of tie rod end</p> |
| <p>49 T028 303 Body (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> | <p>49 T028 304 Attachment (Part of 49 T028 3A0)</p>  | <p>For removal of tie rod end</p> |
| <p>49 0107 680A Engine stand</p>  | <p>For disassembly/assembly of transaxle</p> | <p>49 G019 0A0 Hanger, transaxle</p>  | <p>For disassembly/assembly transaxle</p> |
| <p>49 G030 440 Holder, primary shaft</p>  | <p>For holding primary shaft</p> | <p>49 FT01 361 Remover, bearing</p>  | <p>For removal of bearing race</p> |
| <p>49 B001 795 Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 0636 145 Puller, fan pulley boss</p>  | <p>For removal of bearing</p> |
| <p>49 G030 370 Removing plate</p>  | <p>For removal of secondary 3rd gear and 2nd gear</p> | <p>49 G017 1A0 Remover set, bearing</p>  | <p>For removal of bearings</p> |
| <p>49 F401 366A Plate (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> | <p>49 B092 373 Attachment G (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> |
| <p>49 B092 374 Attachment H (Part of 49 G017 1A0)</p>  | <p>For removal of bearing</p> | <p>49 0839 425C Puller set, bearing</p>  | <p>For removal of bearing</p> |


| | | | |
|---|--|---|--|
| <p>49 F401 330B Installer set, bearing</p>  | <p>For installation of bearing</p> | <p>49 F401 331 Body (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> |
| <p>49 F401 335A Attachment A (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> | <p>49 F401 336B Attachment B (Part of 49 F401 330B)</p>  | <p>For installation of bearing</p> |
| <p>49 G030 380D Shim selector set</p>  | <p>For adjustment of bearing preload</p> | <p>49 G030 381 Selector ø68 (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G030 382A Selector ø58 (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 F401 382A Selector ø52 (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 F401 384 Collar (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 G019 021 Bolt set (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 FT01 515A Adapter, preload (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> | <p>49 F401 385 Bar (Part of 49 G030 380D)</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 B017 102 Adapter, preload</p>  | <p>For adjustment of bearing preload</p> | <p>49 G017 202 Adapter, preload</p>  | <p>For adjustment of bearing preload</p> |
| <p>49 G030 455 Holder, diff. side gear</p>  | <p>For holding side gears</p> | | |

REMOVAL

1. Disconnect the negative battery cable.
2. Oil level ground, raise the vehicle and support it evenly on safety stands.
3. Drain the transaxle oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.




- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Splash shield 3. Fresh-air duct 4. Air cleaner assembly 5. Battery 6. Battery carrier 7. Starter 8. Harness bracket 9. Fuel filter 10. Neutral switch connector 11. Back-up light switch connector 12. Vehicle speedometer sensor (speedometer driven gear) connector 13. Clutch release cylinder Removal Note below | <ol style="list-style-type: none"> 14. Transverse member 15. Exhaust pipe 16. Extension bar 17. Change control rod 18. Tie rod end Removal Note below 19. Stabilizer control link 20. Drive shaft Removal Note page J2-14 21. Joint shaft 22. Engine mounting member Removal Note page J2-14 23. Undercover 24. No.4 engine mount 25. Transaxle Removal Note page J2-15 |
|---|---|



Removal Note
Clutch release cylinder

1. Remove the bolts shown.
2. Put the clutch release cylinder and the clutch pipe in a place where they will not interfere with transaxle removal.




Tie rod end


Caution

- The sharp edges of the SST can slice the tie rod end dust boot. Install the SST so that the sharp edges are between the dust boot and the knuckle.

1. Remove the cotter pin and the nut.
2. Disconnect the tie rod end from the knuckle by using the SST.


**Drive shaft**

1. Remove the clinch bolt from the lower arm ball joint.



2. Wrap a rag around the ball joint dust seal.


3. Pry the lower arm out of the knuckle.

**Caution**


- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when removing the drive shaft from the transaxle.

4. Separate the drive shaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle.

5. Suspend the drive shaft with a rope.




6. Install the **SSTs** into the transaxle to hold the side gears.


**Engine mounting member**

1. Support the engine by using the **SST** before removing the engine mounting member.

2. Remove the engine mounting member.

**Transaxle**

1. Loosen the **SST** (engine support) and lean the engine toward the transaxle.
2. Support the transaxle on a jack.



3. Remove the transaxle mounting bolts.
4. Remove the transaxle.

DISASSEMBLY**Precaution**

1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvent before disassembly.


Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.


2. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and dry with compressed air.
3. Clean out all holes and passages with compressed air, and verify that there are no obstructions.

5th / Reverse Gear and Housing Parts

1. Measure the 5th gear thrust clearance, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | |
|--|--|
| 1. Rear cover | 19. Magnet |
| 2. Locknut (primary shaft) Disassembly Note below | 20. Reverse idler shaft |
| 3. Locknut (secondary shaft) Disassembly Note below | 21. Reverse idler gear Inspection page J2-27 |
| 4. Primary reverse synchronizer gear Inspection page J2-27 | 22. 5th/reverse shift rod |
| 5. Reverse synchronizer ring Inspection page J2-27 | 23. 5th/reverse shift rod end |
| 6. Secondary reverse synchronizer gear Inspection page J2-27 | 24. Pin |
| 7. 5th/reverse shift fork | 25. Crank lever shaft |
| 8. 5th/reverse clutch hub assembly Inspection page J2-27 | 26. Crank lever assembly |
| 9. 5th synchronizer ring Inspection page J2-27 | 27. Shift fork and control rod assembly Disassembly Note page J2-18 |
| 10. 5th gear Preinspection below Inspection page J2-27 | 28. Steel ball |
| 11. Gear sleeve Inspection page J2-28 | 29. Spring |
| 12. Secondary 5th gear Inspection page J2-27 | 30. Primary shaft gear assembly |
| 13. Lock bolt | 31. Secondary shaft gear assembly |
| 14. Guide bolt and washer | 32. Differential assembly |
| 15. Lock bolt, ball and spring | 33. Clutch housing |
| 16. Back-up light switch | 34. Synchronizer key spring |
| 17. Neutral switch | 35. Clutch hub sleeve |
| 18. Transaxle case assembly | 36. Synchronizer key |
| | 37. Clutch hub |
| | 38. 3rd/4th shift fork |
| | 39. Interlock sleeve |
| | 40. Control lever |
| | 41. 1st/2nd shift fork |
| | 42. Control rod |
| | 43. Control end |



Preinspection


5th gear thrust clearance

1. Measure the 5th gear thrust clearance by using a dial indicator.

Clearance: 0.10–0.22 mm {0.004–0.009 in}

Maximum: 0.27 mm {0.011 in}


2. If the clearance exceeds the maximum, check the contact surfaces of 5th gear and the clutch hub. Replace worn or damaged parts.




Disassembly note

Locknut

1. Mount the transaxle on the SSTs.




2. Lock the primary shaft by using the **SST**.
3. Shift to 1st gear to lock the rotation of the primary shaft.
4. Uncrimp the tabs of the locknuts.
5. Remove the locknuts from the primary and secondary shafts.



Shift fork and control rod assembly

1. Align the ends of the interlock sleeve and of the control lever (arrow). Turn the control rod counterclockwise.
2. While holding the 1st/2nd shift fork with one hand and the 3rd/4th shift fork with the other, raise them both at the same time and shift each of the clutch hub sleeves.




3. Lift the control end and remove the steel ball, and, at the same time, remove the control rod from the clutch housing.
4. Separate the control rod and shift fork assembly from each of the clutch hub sleeves.

Clutch Housing and Transaxle Case Components


Note

- The oil seals do not need to be removed unless they are being replaced.

Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | |
|------------------------------------|------------|
| 1. Bearing race (primary shaft) | |
| 2. Oil seal (primary shaft) | |
| Disassembly Note | page J2-20 |
| 3. Bearing race (secondary shaft) | |
| Disassembly Note | page J2-20 |
| 4. Funnel | |
| 5. Guide plate assembly | |
| 6. Change arm | |
| 7. Roll pin | |
| Disassembly Note | page J2-20 |
| 8. Change rod assembly | |
| 9. Boot | |
| 10. Selector | |
| 11. Oil seal (change rod assembly) | |
| Disassembly Note | page J2-20 |
| 12. Bleeder cover | |
| 13. Bleeder | |
| 14. Vehicle speedometer sensor | |
| Inspection | page J2-29 |
| 15. Oil seal (differential) | |
| Disassembly Note | page J2-20 |
| 16. Bearing race (differential) | |
| Disassembly Note | page J2-21 |
| 17. Reverse lever shaft | |
| Disassembly Note | page J2-21 |
| 18. Reverse lever | |
| Inspection | page J2-28 |
| 19. Drain plug and washer | |
| 20. Bearing race (transaxle case) | |
| Disassembly Note | page J2-21 |
| 21. Adjustment shim | |
| 22. Bearing race (differential) | |
| Disassembly Note | page J2-21 |
| 23. Adjustment shim(s) | |
| 24. Oil seal (differential) | |
| Disassembly Note | page J2-20 |
| 25. Oil passage | |
| 26. Joint | |
| 27. Change rod | |




Disassembly note
Oil seal (primary shaft)

Caution


- The clutch housing is made of aluminum, and is therefore easily dented and scratched by metal tools. When removing the oil seal, keep contact with the clutch housing to a minimum.

Remove the oil seal from the clutch housing as shown in the figure.




Bearing race (secondary shaft)

Remove the bearing race by lifting it and the funnel out together.




Roll pin

To remove the clutch housing pin, align the groove with the roll pin, then tap the pin out by using a pin punch.




Oil seal (change rod assembly)


Remove the oil seal.




Oil seal (differential)
 Remove the oil seal.

**Bearing race (differential)**


Remove the bearing race by using the **SST**.

**Reverse lever shaft**

1. Remove the roll pin by using pliers.




2. Protect the reverse lever shaft with a rag, and use pliers to remove the shaft.

**Bearing race (transaxle case)**


Remove the bearing race by using the **SST**.

Primary Shaft Assembly

1. Measure the thrust clearance of all gears before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | | | |
|--------------------------------|------------|--------------------------------|------------|
| 1. Bearing (4th gear end) | | 7. 3rd gear | |
| Disassembly Note | page J2-23 | Preinspection | page J2-23 |
| Inspection | page J2-28 | Disassembly Note | page J2-23 |
| 2. 4th gear | | Inspection | page J2-27 |
| Preinspection | page J2-23 | 8. Bearing (primary shaft end) | |
| Inspection | page J2-27 | Disassembly Note | page J2-23 |
| 3. 4th synchronizer ring | | Inspection | page J2-28 |
| Inspection | page J2-27 | 9. Primary shaft gear | |
| 4. Retaining ring | | Inspection | page J2-28 |
| 5. 3rd/4th clutch hub assembly | | 10. Synchronizer key spring | |
| Disassembly Note | page J2-23 | 11. 3rd/4th clutch hub sleeve | |
| Inspection | page J2-27 | 12. Synchronizer key | |
| 6. 3rd synchronizer ring | | 13. 3rd/4th clutch hub | |
| Disassembly Note | page J2-23 | | |
| Inspection | page J2-27 | | |


**Preinspection****3rd gear thrust clearance**

1. Measure the clearance between 3rd gear and 2nd gear.

Clearance: 0.05–0.20 mm {0.002–0.008 in}

Maximum: 0.25 mm {0.010 in}

2. If the clearance exceeds the maximum, check the contact surfaces of the 3rd gear, 2nd gear and 3rd/4th clutch hub. Replace worn and damaged parts.


**4th gear thrust clearance**

1. Measure the clearance between 4th gear and the ball bearing.


Clearance: 0.17–0.37 mm {0.007–0.015 in}

Maximum: 0.42 mm {0.017 in}


2. If the clearance exceeds the maximum, check the contact surfaces of the 4th gear, ball bearing, and 3rd/4th clutch hub. Replace worn and damaged parts.

**Disassembly note****Bearing (4th gear end)**

Remove the bearing by using the **SST**.

**3rd/4th clutch hub assembly, 3rd synchronizer ring and 3rd gear**


1. Remove the retaining ring.
2. Remove the 3rd/4th clutch hub assembly, 3rd synchronizer ring, and 3rd gear by using the **SST**.

**Bearing (primary shaft end)**


Remove the bearing by using the **SST**.

Secondary Shaft Assembly

1. Measure the thrust clearance of 1st gear and 2nd gear before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- | | | | | |
|--------------------------|-------|------------|--------------------------------------|-------|
| 1. Bearing | | | 8. 1st/2nd clutch hub assembly | |
| Disassembly Note | | page J2-25 | Disassembly Note | |
| Inspection | | page J2-28 | Inspection | |
| 2. Secondary 4th gear | | | Inspection | |
| Disassembly Note | | page J2-25 | 9. 1st synchronizer ring | |
| Inspection | | page J2-27 | Disassembly Note | |
| 3. Retaining ring | | | Inspection | |
| 4. Secondary 3rd gear | | | Inspection | |
| Disassembly Note | | page J2-25 | 10. 1st gear | |
| Inspection | | page J2-27 | Preinspection | |
| 5. 2nd gear | | | Disassembly Note | |
| Preinspection | | page J2-25 | Inspection | |
| Disassembly Note | | page J2-25 | 11. Bearing (secondary shaft end) | |
| Inspection | | page J2-27 | Disassembly Note | |
| 6. 2nd synchronizer ring | | | Inspection | |
| Inspection | | page J2-27 | Inspection | |
| 7. Retaining ring | | | 12. Secondary shaft gear | |
| | | | Inspection | |
| | | | 13. Synchronizer key spring | |
| | | | 14. Clutch hub sleeve (reverse gear) | |
| | | | 15. Synchronizer key | |
| | | | 16. 1st/2nd clutch hub | |


**Preinspection****1st gear thrust clearance**

1. Measure the clearance between 1st gear and the differential drive gear.

Clearance: 0.05–0.28 mm {0.002–0.011 in}

Maximum: 0.33 mm {0.013 in}

2. If the clearance exceeds the maximum, check the contact surfaces of the 1st gear, differential drive gear of the secondary shaft gear, and 1st/2nd clutch hub assembly. Replace worn and damaged parts.


**2nd gear thrust clearance**

1. Measure the clearance between 2nd gear and secondary 3rd gear.


Clearance: 0.18–0.46 mm {0.007–0.018 in}

Maximum: 0.51 mm {0.020 in}


2. If the clearance exceeds the maximum, check the contact surfaces of the 2nd gear, secondary 3rd gear, and 1st/2nd clutch hub assembly. Replace worn and damaged parts.

**Disassembly note****Bearing and secondary 4th gear**


- Remove the bearing and secondary 4th gear by using the SST.

**Secondary 3rd gear and 2nd gear**

1. Remove the retaining ring.
2. Shift the gears to 1st gear.
3. Remove the secondary 3rd gear and 2nd gear by using the SST.

**1st/2nd clutch hub assembly, 1st synchronizer ring, and 1st gear**


1. Remove the retaining ring.
2. Remove the 1st/2nd clutch hub assembly, 1st synchronizer ring, and 1st gear by using a press.




Bearing (secondary shaft end)
Remove the bearing by using the **SSTs**.

INSPECTION


Inspect all parts and repair or replace as necessary.

**Gears**

1. Inspect the synchronizer cones for wear.
2. Inspect the gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer ring matching teeth for damage and wear.

**Synchronizer Ring**


1. Inspect the synchronizer ring teeth for damage, wear, and cracks.
2. Inspect the tapered surface for wear and cracks.




3. Set the synchronizer ring squarely in the gear.
4. Measure the clearance between the synchronizer ring and the flank surface of the gear.

Standard clearance: 1.50 mm {0.059 in}

Minimum: 0.80 mm {0.031 in}

**Clutch Hub Assembly**


1. Inspect the clutch hub sleeve and hub operation.
2. Inspect the gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer keys for damage, wear, and cracks.



4. Measure the clearance between the hub sleeve and shift fork.

Clearance

| | mm {in} | |
|----------|-------------------------|--------------|
| | Standard | Maximum |
| 1st/2nd | 0.10–0.45 {0.004–0.018} | 0.95 {0.037} |
| 3rd/4th | 0.10–0.40 {0.004–0.016} | 0.90 {0.035} |
| 5th/Rev. | 0.10–0.36 {0.004–0.014} | 0.86 {0.034} |




Reverse Idler Gear and Reverse Lever

1. Inspect the gear teeth for damage, wear, and cracks.
2. Measure the clearance between the reverse idler gear bushing and the reverse lever.

Standard clearance:


0.10–0.32 mm {0.004–0.013 in}

Maximum: 0.82 mm {0.032 in}



Bearing


Inspect for damage and rough rotation.



Primary Shaft Gear and Secondary Shaft Gear

1. Inspect the gear contact surface for damage and wear.
2. Inspect the splines for damage and wear.
3. Inspect the gear teeth for damage, wear, and cracks.
4. Inspect the oil passage for clogging.
5. Measure the shaft gear runout.




Primary shaft gear runout: 0.05 mm {0.002 in} max.



Secondary shaft gear runout:

0.015 mm {0.0006 in} max.

6. If the shaft gear is replaced, adjust the bearing preload. (Refer to page J2–36.)



6. Determine the clearance between the shaft gears and the gears.

Clearance

mm {in}

| | Shaft (Outer dia.) | Gear (Inner dia.) | Sleeve (Outer dia.) | Clearance |
|-----|--------------------------------|--------------------------------|--------------------------------|----------------------------|
| 1st | 39.445–39.470 {1.553–1.554} | 39.500–39.525 {1.555–1.556} | — | 0.03–0.08 {0.001–0.003} |
| 2nd | 34.945–34.970 {1.376–1.377} | 35.000–35.025 {1.378–1.379} | — | |
| 3rd | 35.945–35.970 {1.415–1.416} | 36.000–36.025 {1.417–1.418} | — | |
| 4th | 30.945–30.970 {1.218–1.219} | 31.000–31.025 {1.221–1.222} | — | |
| 5th | — | 34.000–34.025 {1.339–1.400} | 33.945–33.970 {1.336–1.337} | |

Vehicle speedometer sensor

1. Inspect the teeth for damage and wear.
2. Inspect the O-ring for damage and wear.


ASSEMBLY

Precaution


1. Replace all O-rings and gaskets with the new ones included in the overhaul kit.
2. Verify that all parts are completely clean before assembly.
3. Assemble parts within 10 minutes after applying sealant. Allow all sealant to cure for at least 30 minutes after assembly before filling the transaxle with transaxle oil.
4. Replace bearing races and bearings as sets.

Secondary Shaft Assembly

Assemble in the order shown in the figure, referring to **Assembly Note**.




- | | |
|--|--|
| 1. 1st/2nd clutch hub Assembly Note page J2-31 | 9. 1st/2nd clutch hub assembly Assembly Note page J2-31 |
| 2. Synchronizer key | 10. Retaining ring |
| 3. Clutch hub sleeve (reverse gear) | 11. 2nd synchronizer ring Assembly Note page J2-32 |
| 4. Synchronizer key spring | 12. 2nd gear Assembly Note page J2-32 |
| 5. Secondary shaft gear | 13. Secondary 3rd gear Assembly Note page J2-32 |
| 6. Bearing (secondary shaft end) Assembly Note page J2-31 | 14. Retaining ring |
| 7. 1st gear Assembly Note page J2-31 | 15. Secondary 4th gear Assembly Note page J2-32 |
| 8. 1st synchronizer ring Assembly Note page J2-31 | 16. Bearing Assembly Note page J2-32 |




Assembly Note
Clutch hub
Synchronizer key dimensions

mm {in}


| | ① | ② | ③ |
|---------------------|--------------|--------------|-------------|
| 1st/2nd | 19.0 {0.748} | 4.25 {0.167} | 5.0 {0.197} |
| 3rd/4th 5th/Rev. | 17.0 {0.669} | 4.25 {0.167} | 5.0 {0.197} |



Install the synchronizer keys and springs in the clutch hub.




Bearing (secondary shaft end)
 Install the new bearing by using the **SST**.




1st gear, 1st synchronizer ring and 1st/2nd clutch hub assembly


The 2nd synchronizer ring has teeth missing at three places around its outer edge to help distinguish it from the other synchronizer rings.



1. Assemble the 1st gear, 1st synchronizer ring, and 1st/2nd clutch hub assembly, as shown in the figure.
2. Align the synchronizer ring grooves and synchronizer keys.




3. Press the 1st/2nd clutch hub assembly on by using the SST.




2nd synchronizer ring, 2nd gear and secondary 3rd gear

1. Install the 2nd synchronizer ring and 2nd gear.
2. Install the secondary 3rd gear by using the SST.




Secondary 4th gear and bearing

1. Install the secondary 4th gear and the bearing by using the SST.



2. Measure the clearance between the 1st gear and the differential drive gear.

Clearance: 0.05–0.28 mm {0.002–0.011 in}
Maximum: 0.33 mm {0.013 in}




3. Measure the clearance between the 2nd gear and the secondary 3rd gear.

Clearance: 0.18–0.46 mm {0.007–0.018 in}
Maximum: 0.51 mm {0.020 in}


4. If not as specified, reassemble the secondary shaft assembly.

Primary Shaft Assembly


Assemble in the order shown in the figure, referring to **Assembly Note**.



- | | |
|---|--|
| 1. 3rd/4th clutch hub Assembly Note page J2-31 | 8. 3rd synchronizer ring Assembly Note page J2-34 |
| 2. Synchronizer key | 9. 3rd/4th clutch hub assembly Assembly Note page J2-34 |
| 3. 3rd/4th clutch hub sleeve | 10. Retaining ring |
| 4. Synchronizer key spring | 11. 4th synchronizer ring Assembly Note page J2-34 |
| 5. Primary shaft gear | 12. 4th gear Assembly Note page J2-34 |
| 6. Bearing (primary shaft end) Assembly Note below | 13. Bearing Assembly Note page J2-34 |
| 7. 3rd gear Assembly Note page J2-34 | |




Assembly note
Bearing (primary shaft end)
 Install the new bearing by using the SST.




3rd gear, 3rd synchronizer ring and 3rd/4th clutch hub assembly

Install the 3rd gear, 3rd synchronizer ring, and 3rd/4th clutch hub assembly by using a press.




4th synchronizer ring, 4th gear and bearing

1. Install the 4th synchronizer ring, 4th gear, and a new bearing by using the SSTs.



2. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05–0.20 mm {0.002–0.008 in}
Maximum: 0.25 mm {0.010 in}



3. Measure the clearance between the 4th gear and bearing.



Clearance: 0.17–0.37 mm {0.007–0.015 in}
Maximum: 0.42 mm {0.017 in}






4. If not as specified, reassemble the primary shaft assembly.

Bearing preload adjustment

When replacing any of the parts listed in the table below, adjust the bearing preload by selecting and installing the proper adjustment shim(s).



| Primary shaft assembly | Secondary shaft assembly | Differential |
|--|--|---|
| <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Primary shaft gear bearing • Primary shaft gear | <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Secondary shaft gear bearing • Secondary shaft gear • Secondary 4th gear | <ul style="list-style-type: none"> • Transaxle case • Clutch housing • Differential side bearing • Ring gear and gear case assembly |






1. Install the primary and secondary shaft bearing races into the transaxle case (diaphragm springs and shims removed).
2. Mount the clutch housing onto the transaxle hanger, and set the differential bearing race into the clutch housing. Position a piece of pipe against the bearing race and tap it in until it contacts the clutch housing.
3. Set the bearing races into the **SSTs** (selector) as shown in the figure.
4. Turn the selector to eliminate the gap indicated by the arrow.
5. Set the differential assembly into the clutch housing, and set the bearing race and the **SST** (selector) on the differential. Set the assembled selectors for the primary and secondary shaft in the clutch housing. Mount the shaft gear assemblies as shown in the figure.
6. Set the **SST** (collars) in the positions shown in the figure.
7. Install the transaxle case and tighten the **SST** (bolts) to the specified torque.

Tightening torque:
 $38-51 \text{ N}\cdot\text{m}$ { $3.8-5.3 \text{ kgf}\cdot\text{m}$, $28-38 \text{ ft}\cdot\text{lbf}$ }
8. To seat the bearings, mount the **SST** (bars) on parts A and B of the selectors, and turn the selectors so the gaps are widened. Then turn the **SST** in the reverse direction until the gaps are eliminated.



| Thickness (Shaft gears) | mm {in} |
|-------------------------|--------------|
| 0.20 {0.008} | 0.50 {0.020} |
| 0.25 {0.010} | 0.55 {0.022} |
| 0.30 {0.012} | 0.60 {0.024} |
| 0.35 {0.014} | 0.65 {0.026} |
| 0.40 {0.016} | 0.70 {0.028} |
| 0.45 {0.018} | |



9. Manually expand the selector until it no longer turns by hand.
10. Verify that both the primary and secondary shafts turn smoothly.

11. Measure the clearance between the two halves of the **SST** (selector) around the circumference by using a feeler gauge.
12. Take the maximum reading and determine the shim to be used. Use no more than two shims.

<Primary shaft adjustment shim>

- Subtract the diaphragm spring thickness (**0.65 mm, {0.026 in}**) from the gap determined in Step 11 for the primary shaft.
- Make a shim selection range by subtracting the standard clearance parameters from the result in the previous step.
- Select the thinner shim within the range to obtain the standard clearance.

Standard clearance:

0–0.05 mm {0–0.002 in}

Example: 0.57 mm {0.022 in}

Shim selection range:

(0.57 mm {0.022 in}–0.05 mm {0.002 in}) – (0.57 mm {0.022 in}–0 mm {0 in}) = 0.52 mm {0.020 in}–0.57 mm {0.022 in}

Shim: 0.55 mm {0.022 in}

<Secondary shaft adjustment shim>

- Subtract the diaphragm spring thickness (**0.65 mm {0.026 in}**) from the gap determined in Step 11 for the secondary shaft.
- Make a shim selection range by adding the standard clearance parameters to the result in the previous step.
- Select the thinner shim within the range to obtain the standard clearance.

Tightening amount:

0.03–0.08 mm {0.001–0.003 in}


Example: 0.57 mm {0.022 in}

Shim selection range:

(0.57 mm {0.022 in} + 0.03mm {0.001 in})–(0.57 mm {0.022 in} + 0.08mm {0.003 in}) = 0.60 mm {0.024 in}–0.65 mm {0.026 in}


Shim: 0.60 mm {0.024 in}

13. Install the **SST** to the differential.



14. Turn the **SST** with a torque wrench. Adjust the **SST** (selector) with the **SST** (bars) until the specified preload is obtained.

Preload: 0.5 N-m {5.0 kgf-cm, 4.3 in-lbf}



15. Measure the gap between A and B around the circumference of the **SST** (selector) by using a feeler gauge.

14. Add **0.15 mm {0.006 in}** to the measured clearance and select the combination of two shims closest in value to that measurement. Use no more than two shims.

| Thickness | mm {in} |
|--------------|--------------|
| 0.10 {0.004} | 0.70 {0.028} |
| 0.20 {0.008} | 0.75 {0.030} |
| 0.25 {0.010} | 0.80 {0.031} |
| 0.30 {0.012} | 0.85 {0.033} |
| 0.35 {0.014} | 0.90 {0.035} |
| 0.40 {0.016} | 0.95 {0.037} |
| 0.45 {0.018} | 1.00 {0.039} |
| 0.50 {0.020} | 1.05 {0.041} |
| 0.55 {0.022} | 1.10 {0.043} |
| 0.60 {0.024} | 1.15 {0.045} |
| 0.65 {0.026} | 1.20 {0.047} |

Example: 0.32 mm {0.013 in}


$0.32 \text{ mm } \{0.013 \text{ in}\} + 0.15 \text{ mm } \{0.006 \text{ in}\} = 0.47 \text{ mm } \{0.019 \text{ in}\}.$

Nearest shim (on thick side) to 0.47 mm {0.019 in} is 0.50 mm {0.020 in}.

17. Remove the transaxle case and the **SSTs**.

18. Remove the selectors, the primary shaft assembly, and the differential.


19. Remove the bearing races.



Assembly note


Oil seal (differential)

1. Using the **SST** and a hammer, tap the new oil seal in evenly until the **SST** contacts the transaxle case.
2. Coat the lip of the oil seal with transaxle oil.




Bearing race (differential)

1. Install the adjustment shim(s) to the differential case.
2. Apply transaxle oil to the bearing race, and install it to the differential case by using a suitable pipe.


**Bearing race (transaxle case)**

1. Install the adjustment shim(s) to the primary and secondary shaft bearing seats in the transaxle case.
2. Apply transaxle oil to each bearing race, and install them to the transaxle case by using a suitable pipe.


**Oil seal (change rod assembly)**

1. Install the new oil seal by using a suitable pipe.
2. Coat the lip of the oil seal with transaxle oil.


Outer diameter of pipe: 26.0 mm {1.02 in}

**Boot**

Install the boot so that the drain hole is facing downward when mounted on the vehicle.

**Oil seal (primary shaft)**

Apply transaxle oil to the outer circumference of the oil seal, and install it to the transaxle case by using a suitable pipe.


**Bearing preload**

Verify the shaft gears and the differential bearing preloads. Readjust the bearing preloads if they are not within specification.

1. Set the primary shaft gear assembly and the differential into the clutch housing.
2. Install the transaxle case, and tighten to the specified torque.

Tightening torque:


38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}



3. Install the **SST** to the differential.
4. Connect a torque wrench to the **SST** and measure the preload.

Preload:


1.4–1.9 N·m {14–20 kgf·cm, 13–17 in·lbf}



5. Remove the **SST**.
6. With the transaxle facing in the direction shown in the figure, install the **SST** to the primary shaft gear assembly.
7. Connect a torque wrench to the **SST** and measure the preload.

Preload:

0.1–0.2 N·m {1.0–2.5 kgf·cm, 0.9–2.1 in·lbf}



8. Remove the **SST**, transaxle case, primary shaft gear assembly and differential.
9. Install the secondary shaft gear assembly and transaxle case, and tighten to the specified torque.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}


10. Install the **SST** to the secondary shaft gear assembly.
11. Connect a torque wrench to the **SST** and measure the preload.

Preload:


0.2–0.4 N·m {2.0–4.0 kgf·cm, 1.8–3.4 in·lbf}

5th/Reverse Gear and Housing Parts

Assemble in the order shown in the figure, referring to **Assembly Note**.




- | | |
|---|---|
| 1. Control rod | 23. Reverse idler gear |
| 2. Control end | Assembly Note page J2-44 |
| 3. 1st/2nd shift fork | 24. Reverse idler shaft |
| 4. Control lever | Assembly Note page J2-44 |
| 5. Interlock sleeve | 25. Magnet |
| 6. 3rd/4th shift fork | 26. Transaxle case assembly |
| 7. Clutch hub | Assembly Note page J2-45 |
| 8. Synchronizer key | 27. Neutral switch |
| 9. Clutch hub sleeve | 28. Back-up light switch |
| 10. Synchronizer key spring | 29. Lock bolt, ball and spring |
| 11. Clutch housing | 30. Guide bolt and washer |
| 12. Differential assembly | 31. Lock bolt |
| 13. Secondary shaft gear assembly | 32. Secondary 5th gear |
| Assembly Note below | Assembly Note page J2-45 |
| 14. Primary shaft gear assembly | 33. Gear sleeve |
| Assembly Note below | 34. 5th gear |
| 15. Spring | 35. 5th synchronizer ring |
| 16. Steel ball | 36. 5th/reverse clutch hub assembly |
| 17. Shift fork and control rod assembly | Assembly Note page J2-45 |
| Assembly Note below | 37. 5th/reverse shift fork |
| 18. Crank lever assembly | Assembly Note page J2-45 |
| Assembly Note page J2-44 | 38. Secondary reverse synchronizer gear |
| 19. Crank lever shaft | 39. Reverse synchronizer ring |
| Assembly Note page J2-44 | 40. Primary reverse synchronizer gear |
| 20. Pin | 41. Locknut (secondary shaft) |
| 21. 5th/reverse shift rod end | Assembly Note page J2-45 |
| Assembly Note page J2-44 | 42. Locknut (primary shaft) |
| 22. 5th/reverse shift rod | Assembly Note page J2-45 |
| Assembly Note page J2-44 | 43. Rear cover |



Assembly Note


Primary shaft gear assembly and secondary shaft gear assembly

Install the primary shaft gear assembly and the secondary shaft gear assembly together.




Shift fork and shift rod assembly


1. Shift to 2nd gear and position the shift fork and shift rod assembly as shown.



2. Insert the spring seat and spring into the reverse lever shaft, install the steel ball, and place a scraper against it.
3. With the edge of the control end against the scraper, push the control end in the direction of the arrow so that the ball goes into the shaft. This will line up the rod with the shift rod coupling hole in the clutch housing.




4. Set each clutch hub sleeve to the neutral position, and tap the shift rod from above so that the steel ball goes into the center groove (of the three grooves in the control end).
5. Pull the ball part of the control end forward so that the steel ball goes into the detent in the groove.



Crank lever assembly and crank lever shaft

1. Install a new O-ring to the crank lever shaft.
2. Fit the crank lever between the change arm and the control end, and connect the crank lever shaft to the crank lever.
3. Align the pin holes of the crank lever shaft and the clutch housing, and insert a new pin.




5th/reverse shift rod end and 5th/reverse shift rod

Install shift rod end (1) and the shift rod (2), and tighten the gate mounting bolt.


Tightening torque:

11.8–13.7 N·m {120–140 kgf·cm, 105–121 in·lbf}



Reverse idler gear and reverse idler shaft

1. Install the reverse idler gear and the reverse idler shaft.
2. Attach the magnet to the clutch housing.
3. Align the end of the interlock sleeve with the control lever (arrow), and face the reverse idler shaft screw hole in the direction shown in the figure.


**Transaxle case assembly**

1. Apply a thin coat of sealant to the contact surfaces of the clutch housing and transaxle case, and tighten the transaxle case installation bolts to the specified torque.


Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}


2. Insert the **SSTs** through the drive shaft and joint shaft hole.

**Secondary 5th gear**

Install the secondary 5th gear as shown.

**5th/reverse clutch hub assembly and 5th/reverse shift fork**

Install the 5th/reverse clutch hub assembly and the 5th/reverse shift fork together.

**Locknut**

1. Shift to 1st gear.
2. Lock the primary shaft by using the **SST**.
3. Tighten new locknuts onto the primary and secondary shafts.

Tightening torque:

128–196 N·m {13–20 kgf·m, 94–145 ft·lbf}


4. Stake the locknuts.

5. Measure the 5th gear thrust clearance by using a dial indicator.


Clearance: 0.10–0.22 mm {0.004–0.009 in}

Maximum: 0.27 mm {0.011 in}

6. If not as specified, reassemble the transaxle.




- | | |
|--|--|
| 1. Transaxle Installation Note below | 11. Exhaust pipe |
| 2. No.4 engine mount | 12. Transverse member |
| 3. Undercover | 13. Clutch release cylinder |
| 4. Engine mounting member Installation Note below | 14. Vehicle speedometer sensor (speedometer driven gear) |
| 5. Drive shaft and joint shaft Installation Note page J2-48 | 15. Back-up light switch connector Installation Note page J2-49 |
| 6. Drive shaft Installation Note page J2-48 | 16. Neutral switch connector |
| 7. Stabilizer control link Installation Note page J2-49 | 17. Fuel filter |
| 8. Tie rod end Installation Note page J2-49 | 18. Harness bracket |
| 9. Change control rod Installation Note page J2-49 | 19. Starter |
| 10. Extension bar Installation Note page J2-49 | 20. Battery carrier |
| | 21. Battery |
| | 22. Air cleaner assembly |
| | 23. Fresh-air duct |
| | 24. Splash shield |
| | 25. Wheel and tire |



Installation Note
Transaxle

1. Set the transaxle on a jack and lift it into place.



2. Install the transaxle mounting bolts.

Tightening torque:
68-99 N·m {6.9-10.1 kgf·m, 50-73 ft·lbf}

3. Loosely tighten the No.4 engine mount bolts.


Engine mounting member


Note

- Put the No.1 and No.2 engine mount stud bolts in the installing holes when installing the engine mounting member.

1. Align the No.1 and No.2 engine mount stud bolts in the installing holes, and install the bolts and nuts as shown.

Tightening torque:
A: 38-51 N·m {3.8-5.3 kgf·m, 28-38 ft·lbf}
B: 64-89 N·m {6.5-9.1 kgf·m, 48-65 ft·lbf}






2. Tighten the No.4 engine mount nuts.

Tightening torque:

A: 67–93 N·m {6.8–9.5 kgf·m, 50–68 ft·lbf}


B: 28–40 N·m {2.8–4.1 kgf·m, 21–29 ft·lbf}

3. Remove the SST (engine support).




Drive shaft and joint shaft

1. Remove the SSTs from the transaxle case.



2. Install the clip with the gap at the top of the groove.




Caution

- The sharp edges of the drive shaft snap ring can slice or puncture the oil seal. Be careful when installing the drive shaft to the transaxle.

3. Apply transaxle oil to the oil seal lip, and install the drive shaft.

4. Verify that the drive shaft is correctly seated by pulling on the shaft. It must not slide out.



5. Insert the joint shaft to the transaxle.

6. Install the joint shaft to the cylinder block in the order shown.


Tightening torque:

43–61 N·m {4.3–6.3 kgf·m, 32–45 ft·lbf}

7. Connect the lower arm to the knuckle and tighten the clinch bolt.

Tightening torque:


44–58 N·m {4.4–6.0 kgf·m, 32–43 ft·lbf}

**Stabilizer control link**

Install the stabilizer control link.

Tightening torque:

44–60 N·m {4.4–6.2 kgf·m, 32–44 ft·lbf}


**Tie-rod end**

1. Install the locknut.

Tightening torque:

43–56 N·m {4.3–5.8 kgf·m, 32–41 ft·lbf}

2. Secure the locknut by using a new cotter pin.

**Change control rod and extension bar**

1. Install the extension bar to the transaxle.


Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

2. Install the change control rod to the transaxle.

Tightening torque:

16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}

**Back-up light switch connector**

1. Install the back-up light switch connector and the bracket for the ground terminals.

2. Connect the back-up light switch connector.

3. Connect the ground terminals.

Tightening torque:






16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}

After warming-up the engine, do the following.

- **Check the amount of oil.**
- **Conduct a road test.**
 1. No abnormal noise in each shift position.
 2. Smooth shift change is possible.
 3. Transaxle does not jump out of gear.
 4. Speedometer operates correctly.
 5. Back-up lights operate correctly.


DIFFERENTIAL

PREPARATION SST

| | | | |
|---|---|---|--|
| <p>49 G017 1A0 Remove set, bearing</p>  | <p>For removal of bearing</p> | <p>49 F401 366A Plate (Part of 49 G017 1A0)</p>  | <p>For removal of side bearing</p> |
| <p>49 B092 375 Attachment J (Part of 49 G017 1A0)</p>  | <p>For removal of side bearing</p> | <p>49 0839 425C Pulley set, bearing</p>  | <p>For removal of side bearing</p> |
| <p>49 G030 338 Attachment E</p>  | <p>For installation of side bearing</p> | | |

DISASSEMBLY / INSPECTION / ASSEMBLY

1. Before disassembly, inspect the backlash of the side gears and pinion gears, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.
5. Measure the backlash after assembly, referring to **Backlash of Side Gear and Pinion Gear**.

**1. Roll pin**

Assembly Note page J2-53

2. Pinion shaft**3. Pinion gear**

Inspect for wear and cracks

Preinspection below

Inspection of backlash page J2-53

4. Thrust washer**5. Side gear**

Inspect for wear and cracks

Preinspection below

Inspection of backlash page J2-53

6. Thrust washer**7. Bearing (side opposite ring gear)**

Disassembly Note page J2-52

Inspection page J2-52

Assembly Note page J2-53

8. Speedometer drive gear**9. Bearing (ring gear side)**


Disassembly Note page J2-52

Inspection page J2-52

Assembly Note page J2-52

10. Ring gear and gear case assembly

Inspection page J2-52


**Preinspection****Backlash of side gear and pinion gear**

Measure the backlash by the following procedure.

1. Install the left and right drive shafts in the differential assembly.
2. Support the drive shafts on V-blocks as shown in the figure.
3. Measure the backlash of both pinion gears.

Backlash: 0-0.1 mm {0-0.004 in}

4. If not as specified, replace worn and damage parts.




Disassembly Note
Bearing (side opposite ring gear)

Note


- The bearing does not need to be removed unless you are replacing it.

Remove the bearing by using the **SSTs**.



Bearing (ring gear side)

Remove the bearing by using the **SST**.




Inspection

Inspect all parts and repair or replace as necessary.


Ring gear and gear case assembly

Inspect the ring gear for wear and cracks. If the gear case is replaced, adjust the bearing preload.



Bearing


Inspect for wear and rough rotation. If the bearing is removed, then replace it and the bearing race together, and adjust the bearing preload.




Assembly Note

Bearing (ring gear side)


Install the new bearing by using the **SST**.

**Bearing (side opposite ring gear)**

1. Install the speedometer drive gear.
2. Install the new bearing by using the **SST**.

**Roll pin**

- Install the new roll pin as shown in the figure to hold the pinion shaft.

**Backlash of Side Gear and Pinion Gear**

Measure the backlash by the following procedure.

1. Install the left and right drive shafts in the differential assembly.
2. Support the drive shafts on V-blocks as shown in the figure.
3. Measure the backlash of both pinion gears.


Backlash: 0–0.1 mm {0–0.004 in}

4. If not as specified, replace worn and damage parts.

SHIFT MECHANISM

OVERHAUL



1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



N·m [kgf·m, ft·lb]

- 1. Transverse member
- 2. Exhaust pipe
- 3. Shift lever knob
- 4. Rear ashtray
- 5. Rear console
- 6. Front console
- 7. Nut
- 8. Bolt
- 9. Nut
- 10. Bolt
- 11. Bushing
- 12. Change control rod
Inspect for bending
- 13. Nut
- 14. Washer
- 15. Pipe
- 16. Bushing
- 17. Washer

- 18. Bushing
- 19. Nuts
- 20. Washers
- 21. Insulator
Inspect for damage and cracks
- 22. Mounting boot
- 23. Spring
Inspect for damage and weakness
Assembly Note below
- 24. Upper ball seat
- 25. Gear shift lever
- 26. Boot
Inspect for wear and damage
- 27. Holder
- 28. Lower ball seat
- 29. Extension bar
Assembly Note below



Assembly Note

Extension bar

- 1. Install the extension bar to the floor, and then onto the transaxle.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

- 2. Tighten the bracket installation nuts to the specified torque.

Tightening torque:

9.81–14.7 N·m {100–150 kgf·cm, 86.8–130.2 in·lbf}

Spring


Make sure that the hooked part of the spring is properly seated in the bracket groove, as shown in the figure.

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

FRONT AND REAR AXLES

| | |
|---|------|
| INDEX | M- 2 |
| OUTLINE | M- 3 |
| SPECIFICATIONS | M- 3 |
| TROUBLESHOOTING GUIDE | M- 3 |
| FRONT AXLE | M- 4 |
| PREPARATION | M- 4 |
| WHEEL HUB, STEERING KNUCKLE | M- 5 |
| REAR AXLE | M-11 |
| PREPARATION | M-11 |
| DRUM BRAKE TYPE | M-11 |
| DISC BRAKE TYPE | M-14 |
| DRIVE SHAFT | M-17 |
| PREPARATION | M-17 |
| JOINT SHAFT | M-19 |
| DRIVE SHAFT (TRIPOD JOINT) | M-24 |

INDEX



| | |
|------------------------------|-----------|
| 1. Front axle | |
| Preinspection | page M- 5 |
| Removal / Installation | page M- 6 |
| Disassembly / Inspection / | |
| Assembly | page M- 8 |
| 2. Rear axle | |
| [Drum brake type] | |
| Preinspection | page M-11 |
| Removal / Inspection / | |
| Installation | page M-12 |
| Disassembly / Assembly | page M-13 |
| [Disc brake type] | |
| Preinspection | page M-14 |
| Removal / Inspection / | |
| Installation | page M-15 |
| Disassembly / Assembly | page M-16 |

| | |
|------------------------------|-----------|
| 3. Joint shaft | |
| Preinspection | page M-19 |
| Removal / Installation | page M-19 |
| Disassembly / Inspection / | |
| Assembly | page M-22 |
| 4. Drive shaft | |
| Removal / Installation | page M-25 |
| Disassembly / Inspection / | |
| Assembly | page M-29 |

OUTLINE

SPECIFICATIONS

| Item | Model | B6 DOHC | | K8 DOHC | |
|---|-----------------|--------------|---------------|---------------|---------------|
| | | MTX | ATX | MTX | ATX |
| Front axle | | | | | |
| Maximum wheel bearing play | mm {in} | 0.05 {0.002} | | | |
| Rear axle | | | | | |
| Maximum wheel bearing play mm {in} | Drum brake type | 0.05 {0.002} | | | |
| | Disc brake type | 0.05 {0.002} | | | |
| Drive shaft | | | | | |
| Length of joint (between center of joint) mm {in} | Right side | NON ABS | 380.5 {14.98} | 388.9 {15.31} | 384.5 {15.14} |
| | | ABS | | 384.9 {15.15} | |
| | Left side | NON ABS | 397.0 {15.63} | 379.5 {14.94} | 396.0 {15.59} |
| | | ABS | | 375.5 {14.78} | |
| Shaft diameter mm {in} | Right side | 23.0 {0.91} | | 25.0 {0.98} | |
| | Left side | 21.5 {0.85} | | 25.0 {0.98} | |

TROUBLESHOOTING GUIDE

Front Axle
















| Problem | Possible Cause | Remedy | Page |
|--|---|----------------------|----------|
| Steering wheel vibration | Worn or damaged wheel bearing | Replace | M-8 |
| | Excessive wheel bearing play | Tighten or replace | M-5 |
| Steering wheel pulls or one-sided braking | Worn or damaged wheel bearing | Replace | M-8 |
| | Excessive wheel bearing play | Tighten or replace | M-5 |
| Excessive steering wheel play | Excessive wheel bearing play | Tighten or replace | M-5 |
| Abnormal noise | Bent drive shaft or joint shaft | Replace | M-19, 25 |
| | Worn or damaged wheel bearing | Replace | M-8 |
| | Worn drive shaft or joint shaft splines | Replace | M-19, 25 |
| | Insufficient grease in joint or on splines of drive shaft | Replenish or replace | M-25, 29 |
| | Insufficient grease in joint or splines of joint shaft | Add or replace | M-19 |
| | Worn drive shaft tripod joint | Replace | M-29 |
| Grease leakage from boot | Damaged or broken boot | Replace | M-29 |
| | Faulty boot band | Replace | M-29 |
| | Excessive grease | Repair | M-29 |


Rear Axle

| Problem | Possible Cause | Remedy | Page |
|--|-------------------------------|--------------------|----------|
| Steering wheel vibration | Worn or damaged wheel bearing | Replace | M-12, 15 |
| | Excessive wheel bearing play | Tighten or replace | M-11, 14 |
| Steering wheel pulls or one-sided braking | Worn or damaged wheel bearing | Replace | M-12, 15 |
| | Excessive wheel bearing play | Tighten or replace | M-11, 14 |
| Excessive steering wheel play | Excessive wheel bearing play | Tighten or replace | M-11, 14 |
| Abnormal noise | Worn or damaged wheel bearing | Replace | M-12, 15 |

FRONT AXLE

PREPARATION SST

| | | | |
|---|--|--|--|
| <p>49 T028 3A0 Puller set, ball joint</p>  | <p>For removal of tie-rod end</p> | <p>49 T028 303 Body (Part of 49 T028 3A0)</p>  | <p>For removal of tie-rod end</p> |
| <p>49 T028 304 Attachment (Part of 49 T028 3A0)</p>  | <p>For removal of tie-rod end</p> | <p>49 F026 103 Puller, wheel hub</p>  | <p>For disassembly of wheel bearing</p> |
| <p>49 B026 1A0 Puller, wheel hub</p>  | <p>For disassembly and assembly of wheel hub</p> | <p>49 G033 102 Handle (Part of 49 B026 1A0)</p>  | <p>For removal of front wheel hub</p> |
| <p>49 G030 727 Attachment A (Part of 49 B026 1A0)</p>  | <p>For removal of front wheel hub</p> | <p>49 E033 101 Installer, dust cover</p>  | <p>For installation of dust cover</p> |
| <p>49 F027 0A1 Installer set, bearing</p>  | <p>For installation of bearing</p> | <p>49 F027 003 Handle (Part of 49 F027 0A1)</p>  | <p>For removal and installation of wheel bearing</p> |
| <p>49 F027 005 Attachment 62 (Part of 49 F027 0A1)</p>  | <p>For removal of wheel bearing</p> | <p>49 F027 007 Attachment 72 (part of 49 F027 0A1)</p>  | <p>For installation of wheel bearing</p> |
| <p>49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1)</p>  | <p>For installation of dust cover</p> | <p>49 V001 795 Installer, oil seal</p>  | <p>For installation of oil seal</p> |
| <p>49 G030 797 Handle</p>  | <p>For installation of wheel bearing</p> | | |



**WHEEL HUB, STEERING KNUCKLE****Preinspection****Wheel bearing play**

1. Remove the wheel and tire.
2. Remove the brake caliper assembly and disc plate.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds specification, check and adjust the locknut torque or replace the wheel bearing if necessary

Maximum wheel bearing play: 0.05mm {0.002 in}

On vehicle service**Replacement****Wheel hub bolt replacement**


1. Remove the wheel hub bolt by using the SSTs.




2. As shown in the figure, install the wheel hub bolt into the wheel hub and set a washer and wheel hub nut in the wheel hub bolt.
3. Tighten the wheel hub nut while holding the wheel hub by using the brass bar.

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the wheel alignment, referring to Section R.




- | | |
|--|-----------------|
| 1. Wheel nut | |
| 2. Wheel and tire | |
| 3. Locknut | |
| Removal Note | below |
| Installation Note | page M-7 |
| 4. Brake caliper assembly | |
| Service | Section P |
| 5. Disc plate | |
| Service | Section P |
| 6. ABS wheel-speed sensor | |
| Service | Section P |
| 7. Tie-rod end | |
| Removal Note | page M-7 |
| Installation Note | page M-7 |
| 8. Lower ball joint | |
| 9. Knuckle, wheel hub and dust cover | |
| Inspect wheel hub for cracks and damage. | |
| Inspect knuckle spindle for cracks and damage. | |
| Inspect dust cover for damage and distortion. | |
| Disassembly / Inspection / Assembly | page M-8 |



Removal Note

Locknut

1. Knock the crimped portion of the locknut outward by using a small chisel and hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.




Tie-rod end

Caution

- The sharp edges of the SST can slice the tie-rod end dust boot. Install the SST so that the sharp edges are between the dust boot and tie-rod end.

1. Remove the tie-rod end nut.
2. Disconnect the tie-rod end by using the SST.



Installation Note


Tie-rod end

1. Position the tie-rod end and dust boot directly over the knuckle hole.
2. Install the nut to the tie-rod end and tighten.

Tightening torque:

43–56 N·m {4.3–5.8 kgf·m, 32–41 ft·lbf}

3. Install a new cotter pin.



Locknut


Install a new locknut and stake it, as shown.

Tightening torque:

236–318 N·m {24.0–32.5 kgf·m, 174–235 ft·lbf}

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Oil seal

Assembly Note page M-10

2. Front wheel hub assembly

Disassembly Note below

Assembly Note page M-10

3. Retaining ring

4. Wheel bearing

Disassembly Note page M- 9

Assembly Note page M-10

5. Dust cover

Disassembly Note page M- 9


Assembly Note page M-10

6. Knuckle

7. Hub bolt

Disassembly Note page M- 9


Assembly Note page M- 9




Disassembly Note

Front wheel hub assembly


1. Remove the front wheel hub assembly by using the **SSTs**.



2. If the bearing inner race remains on the front wheel hub assembly, grind a section of the bearing inner race until approx. 0.5 mm {0.020 in} remains. Then remove it with a chisel.


**Wheel bearing**

Using the SSTs, remove the wheel bearing.

**Dust cover****Note**


- The dust cover does not need to be removed unless you are replacing it.

1. Mark the dust cover and knuckle for proper reassembly.




2. Remove the dust cover with a chisel.

M


**Hub bolt****Note**

- The hub bolts do not need to be removed unless you are replacing them.


Remove the hub bolts with a press.

**Assembly Note****Hub bolt**


Press in new hub bolts.

**Dust cover**


1. Mark the new dust cover as the one removed.




2. Align the marks of the new dust cover and the knuckle.
3. Using the **SSTs**, install the new dust cover.

**Wheel bearing**

Using the **SSTs**, install the new wheel bearing.

**Front wheel hub assembly**



Using the **SSTs**, install the front wheel hub assembly.


**Oil seal**

1. Using the **SST** and a hammer, tap a new oil seal in evenly until the **SST** contacts the steering knuckle.
2. Coat the lip of the oil seal with grease.

REAR AXLE

PREPARATION
SST

| | | | |
|---|---|---|---|
| <p>49 0259 770B Wrench, flare nut</p>  | <p>For removal and installation of brake pipe</p> | <p>49 M005 796 Body</p>  | <p>For installation of ABS sensor rotor</p> |
|---|---|---|---|



DRUM BRAKE TYPE

Preinspection


Wheel bearing play

1. Remove the wheel and tire.
2. Position a dial indicator against the brake drum. Push and pull the rear brake assembly by hand in the axial direction and measure the wheel bearing play.
3. If the bearing play exceeds specification, check and adjust the locknut torque or replace the hub bearing assembly if necessary.

Maximum wheel bearing play: 0.05 mm {0.002 in}


Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, bleed the brake system, adjust the parking brake lever stroke (Refer to Section P.) and check the rear wheel alignment. (Refer to Section R.)



1. Wheel and tire
2. Hub cap
3. Locknut
Removal Note below
Installation Note page M-13
4. Brake drum
5. Hub bearing assembly
Inspect for cracks and damage
Disassembly / Assembly page M-13


6. Parking brake cable
Service Section P
7. Brake pipe
Removal Note page M-13
Installation Note page M-13
8. Rear brake assembly
Service Section P
9. Rear hub spindle
Inspect for cracks and damage



Removal Note


Locknut

1. Raise the staked portion of the locknut using a small cape chisel.
2. Lock the hub by applying the brakes.
3. Remove the locknut.



Brake pipe

1. Using the **SST**, disconnect the brake pipe.
2. Plug the brake pipe to avoid fluid leakage.




Installation Note

Brake pipe

Using the **SST**, tighten the brake pipe.

Tightening torque:

12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lbf}



Locknut

Install a new locknut and stake it, as shown.

Tightening torque:


177–235 N·m {18.0–24.0 kgf·m, 131–173 ft·lbf}

Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.

Caution


- The wheel hub and bearing are one assembly and do not need to be disassembled.



1. Hub bolt

Disassembly Note page M-14
 Assembly Note page M-14

2. Hub bearing assembly




Disassembly Note Hub bolt

Note


- The hub bolts do not need to be removed unless you are replacing them.

Remove the hub bolts with a press.



Assembly Note Hub bolt

Press in new hub bolts.




DISC BRAKE TYPE

Preinspection

Wheel bearing play

1. Remove the wheel and tire.
2. Remove the brake caliper assembly.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds specification, check and adjust the locknut torque or replace the hub bearing assembly if necessary.

Maximum wheel bearing play: 0.05 mm {0.002 in}




On vehicle service

Replacement

Wheel hub bolt replacement


1. Remove the wheel hub bolt by using the SSTs.




2. As shown in the figure, install the wheel hub bolt into the wheel hub and set a washer and wheel hub nut in the wheel hub bolt.
3. Tighten the wheel hub nut while holding the wheel hub by using the brass bar.

Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the rear wheel alignment. (Refer to Section R.)




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Hub cap 3. Locknut Removal Note page M-16 Installation Note page M-16 4. Brake caliper assembly Service Section P 5. Disc plate Inspection Section P | <ol style="list-style-type: none"> 6. Hub bearing assembly Inspect for cracks and damage. Disassembly / Assembly page M-16 7. Dust cover 8. ABS wheel-speed sensor 9. Rear hub spindle Inspect for cracks and damage |
|---|--|



Removal Note

Locknut

1. Knock the crimped portion of the locknut outward by using a small chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.



Installation Note

Locknut

Install a new locknut and stake it, as shown.

Tightening torque:


177–235 N·m {18.0–24.0 kgf·m, 130–173 ft·lbf}

Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.

Caution

- The wheel hub and bearing are one assembly and do not need to be disassembled.



1. ABS sensor rotor

Disassembly Note page M-17


Assembly Note page M-17

2. Hub bolt

Disassembly Note page M-17

Assembly Note page M-17

3. Hub bearing assembly




Disassembly Note
ABS sensor rotor

Note

- The ABS sensor rotor does not have to be removed unless you are replacing it.

Remove the ABS sensor rotor with a chisel.




Hub bolt

Note


- The wheel hub and bearing are one assembly and do not to be disassembled.

Remove the hub bolts with a press.



Assembly Note
Hub bolt

Press in new hub bolts.



ABS sensor rotor



1. Install a new rear ABS sensor rotor on to the wheel hub.
2. Using a steel plate and the **SST**, press the ABS sensor rotor until it is flush with the wheel hub.

















Note


- The ABS sensor rotor can be installed in either direction.

DRIVE SHAFT

PREPARATION
SST

| | | | |
|--|-------------------------------|---|-------------------------------|
| <p>49 H034 2A0</p> <p>Lower arm bushing puller & installer</p>  | <p>For support of bracket</p> | <p>49 H034 201</p> <p>Support block (Part of 49 H034 2A0)</p>  | <p>For support of bracket</p> |
|--|-------------------------------|---|-------------------------------|

| | | | |
|--|---|--|---|
| <p>49 T028 3A0 Puller set, ball joint</p>  | <p>For removal of tie rod end</p> | <p>49 F027 0A1 Installer set, bearing</p>  | <p>For installation of bearing</p> |
| <p>49 F027 005 Attachment 62 (Part of 49 F027 0A1)</p>  | <p>For installation of bearing</p> | <p>49 G030 797 Handle (Part of 49 G030 795)</p>  | <p>For installation of right side dust seal and bearing</p> |
| <p>49 F026 102 Installer, bearing</p>  | <p>For removal of bearing and left side dust seal</p> | <p>49 W027 003 Installer, oil seal</p>  | <p>For installation of left side dust seal</p> |
| <p>49 G025 001 Installer, ABS sensor rotor</p>  | <p>For installation of ABS sensor rotor (K8 DOHC)</p> | <p>49 G017 5A0 Support, engine</p>  | <p>For support of engine</p> |
| <p>49 G017 503 Hook (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 G017 502 Support (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> |
| <p>49 G017 501 Bar (Part of 49 G017 5A0)</p>  | <p>For support of engine</p> | <p>49 B025 003 Installer, ABS sensor rotor</p>  | <p>For installation of ABS sensor rotor (B6 DOHC)</p> |
| <p>49 H027 002 Remover, bearing</p>  | <p>For removal of dust cover</p> | <p>49 B025 005 Installer, dust cover</p>  | <p>For installation of dust cover (K8 DOHC)</p> |
| <p>49 S120 785 Installer, dust boot</p>  | <p>For installation of dust boot (K8 DOHC)</p> | <p>49 B025 004 Installer, dust seal</p>  | <p>For installation of dust seal (B6 DOHC)</p> |




**JOINT SHAFT
Preinspection
Joint shaft**

1. Verify that the joint shaft is not twisted or cracked. Replace it if necessary.
2. Turn the joint shaft by hand and verify that the bearing rotates smoothly and freely. Replace it if necessary.


Removal / Installation

1. Drain the transaxle oil before removal.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, fill the transaxle with the specified amount of the specified transaxle oil and inspect for oil leakage.



1. Wheel and tire
2. Splash shield
3. Drain plug
4. Stabilizer control link
5. Tie-rod end
Removal Note page M-20
Installation Note page M-21
6. Lower ball joint

7. Right drive shaft and axle
Removal Note page M-20
Installation Note page M-21
8. Joint shaft
Removal Note page M-20
Installation Note page M-21
Disassembly / Inspection /
Assembly page M-22
9. Clip
Installation Note page M-21




Removal Note Tie-rod end

Caution

- The sharp edges of the SST can slice the tie-rod end boot. Install the SST so that the sharp edges are between the dust boot and tie-rod end.

1. Remove the tie-rod end nut.
2. Disconnect the tie-rod end by using the SST.




Right drive shaft and axle


Caution

- Be careful not to damage the ball joint dust boot.


1. Remove the clinch bolt and nut.



2. Pry down on the lower arm to disconnect the ball joint.




3. As shown in the figure, insert a pry bar between the drive shaft and the joint shaft and tap on the bar to uncouple them.




Joint shaft

Pull the joint shaft straight out.

**Installation Note****Clip**

1. Install a new clip so that the opening is facing upward.
2. Measure the outer diameter of the clip after installing, and replace the clip if it exceeds the specification.

**Joint shaft**

1. Install a new clip so that the opening is facing upward.


Caution

- Do not damage the transaxle oil seal.


2. Install the joint shaft.
3. Install the joint shaft, bolt Ⓐ must be tightened last as shown. (B6 DOHC)

Tightening torque:

43–61 N·m {4.3–6.3 kgf·m, 32–45 ft·lbf}

**Right drive shaft and axle**


1. Push the drive shaft into the joint shaft.
2. After installation, pull the front hub outward to verify that the drive shaft is securely held by the clip.



3. Install the lower arm ball joint to the knuckle and tighten the through bolt.

Tightening torque:

44–58 N·m {4.4–6.0 kgf·m, 32–43 ft·lbf}

**Tie-rod end**

1. Position the tie-rod end and dust boot directly over the knuckle hole.
2. Install the nut to the tie-rod end and tighten.


Tightening torque:

43–56 N·m {4.3–5.8 kgf·m, 32–41 ft·lbf}

3. Install a new cotter pin.


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Dust cover (differential side, K8 DOHC)
Disassembly Note below
Assembly Note page M-24
2. Dust cover (bracket side, K8 DOHC)
3. Joint shaft
Inspect splines for damage and wear
Disassembly Note page M-23
Assembly Note page M-24


4. Dust seal (differential side)
Disassembly Note page M-23
Assembly Note page M-24
5. Bearing
Disassembly Note page M-23
Assembly Note page M-23
6. Dust seal (drive shaft side)
Assembly Note page M-23
7. Bracket



Disassembly Note


Dust cover (differential side, K8 DOHC)

While holding the joint shaft, press out the dust cover by using the **SST**.




Joint shaft

1. While holding the joint shaft, press it out by using the **SST**.




2. while holding the shaft, press out the bearing inner race by using the **SST**.



Dust seal (differential side)/Bearing


Press out the differential side dust seal and bearing by using the **SSTs**.



Assembly note


Dust seal (drive shaft side)

Tap in the new drive shaft side dust seal by using the **SSTs**.




Bearing


Press in the new bearing by using the **SSTs**.

**Dust seal (differential side)**

Press in the new differential side dust seal by using a steel plate and the **SSTs**.

**Joint shaft**

Press in the new bearing by using the **SST**.


**Dust cover (differential side, K8 DOHC)**

1. Mark the shaft as shown in the figure.

Length


MTX : 89.0 ± 0.5 mm { 3.50 ± 0.02 in}

ATX : 110.5 ± 0.5 mm { 4.35 ± 0.02 in}



2. Press in the dust cover to the marked position by using a steel plate and the **SST**.


3. Verify that length L is within specification.

**DRIVE SHAFT (TRIPOD JOINT)****Preinspection****Drive shaft**


1. Check the drive shaft dust boot for cracks, damage, leaking grease, and loose boot bands.
2. Check the drive shaft for bending, cracks, and wear of joints or splines.
3. Repair or replace the drive shaft if necessary.

Removal / Installation


1. Drain the transaxle oil before removal.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, fill the transaxle with the specified amount of the specified transaxle oil and inspect for oil leakage.
5. Check the front wheel alignment, referring to Section R.



- | | |
|-----------------------------------|---|
| 1. Wheel and tire | 7. Lower ball joint |
| 2. Splash shield | 8. Engine mount member |
| 3. Drain plug | (Only for ATX at left side drive shaft) |
| 4. Locknut | Removal Note page M-26 |
| Removal Note page M-26 | 9. Drive shaft |
| Installation Note page M-28 | Removal Note page M-26 |
| 5. Stabilizer control link | Installation Note page M-27 |
| 6. Tie-rod end | Disassembly / Inspection / |
| Removal Note page M-26 | Assembly page M-29 |
| Installation Note page M-28 | 10. Clip |
| | Installation Note page M-27 |


**Removal Note****Locknut**

1. Knock the crimped portion of the locknut outward by using a chisel and a hammer.
2. Lock the hub by applying the brakes.
3. Remove the locknut.


**Tie-rod end****Caution**

- The sharp edges of the SST can slice the tie-rod end dust boot. Install the SST so that the sharp edges are between the dust boot and tie-rod end.

1. Remove the tie-rod end nut.
2. Disconnect the tie-rod end by using the SST.


**Engine mount member**

Suspend the engine by using the SST and remove the engine mount member.


**Drive shaft****Caution**

- Be careful not to damage the ball joint dust boot.

1. Remove the clinch bolt and nut.




2. Pry down on the lower arm to disconnect the ball joint.


**Caution**

- The sharp edges of the drive shaft can slice or puncture the oil seal. Be careful when removing the drive shaft from the transaxle.


3. Separate the left-side drive shaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle, as shown in the figure.




4. Separate the right-side drive shaft from the joint shaft by hammering on a bar inserted between them.

**Note**

- If the drive shaft will not come out of the front wheel hub easily, install an already discarded nut onto the drive shaft so that the nut is flush with the end of the drive shaft. Tap the nut with a copper hammer to loosen the drive shaft from the front wheel hub.


**Installation Note****Clip**

1. Install a new clip onto the drive shaft.
2. Measure the outer diameter of the clip after installing, and replace the clip if it exceeds the specification.


**Drive shaft****Caution**

- The sharp edges of the drive shaft can slice or puncture the oil seal. Be careful when installing the drive shaft to the transaxle.
- The oil seals are damaged easily if this procedure is not done correctly.


1. Apply grease to the ends of the drive shafts.
2. Push the drive shaft into the transaxle (left side) or joint shaft (right side).



3. After installation, pull the front hub outward to confirm that the drive shaft is securely held by the clip.



4. Install the lower arm ball joint to the knuckle and tighten the through bolt.




Tie-rod end

1. Position the tie-rod end and dust boot directly over the knuckle hole.
2. Install the nut to the tie-rod end and tighten.

Tightening torque:

43–56 N·m {4.3–5.8 kgf·m, 32–41 ft·lbf}

3. Install a new cotter pin.



Locknut


Install a new locknut and stake it, as shown.

Tightening torque:


236–318 N·m {24.0–32.5 kgf·m, 174–235 ft·lbf}

Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|--|---|
| <p>1. Boot band Disassembly Note page M-30 Assembly Note page M-32</p> <p>2. Stopper ring</p> <p>3. Outer ring Disassembly Note page M-30 Inspect inside bore for wear, corrosion, and scoring. Assembly Note page M-32</p> <p>4. Snap ring Disassembly Note page M-30 Assembly Note page M-31</p> <p>5. Tripod joint Disassembly Note page M-30 Inspect for damage and wear. Assembly Note page M-31</p> | <p>6. Band Disassembly Note page M-30 Assembly Note page M-32</p> <p>7. Dynamic damper Disassembly Note page M-30 Assembly Note page M-31</p> <p>8. Boot Disassembly Note page M-30 Inspect for damage. Assembly Note page M-31</p> <p>9. ABS sensor rotor Disassembly Note page M-31 Assembly Note page M-31</p> <p>10. Shaft and ball joint assembly Inspect splines for damage and wear. Inspect wheel-side joint for excessive play and rough rotation.</p> |
|--|---|

**Disassembly Note****Boot band**

1. Pry up the locking clips of the boot bands with a screwdriver.
2. Remove the bands with pliers.

**Outer ring**

Mark the outer ring and the shaft for proper reassembly.


**Snap ring / Tripod joint**

1. Mark the shaft and tripod joint for proper reassembly.
2. Remove the snap ring with snap-ring pliers.

Caution


- Do not damage the bearing.

3. Remove the tripod joint from the shaft with a bar and a hammer.

**Note**


- The wheel-side boot does not need to be removed unless you are replacing it.

Wrap the splines of the shaft with tape to prevent damaging the boot.

**Band / Dynamic damper****Note**


- The dynamic damper does not need to be removed unless you are replacing it.

1. Pry up the locking clip of the band with a screwdriver.
2. Remove the band with pliers.
3. Remove the dynamic damper.


**ABS sensor rotor****Note**

- The ABS sensor rotor does not need to be removed unless you are replacing it.


Tap the sensor rotor off the drive shaft with a chisel.

**Assembly Note****ABS sensor rotor**

Set a new ABS sensor rotor on the drive shaft in the direction as shown, and press it onto the shaft assembly by using the SST.

**Dynamic damper / Band**

1. Push the joint fully toward the drive shaft.
2. Make sure the dynamic damper position is as shown in the figure.
3. Install the band and dynamic damper.
4. Fold the band back by pulling on the end of it with pliers, so that the end of the band is pointing opposite the forward revolving direction of the shaft.
5. Lock the end of the band by bending the locking clip.

**Boot****Note**


- The initials TJ and BJ are stamped on the wheel-side and differential-side boots respectively.

1. Wrap the splines of the transaxle side shaft, and install the boot, noting the shape and size of each one in the figure.
2. Fill the wheel side boot with the grease, supplied in the boot and joint kit.

Grease amount


B6 DOHC: 60–80 g {2.12–2.82 oz}

K8 DOHC: 80–100 g {2.83–3.53 oz}

**Tripod joint / Snap ring****Caution**

- Do not damage the bearing.

1. Align the marks and install the tripod joint With a bar and a hammer.
2. Install the new snap ring With snap-ring pliers.

**Outer ring**

1. Fill the outer ring and boot (transaxle side) with the specified grease supplied in the boot and joint kit.

Grease amount**B6 DOHC**

Right side: 110–130 g {3.89–4.58 oz}

Left side: 115–135 g {4.06–4.76 oz}

K8 DOHC




MTX : 135–155g {4.97–5.47 oz}

ATX : 130–150g {4.59–5.29 oz}

2. Align the free ring marks and the tripod joint marks.

Caution

- Be careful not to drop the free rings when installing the tripod joint outer ring.

**Boot band**

1. Verify that the boots are not dented or twisted.
2. Set the drive shaft to the standard length.

Standard length

mm {in}

| | | B6 DOHC | | K8 DOHC | |
|------------|---------|------------------------------|-----|------------------------------|------------------------------|
| | | MTX | ATX | MTX | ATX |
| Right side | | 595.5–605.5 {23.45–23.83} | | 595.9–605.9 {23.47–23.85} | 597.5–607.5 {23.53–23.91} |
| Left side | NON ABS | 653.0–663.0 {25.71–26.10} | | 635.5–645.5 {25.02–25.41} | 648.0–658.0 |
| | ABS | | | 639.5–649.5 {25.18–25.57} | {25.52–25.90} |

3. Release any trapped air from inside the boot by using a rag-covered screwdriver.
4. Verify that the drive shaft length is within the standard.
5. If the drive shaft length is not within the standard, return to step 1.
6. Fold the new bands back by pulling on the ends with pliers, so that the end of the bands are pointing opposite the forward revolving direction of the shaft.
7. Lock the ends of the bands by bending the locking clips.


Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

STEERING SYSTEM

| | |
|-----------------------------------|------|
| INDEX | N- 2 |
| ENGINE SPEED SENSING POWER | |
| STEERING (ESPS) | N- 2 |
| OUTLINE | N- 4 |
| SPECIFICATIONS | N- 4 |
| ENGINE SPEED SENSING POWER | |
| STEERING | N- 4 |
| PREPARATION | N- 4 |
| TROUBLESHOOTING GUIDE | N- 8 |
| AIR BLEEDING | N- 8 |
| POWER STEERING FLUID | N- 9 |
| STEERING WHEEL AND COLUMN | N-12 |
| BOOT | N-17 |
| STEERING GEAR AND LINKAGE | |
| (B6 DOHC) | N-19 |
| STEERING GEAR AND LINKAGE | |
| (K8 DOHC) | N-20 |
| POWER STEERING OIL PUMP | |
| (B6 DOHC) | N-43 |
| POWER STEERING OIL PUMP | |
| (K8 DOHC) | N-44 |
| DRIVE BELT (B6 DOHC) | N-51 |
| DRIVE BELT (K8 DOHC) | N-52 |

INDEX


ENGINE SPEED SENSING POWER STEERING (ESPS)



| | |
|-------------------------------|-----------|
| 1. Power steering fluid | |
| Air bleeding | page N- 8 |
| Inspection (On-vehicle) | page N- 9 |
| 2. Steering wheel and column | |
| Inspection (On-vehicle) | page N-12 |
| Removal / Installation | page N-13 |
| Disassembly / Assembly / | |
| Inspection | page N-14 |
| 3. Boot | |
| Removal / Inspection | page N-17 |

| | |
|--------------------------------|-----------|
| 4. Steering gear and linkage | |
| Removal / Installation | page N-19 |
| Disassembly / Inspection | page N-22 |
| Assembly | page N-25 |
| 5. Power steering oil pump | |
| Removal / Installation | page N-43 |
| Disassembly / Inspection / | |
| Assembly | page N-45 |
| 6. Drive belt | |
| Inspection | page N-51 |
| Adjustment | page N-51 |
| Replacement | page N-51 |

K8 DOHC



- 1. Power steering fluid
 - Air bleeding page N- 8
 - Inspection (On-vehicle) page N- 9
- 2. Steering wheel and column
 - Inspection (On-vehicle) page N-12
 - Removal / Installation page N-13
 - Disassembly / Inspection /
Assembly page N-14
- 3. Boot
 - Removal / Installation page N-17

- 4. Steering gear and linkage
 - Removal / Installation page N-20
 - Disassembly / Inspection page N-30
 - Assembly page N-35
- 5. Power steering oil pump
 - Removal / Installation page N-44
 - Disassembly / Inspection /
Assembly page N-48
- 6. Drive belt
 - Inspection page N-52
 - Adjustment page N-52
 - Replacement page N-52

OUTLINE










SPECIFICATIONS

















| Item | Type/Engine | Engine speed sensing power steering | |
|--------------------------|----------------------------------|---|------------------|
| | | B6 DOHC | K8 DOHC |
| Steering wheel | Outer diameter mm {in} | 370 {14.57}, 380 {14.96} (With air bag) | |
| | Lock-to-lock | 3.1 | 2.7 |
| Steering shaft and joint | Type | Collapsible | |
| | Joint type | 2-cross joint | |
| | Tilt stroke mm {in} | 30 {1.18} | |
| Steering gear | Type | Rack-and-pinion | |
| | Gear ratio | 15.0 | |
| | Rack stroke mm {in} | 140 {5.51} | |
| Oil | Capacity liters {US qt, Imp, qt} | 0.8 {0.85, 0.70} | 1.2 {1.27, 1.06} |
| | Type | ATF M-III or Dexron®II | |

ENGINE SPEED SENSING POWER STEERING

















PREPARATION

















SST

| | | | | | |
|--|---|--------------------------------------|--|---|-----------------------------------|
| 49 B032 312 Protector, slipper seal |  | For installation of seal ring | 49 1243 785 Installer, dust boot |  | For installation of dust boot |
| 49 B032 311 Protector, slipper seal |  | For installation of pinion shaft | 49 B032 315 Installer, oil seal |  | For installation of oil seal |
| 49 B032 309 Installer body, pinion seal |  | For installation of oil seal | 49 B032 316 Support block, plug |  | For removal of oil seal & bearing |
| 49 B032 310 Protector, pinion seal |  | For installation of oil seal | 49 B032 317 Remover, bearing & oil seal |  | For removal of oil seal & bearing |
| 49 B032 306 Wrench, plug |  | For removal and installation of plug | | | |

| | | | |
|--|---|---|---|
| <p>49 B032 320 Wrench</p>  | <p>For removal and installation of adjustment cover locknut</p> | <p>49 0180 510B Attachment, preload</p>  | <p>For measurement of pinion torque</p> |
| <p>49 B032 314 Slipper seal former</p>  | <p>For form of seal ring</p> | <p>49 G030 797 Handle</p>  | <p>For installation of pinion seal</p> |
| <p>49 B032 321 Adapter</p>  | <p>For hermetic inspection</p> | <p>49 G032 3A1 Joint hose</p>  | <p>For hermetic inspection</p> |
| <p>49 G032 317 Hose (Part of 49 B032 3A1)</p>  | <p>For hermetic inspection</p> | <p>49 1232 670A Gauge set, power steering</p>  | <p>For measurement of fluid pressure</p> |
| <p>49 1232 673 Valve body (Part of 49 1232 670A)</p>  | <p>For measurement of fluid pressure</p> | <p>49 H032 301 Wrench</p>  | <p>For removal of tie-rod</p> |
| <p>49 1232 672 Gauge (Part of 49 1232 670A)</p>  | <p>For measurement of fluid pressure</p> | <p>49 B032 304 Adapter</p>  | <p>For measurement of fluid pressure</p> |
| <p>49 H002 671 Adapter</p>  | <p>For measurement of fluid pressure</p> | <p>49 B032 313 Protector, outer box</p>  | <p>For installation of outer box</p> |
| <p>49 B032 307 Wrench, outer box</p>  | <p>For removal and installation of outer box</p> | <p>49 B032 318 Guide, rod seal</p>  | <p>For installation of inner guide & oil seal</p> |

N


| | | | |
|--|---|--|---|
| <p>49 B032 308 Remover body, rod seal</p>  | <p>For removal of oil seal</p> | <p>49 B032 319 Protector body, rod seal</p>  | <p>For installation of inner guide & oil seal</p> |
| <p>49 G032 3A0 Repair set, power steering</p>  | <p>For repairing power steering</p> | <p>49 G032 307 Remover body, oil seal (Part of 49 G032 3A0)</p>  | <p>For removal of oil seal</p> |
| <p>49 F032 303 Handle (Part of 49 G032 3A0)</p>  | <p>For removal of spacer and oil seal</p> | <p>49 G032 308 Installer, oil seal (Part of 49 G032 3A0)</p>  | <p>For installation of oil seal</p> |
| <p>49 G032 301 Attachment (Part of 49 G032 3A0)</p>  | <p>For removal of spacer and oil seal</p> | <p>49 G032 309 Protector, pinion shaft (Part of 49 G032 3A0)</p>  | <p>For installation of oil seal</p> |
| <p>49 G032 302 Attachment (Part of 49 G032 3A0)</p>  | <p>For removal of oil seal and bearing</p> | <p>49 G032 310 Installer, oil seal & spacer (Part of 49 G032 3A0)</p>  | <p>For installation of spacer and oil seal</p> |
| <p>49 G032 303 Handle (Part of 49 G032 3A0)</p>  | <p>For removal of oil seal and bearing</p> | <p>49 G032 311 Installer, guide, oil seal & spacer (Part of 49 G032 3A0)</p>  | <p>For installation of spacer and oil seal</p> |
| <p>49 G032 304 Installer, oil seal (Part of 49 G032 3A0)</p>  | <p>For installation of oil seal</p> | <p>49 G032 312 Installer, bearing (Part of 49 G032 3A0)</p>  | <p>For installation of bearing</p> |
| <p>49 G032 305 Protector, rack (Part of 49 G032 3A0)</p>  | <p>For removal and installation of rack</p> | <p>49 G032 306 Remover shaft, oil seal (Part of 49 G032 3A0)</p>  | <p>For removal of oil seal</p> |

| | | | |
|---|--|--|---|
| <p>49 G032 335 Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 H032 321A Hexagon wrench (Part of 49 G032 3A0)</p>  | <p>For removal and installation of a djusting cover</p> |
| <p>49 D032 316 Protractor (Part of 49 G032 3A0)</p>  | <p>For installation of adjusting cover</p> | <p>49 G032 319 Adapter (Part of 49 G032 3A0)</p>  | <p>For hermetic inspection</p> |
| <p>49 E032 301 Installer, oil seal</p>  | <p>For installation of oil seal</p> | <p>49 E032 302 Installer guide, spacer & oil seal</p>  | <p>For installation of spacer & oil seal</p> |
| <p>49 E032 303 Installer, bearing</p>  | <p>For installation of bearing</p> | <p>49 E032 304 Installer, pinion seal</p>  | <p>For installation of pinion seal</p> |
| <p>49 F032 301 Hanger, power steering pump</p>  | <p>For disassembly of oil pump</p> | <p>49 B032 305 Holder, power steering pump</p>  | <p>For installation of oil pump</p> |
| <p>49 T028 3A0 Puller set, ball joint</p>  | <p>For removal of tie-rod end ball joint</p> | <p>49 9200 020 V-ribbed belt tension gauge</p>  | <p>For measurement of drive belt tension</p> |
| <p>49 G032 3A4 Adapter, power steering gauge</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 G032 351 Adapter (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering pressure</p> |
| <p>49 G032 352 Adapter (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering fluid pressure</p> | <p>49 G032 353 Bolt (Part of 49 G032 3A4)</p>  | <p>For inspection of power steering fluid pressure</p> |


N

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|---|--|---|---|
| Steering feels heavy | Poor lubrication, foreign material in mechanism, stuck or abnormal wear of steering ball joint Improper steering pinion preload Damaged steering gear Malfunction of steering shaft joint Malfunction of steering gear Leakage of fluid Low fluid level or air in system Malfunction of P/S oil pump Damaged or loose P/S oil pump drive belt Clogged lines Damaged wheel or tire Malfunction of suspension | Lubricate or replace Adjust Replace gear assembly Replace Replace gear assembly Repair or replace Add fluid or bleed air Replace Adjust or replace Repair or replace — — | N-19, 20 N-28, 41 N-19, 20 N-13 N-19, 20 N-9 N-9 N-43, 44 N-51, 52 — Section Q Section R |
| Steering wheel pulls to one side | Damaged steering linkage Damaged wheel or tire Malfunction of braking system Malfunction of suspension | Replace — — — | N-19, 20 Section Q Section P Section R |
| General instability | Worn or damaged steering ball joint Improper steering pinion preload Damaged steering linkage Damaged wheel or tire Malfunction of suspension | Replace Adjust Replace — — | N-17 N-28, 41 N-19, 20 Section Q Section R |
| Steering feels unstable | Loose P/S oil pump drive belt Malfunction of steering gear Malfunction of steering ball joint Malfunction of steering linkage | Adjust or replace Replace gear assembly Replace Replace | N-51, 52 N-19, 20 N-17 N-19, 20 |
| Excessive steering wheel play | Worn steering gear Worn or damaged steering ball joint Loose steering gear mounting bolts | Replace gear assembly Replace Tighten | N-19, 20 N-17 N-19, 20 |
| Steering wheel doesn't return properly | Stuck or damaged steering ball joint Improper steering pinion preload Damaged wheel or tire Malfunction of suspension | Replace Replace gear assembly — — | N-17 N-19, 20 Section Q Section R |
| Shimmy (Steering wheel vibrates circumferential) | Damaged steering linkage Loose steering gear mounting bolts Stuck or damaged steering ball joint Damaged or worn front wheel bearing Damaged wheel or tire Malfunction of suspension | Replace Tighten Replace Replace — — | N-19, 20 N-19, 20 N-17 Section M Section Q Section R |
| Abnormal noise from steering system | Loose steering gear mounting bolts Malfunction of steering gear Obstruction near steering column Loose steering linkage Worn or damaged steering ball joint Loose or damaged P/S oil pump drive belt Loose P/S oil pump bracket Loose P/S oil pump mounting bolts Air in system Malfunction of P/S oil pump | Tighten Replace gear assembly Repair Tighten Replace Adjust or replace Tighten Tighten Bleed air Replace | N-19, 20 N-19, 20 N-13 N-19, 20 N-17 N-51, 52 Section B1, B2 N-43, 44 N-8 N-43, 44 |

**AIR BLEEDING**

1. Jack up the front of the vehicle.
2. Check the fluid level. (Refer to page N-9.)
3. Turn the steering wheel fully to the left and right several times with the engine not running.
4. Recheck the fluid level. If the level has lowered, add fluid.
5. Repeat steps 2 and 3 until the fluid level stabilizes.
6. Lower the vehicle.
7. Start the engine and let it idle.
8. Turn the steering wheel fully to the left and right several times.



9. Check that the fluid is not foamy and that the fluid level has not dropped.
10. Add fluid if necessary and repeat steps 6 and 7.

POWER STEERING FLUID

On-vehicle Inspection

Inspection of fluid level

1. Verify that the fluid level is between the F and L marks.
2. Add or remove the specified power steering fluid if not within specification.


Inspection of fluid leakage

Caution




- Never hold the steering wheel to the extreme left or right for more than five seconds with the engine running. This could damage power steering pump.

Start the engine and let it idle. Turn the steering wheel fully left and right to apply fluid pressure. Inspect the points shown in the figure for fluid leakage.

B6 DOHC



K8 DOHC






Inspection of fluid pressure

1. Assemble the **SSTs** as shown in the figure. Remove the transverse member. (K8 engine) (Refer to section R.)

Tightening torque:

40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lb}

2. Mark both hose connections to ensure that the hose is re-installed in its original position.
3. Disconnect the pressure hose on the oil pump side, and attach the **SSTs**.
4. Bleed the air from the system. (Refer to page N-8.)
5. Open the gauge valve fully. Start the engine and turn the steering wheel fully left and right to raise the fluid temperature to 50–60 °C {122–140°F}.



6. Close the gauge valve completely. Increase the engine speed to 1,000–1,500 rpm and measure the fluid pressure generated by the oil pump. If the pressure is below specification, replace the oil pump assembly.

Oil pump fluid pressure:

7,846–8,335 kPa {80.0–80.5 kgf/cm², 1,138–1,208 psi}

Caution

- Do not left the valve stay closed for more than 5 seconds. The increase in fluid temperature will damage the power steering oil pump.

7. Open the gauge valve fully again and increase the engine speed to 1,000–1,500 rpm.

Caution

- Never hold the steering wheel to the extreme left or right for more than five seconds. This could damage power steering oil pump.

8. Turn the steering wheel fully to the left and right and measure the fluid pressure generated by the gear housing. If the pressure is below specification, repair or replace the steering gear assembly.

Gear housing fluid pressure:


7,846–8,335 kPa {80.0–80.5 kgf/cm², 1,138–1,208 psi}

9. Remove the gauge set. Install the high pressure hose and tighten the joint nut to the specified torque.

Tightening torque:

B6 DOHC: 16–23 N·m {1.6–2.4 kgf·m, 12–17 ft·lbf}
K8 DOHC: 24–35 N·m {2.4–3.6 kgf·m, 18–26 ft·lbf}

10. Bleed the air from the system. (Refer to page N-8.)



STEERING WHEEL AND COLUMN


On-vehicle inspection

Steering wheel play

With the wheel in the straight-ahead position, gently turn the steering wheel to the left and right to determine if play is within specification.


Play: 0–30 mm (0–1.18 in)

If play exceeds specification, either the steering joints are worn or the backlash of the steering gear is excessive.



Looseness of steering wheel and column

Move the steering wheel in directions ①, ②, and ③ to check for column bearing wear, steering shaft joint play, steering wheel looseness, and column looseness.




Steering wheel effort

1. With the vehicle on a hard level surface, move the steering wheel to put the wheels in the straight-ahead position.
2. Turn the steering wheel to the left and right five times or more.
3. Attach a pull scale to the outer of the steering wheel, and then starting with the wheels in the straight-ahead position, check the steering effort required to turn the steering wheel to the left and to the right.
4. If the measured effort exceeds specification, check the following: rotation-starting torque of the pinion, rotation torque of each ball joint, and seizure of each joint.

Steering wheel effort: 108 N {11 kgf, 24.2 lbf}


Removal/Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



1. Horn cap or air bag module
Service Body electrical troubleshooting manual, section S
2. Locknut
3. Steering wheel
Removal Note page N-14
Installation Note page N-14
4. Column cover
5. Combination switch
Operation section T

6. Lower panel
7. Set plate
8. Dust cover
9. Fixing bolt (Intermediate shaft / Pinion shaft)
Installation Note page N-21
10. Interlock cable (ATX only)
11. Steering shaft assembly
Disassembly / Inspection /
Assembly page N-14




Removal Note Steering wheel

Caution

- Do not try to remove the steering wheel by hitting the shaft with a hammer. The column will collapse.

Remove the steering wheel with a suitable puller.




Installation Note Steering wheel

With the wheels in the straight-ahead position, install the steering wheel.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



1. Steering lock assembly

Disassembly Note page N-15
 Inspection page N-16
 Assembly Note page N-16


2. Fixing bolt (Universal joint / Intermediate shaft)

3. Intermediate shaft
 Inspection page N-15


4. Fixing bolt (Steering shaft / Universal joint)

5. Universal joint
 Inspection page N-15

6. Energy absorbing shaft assembly Inspection page N-15

**Disassembly Note****Steering lock assembly**


Use a chisel to make a groove in the head of the steering lock mounting bolts. Remove the bolts with a screwdriver; then remove the steering lock assembly.

**Inspection**

Check for the following and replace the assembly if necessary.

Steering shaft assembly

1. Column bushing wear.




2. Steering shaft length.

Specified length

With air bag: 570.6–572.6 mm {22.47–22.54 in}


Without air bag (Canada):

558.3–560.3 mm {21.99–22.05 in}


**Inspection of tilt operation**

Check the following and repair or replace if necessary.


1. Adjust lever operates smoothly to locked position from unlocked position.
2. Steering shaft is held securely in the locked position.

**Intermediate shaft and universal joint**

Universal joint and intermediate shaft looseness, abnormal noise, or sticking.

**Steering lock assembly
(ATX)**

Verify that the cable connector does not move when the key is in the LOCK position and that it moves freely with the key in other positions.


**Assembly Note
Steering lock assembly**

Install the steering lock assembly on the jacket. Install new steering lock mounting bolts, and tighten them until the heads break off.

BOOT


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. Check the front wheel alignment. (Refer to Section R.)



N·m (kgf·m, ft·lbf)


- | | |
|------------------------------|-----------------------------------|
| 1. Cotter pin, nut | 5. Tie-rod end boot |
| 2. Tie-rod end ball joint | Removal Note page N-18 |
| Removal Note below | Installation Note page N-18 |
| 3. Locknut | 6. Boot band |
| Removal Note page N-18 | 7. Boot wire |
| 4. Tie-rod end | 8. Rack boot |




Removal Note

Tie-rod end ball joint


Disconnect the tie-rod end ball joint by using the **SST**.

**Locknut**

Mark the tie-rod end, the locknut, and the tie rod.

**Tie-rod end boot**

1. Secure the tie-rod end ball joint in a vise.
2. Place a chisel against the boot and hold it at the angle shown.
3. Remove the boot by tapping it with a hammer.


**Installation Note****Tie-rod end boot**

1. Wipe the grease off the tie-rod end ball joint.
2. Put a small amount of lithium-based grease into a new dust boot.
3. Install the dust boot onto the tie-rod end ball joint by using the SST and a press.
4. Wipe away any excess grease.

STEERING GEAR AND LINKAGE (B6 DOHC)

Removal / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation, bleed air from the steering system and adjust the toe-in if necessary.
(Refer to section R.)




- 1. Cotter pin
- 2. Locknut
- 3. Tie-rod end ball joint
Removal Note page N-17
- 4. Pressure pipe
- 5. Return hose
- 6. Set plate and dust cover

- 7. Fixing bolt
(intermediate shaft / pinion shaft)
Installation Note page N-21
- 8. Extension bar / Control rod (MTX)
- 9. Nut (Steering gear mounting bolt)
Installation Note page N-21
- 10. Steering gear and linkage
Removal Note page N-21

STEERING GEAR AND LINKAGE (K8 DOHC)


Removal / Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. After installation, bleed air from the steering system and adjust the toe-in if necessary.
(Refer to section R.)




1. Cotter pin
2. Locknut
3. Tie-rod end ball joint
Removal Note page N-17
4. Support bracket
5. Tube rubber
6. Pressure pipe
7. Return pipe
8. Set plate

9. Dust cover
10. Fixing bolt
(intermediate shaft / pinion shaft)
Installation Note page N-21
11. Insulator
12. Nut (Steering gear mounting bolt)
Installation Note page N-21
13. Steering gear and linkage
Removal Note page N-21

**Removal Note****Steering gear and linkage**


Remove the steering gear from the right side of the vehicle.

**Installation Note****Nut**

Tighten the steering gear mounting nuts in the order shown in the figure.

Tightening torque:

38–51 N·m {3.8–5.3 kgf·m, 28–38 ft·lbf}

**Fixing bolt (Intermediate shaft / Pinion shaft)**


1. Remove the intermediate shaft and pinion shaft bolts, and move the intermediate shaft upward.
2. Connect the intermediate shaft and the pinion shaft. Tighten the bolts, to the specified torques.
3. Attach the dust cover onto the set plate.

Tightening torque:


18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}

Disassembly / Inspection (B6 DOHC)


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.




- | | |
|---|--|
| 1. Oil pipe Disassembly Note page N-23 | 19. Oil seal Disassembly Note page N-24 |
| 2. Tie rod end | 20. Pinion shaft assembly Inspect for damage and wear |
| 3. Locknut | 21. Seal ring |
| 4. Boot band | 22. Outer box Disassembly Note page N-24 |
| 5. Boot wire | 23. O-ring |
| 6. Boot | 24. U-gasket |
| 7. Tie rod Disassembly Note page N-23 Inspect for damage Inspect operation of ball joint | 25. Steering rack Inspection page N-25 |
| 8. Locknut Disassembly Note page N-23 | 26. Seal ring |
| 9. Dust cover | 27. O-ring |
| 10. Washer | 28. Oil seal Disassembly Note page N-24 |
| 11. Adjustment cover | 29. Inner guide Disassembly Note page N-24 |
| 12. Spring | 30. Bearing |
| 13. Support yoke | 31. Oil seal |
| 14. Housing cover Disassembly Note page N-23 | 32. Bearing |
| 15. Locknut | 33. Mounting bracket |
| 16. Plug Disassembly Note page N-23 Inspection page N-25 | 34. Mounting rubber |
| 17. O-ring | 35. Gear housing Inspect for damage and crack |
| 18. Bearing Disassembly Note page N-24 | |

**Disassembly Note****Oil pipe**


After disconnecting the pipes, use a plug or adhesive type tape to seal each port to prevent the entry of foreign materials.

**Tie rod**

Use the **SST** to remove the tie rod.


**locknut**

Use the **SST** to remove the locknut.


**Housing cover****Caution**

- If the drill diameter and/or the depth of the recess are excessive, the threads will be too loose when the plug reused.


Use a drill ($\Phi 1.5\text{mm}$ {0.06 in}) to make a recessed area (approx. 1.5mm {0.06 in}) at the punch-crimped part of the threaded part.

**Plug**


Use the **SST** to remove the plug.

**Oil seal and bearing**


Use the **SSTs** to remove the bearing and the oil seal from the plug.

**Outer box**

Use the **SST** to remove the outer box.


**Oil seal, inner guide**

Use the **SSTs** to remove the oil seal and inner guide toward the cylinder side.


**Inspection****Steering rack**

1. Check the rack for cracking or other damage or for abnormal wear of the teeth; replace it if necessary.
2. Check the seal ring installation part of the rack for abnormal wear or damage; replace it if necessary.
3. Use V blocks to support both ends of the large-diameter part of the rack; check for excessive bending; replace it if necessary.


Bending limit: 0.15 mm {0.006 in} (near rack center)

**Plug**


Check for scratches or other damage at the oil seal installation inner diameter; replace it if necessary.

**Assembly****1. Mounting bracket and mounting rubber**


- (1) Install the mounting rubber.
- (2) Tap the mounting bracket on with a plastic hammer.

**2. Steering rack assembly**

- (1) Install a new O-ring and new seal ring to the rack's piston.
- (2) After installing the seal ring, seat it properly at the piston circumference.
- (3) Install a new oil seal and inner guide to the **SSTs**.



- (4) Using the **SST**, place the oil seal and inner guide at the edge of the steering rack's pinion, and remove the **SST**.
- (5) After mounting the steering rack to the gear housing, use a press to install the oil seal and inner guide to the correct position. Do not press over **2,940 N {300 kgf, 660 lbf}**.
- (6) Apply grease to the seal ring, oil seal and inner guide.




3. Outer box assembly

- (1) Apply grease to a U-gasket and new O-ring.
- (2) Install the U-gasket and O-ring into the outer box.


Tightening torque:

40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}




4. Cylinder air-tightness check

- (1) Install the **SSTs** to the cylinder part of the gear housing.
- (2) Using a vacuum pump, apply a vacuum of **400 mmHg** and check to be sure that the vacuum is maintained for **30 seconds**.
- (3) If there is any leakage, replace the oil seal.




5. Oil seal and bearing (Upper, Lower)

- (1) Use the **SSTs** to install a new oil seal and bearing (Upper) to the gear housing.
- (2) Apply grease to the oil seal.
- (3) Install the bearing (Lower).




6. Pinion shaft assembly and seal ring

- (1) Use the **SST** to install a new seal ring to the valve part of the pinion shaft.
- (2) After installing it, use the **SSTs** to seat it properly.




- (3) Use the **SST** to install the pinion shaft assembly to the gear housing.

**7. Plug assembly**

- (1) Use the **SST** to press in a new oil seal.
- (2) Press in by placing the flat plate against the bearing.
- (3) Install the new O-ring.

Caution


- Apply grease to the O-ring, oil seal and bearing.

**8. Locknut**

- (1) Temporarily install the tie rod on the tube side of the rack.
- (2) Invert the housing and install the locknut on the pinion shaft. Turn it until the tie rod contacts the tube.
- (3) Tighten the locknut.

Tightening torque:


40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}

**9. Housing cover**


- (1) Apply thread sealant to the housing cover threads.
- (2) Install the housing cover.

Tightening torque:

40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}



- (3) Stake between the rack housing and housing cover at two points with a center punch.




- (4) Use the **SST** to tighten the plug assembly to the gear housing.


Tightening torque:

30–39 N·m {3.0–4.0 kgf·m, 22–28 ft·lbf}

- (5) Stake between the housing and plug assembly at one point with a center punch.

**10. Support yoke**


- (1) Secure the gear housing in a vise so that the support yoke position faces upward.
- (2) Apply grease to the rack sliding surface of the support yoke, then install it in the housing.
- (3) Install the support yoke.
- (4) Install the spring.

**11. Adjusting cover and locknut**

- (1) Apply sealant to the adjusting cover and temporarily tighten it to a torque of **11 N·m {110 kgf·cm, 95 in·lbf}**.
- (2) Move the rack back and forth **approx. 3 times** and loosen the adjusting cover.
- (3) Retighten the adjusting cover to the specified torque and then loosen it **0–40°**.

Tightening torque:

4.5–5.3 N·m {45–55 kgf·cm, 40–47 in·lbf}



- (4) Tighten the locknut with the **SST**.

- (5) Measure the pinion starting torque with the **SST** and a pull scale.

Starting torque

At ±90° from the straight-ahead position

1.0–1.3 N·m {10–14 kgf·cm, 8.7–12.1 in·lbf}


(Pull scale reading: 1.0–1.4 kgf {2.2–3.0 lbf})

At other position:


1.6 N·m {17 kgf·cm, 14.7 in·lbf} max.

(Pull scale reading: 1.7 kgf {3.7 lbf} max.)

- (6) If not as specified, repeat Steps 3 to 5.

**12. Tie rod**

- (1) Install the tie rod (with air bled out) at the rack housing side.




- (2) Secure the rack in a vise.

- (3) Install the new washer and tie rod onto the steering rack.


Tightening torque:

59–78 N·m {6.0–8.0 kgf·m, 44–57 ft·lbf}


- (4) Align the washer with the rack groove, and crimp the washer.

**13. Boot, Boot wire, Boot band**

- (1) Apply grease to the inner surface of the small end of the boot.
- (2) Install the boot. Wrap a new boot wire around the large end of the boot twice and then twist it 4 to 4.5 times. Bend the twisted part toward the mounting bracket.
- (3) Install the boot band on the small end of the boot.

**14. Tie-rod end**

- Align with the marks made before disassembly, and tighten the nut.

**15. Oil pipe and dust cover**

- (1) Secure the mounting bracket in a vise so that the oil pipe connections face upward.
- (2) Install the oil pipes.

Tightening torque**Cylinder pipe:**

20–29 N·m {2.0–3.0 kgf·m, 15–21 ft·lbf}


Pressure and return pipe:

30–39 N·m {3.0–4.0 kgf·m, 22–28 ft·lbf}


- (3) Install the dust cover.

Disassembly / Inspection (K8 DOHC)

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace if necessary.



1. Oil pipe
Disassembly Note page N-32
Inspect for clogging and damage
2. Tie-rod end
Disassembly Note page N-32
Inspect ball joint for
damage and malfunction
3. Locknut (Tie rod end)
4. Boot clamp
5. Boot wire
6. Boot
Inspect for cracks and other damage
7. Tie rod
Disassembly Note page N-32
Inspect for bending
Inspect ball joint for
damage and malfunction
8. Locknut (Adjusting cover)
9. Adjusting cover
Assembly Note page N-32
10. Yoke spring
Inspect for weakness and damage
11. Support yoke
Disassembly Note page N-33
Inspect for damage and wear
12. Snap ring
Disassembly Note page N-33
13. Housing cover
Disassembly Note page N-33
14. Locknut
15. Pinion shaft assembly
Disassembly Note page N-33
Inspect for damage and wear
16. Oil seal
17. Upper bearing
Inspect for wear, damage and malfunction
18. Rack bushing
Disassembly Note page N-33
Inspect for damage and wear
19. Steering rack
Disassembly Note page N-34
Inspection page N-35
20. Oil seal
Disassembly Note page N-34
21. Spacer
Disassembly Note page N-34
22. Oil seal
Disassembly Note page N-34
23. Lower bearing
Disassembly Note page N-34
Inspect for cracks, damage and wear
24. Needle bearing
Disassembly Note page N-35
Inspect for cracks, damage and wear
25. Oil seal
Disassembly Note page N-35
26. Seal ring
Disassembly Note page N-35
27. O-ring
Disassembly Note page N-35
28. Mounting bracket
29. Mounting rubber
30. Gear housing
Inspect for cracks and damage




Disassembly Note Oil pipe


Note

- The pipe clip does not need to be removed unless you are replacing it.

1. Secure the gear and linkage in a vise.
2. Mark the pipe clip and the gear housing for proper assembly.




3. Remove the oil pipe.




Tie-rod end

1. Before removing the tie-rod end, make a mark for proper installation.
2. Remove the tie-rod end.




Tie rod

1. Secure the rack in a vise.
2. Remove the tie rod.




Adjusting cover


1. Remove the locknut from the adjusting cover.
2. Remove the adjusting cover with the SST.
3. Remove the yoke spring.

**Support yoke**

Remove the support yoke with a snap ring plier.


**Snap ring**

Remove the snap ring with a snap ring plier.


**Housing cover****Caution**

- If the drill diameter and/or the depth of the recess are excessive, the threads will be too loose when the plug is reused.


1. Use a drill ($\Phi 1.5\text{mm}$ {0.06 in}) to make a recessed area (approx. 1.5mm {0.06 in}) at the punch-crimped part of the threaded part.
2. Remove the housing cover.

**Pinion shaft assembly**


1. Remove the locknut.
2. Set the gear housing assembly on a press and remove the pinion shaft assembly as shown in the figure.

**Rack bushing**


1. Cut away the staked areas with a drill.
2. Remove the rack bushing.

**Steering rack and oil seal at tube side**


1. Slide the **SST** over the rack from the gear housing side.




2. Install the **SSTs** to the threaded part of the rack at the tube side.
3. Remove the oil seal at the tube side by pulling out the rack.

**Spacer, oil seal**


1. Insert the **SST** from the pinion housing side so that it contacts the spacer.




2. Set the **SST** against the **SST** inserted in step 1.
3. Secure the gear housing in a vise.
4. Remove the spacer and oil seal out of the housing.

**Lower bearing**


- Remove the lower bearing out of the housing with the **SST**.

**Needle bearing oil seal**

1. Insert the **SST** so that it contacts the needle bearing.
2. Remove the oil seal and needle bearing out with the **SST** bar.

**Seal ring, O-ring**

- Remove the seal ring and O-ring out of the steering rack with a flat-tipped screw driver.

**Inspection****Steering rack**


1. Inspect for cracking, damage, and tooth wear, replace if necessary.
2. Measure runout of the rack.

Runout


Near point A: 0.15 mm {0.006 in}

Near point B: 0.20 mm {0.008 in}


3. If not within specification, replace the rack.

**Assembly****1. Mounting bracket and rubber**

- (1) Install the mounting rubber.
- (2) Tap the mounting bracket on with a plastic hammer.


**2. O-ring and seal ring**

- (1) Apply ATF to a new O-ring and seal ring.
- (2) Install the O-ring in the ring groove of the rack.
- (3) Install the seal ring in the groove of the rack.
- (4) Compress the seal ring by hand to fit it into the groove.




3. Needle bearing

- (1) Apply grease to the end of the **SST**.
- (2) Apply ATF to the needle bearing.
- (3) Set the needle bearing on the **SST** so that the embossed side of the bearing faces the **SST**.




- (4) Insert the needle bearing and the **SST** into the housing.
- (5) Set the housing on a press and press in the bearing.




4. Oil seal


- (1) Apply grease to the end of the **SST**.
- (2) Apply ATF to a new oil seal.
- (3) Set the oil seal on the **SST**.




- (4) Insert the oil seal and the **SSTs** into the housing.




- (5) Set the housing on a press and press in the oil seal
- (6) Remove the **SSTs**.




- 5. Spacer and pinion housing side oil seal**
 (1) Apply grease to flat surface of the spacer.




- (2) Connect a new oil seal to the grease coated surface of the spacer.
 (3) Apply ATF to the inside and outside of the spacer and new oil seal.




- (4) Set the spacer and oil seal on the **SST**.



- (5) Insert the **SST** from the tube side.




- (6) Install and tighten the **SST** nut against the tube.
 (7) Turn the **SST** shaft in as far as it will go to push in the seal and spacer.
 (8) Remove the **SSTs**.




6. Steering rack

- (1) Apply grease (lithium base, NLGI No.2) to the friction surface and teeth of the steering rack.
- (2) Slide the **SST** over the steering rack and slide it in from the tube side.
- (3) Remove the **SST**.




7. Oil seal (Rack)

- (1) Apply ATF to a new oil seal and slide it on the steering rack.



- (2) Set the **SST** on the rack.
- (3) Turn the **SST** as far as it will go to push the oil seal into the tube.
- (4) Remove the **SST**.



8. Rack bushing


Install the rack bushing assembly in the rack housing.

Tightening torque:

89–98 N·m {9.0–10.0 kgf·m, 66–72 ft·lbf}


Note

- The oil seal is pushed to the correct position in the rack housing by tightening the rack bushing.



9. Hermetic inspection


- (1) Connect the **SSTs** to the cylinder housing.
- (2) Connect a vacuum pump to the **SST**.
- (3) Apply **53.3 kPa {400 mmHg, 15.7 inHg}** vacuum.
- (4) Verify that vacuum is held for at least **30 sec**. If not, check the seal and assembly.



- (5) Stake the rack housing at two points **approx 1.5mm (0.06 in)** from the end.


Caution

- Stake a point **90°** from the part which was cut away with a drill during disassembly.




10. Lower bearing

- (1) Secure the gear housing in a vise so that the lower bearing bore faces upward.
- (2) Apply ATF to the lower bearing, then install it in the housing.
- (3) Press the bearing into the gear housing with the housing cover. Tighten the cover until resistance suddenly increases.




11. Pinion shaft assembly

- (1) Apply grease (lithium base, NLGI No.2) to the teeth of the pinion shaft.
- (2) Apply ATF to a new seal ring and the friction surface of the control valve.
- (3) Install the pinion shaft in the housing.




12. Upper bearing

Apply ATF to the upper bearing, then install it.




13. Oil seal

- (1) Apply ATF to a new oil seal, and fill inside the lip with grease (lithium base, NLGI No.2).
- (2) Slide the **SST** over the serrations of the pinion shaft assembly.
- (3) Slide the oil seal over the **SST** and position it in the housing.




- (4) Tap the oil seal in with the **SST** until the snap ring installation groove in the housing is just visible.



14. Snap ring

1. Install the new snap ring.
2. Verify that the snap ring is correctly seated in the ring groove of the housing.




15. Locknut

- (1) Temporarily install the tie rod on the tube side of the rack.
- (2) Invert the housing and install the locknut on the pinion shaft. Turn it until the tie rod contacts the tube.
- (3) Tighten the locknut.

Tightening torque:

40–49 N·m {4.0–5.0 kgf·m, 29–36 ft·lbf}




16. Housing cover


- (1) Apply thread sealant to the housing cover threads.
- (2) Install the housing cover.

Tightening torque:


54–68 N·m {5.5–7.0 kgf·m, 40–50 ft·lbf}




- (3) Stake between the rack housing and housing cover at two points with a center punch.

**17. Support yoke**

- (1) Secure the gear housing in a vise so that the support yoke position faces upward.
- (2) Apply grease (lithium base NLGI No.2) to the rack sliding surface of the pressure pad, then install it in the housing.
- (3) Install the support yoke.
- (4) Install the yoke spring.

**18. Adjusting cover**

- (1) Set the rack in the center position.
- (2) Apply sealant to the adjusting cover.
- (3) Set the **SSTs** and a torque wrench against the adjusting cover.
- (4) Tighten the adjusting cover to **9.8 N·m {100 kgf·cm, 87 in·lbf}**, then loosen it.
- (5) Tighten again to **4.5–5.3 N·m {45–55 kgf·cm, 40–47 in·lbf}**, and then return it 45°.



- (6) Measure pinion torque with the **SST** and a pull scale.


Standard

Center of rack $\pm 90^\circ$:

1.0–1.3 N·m {10–14 kgf·cm, 8.7–12.1 in·lbf}
(Pull scale reading: 1.0–1.2 kgf {2.2–2.6 lbf})

At other position:

1.6 N·m {17 kgf·cm, 14.7 in·lbf} max.
(Pull scale reading: 1.7 kgf {3.7 lbf} max.)




- (7) If not within specification, repeat steps (5) through (6).

- (8) Apply thread sealant to the threads of the locknut.

- (9) Use the **SST** to tighten the locknut.

Tightening torque:


50–58 N·m {5.0–6.0 kgf·m, 37–43 ft·lbf}

**19. Tie rod**


- (1) Secure the rack in a vise.
- (2) Install the tie rod onto the rack.

Tightening torque:


123–142 N·m {12.5–14.5 kgf·m, 91–104 ft·lbf}

**20. Boot, boot wire, boot clamp**

- (1) Apply grease to the inner surface of the small end of the boot.
- (2) Install the boot. Wrap a new boot wire around the large end of the boot twice and then twist it 4 to 4.5 times. Bend the twisted part toward the mounting bracket.
- (3) Install the boot clamp on the small end of the boot.

**21. Tie-rod end**

- Align with the marks made before disassembly, and tighten the nut.

**22. Oil pipe**

- (1) Secure the mounting bracket in a vise so that the oil pipe connections face upward.
- (2) Install the oil pipes.


Tightening torque:

25–34 N·m {2.5–3.5 kgf·m, 19–25 ft·lbf}

POWER STEERING OIL PUMP (B6 DOHC)

Removal / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.
4. After installation, bleed air from system (Refer to page N-8.)




- | | |
|-----------------------------|---------------------------------------|
| 1. Bolt | 8. Return hose |
| 2. Nut | 9. Bolts |
| 3. Nut | 10. P/S oil pump assembly and bracket |
| 4. Adjusting bolt | 11. P/S oil pump assembly |
| 5. P/S drive belt | Disassembly / Inspection / |
| Replacement page N-51 | Assembly page N-45 |
| Adjustment page N-51 | |
| Inspection page N-51 | 12. Bracket |
| | Inspect cracks and damage |

POWER STEERING OIL PUMP (K8 DOHC)

Removal / Installation

1. Remove the A/C drive belt. (Refer to section U.)
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal.
4. After installation, bleed air from system.
5. Install the A/C drive belt. (Refer to section U.)




1. Power steering pressure switch connector
2. Bolt
3. Pressure hose
4. Return hose
5. P/S drive belt

6. Bolt
7. Bolt
8. P/S oil pump assembly

Disassembly / Inspection /
Assembly page N-48

Removal Note below
Inspection / Adjustment /
Replacement page P-52




Removal Note P/S Drive belt


Loosen nut (A) and turn adjusting bolt (B) to release the belt tension.

Disassembly / Inspection / Assembly (B6 DOHC)


1. The following procedures show replacement of the O-rings. If a problem is found in other parts, replace the oil pump assembly.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and replace as necessary.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|---|--|
| <p>1. Oil pump Disassembly Note page N-46</p> <p>2. Suction pipe</p> <p>3. O-ring</p> <p>4. Pressure-switch assembly</p> <p>5. O-ring</p> <p>6. Connector</p> <p>7. O-rings</p> <p>8. Control valve Inspection page N-46</p> <p>9. Spring Inspection page N-46</p> <p>10. Bracket</p> <p>11. Pump body (rear) Inspection page N-46 Assembly Note page N-47</p> <p>12. O-ring</p> <p>13. Cam ring Inspection page N-46 Assembly Note page N-47</p> | <p>14. Vane Inspection page N-46 Assembly Note page N-47</p> <p>15. Rotor Inspection page N-46 Assembly Note page N-46</p> <p>16. Side plate Inspection page N-46</p> <p>17. O-ring</p> <p>18. O-ring</p> <p>19. Pin</p> <p>20. Pump body (front) Inspection page N-46</p> |
|---|--|

**Disassembly Note****Oil pump**


Use the **SST** when securing the oil pump in a vise, so that force is not applied to the pulley or shaft.

**Inspection
pump body**


Check the front and rear pump bodies for cracking or other damage and for abnormal wear of the moving surface of the rotor. Replace the pump assembly if a problem is found.

**Cam ring, rotor, vanes, side plate**


1. Check the moving surface of the cam ring's vanes for abnormal wear.
2. Check the moving surface of the side plate and the pump bodies for abnormal wear.
3. Check the moving surface of the vane cam ring for abnormal wear.
4. Check the clearance of the rotor and vanes.

**Control valve and spring**


1. Check the control valve for cracking and other damage, for blockage, and for abnormal wear of the moving part.
2. Check the spring for damage.

**Assembly Note****Rotor**

Install the rotor to the shaft with the rotor's identification mark facing upward.

**Cam ring**

Install the cam ring so that its identification mark is facing downward.

**Vane**


Install the vanes (10 pieces) to the rotor, with the radiused part of the vanes facing outward.

Pump body (rear)


Turn the pulley by hands, inspect for smooth turn.

Disassembly / Inspection / Assembly (K8 DOHC)


1. The following procedures show replacement of the O-rings. If a problem is found in other parts, replace the oil pump assembly.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and replace as necessary.
4. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




- | | |
|-----------------------------|-----------|
| 1. Bracket | |
| 2. Pulley | |
| Disassembly Note | page N-49 |
| Assembly Note | page N-50 |
| 3. Suction pipe | |
| 4. O-ring | |
| 5. Pressure-switch assembly | |
| 6. O-ring | |
| 7. Connector | |
| 8. O-ring | |
| 9. Control valve | |
| Inspection | page N-49 |
| 10. Spring | |
| Inspection | page N-49 |
| 11. Pump body (rear) | |
| Inspection | page N-49 |
| Assembly Note | page N-50 |
| 12. Seal washer | |
| 13. Cam ring | |
| Inspection | page N-49 |
| Assembly Note | page N-50 |
| 14. Vane | |
| Inspection | page N-49 |
| Assembly Note | page N-50 |
| 15. Rotor | |
| Inspection | page N-49 |
| Assembly Note | page N-50 |
| 16. Side plate | |
| Inspection | page N-49 |
| 17. O-ring | |
| 18. O-ring | |
| 19. Pin | |
| 20. Pump body (front) | |
| Inspection | page N-49 |

**Disassembly Note****Pulley**


1. Secure the oil pump assembly in a vise with the **SST** and bolts.




2. Remove the locknut while holding the pulley by using a screw driver.

**Inspection****Pump body**


Check the front and rear pump bodies for cracking and other damage and for abnormal wear of the friction surface of the rotor. Replace the pump assembly if a problem is found.

**Cam ring, rotor, vanes, side plate**


1. Check the friction surface of the cam ring vanes for abnormal wear.
2. Check the friction surface of the side plate and the pump bodies for abnormal wear.
3. Check the friction surface of the cam ring for abnormal wear.
4. Check the clearance of the rotor and vanes.

**Control Valve and spring**


1. Check the control valve for cracking, damage, blockage, and abnormal wear.
2. Check the spring for damage.

**Assembly Note****Rotor**


Install the rotor to the shaft with the rotor identification mark upward.

**Cam ring**


Install the cam ring with its identification mark downward.

**Vane**

Install the vanes (10 pieces) to the rotor, with the radiused part of the vanes outward.

**Pump body (rear)**



1. Install the rear pump body.
2. Turn the pump shaft by hand, and verify that it turns smoothly.

**Pulley**

Install the pulley locknut while holding the pulley by using a screwdriver.

TIGHTENING TORQUE:

50–58 N·m {5.0–6.0 kgf·m, 37–43 ft·lb}



DRIVE BELT (B6 DOHC)

Inspection

1. Check the drive belt for wear, cracks and fraying. Replace as necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.
3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure (98 N {10 kgf, 22 lbf}) midway between the specified pulleys.

Deflection

mm{in}

| New* | Used | Limit |
|---------------------|----------------------|-------------|
| 8.0-9.0 {0.32-0.35} | 9.0-10.0 {0.36-0.39} | 11.5 {0.45} |

* A belt that has been on a running engine for less than five minutes.

4. If the deflection is not within specification, adjust it.

Drive belt tension check

1. Belt tension can be checked in place of belt deflection. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the SST, check the belt tension between any two pulleys.



Tension

N{kgf·lbf}

| New* | Used | Limit |
|-----------------------------|----------------------------|-----------------|
| 491-588 {50-60, 110-132} | 422-490 {43-50, 95-110} | 245 {25, 55} |

* A belt that has been on a running engine for less than five minutes.

2. If the tension is not within specification, adjust it.



Adjustment





1. Loosen bolt A, locknut B, and nut C. Turn adjusting bolt D to adjust the belt to the specified deflection and tension.
2. Tighten nut C, bolt A, and locknut B to the specified torques.

Tightening torque

- Bolt A : 37-53 N·m {3.7-5.5 kgf·m, 27-39 ft·lbf}
- Nut B : 19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}
- Locknut C : 32-46 N·m {3.2-4.7 kgf·m, 24-33 ft·lbf}

Replacement

1. Loosen bolt A, nut C, and locknut B.
2. Turn adjusting bolt D to release the belt tension.
3. Remove the belt.
4. Install a new drive belt and adjust the tension and deflection. (Refer to above for adjustment.)



DRIVE BELT (K8 DOHC)

Inspection

1. Check the drive belt for wear, cracks, and fraying. Replace as necessary.
2. Verify that the drive belts are correctly mounted on the pulleys.
3. Check the drive belt deflection when the engine is cold, or at least 30 minutes after the engine has stopped. Apply moderate pressure (98 N {10 kgf, 22 lbf}) midway between the specified pulleys.

Deflection

mm{in}

| New* | Used | Limit |
|---------------------|---------------------|------------|
| 6.0-7.0 {0.24-0.27} | 7.0-8.0 {0.28-0.31} | 9.0 {0.35} |

* A belt that has been on a running engine for less than five minutes.

4. If the deflection is not within specification, adjust it.

Drive belt tension check

1. Belt tension can be checked in place of belt deflection. Check the drive belt tension when the engine is cold, or at least 30 minutes after the engine has stopped. Using the SST, check the belt tension between any two pulleys.

Tension

N{kgf·lbf}

| New* | Used | Limit |
|-----------------------------|----------------------------|-----------------|
| 540-686 {55-70, 130-154} | 392-539 {40-55, 88-121} | 343 {35, 77} |

* A belt that has been on a running engine for less than five minutes.

2. If the tension is not within specification, adjust it.

Adjustment

1. Loosen locknut (A). Turn adjusting bolt (B) to adjust the belt to the specified deflection and tension.
2. Tighten locknut (A) to the specified torques.

Tightening torque

Nut A : 32-46 N·m {3.2-4.7 kgf·m, 24-33 ft·lbf}

Replacement


1. Remove the alternator and A/C drive belt. (Refer to body electrical troubleshooting manual, section G.)
2. Loosen locknut (A).
3. Turn adjusting bolt (B) to release the belt tension.
4. Remove the belt.
5. Install a new P/S drive belt and adjust the tension and deflection. (Refer to above for adjustment.)
6. Install A/C drive belt and adjust the tension and deflection. (Refer to body electrical troubleshooting manual, section G.)

Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

BRAKING SYSTEM


| | |
|---|------|
| INDEX | P- 2 |
| OUTLINE | P- 4 |
| SPECIFICATIONS | P- 4 |
| CONVENTIONAL BRAKING SYSTEM | P- 5 |
| PREPARATION | P- 5 |
| TROUBLESHOOTING GUIDE | P- 6 |
| AIR BLEEDING | P- 7 |
| BRAKE HYDRAULIC LINE | P- 7 |
| BRAKE FLUID | P- 9 |
| BRAKE PEDAL | P- 9 |
| MASTER CYLINDER (B6 DOHC) | P-12 |
| MASTER CYLINDER (K8 DOHC) | P-19 |
| POWER BRAKE UNIT | P-26 |
| DUAL PROPORTIONING VALVE | P-30 |
| FRONT BRAKE (DISC) | P-32 |
| CALIPER | P-35 |
| REAR BRAKE (DISC) | P-37 |
| CALIPER | P-40 |
| REAR BRAKE (DRUM) | P-42 |
| WHEEL CYLINDER | P-44 |
| PARKING BRAKE SYSTEM | P-45 |
| TROUBLESHOOTING GUIDE | P-45 |
| PARKING BRAKE SHOE | P-45 |
| PARKING BRAKE (LEVER TYPE) | P-45 |
| PARKING BRAKE CABLE | P-46 |
| PARKING BRAKE LEVER | P-47 |
| ANTI-LOCK BRAKE SYSTEM (ABS) | P-48 |
| DESCRIPTION | P-48 |
| PREPARATION | P-48 |
| TROUBLESHOOTING GUIDE | P-48 |
| WIRING DIAGRAM | P-49 |
| RELATIONSHIP CHART | P-50 |
| DIAGNOSTIC CHART | P-50 |
| DIAGNOSTIC INDEX | P-50 |
| SYMPTOM TROUBLESHOOTING | P-51 |
| ON-BOARD DIAGNOSIS FUNCTION | P-54 |
| ABS HYDRAULIC UNIT | P-69 |
| ABS CONTROL MODULE | P-71 |
| ABS RELAY | P-72 |
| ABS WHEEL-SPEED | |
| SENSOR (FRONT) | P-74 |
| ABS SENSOR ROTOR (FRONT) | P-75 |
| ABS WHEEL-SPEED SENSOR (REAR) ... | P-76 |
| ABS SENSOR ROTOR (REAR) | P-77 |

INDEX



- | | | | |
|---|-----------|---|-----------|
| 1. Brake hydraulic line Inspection / Removal / Installation | page P- 7 | 7. Caliper Disassembly / Inspection / Assembly | page P-35 |
| 2. Brake pedal Inspection (on-vehicle) | page P- 9 | 8. Rear brake (disc) Quick inspection (on-vehicle) .. | page P-37 |
| Removal / Inspection / Installation | page P-11 | Replacement | page P-37 |
| 3. Master cylinder (B6 DOHC) Removal / Installation | page P-12 | Removal / Installation | page P-38 |
| Disassembly / Inspection / Assembly | page P-17 | Inspection | page P-39 |
| 3. Master cylinder (K8 DOHC) Removal / Installation | page P-19 | 9. Caliper Disassembly / Inspection / Assembly | page P-40 |
| Disassembly / Inspection / Assembly | page P-22 | 10. Rear brake (drum) Inspection (on-vehicle) | page P-42 |
| 4. Power brake unit Quick inspection (on-vehicle) .. | page P-26 | Removal/Inspection / Installation | page P-42 |
| Removal / Installation | page P-28 | 11. Wheel cylinder Disassembly / Inspection / Assembly | page P-44 |
| 5. Dual proportioning valve Inspection | page P-30 | 12. Parking brake (lever type) Inspection (on-vehicle) | page P-45 |
| Replacement | page P-30 | Adjustment | page P-45 |
| 6. Front brake (disc) Quick inspection (on-vehicle) .. | page P-32 | 13. Parking brake cable Removal / Inspection / Installation | page P-46 |
| Replacement | page P-32 | 14. Parking brake lever Removal / Inspection / Installation | page P-47 |
| Removal / Installation | page P-33 | | |
| Inspection | page P-34 | | |

ANTI-LOCK BRAKE SYSTEM (ABS)



- 1. ABS hydraulic unit
 Inspection / Removal /
 Installation page P-69
- 2. ABS control module
 Removal / Installation page P-71
- 3. ABS relay
 Removal / Inspection /
 Installation page P-72
- 4. ABS wheel-speed sensor (front)
 Removal / Inspection /
 Installation page P-74

- 5. ABS sensor rotor (front)
 Removal / Inspection page P-75
 Installation page P-76
- 6. ABS wheel-speed sensor (rear)
 Removal / Inspection /
 Installation page P-77
- 7. ABS sensor rotor (rear)
 Removal / Inspection /
 Installation page P-78

OUTLINE

















SPECIFICATIONS





| Item | | Engine | B6 DOHC | K8 DOHC |
|------------------------------|---|---------|--|-----------------------|
| | | | | |
| Brake pedal | Type | | Suspended | |
| | Pedal lever ratio | | 4.1 | |
| | Max. stroke | mm {in} | 140 {5.51} | |
| Master cylinder | Type | | Tandem (with level sensor) | |
| | | | Conventional | Plunger |
| | Cylinder inner diameter | mm {in} | 22.22 {0.875} | 23.81 {0.937} |
| Front disc brake | Type | | Ventilated disc | |
| | Cylinder bore | mm {in} | 53.97 {2.125} | |
| | Pad dimensions (area × thickness) mm ² {in ² } × mm {in} | | 4300 {6.66} × 10 {0.39} | |
| | Disc plate dimensions (outer diameter × thickness) | mm {in} | 257 × 22 {10.12 × 0.87} | |
| Rear disc brake | Type | | Solid disc | |
| | Cylinder bore | mm {in} | 30.2 {1.19} | |
| | Pad dimensions (area × thickness) mm ² {in ² } × mm {in} | | 2600 × 7.5 {4.03 × 0.3} | |
| | Disc plate dimensions (outer diameter × thickness) | mm {in} | 251 × 9.0 {9.88 × 0.35} | |
| Rear drum brake | Type | | Leading-trailing | — |
| | Wheel cylinder inner diameter | mm {in} | 17.46 {0.687} | — |
| | Lining dimensions (width × length × thickness) | mm {in} | 35.0 × 191.9 × 4.0 {1.38 × 7.56 × 0.16} | — |
| | Drum inner diameter | mm {in} | 200 {7.87} | — |
| | Shoe clearance adjustment | | Automatic adjuster | — |
| Power brake unit | Type | | Vacuum multiplier | |
| | | | Single diaphragm | Tandem diaphragm |
| | Diameter | mm {in} | 214 {8.4} | 188 + 215 {7.4 + 8.5} |
| Braking force control device | Type | | Dual proportioning valve | |
| Brake fluid | | | FMVSS116, DOT-3 | |
| Parking brake | Type | | Mechanical two-rear-wheel control | |
| | Operation system | | Center lever | |

CONVENTIONAL BRAKE SYSTEM

PREPARATION


SST

| | | | |
|--|---|--|--|
| <p>49 0259 770B Wrench, flare nut</p>  | <p>For removal of brake pipe</p> | <p>49 F043 001 Adjust gauge</p>  | <p>For adjustment of piston-to-push rod clearance</p> |
| <p>49 0208 701A Air-out tool, boot</p>  | <p>For removal of piston seal</p> | <p>49 0221 600C Expand tool, disc brake</p>  | <p>For installation of brake pads (Front disc brake)</p> |
| <p>49 E043 001A Adjust gauge</p>  | <p>For adjustment of push rod clearance</p> | <p>49 E043 003A Lock tool, turning</p>  | <p>For adjustment of push rod clearance</p> |
| <p>49 B043 004 Socket wrench</p>  | <p>For adjustment of push rod clearance</p> | <p>49 E043 002A Installer, retainer</p>  | <p>For installation of retainer</p> |
| <p>49 Z043 001 Wrench, cap nut</p>  | <p>For removal and installation of cap</p> | <p>49 Z043 0A0 Piston adjuster set</p>  | <p>For adjustment of master cylinder</p> |
| <p>49 Z043 002 Adapter</p>  | <p>For adjustment of master cylinder</p> | <p>49 R015 002 Hose, pressure</p>  | <p>For adjustment of master cylinder</p> |
| <p>49 FA18 602 Wrench, disc brake piston</p>  | <p>For removal of piston</p> | <p>49 1285 071 Puller, bearing</p>  | <p>For removal of needle bearing</p> |
| <p>49 B043 002 Installer, bearing</p>  | <p>For installation of needle bearing</p> | <p>49 U043 0A0 Gauge set, oil pressure</p>  | <p>For inspection of brake fluid pressure</p> |

| | | | |
|--|---|--|---|
| <p>49 U043 004 Gauge, oil pressure (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> | <p>49 U043 005 Joint (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> |
| <p>49 U043 006 Hose (Part of 49 U043 0A0)</p>  | <p>For inspection of brake fluid pressure</p> | <p>49 B043 001 Adjust gauge</p>  | <p>For adjustment of push rod clearance</p> |

TROUBLESHOOTING GUIDE


| Problem | Possible cause | Remedy | Page |
|--|--|--|---|
| <p>Poor braking</p> | <p>Leakage of brake fluid Air in system Worn pad or lining Brake fluid, grease, oil, or water on pad or lining Hardening of pad or lining surface or poor contact Malfunction of disc brake piston Malfunction of master cylinder or wheel cylinder</p> <p>Malfunction of power brake unit Malfunction of check valve (vacuum hose) Damaged vacuum hose Deterioration of flexible hose Malfunction of dual proportioning valve</p> | <p>Repair Bleed air Replace Clean or replace Grind or replace Replace Repair or replace</p> <p>Repair or replace Replace Replace Replace</p> | <p>P-8 P-7 P-32,37,42 P-32,37,42 P-32,37,42 P-33,40 P-14,19 35,40,42,44 P-28,29 P-28 — — P-30</p> |
| <p>Brakes pull to one side</p> | <p>Worn pad or lining Brake fluid, grease, oil, or water on pad or lining Hardening of pad or lining surface or poor contact Abnormal wear or distortion of disc, drum, pad, or lining Malfunction of automatic adjuster Looseness of backing plate / dust cover mounting bolts Malfunction of wheel cylinder Improperly adjuster wheel alignment Unequal tire air pressures</p> | <p>Replace Clean or replace Grind or replace Repair or replace Repair or replace Tighten Repair or replace Adjust Adjust</p> | <p>P-32,37,42 P-32,37,42 P-32,37,42 P-32,37,42 — Section M P-35,40,42 Section R Section Q</p> |
| <p>Brakes do not release</p> | <p>No brake pedal play Improperly adjusted push rod clearance Clogged master cylinder return port Weak brake pad or shoe return spring Wheel cylinder not returning properly Malfunction of piston seal of disc brake Excessive runout of disc plate</p> | <p>Adjust Adjust Clean Replace Clean or replace Replace Replace</p> | <p>P-13 P-15,20 — P-32,37,42 P-42,44 P-35,40 P-34,39</p> |
| <p>Pedal goes too far (too much pedal stroke)</p> | <p>Improperly adjusted pedal play Worn pad or lining Air in system</p> | <p>Adjust Replace Bleed air</p> | <p>P-13 P-32,37,42 P-10</p> |
| <p>Abnormal noise or vibration during braking</p> | <p>Worn pad or lining Deteriorated pad or lining Brakes do not release Foreign material or scratches on disc plate or drum contact surface Looseness of backing plate / dust cover or caliper mounting bolts Damaged disc or drum contact surface Poor contact of pad or lining Insufficient grease on sliding parts</p> | <p>Replace Grind or replace Repair Clean</p> <p>Tighten</p> <p>Replace Repair or replace Grease</p> | <p>P-32,37,42 P-32,37,42 — P-33,38,42</p> <p>Section M P-33,38</p> <p>P-33,38,42 P-32,37,42 —</p> |
| <p>Steering wheel pulls to one side</p> | <p>Dragging brake Malfunction of steering system Damaged or unbalanced wheels Incorrect tire pressure Malfunction of suspension</p> | <p>Repair</p> <p>— — — —</p> | <p>—</p> <p>Section N Section Q Section Q Section R</p> |




AIR BLEEDING

Note

- The brakes should be bled whenever a brake line is disconnected. If a hydraulic line is disconnected at the master cylinder, start at the slave cylinder farthest from the brake master cylinder, and move to the next closest slave cylinder until all four cylinders have been bled. If the disconnection point is anywhere except the master cylinder, start at the point closest to the disconnection, and move to the next farthest slave cylinder until all four cylinders have been bled.



1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the bleeder cap and attach a vinyl tube to the bleeder screw.
3. Place the other end of the vinyl tube in a clear container.
4. One person should depress the brake pedal a few times, and then hold it in the depressed position.
5. A second person should loosen the bleeder screw, drain out the fluid, and retighten the screw by using the **SST**.
6. Repeat step 4 and 5 until no air bubbles are seen. The reservoir should be kept about 3/4 full during bleeding to prevent air from reentering the lines.




Tightening torque:

5.9–8.8 N·m {60–90 kgf·cm, 53–78 in·lbf}


7. Check for correct brake operation.
8. Verify that there is no fluid leakage. Wipe off any spilled fluid immediately.
9. After bleeding the brakes, add brake fluid to MAX.

BRAKE HYDRAULIC LINE




1. Brake pipe
Inspection / Removal /
Installation page P-8


2. Flexible hose
Inspection / Removal /
Installation page P-8

**Inspection (on-vehicle)****Brake pipe**


Check for cracks, damage, and corrosion of the brake pipe. Replace the pipe or flare nut(s) if necessary.

**Flexible hose**


Check for scars, cracks, and swelling of flexible hose. Replace the hose if necessary.

**Removal**

1. Remove the brake pipe by using the **SST**.
2. Disconnect the clip and remove the flexible hose from the bracket.

**Installation**


1. Fix the flexible hose in the bracket and connect the clip to it.



2. Connect the flexible hose to the brake pipe. Verify that the hose is not twisted.
3. Tighten the flare nut by using the **SST**. Verify that the hose can not come in contact with any other parts of vehicle.

Tightening torque:

12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lbf}




BRAKE FLUID

Inspection

Leakage inspection


Depress the brake pedal several times, and inspect for leakage of the brake line system.



Brake Fluid Level

Leakage check


Verify that the fluid level in the reservoir is between the MAX and MIN lines on the reservoir. Add fluid if it is below MAX.



Replacement

1. Follow the procedure outlined in Air Bleeding. (Refer to page P-7.)
2. Continue bleeding and replacing the brake fluid until only clean fluid is expelled.
3. Fill the reservoir to the MAX level.

P



BRAKE PEDAL

Inspection (on-vehicle)

Brake pedal height

Inspection

Verify that the distance from the center on the pedal pad to the floor mat is as specified.

Specification: 193–196 mm {7.598–7.717 in}


Adjustment

1. Disconnect the brake switch connector.
2. Loosen locknut **B** and turn switch **A** until it does not contact the pedal.
3. Loosen locknut **D** and turn rod **C** to adjust the height of the brake pedal.
4. Tighten the brake switch until it contacts the pedal; then turn it an additional 1/2 turn. Tighten locknut **B** and **D**.

Tightening torque:

13.8–17.6 N·m {140–180 kgf·m, 122–156 in·lb}


5. Connect the brake switch connector.
6. Verify operation of the brake lights.



Pedal Play Inspection

1. Depress the pedal a few times to eliminate the vacuum in the system.
2. Gently depress the pedal by hand and check the free play (until resistance is felt).

Pedal play: 4–7 mm {0.16–0.27 in}




Adjustment

1. Loosen lock nut Ⓧ and turn rod © to adjust the free play.
2. Verify the pedal height and the brake light operation.

Tightening torque:

24–34 N·m {2.4–3.5 kgf·m, 18–25 ft·lbf}



Pedal-To-Floor Clearance

Inspection

Verify that the distance from the floor panel to the center of the pedal pad is as specified when the pedal is depressed with a force of **588 N {60 kgf, 132 lbf}**.


Pedal-to-floor clearance: 70 mm {2.76 in} min.

If the distance is less than specified, check for the following problems:


1. Air in brake system
2. Malfunction of automatic adjuster (Rear drum brakes)
3. Worn shoes or pads

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal.
4. After installation, check and adjust the pedal height and free play if necessary.



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Brake switch connector 2. Snap pin 3. Clevis pin 4. Steering shaft Service section N | <ol style="list-style-type: none"> 5. Brake switch Inspection below 6. Pad Inspect for wear 7. Brake pedal Inspect for bending and damage |
|--|--|




Inspection Brake switch


1. Disconnect the brake switch connector.
2. Connect an ohmmeter between the terminals of the brake switch.
3. Confirm continuity between the terminals when the brake pedal is depressed.

**MASTER CYLINDER (B6 DOHC)
Removal / Installation / Inspection
(NON ABS)**

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.



- | | |
|--|--|
| <p>1. Fluid level sensor Inspection page P-13</p> <p>2. Brake pipe Removal Note below Installation Note page P-13</p> <p>3. Hose (MTX)</p> | <p>4. Nut and washer</p> <p>5. Master cylinder Installation Note below Disassembly / Inspection / Assembly page P-17</p> |
|--|--|




**Removal Note
Brake pipe**

Disconnect the brake pipe from the master cylinder by using the **SST**.

Caution

- Brake fluid will damage painted surfaces. If brake fluid does get on a painted surface, wipe it off immediately.




Installation Note

Master cylinder


Piston to push rod clearance

Before installing the master cylinder, check the clearance between the piston of the master cylinder and the push rod of the power brake unit as follows.

1. Place the **SST** atop the master cylinder. Turn the adjusting bolt until it bottoms in the push rod hole in the piston.




2. Apply 66.7 kPa {500 mmHg, 19.7 inHg} vacuum to the power brake unit with a vacuum pump.
3. Invert the adjustment gauge used in Step 1 and place it on the power brake unit.
4. Measure the clearance between the end of the gauge and the push rod of the power brake unit. If it is not 0 mm {0 in}, loosen the push rod locknut and turn the push rod to make the adjustment.



Note

- This adjustment produces the following distance.

| | Push rod-to-piston clearance |
|---|------------------------------|
| When vacuum applied to unit is approx. 66.7 kPa {500 mmHg, 19.7 inHg} | 0.1–0.4 mm {0.004–0.015 in} |




Brake pipe

Tighten the brake pipe flare nut with the SST.

Tightening torque:

12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lbf}



Inspection


Fluid level sensor

1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above the MIN mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the MIN mark.
5. Replace the sensor if necessary.

Removal / Installation / Inspection

(ABS)

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.



1. Fluid level sensor

Inspection page P-16

2. Brake pipe

Removal Note page P-12

Installation Note page P-13

3. Hose (MTX)


4. Nuts and washers

5. Master cylinder

Installation Note page P-14

Disassembly / Inspection /

Assembly page P-17



Installation Note

Master cylinder

Push rod clearance

Inspect the push rod clearance as follows.

1. Turn the nut of the **SST** clockwise to fully retract the **SST** gauge rod. Attach the **SST** to the power brake unit.


Tightening torque:


9.9-15.6 N·m {100-160 kgf·cm, 86.8-138 in·lbf}

2. Apply **66.7 kPa {500 mmHg, 19.7 inHg}** vacuum using a vacuum pump.

3. Turn the adjusting nut of the **SST** counterclockwise until the gauge rod just contacts the push rod end of the power brake unit.

Push lightly on the end of the gauge rod to be sure it is seated. Verify that there is no gap between the adjusting nut and **SST** body.






4. Remove the **SST** from the power brake unit without disturbing the adjusting nut. Set the **SST** onto the master cylinder as shown in the figure.

Caution

- When pushing only use enough pressure to bottom the rod in the piston. If too much pressure is applied a false reading will occur.

5. Push lightly on the end of the **SST** gauge rod to be sure it is bottomed in the master cylinder piston, and note any clearance between the **SST** body and the adjusting nut (clearance B) or between the body and the master cylinder (clearance C). Adjust the push rod as necessary as outlined in "Adjustment" below.

| Measurement | Push rod |
|----------------------------|-----------|
| Clearance at (B) | Too short |
| Clearance at (C) | Too long |
| No clearance at (B) or (C) | OK |




Adjustment

Note

- The threads of the push rod are specially designed so that the bolt becomes harder to turn past a certain point to prevent loosening of the bolt. Turn the bolt only within this range when adjusting.


Clearance at B


1. Push lightly on the end of the **SST** gauge rod, and measure the clearance between the adjusting nut and the **SST** body.
2. Using the **SSTs**, turn the nut to lengthen the power brake unit push rod an amount equal to the clearance measured at B.




Clearance at C

1. Measure and record height D1 of the gauge rod.






2. Turn the adjusting nut until the **SST** body sets squarely on the master cylinder. (Turn only enough for the body to touch.)
3. Measure and record height D2 of the gauge rod.



4. Subtract D1 from D2 and using the **SSTs**, turn the nut to shorten the power brake unit push rod an amount equal to the sum.



Inspection

Fluid level sensor


1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above the **MIN** mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the **MIN** mark.
5. Replace the sensor if necessary.

Disassembly / Assembly / Inspection

1. After removing the brake fluid, disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.


Caution

- The brake master cylinder is made of aluminum, and can be easily damaged by tightening in a vise. When securing the master cylinder in a vise, tighten only the flange of the master cylinder.




- 1. Fluid level sensor
Inspection page P-13
- 2. Screw
- 3. Cap set
- 4. Float
- 5. Reservoir
Inspect for damage and deformation
- 6. Bushings
- 7. Stop screw and O-ring
(B6 DOHC, NON ABS)
Assembly Note page P-18

- 7. Stop pin and O-ring (B6 DOHC, ABS)
Assembly Note page P-18
- 8. Snap ring (B6 DOHC, NON ABS)
- 8. Snap ring and space (B6 DOHC, ABS)
- 9. Primary piston assembly
Inspect for abnormal wear, rust, and damage
- 10. Secondary piston assembly
Assembly Note page P-18
Inspect for abnormal wear, rust, and damage
- 11. Master cylinder body
Inspect for abnormal wear, rust, and damage

**Assembly Note****Secondary piston assembly, stop screw and O-ring (B6 DOHC, NON ABS)**

1. Push the secondary piston assembly in fully.
2. Install and tighten a new O-ring and stop screw.
3. Push and release the piston to verify that it is held by the stop screw.

**Secondary piston assembly, stop pin and O-ring (B6 DOHC, ABS)**

1. Install the secondary piston assembly with the piston hole facing the stop pin.
2. Install and tighten the new O-ring and stop pin.
3. Push and release the piston to verify that it is held by the stop pin.


MASTER CYLINDER (K8 DOHC)

Removal / Installation / Inspection

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.


Caution

- Before removing the master cylinder, be sure to disconnect the vacuum hose (with check valve) from the power brake unit. Removing the master cylinder with vacuum remaining in the power brake unit will cause the master cylinder piston to pop out and drain the brake fluid.




- | | |
|----------------------------|-----------|
| 1. Vacuum hose | |
| 2. Fluid level sensor | |
| Inspection | page P-21 |
| 3. Hose (MTX) | |
| 4. Brake pipe | |
| 5. Nuts and washers | |
| 6. Master cylinder | |
| Installation Note | page P-20 |
| Disassembly / Inspection / | |
| Assembly | page P-22 |

- | | |
|----------------------------|-----------|
| 7. Gasket | |
| 8. Retainer | |
| Removal Note | page P-20 |
| Installation Note | page P-20 |
| 9. Seal and plate assembly | |
| Removal Note | page P-20 |
| Installation Note | page P-20 |

**Removal Note****Retainer, seal and plate assembly**

1. Remove the retainer as shown in the figure.
2. Remove the seal and plate assembly.

**Installation Note****Master cylinder, retainer, seal and plate assembly**

1. Remove the seal and plate assembly, and install the power brake unit gasket.
2. Adjust the push rod clearance as follows.

- (1) Attach the **SST** to the power brake unit as shown in the figure, and tighten the locknuts to the specified torque.




Tightening torque:

9.9–15.6 N·m {100–160 kgf·cm, 86.8–138 in·lbf}

- (2) Apply 66.7kpa {500 mmHg, 19.7 inHg} vacuum by using a vacuum pump.
- (3) Measure the depth L of the gauge rod.

Depth: 35.3–35.5 mm {1.390–1.397 in}

- (4) If it not specified, use the **SSTs** to adjust the push rod to the proper length.
- (5) Verify depth L of the gauge rod.




3. (1) Install the new retainer and the seal and plate assembly by using the **SST**.
- (2) Apply specified grease supplied in the repair kit to the seal plate assembly.

4. When installing the master cylinder into the power brake unit, be sure to align it correctly, fitting the master cylinder squarely into the power brake unit seal. Do not roll the lip of the power brake unit seal.

5. After tightening the brake pipe:

- (1) Add brake fluid and bleed the air. (Refer to page P-7.)
- (2) Check the brake lines for fluid leakage. (Refer to page P-9.)



Inspection

Fluid level sensor


1. Disconnect the sensor connector.
2. Connect an ohmmeter to the connector.
3. Starting with the fluid level above MIN mark on the reservoir, verify that there is no continuity.
4. Remove the brake fluid and verify continuity when the level is below the MIN mark.
5. Replace the sensor if necessary.

Disassembly / Assembly / Inspection

1. After removing the brake fluid, disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.


Caution

- The brake master cylinder is made of aluminum, and can be easily damaged by tightening in a vise. When securing the master cylinder in a vise, tighten only the front ports of the cylinder body.



1. Cap
2. Tank filter
3. Fluid level sensor
4. Tank retainer
Assembly Note page P-24
5. Reservoir tank
Inspect for damage and deformation page P-24


6. Grommet
Assembly Note page P-24
7. Piston assembly
Disassembly Note below
Assembly Note page P-23
8. Master cylinder body
Inspect for abnormal wear, rust and damage



Disassembly Note


Piston Assembly

Loosen the cap by using the **SST**, remove the primary piston assembly out of the cylinder.




Assembly Note Piston assembly


1. Before assembly, clean the cylinder body inner surface and a new piston assembly by using brake fluid.
2. Install the secondary spring assembly into the cylinder body with the larger diameter facing the cylinder body.




3. Apply specified grease supplied in the repair kit to the cup of the secondary piston assembly.
4. Install the secondary piston assembly into the cylinder body with the hole on the piston assembly facing the cylinder body.



5. Using the old sleeve of the primary piston assembly, push the secondary piston assembly to the cylinder body.




6. Apply specified grease supplied in the repair kit to the cup of the primary piston assembly.
7. Install the primary piston assembly into the cylinder body.



8. Tighten the cap by using the **SST**.

Tightening torque:


11.8–15.6 N·m {120–160 kgf·m, 105–138 in·lbf}



9. Measure clearance between the cylinder body flange and the cap.


Clearance: 14.4 mm {0.567 in} max.

10. If the clearance is greater than specified, disassemble and reassemble the master cylinder.




Grommet, reserve tank, tank retainer


1. Install the new grommet to the reserve tank.



2. Install the reserve tank to the cylinder.



3. Install the tank retainer while pushing the reserve tank to the cylinder body.



Inspection


Master cylinder assembly

1. Set the **SST** as shown in the figure, tighten the nut to the specified torque.






Tightening torque:

9.9–15.6 N·m {100–160 kgf·cm, 87–138 in·lb}

2. Turn the adjusting bolt until gap A is **21 mm {0.83 in}**.



3. Install a radiator cap tester and the **SSTs** to the front port on the master cylinder. Apply air into the master cylinder and verify that the air pressure is not built.
4. Tighten the adjustment bolt on the **SST** until the gap A' becomes **11 mm {0.433 in}**. Raise the air pressure **49.05 kPa {0.5 kgf/cm², 7.11 psi}** and verify that the pressure is held for more than 5 seconds.
5. Check for the rear port on the master cylinder by using same procedure.

**POWER BRAKE UNIT****Quick inspection (on-vehicle)****Power brake unit function Check****(Simple method)****Step 1**

1. With the engine stopped, depress the pedal a few times.
2. With the pedal depressed, start the engine.
3. If immediately after the engine starts the pedal moves down slightly, the unit is operating.

Step 2

1. Start the engine.
2. Stop the engine after it has run for **1 or 2 minutes**.
3. Depress the pedal with the usual force.
4. If the first pedal stroke is long and becomes shorter with subsequent strokes, the unit is operating.
5. If a problem is found, inspect for damage of the check valve or vacuum hose and examine the installation. Repair if necessary, and inspect it once again.

Step 3

1. Start the engine.
2. Depress the pedal with the usual force.
3. Stop the engine with the pedal held depressed.
4. Hold the pedal down for **about 30 seconds**.
5. If the pedal height does not change, the unit is operating.
6. If there is a problem, check for damage to the check valve or vacuum hose, and check the connection. Repair if necessary and check once again.


If the nature of the problem is still not clear after the 3 steps above, follow the more detailed check described in "Method-using tester," below.

(Inspection using gauges)

Connect the **SST** gauges, vacuum gauge **A**, and pedal depression force gauge **B** as shown. Bleed the air from the **SST** gauges before performing the following tests.


a) Checking for vacuum loss**Unloaded condition**

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3–66.7 kPa {475–500 mmHg, 18.7–19.7 inHg}**, the unit is operating.



Loaded condition


1. Start the engine.
2. Depress the brake pedal with a force of **196 N {20 kgf, 44 lbf}**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **66.7 kPa {500 mmHg, 19.7 inHg}**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3–66.7 kPa {475–500 mmHg, 18.7–19.7 inHg}**, the unit is operating.



b) Checking for hydraulic pressure


1. Depress the brake pedal with the engine stopped (Vacuum **0 kPa {0 mmHg, 0 inHg}**). If the fluid pressure is within specification, the unit is operating.

| Pedal force | Fluid pressure |
|---------------------------|--|
| 196 N {20 kgf, 44 lbf} | B6 DOHC . . 588 kPa {6 kgf/cm ² , 86 psi} min |
| | K8 DOHC . . 393 kPa {4 kgf/cm ² , 57 psi} min |




2. Start the engine. Depress the brake pedal when the vacuum reaches **66.7 kPa {500 mmHg, 19.7 inHg}**. If the fluid pressure is within specification, the unit is operating.

| Pedal force | Fluid pressure |
|---------------------------|--|
| 196 N {20 kgf, 44 lbf} | B6 DOHC (MTX)...6081 kPa {62 kgf/cm ² , 882 psi} min |
| | B6 DOHC (ATX)...6767 kPa {69 kgf/cm ² , 982 psi} min |
| | K8 DOHC 7061 kPa {72 kgf/cm ² , 1024 psi} min |



Check Valve Inspection


1. Remove the clamps and the vacuum hose.



2. Apply both suction and pressure to the engine-side of the hose, and verify that air flows only toward that side. If air flows in both directions or not at all, replace the vacuum hose.

Removal / Installation (B6 DOHC)


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.





- | | |
|-----------------------------------|--------------------------------|
| 1. Connector | 5. Spring clip and clevis pin |
| 2. Brake pipe | 6. Nut |
| Removal Note page P-11 | 7. Fork |
| Installation Note page P-11 | 8. Nut |
| 3. Master cylinder assembly | 9. Power brake unit |
| Installation Note page P-12 | 10. Gasket, spacer (ATX model) |
| 4. Vacuum hose | 11. Gasket |

Removal / Installation (K8 DOHC)

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. Take the following steps after installation:
 - Add fluid and bleed the air. (Refer to page P-7.)
 - Check all parts for fluid leakage. (Refer to page P-9.)
 - Adjust and check the brake pedal. (Refer to page P-9.)
 - Make an on-vehicle check of the unit. (Refer to page P-26.)



- | | |
|---|---|
| <p>1. Connector</p> <p>2. Vacuum hose</p> <p>3. Hose (MTX)</p> <p>4. Brake pipe</p> <p>5. Master cylinder assembly Installation Note page P-20</p> <p>6. Gasket</p> <p>7. Retainer Removal Note page P-20 Installation Note page P-20</p> | <p>8. Seal and plate assembly Removal Note page P-20 Installation Note page P-20</p> <p>9. Spring clip and clevis pin</p> <p>10. Nut</p> <p>11. Fork</p> <p>12. Nut</p> <p>13. Power brake unit</p> <p>14. Gasket</p> |
|---|---|



DUAL PROPORTIONING VALVE

Inspection

1. Connect the **SSTs** to the brake pipes with adapters as shown in the figure.

Adapter and flare nut tightening torque:

12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lbf}

Note

- Connect the brake pipes with **SST** (49 0259 770B)

2. Bleed the air from the brake system. (Refer to page P-7.)
3. Depress the brake pedal until the master cylinder pressure equals A; then record rear brake pressure A'.
4. Depress the brake pedal again, apply additional pressure until the pressure equals B; then record pressure B'.


Fluid pressure

kPa {kgf/cm², psi}

| | A | A' | B | B' |
|-------------------|----------------|----------------------------|----------------|----------------------------|
| ABS | 2,453 {25,356} | 2,453 {25,356} ±196 {2,28} | 5,886 {60,853} | 3,826 {39,555} ±333 {3,43} |
| K8 DOHC (non ABS) | 2,453 {25,356} | 2,453 {25,356} ±196 {2,28} | 5,886 {60,853} | 3,138 {32,455} ±294 {3,43} |
| B6 DOHC (nonABS) | 2,943 {30,427} | 2,943 {30,427} ±196 {2,28} | 5,886 {60,853} | 3826 {39,555} ±284 {3,43} |


Replacement

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.
3. After installation, add brake fluid, bleed air, and check for fluid leakage.



1. Brake pipe
Removal / Installation Note page P-31

2. Bolt
3. Dual proportioning valve
Installation Note page P-31




Removal / Installation Note

Brake pipe

Loosen and tighten the brake pipe by using the SST.

Tightening torque:


12.8–21.5 N·m {130–220 kgf·cm, 113–190 in·lb}



Installation Note

Dual proportioning valve

Install the dual proportioning valve with R marks facing the right side.



FRONT BRAKE (DISC)

Quick inspection (on-vehicle)

Disc pad


1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheel and tires.
3. Verify the remaining thickness of the pads.

Thickness: 2.0 mm {0.08 in} min.

Replacement

Disc pad

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.




- | | |
|-------------|---------------------|
| 1. M-spring | 5. Anti-squeak shim |
| 2. W-pin | 6. Outer shim |
| 3. Pad pin | 7. Inner shim |
| 4. Disc pad | |

Installation Note below
 Inspection page P-32

Installation Note

Disc pad

When installing the disc pads, push the piston fully inward by using the **SST** and the old pad.




49 0221 600C

Removal / Installation


Caliper

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.
3. Take the following steps after installation:
 - Add fluid and bleed the air. (Refer to page P-7.)
 - Check for fluid leakage. (Refer to page P-9.)
 - Depress the brake pedal a few times and check that the rear brakes do not drag while rotating the wheel.



- 1. Flexible hose
- 2. Disc pad assembly
Inspection page P-34
- 3. Bolt

- 4. Caliper
Disassembly / Inspection /
Assembly page P-35
- 5. Guide plate
- 6. Disc plate
Inspection page P-34

**Inspection**

Check for the following and repair or replace parts as necessary.


Disc pad

1. Check for oil or grease on the facing, abnormal wear or cracks, and deterioration or damage from heat.
2. Measure the thickness of the lining.

Standard: 10.0 mm {0.39 in}

Minimum: 2.0 mm {0.08 in}

3. Check visually for damage or wear of the guide plate.

**Disc plate****Thickness**

1. measure the thickness of the disc plate.

Caution


- Runout will increase if the machining is performed off-vehicle.

Standard : 22.0 mm {0.8661 in}

Minimum : 20.0 mm {0.7874 in}

Minimum thickness after machining by using a brake lathe on-vehicle

: 20.8 mm {0.8189 in}

**Runout**


1. Verify that there is no wheel bearing looseness. (Refer to section M)
2. Measure the runout at the outer edge of the contact surface of the disc pad.

Runout: 0.05 mm {0.002 in} max.

CALIPER


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly.



1. Sleeve pin
2. Boot
3. Rubber cap and bleeder screw below
4. Retaining ring
5. Dust seal
6. Piston
Disassembly Note page P-36
Inspect or damage, wear and rust


7. Piston seal
Disassembly Note page P-36
8. Caliper body
Inspect for damage, wear and rust




Disassembly Note

Rubber cap and bleeder screw


Remove the rubber cap and remove the bleeder screw from the brake caliper by using the **SST**.

**Piston**

1. Place a piece of wood in the caliper.
2. Gently blow compressed air through the hole to force the piston out of the caliper.

**Piston seal**

Remove the piston seal from the brake caliper by using the **SST**.



REAR BRAKE (DISC)
Quick inspection (on-vehicle)
Disc pad

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Sight through the caliper inspection hole and verify the remaining thickness of the pads.


Thickness: 1.0 mm {0.04 in} min.

4. Replace the pads on the axle as a set if they are at or less than the minimum thickness.

Replacement


Disc pad

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



1. Bolt
2. Caliper assembly
Removal / Installation page P-38
3. V-spring

4. Disc pad
Removal Note below
Inspection page P-39
5. Shim
6. Guide plate



Removal Note

Disc pad


Install the piston with the **SST** by turning it clockwise until it stops.

49 FA18 602

Removal / Installation


Caliper

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheel and tires.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Perform the following after installation:
 - Add brake fluid and bleed the air. (Refer to page P-7.)
 - Check for fluid leakage. (Refer to page P-9.)
 - Depress the brake pedal and operate the parking brake a few times and check that the rear brakes do not drag excessively while rotating the wheels by hand.



- 1. Parking cable
Removal / Inspection /
Installation page P-47
- 2. Connector and gasket
- 3. Flexible hose
- 4. Bolt
- 5. Disc pad assembly

- 6. Caliper assembly
Disassembly / Inspection /
Assembly page P-42
- 7. Bolt
- 8. Mounting support
- 9. Disc plate
Inspection page P-41




Inspection

Check for the following and repair or replace parts as necessary.

Disc pad assembly

1. Oil or grease on facing
2. Abnormal wear or cracks
3. Deterioration or damage by heat
4. Remaining lining thickness

Standard: 7.5 mm {0.30 in}
Minimum: 1.0 mm {0.04 in}



Disc plate

Disc plate thickness


Measure the thickness of the disc plate.

Caution

- Runout will increase if the machining is performed off-vehicle.

Standard : 9.0 mm {0.3543 in}
Minimum : 8.0 mm {0.315 in}

Minimum thickness after machining by using a brake lathe on-vehicle
 : 8.4 mm {0.331 in}



Disc plate runout


1. Verify that there is no wheel bearing looseness. (Refer to section M.)
2. Measure the runout at the outer edge of the contact surface of the disc pad.

Runout: 0.05 mm {0.002 in} max.

CALIPER


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



N·m (kgf·m, ft·lbf)


- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Guide pin Inspect for damage and wear 2. Pin boot 3. Bushing 4. Retaining ring 5. Dust seal 6. Piston Disassembly Note below Inspect for damage, wear and corrosion Assembly Note page P-41 7. Piston seal Disassembly Note page P-41 8. Snap ring 9. Spring case 10. Spring 11. Washer | <ol style="list-style-type: none"> 12. Stopper 13. Adjuster spindle Inspect for damage and wear 14. O-ring 15. Connecting link Inspect for damage and wear 16. Spring 17. Nut 18. Operating lever 19. Boot 20. Needle bearing Disassembly Note page P-41 Assembly Note page P-41 21. Rubber cap and bleeder screw 22. Mounting support 23. Caliper body Inspect for damage, wear and corrosion. |
|--|---|



Disassembly Note


Piston

Remove the piston by turning the **SST** counterclockwise.




Piston seal

Remove the piston seal with the **SST**.



Needle bearing


1. Secure the caliper in a vise.
2. Remove the needle bearing from the caliper with the **SST**.



Assembly Note


Needle bearing

Press the needle bearing into the caliper with the **SST** until the **SST** bottoms against the caliper.



Piston

1. Clean the piston.
2. Install a new dust seal in the piston groove.
3. Turn the piston into the caliper by rotating the **SST** clockwise until it stops.



REAR BRAKE (DRUM)

Quick Inspection (On-vehicle)

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the plug as shown in the figure, then inspect the thickness of the brake lining through the inspection hole.

Thickness:


Standard : 4.0 mm {0.16 in}

Minimum : 1.0 mm {0.04 in}

3. Replace if below the limit.


Removal / Inspection / Installation

1. Remove the lining in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



- 1. Screw
- 2. Brake drum
Removal Note page P-43
Inspection page P-43
Installation Note page P-43
- 3. Return spring
- 4. Hold pin and spring
- 5. Anti-rattle spring
- 6. Brake shoe (leading side)
Inspection Above
- 7. Brake shoe (trailing side)
Inspection Above
- 8. Stopper spring and clip
- 9. Return spring
- 10. Parking brake cable


- 11. Operating lever assembly
- 12. Brake pipe
Removal Note page P-43
- 13. Bolt
- 14. Wheel cylinder assembly
Disassembly / Inspection /
Assembly page P-44
- 15. Wheel cylinder gasket
- 16. Dust boot
- 17. Hub cap
- 18. Locknut
- 19. Wheel hub assembly
- 20. Bolt
- 21. Backing plate



Removal Note

Brake drum

If the brake drum is hard to remove, secure the stopper until the operating lever returns to release the sticking of the brake drum.




Brake pipe

Disconnect or connect the brake pipe from/to the wheel cylinder by using the SST.

Tightening torque:

16–21 N·m {1.6–2.2 kgf·m, 12–15 ft·lb}



Inspection

Check for the following and repair or replace as necessary.


Brake drum

1. Drum inner diameter

Standard diameter : 200.0 mm {7.874 in}

Diameter limit : 201.0 mm {7.913 in}


2. Scratches, uneven or abnormal wear inside drum.



Installation Note


Grease points

- (1) Piston of wheel cylinder
- (2) Anchor sliding parts
- (3) Projection of backing plate
- (4) Adjusting screw
- (5) Adjusting sleeve contact surfaces



Brake drum

1. Before installing the brake drum, depress the brake pedal to verify operation of the automatic adjuster.
2. Install the brake drum.




3. Take the following steps after installation:

- Add fluid and bleed the air. (Refer to page P-7.)
- Check for fluid leakage. (Refer to page P-9.)
- Depress the brake pedal a few times; then verify that the rear brakes do not drag while rotating the wheel.
- Check the parking brake lever stroke. (Refer to page P-45.)

WHEEL CYLINDER

Disassembly / Inspection / Assembly

1. Disassemble the wheel cylinder in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary. If a problem is found in wheel cylinder body or piston replace the wheel cylinder as an assembly.
3. Assemble in the reverse order of disassembly.



N·m (kgf·cm, in·lb)

1. Dust boot
2. Piston
Inspect for corrosion and damage
3. Piston cup
4. Spring

5. Rubber cup and bleeder screw
Inspect for corrosion and damage
6. Steel ball
7. Wheel cylinder body

PARKING BRAKE SYSTEM

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Remedy | Page |
|----------------------------------|--|---|---------------------------|
| Brakes do not release | Improper return of parking brake cable or improper adjustment | Repair or adjust | P-46 |
| Parking brake does not hold well | Excessive lever stroke Brake cable stuck or damaged Brake fluid or oil on pad or lining Hardening of pad / lining surface or poor contact | Adjust Repair or replace Clean or replace Grind or replace | P-45 P-46 — P-42 |


PARKING BRAKE SHOE

Removal / Inspection / Installation

Drum brake

Removal and Installation (Refer to page P-42)

Inspection (Refer to page P-43)




PARKING BRAKE (LEVER TYPE)

Inspection

Check the stroke is within specification when parking brake lever is pulled with a force of 98 N {10 kgf, 22 lbf}.

Stroke: 5-7 notches




Adjustment

1. Before adjustment, start the engine and depress the brake pedal several times while the vehicle is moving in reverse.
2. Stop the engine.
3. Remove the screw and the parking brake lever cover.
4. Remove the adjusting nut clip and turn the adjusting nut at the front of the parking cable.
5. After adjustment, check the following points:
 - (1) Turn the ignition switch ON, pull the parking brake lever one notch, and check that the parking brake warning light illuminates.
 - (2) Verify that the rear brakes do not drag.

PARKING BRAKE CABLE
Removal / Inspection / Installation

1. Remove the cable in the order shown in the figure.
2. Visually check each part, and replace it if necessary.
3. Install in the reverse order of removal.
4. Depress the brake pedal a few times and check the rear brakes do not drag while rotating the wheels.
5. Adjust the parking brake lever stroke.




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Rear console Removal / Installation Section S 2. Adjusting nut 3. Return spring 4. Front parking cable Inspect for damage and wear | <ol style="list-style-type: none"> 5. Nut (Disc brake type) 6. Bolts (Drum brake type) 7. Clip 8. Rear parking cable |
|--|--|

PARKING BRAKE LEVER

Removal / Inspection / Installation

1. Block the wheels firmly.
2. Release the parking brake.
3. Remove in the order shown in the figure.
4. Inspect all components and parts. Replace parts if necessary.
5. Install in the reverse order of removal. Install the parking brake switch so that it contacts the parking brake lever when the lever is fully released.
6. After installation: Adjust the parking lever stroke. (Refer to page P-45.)
7. Turn the ignition switch ON, and check that the parking brake warning light illuminates with the lever pulled one notch.



1. Rear console
Removal / Installation Section S
2. Adjusting nut
3. Bolt
4. Parking brake lever assembly
Inspect for damage and wear

5. Parking brake switch
6. Parking lever cap
7. Release button
8. Parking lever spring
9. Parking brake lever

ANTI-LOCK BRAKE SYSTEM (ABS)







DESCRIPTION

There is the following distinctive characteristics in the ABS vehicles compared with the non-ABS vehicles. Note that it does not indicate malfunction.

- When the brakes are applied rapidly or on a slippery road surface, the ABS will activate; the brake pedal will pulsate slightly and the vehicle and the steering wheel will vibrate slightly.

PREPARATION

SST

| | | | |
|--|--------------------------------------|--|--|
| 49 G025 001 ABS sensor rotor installer  | For installation of ABS sensor rotor | 49 0259 770B Wrench, flare nut  | For removal and installation of brake pipe |
| 49 H018 9A1 On-Board Diagnosis Checker  | For diagnosis | 49 B019 9A0 System Selector  | For diagnosis |
| 49 M005 796 Body  | For installation of ABS sensor rotor | 49 B025 003 Sensor rotor installer  | For installation of ABS sensor rotor |

TROUBLESHOOTING GUIDE

Precaution

Conditions that are not malfunctions

1. It may happen that vibration is felt in the steering wheel, body, and/or brake pedal when the ABS is functioning; such vibration is simply an indication that the system is functioning.
2. The ABS warning light may illuminate under any of the following conditions:
 - When the vehicle is traveling on snow or ice with the parking brake activated or a brake dragging at one wheel.
 - When different size tires are used.
 - When tires of different gripping performance are used.
 - When (while the vehicle is jacked up or stuck) the front wheels only are spun for 20 seconds or more.
 - When there is insufficient battery positive voltage.

Note:

- Under the above conditions, the warning light will not illuminate a second time when the ignition is switched OFF then back ON, and there will be no problem entry made to the ABS control module memory.

Troubleshooting notes

The ABS is composed of electrical components, mechanical components (ABS hydraulic unit), and the components of the standard brake system.

Fundamentally, malfunction of the ABS electrical or mechanical components is judged by the on-board diagnosis function within the ABS control module, and malfunctions are indicated by the warning light in the instrument panel. The location of a malfunction is indicated by the technician switching the system to the diagnosis-indication mode.



The on-board diagnosis and indication functions must be used when diagnosing malfunctions of the ABS.

WIRING DIAGRAM

Z WIRING DIAGRAM

0 ■ 4 WHEEL ANTILOCK BRAKE SYSTEM(4WABS)

© B... CANADA
 < >...RB 00MC



RELATIONSHIP CHART

| Input \ Output | ABS hydraulic unit | | ABS warning light | Data link connector |
|------------------------|--------------------|-----------|-------------------|---------------------|
| | Solenoid valve | ABS motor | | |
| ABS wheel-speed sensor | ○ | ○ | ○ | ○ |
| Brake switch | ○ | ○ | | |
| Fail-safe relay | ○ | | ○ | ○ |
| Motor relay | | ○ | ○ | ○ |



DIAGNOSTIC CHART

| Symptom | Cause | Input | | | | Output | | | ABS control module | |
|---|-------|------------------------|--------------|-----------------|-------------|----------------|-----------|-------------------|--------------------|---------------------|
| | | ABS wheel-speed sensor | Brake switch | ABS relay | | Hydraulic unit | | ABS warning light | | Data link connector |
| | | | | Fail-safe relay | Motor relay | Solenoid valve | ABS motor | | | |
| 1 ABS warning light not illuminated when ignition switch turned ON. | | | | | | | ○ | | | |
| 2 ABS warning light remains ON. | | ○ | ○ | ○ | ○ | ○ | ○ | | ○ | |
| 3 ABS warning light flashes. | | | | | | | | ○ | | |



DIAGNOSTIC INDEX

| No. | Troubleshooting Items | Remarks | Page |
|-----|---|---|------|
| 1 | ABS warning light not illuminated when ignition switch turned ON. | — | P-51 |
| 2 | Warning light remains ON. | Warning light remains ON and ABS does not operate | P-52 |
| 3 | ABS warning light flashes. | — | P-53 |

SYMPTOM TROUBLESHOOTING


| 1 | WARNING LIGHT NOT ILLUMINATED WHEN IGNITION SWITCH TURNED ON. | | |
|---|---|--------|---|
| DETAILED DESCRIPTION | | — | |
| Possible cause: <ul style="list-style-type: none"> • If other warning indicators do not illuminate, METER 15A fuse may be fused. • Failed indicator light or open in related wiring harness. | | | |
| STEP | INSPECTION | ACTION | |
| 1 | Is METER 15A fuse OK? ↔page P-63  | Yes | Go to next step |
| | | No | Replace METER 15A fuse |
| 2 | Are harness of ABS warning light normal? ↔page P-60  | Yes | Inspect ABS warning light ↔page P-60 |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ABS relay. • Inspect harness between instrument panel and ABS CM. • Inspect harness between instrument panel and ABS relay. • Inspect ABS warning light bulb. |

CM: CONTROL MODULE

| 2 | | WARNING LIGHT REMAINS ON. | |
|--|--|---|--|
| DETAILED DESCRIPTION | | Warning light remains ON and ABS does not operate | |
| Possible cause: <ul style="list-style-type: none"> • If ABS warning light only illuminates, activate diagnostic mode and check for diagnostic trouble code. • Malfunction of battery • Malfunction of ABS warning light harness (fail-safe relay) • Malfunction of ABS CM | | | |
| STEP | INSPECTION | ACTION | |
| 1 | With the SSTs (self diagnosis checker), verify that diagnostic trouble code is indicated. (Connect the SSTs to the data link connector) 49 B019 9A0 49 H018 9A1  | Yes | Read diagnostic trouble code ⇨ Inspect as indicated ⇨ page P-56 |
| | | No | Go to next step |
| 2 | Is battery voltage OK? ⇨ page P-60 | Yes | Go to next step |
| | | No | Charge or replace battery |
| 3 | Are ABS warning light harness normal? ⇨ page P-60  | Yes | Go to next step |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ABS relay. • Inspect harness between instrument panel and ABS CM. • Inspect harness between instrument panel and ABS relay. |
| 4 | Connect terminal 2J of ABS CM connector (18 pins) to a ground and check the following points (IG ON) <ul style="list-style-type: none"> • Operation sound of relay is heard. • ABS warning light is not illuminated. • 1D terminal of ABS CM connector indicates 12V. | Yes | Go to next step |
| | | No | <ul style="list-style-type: none"> • Inspect ABS relay (fail-safe relay) • Inspect harness between ABS relay (fail-safe relay) and ABS CM, battery • Inspect harness between ABS relay (fail-safe relay) and HU |

CM: CONTROL MODULE

| STEP | INSPECTION | | ACTION |
|------|---|-----|---|
| 5 | Is voltage at terminals 1 E, 1F and 1 H of ABS CM connector (12 pins) and terminals 2B and 2L of ABS CM connector (18 pins) as specified? page P-64 | Yes | Replace ABS CM |
| | | No | <ul style="list-style-type: none"> • Inspect harness between ABS CM and ground • Inspect harness between ignition switch and ABS CM • Inspect harness between data link connector and ABS CM • Inspect harness between ABS warning light and ABS CM |

| 3 | ABS WARNING LIGHT FLASHES. | | |
|--|---|-----|---|
| DETAILED DESCRIPTION | | — | |
| Possible cause: <ul style="list-style-type: none"> • Data link connector terminal TBS grounded | | | |
| STEP | INSPECTION | | ACTION |
| 1 | Verify that there is no continuity between terminal TBS and ground  | Yes | Inspect ABS CM |
| | | No | Repair short between terminals TBS and ground |


CM: CONTROL MODULE

ON-BOARD DIAGNOSIS FUNCTION

Inspection By Diagnostic Mode


Outline

The ABS control module contains on-board diagnosis and memory functions to watch for and indicate present and past failures. Read and note the diagnostic indications using the **SSTs** then take action according to the diagnostic trouble code table. (Refer to page P-56.)




Inspection procedure

1. Connect the **SSTs** to the data link connector and a ground.
2. Set the select switch to position A.



3. Set the system selector to position 3 and SELF TEST as shown.




4. Turn the ignition switch ON.
5. Verify that **88** flashes on the digital display and the buzzer sounds for **3 sec.** after turning the ignition switch ON.
6. If **88** does not flash, check power supply circuit, and ground wiring.
7. If **88** flashes and the buzzer continues for more than **20 sec.**, check for a short circuit between terminal TBS and ground. Replace ABS control module if necessary and perform steps 3 and 4 again.
8. Note any code numbers and check for the causes by referring to the check sequences shown on pages P-57 to P-59. Repair as necessary.
9. After repairs, cancel the code numbers by performing "Memory Cansel." (Refer to page P-56.)

Principle of Code Cycle

Diagnostic trouble codes are determined as shown below.


1. Code cycle break

The time between diagnostic trouble code cycles is 4.0 seconds (the time the buzzer is off).



2. Second digit of diagnostic trouble code (ones position)


The digit in the ones position of the diagnostic trouble code represents the number of times the buzzer sounds 0.4 second during one cycle.



3. First digit of diagnostic trouble code (tens position)

The digit in the tens position of the diagnostic trouble code represents the number of times the buzzer is on 1.2 seconds during one cycle.

It should also be noted that the light goes off for 1.6 seconds between the long and short pulses of the buzzer.



Memory Cancel

Diagnostic trouble codes memorized in the ABS control module are canceled by performing the following steps.










1. Connect the TBS terminal to GND at the data link connector.
2. Turn the ignition switch ON.
3. Output all memorized codes.
4. After verifying that the first code is repeated, depress the brake pedal 10 times at intervals of less than **one second (1 sec.)**.

Note

Diagnostic trouble codes will not be canceled if:
 intervals of depressing the brake pedal exceed **one second (1 sec.)**.
 Brake switch has failed.

- While performing the memory cancel operation, the ABS warning light will illuminate.
- After memory cancel, the ABS control module will perform on-board diagnosis.

Diagnostic Trouble Code Table

| Code No. | Possible cause | Pattern of output signal (On-Board Diagnosis Checker) | Diagnosis chart No. |
|----------|--|--|---------------------|
| 11 | Right front ABS wheel-speed sensor Right front ABS sensor rotor |  | ABS-1 |
| 12 | Left front ABS wheel-speed sensor Left front ABS sensor rotor |  | |
| 13 | Right rear ABS wheel-speed sensor Right rear ABS sensor rotor |  | |
| 14 | Left rear ABS wheel-speed sensor Left rear ABS sensor rotor |  | |
| 15* | ABS wheel-speed sensor |  | ABS-2 |
| 22 | Right front solenoid valve |  | ABS-3 |
| 24 | Left front solenoid valve |  | |
| 26 | Right rear solenoid valve |  | |
| 28 | Left rear solenoid valve |  | |

*If the ignition switch is turned OFF and then ON again, and the vehicle is then accelerated to higher than **10km/h {6.2MPH}**, diagnostic trouble code 15 will be replaced by a code from 11 through 14.

| | | | |
|----|----------------------|--|-------|
| 51 | Fail-safe relay | | ABS-4 |
| 53 | Motor Motor relay | | ABS-5 |
| 61 | ABS control module | | ABS-6 |

Diagnosis Chart

| | | | |
|--------------|--|--|-----------------|
| ABS-1 | Diagnostic trouble code: 11-14 | | |
| | Possible failure: ABS wheel-speed sensor, harness, sensor rotor, hydraulic pressure 11: Right front 12: Left front 13: Right rear 14: Left rear | | |
| Step | Check item | Remark | Refer to |
| 1 | Check ABS control module connector | Check for poor connection | — |
| 2 | Check wiring harness between control module and ABS wheel-speed sensor | Check for open or short to ground | — |
| 3 | Check ABS wheel-speed sensor | — | P-68 |
| 4 | Check ABS sensor rotor | — | P-68 |
| 5 | Check brake switch | — | P-61 |
| 6 | Check hydraulic system | If a problem is found, replace hydraulic unit or repair hydraulic system piping as necessary | P-69 |
| 7 | If all above are OK after diagnostic trouble code(s) is erased, recheck for diagnostic code after driving from vehicle stop to over 10 km/h {6.2 mph} | If code of 11-14 is obtained, replace ABS control module | P-71 |
| 8 | If all above are OK, there was temporary poor contact in wiring and now ABS system is functioning | | |

| | | | |
|--------------|--|---|-----------------|
| ABS-2 | Diagnostic trouble code: 15 | | |
| | Possible failure: Wheel-speed sensor, harness | | |
| Step | Check item | Remark | Refer to |
| 1 | If all the malfunction are OK after diagnostic trouble code is erased, recheck for diagnostic trouble code after driving from vehicle stop to over 10 km/h {6.2 mph} | If code of 11-14 is obtained, go to ABS-1 | Above |
| | | If code 15 is obtained, replace ABS control module | P-71 |
| | | If nothing is displayed, there was a temporary poor contact in wiring and now ABS is OK | — |


| | | | |
|--------------|--|---|-----------------|
| ABS-3 | Diagnostic trouble code: 22, 24, 26, 28 | | |
| | Possible failure: Solenoid valve, harness | | |
| Step | Check item | Remark | Refer to |
| 1 | Check ABS control module connector | Check for poor connection | — |
| 2 | Check wiring harness between hydraulic unit and ABS control module | Check for open or short to ground | — |
| 3 | Check ABS hydraulic unit solenoid valve | Check for open circuit | P-63 |
| 4 | Check ABS warning light operation | If warning illuminates constantly after turning ignition switch ON, replace ABS control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was a temporary poor contact in wiring and now ABS system is functioning | |

| | | | |
|--------------|---|---|-----------------|
| ABS-4 | Diagnostic trouble code: 51 | | |
| | Possible failure: Fail-safe relay | | |
| Step | Check item | Remark | Refer to |
| 1 | Check pump fuse | Check pump fuse condition | P-63 |
| | | Check short to ground | — |
| 2 | Check relay box | Check for open circuit | P-72 |
| 3 | Check wiring harness between relay box and hydraulic unit or control module | Check for open or short to ground | — |
| 4 | Check ABS warning light operation | If warning light illuminates constantly after turning ignition switch ON, replace ABS control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was a temporary poor contact in wiring and now ABS system is functioning | |

| | | | |
|--------------|--|---|-----------------|
| ABS-5 | Diagnostic trouble code: 53 | | |
| | Possible failure: Motor, motor relay | | |
| Step | Check item | Remark | Refer to |
| 1 | Check ABS motor relay | If pump motor continues operating after turning ignition switch OFF, motor relay may be faulty | P-73 |
| 2 | Check ABS pump fuse | Check ABS pump fuse condition | P-63 |
| | | Check short to ground | — |
| 3 | Check wiring harness between ABS relay and hydraulic unit and ABS control module | Check for open or short to ground | — |
| 4 | Check voltage at ABS control module terminal | Turn ignition switch ON and check motor relay terminal voltage | P-65 |
| 5 | Check ABS motor | Check for open circuit | P-62 |
| 6 | Check wiring harness between ABS motor and ground | Check for open circuit | — |
| 7 | Check wiring harness between ABS motor and ABS control module | Check for open or short to ground | — |
| 8 | Check ABS warning light operation | If warning illuminates constantly after turning ignition switch ON, replace control module | — |
| | | If warning light does not illuminate after turning ignition switch ON, there was a temporary poor contact in wiring and now ABS system is functioning | |

| | | | |
|--------------|---|----------------------------|-----------------|
| ABS-6 | Diagnostic trouble code: 61 | | |
| | Possible failure: ABS control module | | |
| Step | Check item | Remark | Refer to |
| 1 | — | Replace ABS control module | P-71 |

Inspection of ABS system



Check battery


Note

- If the battery positive voltage is low, the ABS warning light may illuminate.

1. Start the engine.
2. Check the voltage at the battery and at the ABS control module terminal 1H.


Voltage: 10V min.

3. If the battery positive voltage is below specification, charge or replace the battery as necessary.
4. If the battery positive voltage is within specification and terminal 1H voltage is below specification, check the wiring harness between the battery and the ABS control module terminal 1H.




Check ABS warning light harness

1. Turn the ignition switch OFF, and disconnect the ABS control module connector (18 pins).
2. Turn the ignition switch ON. If the warning light is ON, go to next step. If the warning light is OFF, check ABS relay and the harness. (Warning light-ABS relay (h), ABS relay (b)-Ground)



3. Disconnect the ABS relay connector.
4. If the warning light harness remains illuminated, check the warning light harness for short to ground.




Check ABS warning light bulb

1. Remove the meter assembly.
2. Remove the warning light bulb from the rear of the cluster.
3. Check the condition of the bulb.
4. Replace the bulb if necessary.


Check brake switch


1. Depress the brake pedal.
2. Verify that the brake lights illuminate.
3. If not illuminated, check the following:
 - Brake light bulb
 - Brake light fuse
 - Brake switch
 - Brake switch harness
 - Brake light harness
4. Repair or replace parts as necessary.



Check brake switch harness at ABS control module

1. Turn the ignition switch OFF.
2. Disconnect the ABS control module connector (12 pins).
3. Turn the ignition switch ON.
4. Check for voltage between terminal 1M at the vehicle side harness and ground. (Refer to page 64.)
5. If not as specified, check wiring harness between the brake switch and the ABS control module.







Check motor harness at ABS control module

1. Turn the ignition switch OFF, and disconnect the ABS control module connector (12 pin).
2. Measure the resistance between 1 L terminal of the ABS control module connector and a ground.

Resistance: 1Ω max.

3. If not as specified, check the wiring harness between the ABS motor and the ABS control module and check the motor.




Check motor at ABS hydraulic unit

1. Turn the ignition switch OFF.
2. Disconnect the ABS hydraulic unit connector (2 pin).
3. Measure the resistance between the connector terminals.

Resistance: 1Ω max.

4. Verify that the motor operates when applying 12V to connector (2 pin).
5. If not as specified, replace the ABS hydraulic unit.




Check solenoid valve harness of ABS control module


1. Turn the ignition switch OFF.
2. Measure the resistance between a ground and the following terminals at the ABS control module connector (12 pin).

Terminal: 1A, Right rear
 1B, Left front
 1C, Right front
 1D, Left rear

Resistance: Approx. 3Ω

3. If not as specified, check the wiring harness between the hydraulic unit connector (8 pin) and the ABS control module.





Check solenoid valve at ABS hydraulic unit

1. Disconnect the ABS hydraulic unit connector (6 pin).
2. Measure the resistance between following terminals.
4f-4a, 4b
4e-4c, 4d


Resistance: approx. 3Ω

3. If not as specified, check the ABS hydraulic unit wiring harness or replace the ABS hydraulic unit if necessary.


Check fuse

Check the fuses according to the following table. If a fuse is burned, replace it.

| Fuse name | Rating (Amp) | Location | Failure condition | Refer to |
|-----------|--------------|-------------------------------|--|----------|
| ABS PUMP | 60 | Main fuse box | <ul style="list-style-type: none"> • ABS warning light illuminates (Diagnostic trouble code 51 or 53) • ABS motor and solenoid valves do not operate | P-58, 59 |
| MAIN | 100 | | <ul style="list-style-type: none"> • Engine does not start | — |
| ABS | 10 | Fuse panel (at driver's side) | <ul style="list-style-type: none"> • ABS warning light illuminates after engine started • ABS control module not activated | — |
| STOP | 20 | | <ul style="list-style-type: none"> • Brake light does not illuminate | — |
| METER | 15 | | <ul style="list-style-type: none"> • ABS warning light does not illuminate | — |




Check ABS control module



B+: Battery Positive Voltage

| Connector | Terminal | Connected to | Condition | Voltage (v) | Remark |
|-----------|--------------|----------------------------|---------------------|-------------|---|
| 12 pins | 1A | Right rear wheel solenoid | Solenoid ON* | 0-2 | * Solenoid is ON only when ABS system is functioning. Voltage when solenoid is ON can be measured following "Hydraulic System Test". (Refer to P-69.) |
| | | | Ignition switch ON | B+ | |
| | 1B | Left front wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1C | Right front wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1D | Left rear wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1E | Ground | Constant | 0 | |
| | 1F | Ground | Constant | 0 | |
| | 1H | Battery | Ignition switch ON | B+ | |
| | | | Ignition switch OFF | 0 | |
| | 1J | Not used | — | — | |
| | 1K | Not used | — | — | |
| 1L | ABS motor | ABS motor running | B+ | | |
| | | ABS motor stopped | 0-1 | | |
| 1M | Brake switch | Brake pedal depressed | B+ | | |
| | | Brake pedal released | 0-2 | | |
| 1N | Not used | — | — | | |


| Connector | Terminal | Connected to | Condition | Voltage (v) | Remark | |
|-----------|------------|------------------------|--------------------------------------|--------------------------------------|--|--|
| 18 pins | 2A | FBS check terminal | Ignition switch ON | 0 | | |
| | 2B | TBS check terminal | Normal mode | B+ | | |
| | | | Diagnostic mode | 0 | | |
| | 2C | Not used | — | — | | |
| | 2D | Not used | — | — | | |
| | 2E | Not used | — | — | | |
| | 2F | Not used | — | — | | |
| | | | Engine idling | B+ | | |
| | 2H | Motor relay | Motor relay ON | 0-2 | | |
| | | | Motor relay OFF | B+ | | |
| | 2J | Fail-safe relay | Normal | 0-2 | | |
| | | | If malfunction present | B+ | | |
| | 2L | Warning light | Illuminated | 0-3 | | |
| | | | Not illuminated | B+ | | |
| | 2M | ABS wheel-speed sensor | Right front | Vehicle stopped | 0 | <ul style="list-style-type: none"> • Turn wheel at specified speed to prevent incorrect diagnosis • Check following terminals of ABS wheel-speed sensor in AC range: 2N-2M (right front) 2O-2P (left front) 2R-2Q (left rear) 2S-2T (right rear) |
| | 2N | | | Wheel turned 1 revolution per second | 0.25-1.2 | |
| | 2O | | Left front | Vehicle stopped | 0 | |
| | 2P | | | Wheel turned 1 revolution per second | 0.25-1.2 | |
| 2Q | Left rear | | Vehicle stopped | 0 | | |
| 2R | | | Wheel turned 1 revolution per second | 0.25-1.2 | | |
| 2S | Right rear | | Vehicle stopped | 0 | | |
| 2T | | | Wheel turned 1 revolution per second | 0.25-1.2 | | |
| | | | | | <ul style="list-style-type: none"> • In DC range, ABS wheel-speed sensor voltage will be approx. 1.0V (with ignition switch ON) | |



Check ABS relay harness (fail-safe relay)

1. Turn the ignition switch OFF and disconnect the ABS control module connector (18 pin).
2. Turn the ignition switch ON.
3. Connect terminal 2J of the ABS control module connector (18 pin) to a ground.
4. Check the following points.

| Condition | Action |
|--|---|
| Fail-safe relay in ABS relay does not click when 2J terminal grounded | <ul style="list-style-type: none"> • Check fail-safe relay • Check harness between fail-safe relay and ABS control module |
| Warning light illuminates after grounding 2J terminal | <ul style="list-style-type: none"> • Check fail-safe relay |
| 1D (BR) terminal of ABS control module connector does not indicate 12V | <ul style="list-style-type: none"> • Check fail-safe relay • Check harness between fail-safe relay and ABS hydraulic unit |



Check ABS relay (fail-safe relay)

1. Measure resistance between terminals (c) and (d) of ABS relay connector.


Resistance: 60–100Ω



2. Check continuity between terminals (a) and (e) and between (b) and (e).

| Terminal | Continuity |
|----------|------------|
| a-e | Yes |
| b-e | No |

3. Apply 12V to terminals between d and c. Check for continuity between terminals (b) and (e) and between (a) and (e).

| Terminal | Continuity |
|----------|------------|
| b-e | Yes |
| a-e | No |





Check ABS relay harness (motor relay)


1. Inspect the fail-safe relay.
2. Turn the ignition switch OFF and disconnect the ABS control module connector (18 pin).
3. Turn the ignition switch ON.
4. Connect terminal 2J to a ground.
5. Connect terminal 2H to a ground.
6. Check the following points:

| Condition | Action |
|---|--|
| Motor relay in ABS relay does not click when terminals grounded | <ul style="list-style-type: none"> • Check harness between motor relay and ABS control module • Check motor relay |
| ABS motor does not operate | <ul style="list-style-type: none"> • Check motor relay • Check harness between motor relay and ABS motor • Check fuse |

Caution

- Allowing the motor to operate for more than two seconds will damage the ABS motor.

7. If not as specified, replace the ABS relay.



Check ABS relay (motor relay)

1. Measure the resistance between terminals (e) and (h) or between (a) and (h) of ABS relay box connector.

Resistance: 50–90Ω




2. Check continuity between terminals (b) and (f).

| Terminal | Continuity |
|----------|------------|
| b-f | No |

3. Apply 12V to terminals (g) (+) and (h) (-).
Check for continuity between terminals (b) and (f).

| Terminal | Continuity |
|----------|------------|
| b-f | Yes |

4. If not as specified, replace the ABS relay.



Check ABS wheel-speed sensor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the wheel and tire assembly.
3. Check for looseness and damage.

4. Check the clearance between the ABS wheel-speed sensor and the ABS sensor rotor.

Clearance: 0.3–1.1 mm (0.012–0.043 in)

5. If not as specified, replace the ABS wheel-speed sensor or ABS sensor rotor as needed.

Check resistance of ABS wheel-speed sensor

1. Disconnect the ABS wheel-speed sensor connector.
2. Check resistance at the ABS wheel-speed sensor.


Resistance: 1.6–2.0 k Ω

Check Voltage of ABS wheel-speed sensor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Disconnect the ABS wheel-speed sensor connector.
3. While rotating a wheel one revolution per second by hand, check for voltage at the ABS wheel-speed sensor terminal. Check each wheel.

Voltage: 0.25–1.2V (AC)

4. If not as specified, replace the ABS wheel-speed sensor or ABS sensor rotor as needed.
5. Cancel the ABS control module memory.







Check ABS sensor rotor

1. On level ground, jack up the vehicle and support it evenly on safety stands.
2. Remove the wheel and tire assembly.
3. Inspect for missing and damaging teeth.
4. Replace the ABS sensor rotor as necessary.

ABS HYDRAULIC UNIT

The ABS control module contains a self-diagnostic function to check the hydraulic system operation. During the diagnostic mode, the ABS control module activates the ABS hydraulic unit to reduce the hydraulic pressure of the right front, left front, right rear, left rear in sequence for **0.5 second** each at intervals of **1.5 seconds**.



Inspection


1. Verify that the battery is fully charged. Verify that the ABS warning light goes out after the engine is started.
2. If the light stays ON after the engine has started, the ABS control module detects a failure and will not activate the hydraulic unit.
3. Turn off the engine.
4. On level ground, jack up the vehicle and support it evenly on safety stands. Shift the transaxle to neutral or N range.
5. Release the parking brake.
6. Rotate the wheels by hand, and inspect for brake drag.
7. Using a jumper wire, connect the TBS and GND terminals of the data link connector.
8. Depress the brake pedal, and have an assistant verify that the right front wheel will not turn.
9. With the brake still depressed, turn the ignition switch ON and verify that the brake is released momentarily (**approx. 0.5 sec.**) and the wheel turns when pressure-reduction operates.
10. Check operation of the remaining wheels in order: left front, right rear, left rear.
11. If Steps 8,9 and 10 show correct operation, the following systems are OK:
 - Brake piping to ABS hydraulic unit
 - Braking system, including ABS hydraulic unit
 - Electrical system in ABS hydraulic unit (solenoid, motor, etc.)
 - ABS control module, its output system (solenoid, relay, etc.) and harness

The following are not checked with the above steps.

 - Input system and harness of ABS control module
 - Fluid leakage
 - Intermittent failure
12. Replace the ABS hydraulic unit if necessary.

Removal / Installation

1. Remove the nuts mounting the fuel filter and igniter to the bracket, and move them toward the engine.
2. Remove the hydraulic unit in order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add brake fluid, bleed the air, and check for fluid leakage.
5. Verify whether the diagnostic trouble code is canceled. (Refer to P-56.)




- 1. Battery
- 2. Air cleaner
- 3. Mount bushing
- 4. Connectors

- 5. Brake pipe
Removal / installation
Note below
- 6. ABS hydraulic unit assembly
- 7. Casing

- 8. Mount
- 9. Hex stud

N·m {kgf·m, ft·lbf}




Removal Note Brake pipes

Caution

- Brake fluid will damage painted surfaces. If it does get on a painted surface, wipe it off immediately.


Loosen the brake pipes by using the SST.



Installation Note

ABS hydraulic unit

1. Clamp the harness to point A of the bracket.
2. Install the band around point B of the bracket and the harness, and tighten the band until it contacts the bracket.
3. Cut off the rest of the band end so that the rest of band notches are less than seven.



Brake pipes

Tighten the brake pipe by using the **SST**.


Tightening torque:

13–22 N·m { 1.3–2.3 kgf·m, 10–16 ft·lbf }

ABS CONTROL MODULE

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove the passenger seat.
3. Roll back the carpet.
4. Remove in order shown in the figure.
5. Install in the reverse order of removal.
6. Connect the negative battery cable, verify whether the diagnostic trouble code is canceled. (Refer to page P-56.)



1. Bolt
2. Connector


3. ABS control module

N·m (kgf·cm, In·lbf)

ABS RELAY

Removal / Inspection / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.
4. Connect the negative battery cable, verify whether the diagnostic trouble code is canceled. (Refer to page P-56.)



N·m (kgf·cm, in·lbf)

1. Bolt
2. Connector

3. ABS relay
Inspection below



Inspection

ABS relay (Fail-safe relay)

1. Measure resistance between terminals (c) and (d) of the ABS relay connector.


Resistance: 60-100Ω

2. Check continuity between terminals (a) and (e) and between (b) and (e).

| Terminal | Continuity |
|----------|------------|
| a-e | Yes |
| b-e | No |

3. Apply 12V to terminals (d) and (c). Check for continuity between terminals (b) and (e) and between (a) and (e).

| Terminal | Continuity |
|----------|------------|
| b-e | Yes |
| a-e | No |



4. If not as specified, replace the ABS relay.

ABS relay (Motor relay)

1. Measure the resistance between terminals (e) and (h) or between (a) and (h) of the ABS relay connector.

Resistance: 50–90Ω

2. Check continuity between terminals (b) and (f).

| Terminal | Continuity |
|----------|------------|
| b-f | No |

3. Apply 12V to terminals (g) (+) and (h) (-).
Check for continuity between terminals (b) and (f).


| Terminal | Continuity |
|----------|------------|
| b-f | Yes |

4. if not as specified, replace the ABS relay.

ABS WHEEL-SPEED SENSOR (FRONT)


Removal / Inspection / Installation

1. Jack up the vehicle and support it on safety stands.
2. Remove the wheel and tire assembly.
3. Remove in the order shown in the figure.
4. Install in the reverse order of the removal.
5. Install the wheel and tire assembly.
6. Verify whether the diagnostic trouble code is canceled. (Refer to page P-56.)



1. Connector
2. Clip
3. Bolts

4. ABS wheel-speed sensor
Inspection below



Inspection

1. Check resistance at the ABS wheel-speed sensor terminals.


Resistance: 1.6–2.0 kΩ

2. If not as specified, replace the ABS wheel-speed sensor.

ABS SENSOR ROTOR (FRONT)

Removal / Inspection


1. Inspect the ABS sensor rotor for missing and damaged teeth.
2. Remove the drive shaft assembly from the vehicle.
3. Remove in the order shown in the figure, referring to **Removal Note**.



1. Driveshaft
Removal section M

2. ABS sensor rotor
Removal Note below

3. Boot band and boot




Removal Note

ABS sensor rotor

Tap the ABS sensor rotor off the drive shaft with a chisel as shown.


Installation

1. Install in the order shown in the figure, referring to **Installation Note**.
2. Install the drive shaft assembly to the vehicle.



1. ABS sensor rotor
Installation Note below
2. Boot and boot band
Installation section M

3. Drive shaft
Installation section M




Installation Note
ABS sensor rotor

Set a new ABS sensor rotor on the drive shaft in the direction shown and press it on by using the **SST**.

ABS WHEEL-SPEED SENSOR (REAR)


Removal / Inspection / Installation

1. Jack up the vehicle and support it on safety stands.
2. Remove the wheel and tire assembly.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.
5. Install the wheel and tire assembly.
6. Verify whether the diagnostic trouble code is canceled. (Refer to P-56.)



1. Connector
2. Clip
3. Bolt

4. ABS wheel-speed sensor
Inspection below



Inspection

1. Check resistance at the ABS wheel-speed sensor terminals.


Resistance: 1.6–2.0 kΩ

2. If not as specified, replace the ABS wheel-speed sensor.

ABS SENSOR ROTOR (REAR)


Removal/Installation

1. Remove the rear wheel hub assembly from the vehicle.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the order shown in the figure, referring to **Installation Note**.
4. Install the rear wheel hub assembly to the vehicle.



1. Wheel hub


2. ABS sensor rotor
 Removal Note below
 Installation Note below



Removal Note

ABS sensor rotor

Tap the ABS sensor rotor off the wheel hub with a chisel.



Installation Note

ABS sensor rotor

1. Install a new rear ABS sensor rotor on to the wheel hub.
2. Press the rotor until it is flush with the wheel hub by using the SST.

Note

- The ABS sensor rotor can be installed in either direction.

WHEELS AND TIRES

| | | |
|---|----|---|
| OUTLINE | Q- | 2 |
| SPECIFICATIONS | Q- | 2 |
| TROUBLESHOOTING GUIDE | Q- | 3 |
| WHEELS AND TIRES | Q- | 4 |
| SPECIAL NOTES ABOUT WHEELS AND TIRES | Q- | 4 |
| NOTES REGARDING TIRE REPLACEMENT | Q- | 4 |
| INSPECTION / ADJUSTMENT | Q- | 4 |
| REMOVAL / INSTALLATION | Q- | 6 |
| TIRE ROTATION | Q- | 6 |
| WHEEL BALANCE ADJUSTMENT | Q- | 6 |

OUTLINE

SPECIFICATIONS

Standard Tire

| Item | | | Specifications | | |
|-------|---|---------|-------------------------|----------------|--------------------|
| | | | B6 DOHC | | K8 DOHC |
| Wheel | Size | | 14x5 1/2JJ | 15x6JJ | |
| | Offset | mm {in} | 45 {1.77} | 45 {1.77} | |
| | Pitch circle diameter | mm {in} | 100 {3.94} | 100 {3.94} | |
| | Material | | Steel or aluminum alloy | Aluminum alloy | |
| Tire | Size | | P185/65R14 85S | P205/55R15 87V | P205/55R15 87V M+S |
| | Air pressure kPa {kgf/cm ² , psi} | Front | 216 {2.2, 32} | 196 {2.0, 28} | 216 {2.2, 32} |
| | | Rear | 216 {2.2, 32} | 196 {2.0, 28} | 216 {2.2, 32} |

Temporary spare tire

| Item | | | Specifications | |
|-------|-----------------------|---------------------------------|----------------|------------|
| | | | B6 DOHC | K8 DOHC |
| Wheel | Size | | 15 × 4T | |
| | Offset | mm {in} | 45 {1.77} | |
| | Pitch circle diameter | mm {in} | 100 {3.94} | |
| | Material | | Steel | |
| Tire | Size | | T115/70D14 | T115/70D15 |
| | Air pressure | kPa {kgf/cm ² , psi} | 415 {4.2, 60} | |

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Action | Page |
|---|--|--|--|
| Excessive or Irregular tire wear | Refer to pages Q-5 for details. | | |
| Premature tire wear | Incorrect tire pressure | Adjust | Q-5 |
| Tire squeal | Incorrect tire pressure Tire deterioration | Adjust Replace | Q-5 — |
| Road noise or body vibration | Insufficient tire pressure Unbalanced wheel Deformed wheel or tire Irregular tire wear | Adjust Adjust Repair or replace — | Q-5 Q-6 — Q-5 |
| "Shake" occurs (steering wheel vibrates up / down) | Excessive tire and wheel runout Loose lug nuts Unbalanced wheel Cracked or worn engine mount rubber Cracked or worn transaxle mount rubber | Replace Tighten Adjust Replace Replace | — Q-5 Q-6 section B section J, K |
| "Shimmy" occurs (steering wheel vibrates circumferentially) | Excessive tire and wheel runout Loose lug nuts Unbalanced wheel Irregular tire wear Insufficient tire pressure Damaged or worn front wheel bearing Malfunction of steering system Malfunction of suspension | Replace Tighten Adjust — Adjust Replace — — | — Q-5 Q-6 Q-5 Q-5 section M section N section R |
| Steering wheel pulls to one side | Incorrect tire pressure Excessive or irregular tire wear Malfunction of steering system Malfunction of braking system Malfunction of suspension | Adjust — — — — | Q-5 Q-6 section N section P section R |
| General driving Instability | Unequal tire pressures Deformed wheel or tire Loose lug nuts Malfunction of steering system Malfunction of suspension | Adjust Repair or replace Tighten — — | Q-5 — Q-5 section N section R |
| Uneven (one-sided) braking | Unequal tire pressures Malfunction of braking system | Adjust — | Q-5 section P |
| Heavy handling | Insufficient tire pressure Malfunction of steering system Malfunction of suspension | Adjust — — | Q-5 section N section R |
| Steering wheel doesn't return properly | Insufficient tire pressure Malfunction of steering system Malfunction of suspension | Adjust — — | Q-5 section N section R |

WHEELS AND TIRES


SPECIAL NOTES ABOUT WHEELS AND TIRES

1. Do not use wheels or tires other than those types specified.
2. Aluminum wheels are easily scratched. When washing them, use a soft cloth, never a wire brush. If the vehicle is steam cleaned, do not allow boiling water to contact the wheels.
3. If alkaline compounds (such as salt-water or road salts) get on aluminum wheels, wash them as soon as possible to prevent damage. Use only a neutral detergent.

NOTES REGARDING TIRE REPLACEMENT

Note the following points when tires are to be removed from or mounted onto the wheels.

1. Be careful not to damage the tire bead, the rim bead, or the edge of the rim.
2. Use a wire brush, sandpaper, or cloth to clean and remove all rust and dirt from the rim edge and the rim bead.
3. When cleaning aluminum wheels, use a soft cloth, never a wire brush or sandpaper.
4. Remove pebbles, glass, nails, and other foreign items embedded in the tire tread.
5. Be sure the air valve is installed correctly.
6. Apply a soapy solution to the tire bead and the edge of the rim before mounting.
7. After mounting a tire onto a wheel, inflate the tire to **250–300 kPa (2.55–3.06 kgf/cm², 36–42 psi)**. Verify that the bead is seated correctly on the rim and that there are no air leaks. Then reduce the pressure to the specified level.
8. If a tire iron is used to change a tire on an aluminum wheel, be sure to use a piece of rubber between the iron lever and the wheel to avoid damage to the wheel. Work should be done on a rubber mat, not on a hard or rough surface.




INSPECTION / ADJUSTMENT

Visual Inspection

Inspection (Tire and Wheel)

A wheel or a tire should be replaced if any cracks, damage, deformation and other problem is found.



Tire Wear


1. Check the remaining tread.

Remaining tread

Standard tires: 1.6 mm {0.063 in} min.

Snow tires : 50% of tread


2. A tire should be replaced if the wear indicators are exposed.



Abnormal tire wear

Abnormal tire wear patterns, such as those shown in the illustration can occur. Refer to the chart for the possible causes and actions.


| | Possible cause | Action |
|-----|--|--|
| (a) | <ul style="list-style-type: none"> Excessive tire pressure (both sides worn) Incorrect camber (one side worn) Hard cornering Lack of rotation | <ul style="list-style-type: none"> Measure and adjust pressure Repair or replace suspension parts Reduce speed Rotate tires |
| (b) | <ul style="list-style-type: none"> insufficient tire pressure Lack of rotation | <ul style="list-style-type: none"> Measure and adjust pressure Rotate tires |
| (c) | <ul style="list-style-type: none"> Incorrect toe-in | <ul style="list-style-type: none"> Adjust toe-in |
| (d) | <ul style="list-style-type: none"> Incorrect camber or caster Malfunctioning suspension Unbalanced wheel Out-of-round brake drum or disc Other mechanical problem Lack of rotation | <ul style="list-style-type: none"> Repair or replace axle and suspension parts Repair or replace Balance or replace Correct or replace Correct or replace Rotate tires |



Air Pressure


Check the air pressure of all tires when they are cold, including the spare tire, with an air pressure gauge. If necessary, adjust the air pressure.

Air pressure: Refer to Page Q-2



Air Leakage


Verify that there is no air leakage from the air valve.



Loose Lug Nut

Verify that the lug nuts are tightened to the specified torque.

Tightening torque:
89-117 N·m {9.0-12.0 kgf·m, 66-86 ft-lbf}




Wheel and Tire Runout

1. Jack up the vehicle and support it on safety stands.
2. Set the probe of a dial indicator against the wheel, and measure the runout through one full revolution.

Runout limit

| | | mm{in} |
|-------------------|------------|----------|
| Radial direction | 1.5 {0.06} | |
| Lateral direction | 2.5 {0.10} | Steel |
| | 2.0 {0.08} | Aluminum |

3. Replace the wheel if necessary.



REMOVAL / INSTALLATION

Installation

Caution


- Applying oil to the lug nuts, bolts, or wheels will cause the lug nuts to become loosened.

1. The wheel-to-hub contact surfaces must be clean.
2. Tighten the lug nuts to the specified torque in a crisscross fashion.

Tightening torque:

89–117 N·m {9.0–12.0 kgf·m, 66–86ft·lbf}

3. When reinstalling a wheel, retighten the lug nuts to the specified torque after about 1,000km {620 miles} driving.




TIRE ROTATION

To prolong tire life and assure uniform tire wear, rotate the tires as specified below except the "TEMPORARY USE ONLY" spare tire after rotating the tires, adjust each tire to the specified air pressure. (Refer to page Q-2.)


USA: Every 6,000 km{3,750 miles}

Canada: Every 24,000km{15,000miles} or 15 months (Which ever comes first)



WHEEL BALANCE ADJUSTMENT

If a wheel becomes unbalanced or if a tire is replaced or repaired, the wheel must be rebalanced to within specification.

**When balancing a wheel:**

- (1) Use no more than two balance weights on the inner or outer side of the wheel.
- (2) One balance weight should weigh no more than **60g {2.1 oz}**. If the total weight of all the balance weights on one side exceeds **100g {3.53 oz}**, then rebalance after repositioning the tire on the rim.
- (3) Select suitable balance weights for steel or aluminum alloy wheels.

Caution

- Using an on-vehicle balancer may cause damage to the transaxle. Always use an off-vehicle balancer whenever balancing a wheel (s).


Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

SUSPENSION

| | |
|--|------|
| INDEX | R- 2 |
| FRONT SUSPENSION | R- 2 |
| REAR SUSPENSION | R- 3 |
| OUTLINE | R- 4 |
| SPECIFICATIONS | R- 4 |
| TROUBLESHOOTING GUIDE | R- 6 |
| WHEEL ALIGNMENT | R- 7 |
| PRE-INSPECTION | R- 7 |
| FRONT WHEEL ALIGNMENT | R- 7 |
| REAR WHEEL ALIGNMENT | R- 9 |
| FRONT SUSPENSION (STRUT) | R-10 |
| PREPARATION | R-10 |
| FRONT SHOCK ABSORBER AND SPRING | R-11 |
| FRONT LOWER ARM | R-18 |
| FRONT STABILIZER (K8 DOHC) | R-20 |
| FRONT STABILIZER (B6 DOHC) | R-22 |
| STABILIZER CONTROL LINK | R-24 |
| TRANSVERSE MEMBER (K8 DOHC) | R-25 |
| FRONT CROSSMEMBER | R-26 |
| REAR SUSPENSION (STRUT) | R-28 |
| PREPARATION | R-28 |
| REAR SHOCK ABSORBER AND SPRING ... | R-29 |
| PERFORMANCE ROD, LATERAL LINK AND TRAILING LINK | R-34 |
| REAR STABILIZER | R-35 |
| STABILIZER CONTROL LINK | R-36 |
| REAR CROSSMEMBER | R-37 |

INDEX

FRONT SUSPENSION

**FRONT WHEEL ALIGNMENT**

MAXIMUM STEERING ANGLE: $39^{\circ}31' \pm 2^{\circ}$ (Inner) $32^{\circ}54' \pm 2^{\circ}$ (Outer)

TOTAL TOE-IN: 3 ± 4 mm (0.12 ± 0.15 in)

$0.3^{\circ} \pm 0.4^{\circ}$

CAMBER: $-0^{\circ}58' \pm 1^{\circ}$

CASTER: $2^{\circ}46' \pm 1^{\circ}$

1. Front shock absorber and spring

Removal / Installation page R-11

Disassembly / Inspection page R-12

Assembly page R-14

2. Front lower arm

Removal / Inspection /

Installation page R-18

3. Front stabilizer

Removal / Inspection /

Installation page R-20

4. Stabilizer control link

Removal / Inspection /

Installation page R-24

5. Transverse member

Removal/Inspection /


Installation page R-25

6. Front crossmember

Removal / Inspection /

Installation page R-26

REAR SUSPENSION



REAR WHEEL ALIGNMENT
TOTAL TOE-IN: 2 ± 4 mm (0.08 ± 0.15 in)
 $0.2^\circ \pm 0.4^\circ$
CAMBER: $-0^\circ 57' \pm 1^\circ$
THRUST ANGLE: $0^\circ \pm 0.8^\circ$

- | | |
|---|--|
| 1. Rear shock absorber and spring Removal / Installation page R-29 Disassembly / Inspection / Assembly page R-30 | 3. Rear stabilizer Removal / Inspection / Installation page R-35 |
| 2. Performance rod, lateral link and trailing link Removal / Inspection / Installation page R-34 | 4. Stabilizer control link Removal / Inspection / Installation page R-36 |
| | 5. Rear crossmember Removal / Inspection / Installation page R-37 |

OUTLINE

SPECIFICATIONS
Front Suspension

| Item | | Specifications | |
|---|----------------------------|--|----------------------------------|
| Type | | Strut | |
| Shock absorber | Type | Cylindrical double-acting (Oil-filled) | |
| Stabilizer | Type | Torsion bar | |
| | Diameter | mm {in} | |
| Wheel alignment (Unladen) ^{*1} | Maximum steering angle | Inner | $39^{\circ}31' \pm 2^{\circ}$ |
| | | Outer | $32^{\circ}54' \pm 2^{\circ}$ |
| | Total toe-in | mm {in} | $3 \pm 4 \{0.12 \pm 0.15\}$ |
| | | degree | $0.3^{\circ} \pm 0.4^{\circ} *2$ |
| | Camber angle ^{*3} | | $-0^{\circ}58' \pm 1^{\circ}$ |
| | Caster angle ^{*3} | | $2^{\circ}46' \pm 1^{\circ}$ |
| | SAI ^{*4} | | $14^{\circ}16'$ |

*1 • Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position

• Adjust to the median when carrying out wheel alignment

*2 Indicates measurements made by using the 4-wheel alignment tester

*3 Difference between left and right must not exceed 1.5°

*4 SAI: Steering Axis Inclination

Rear Suspension

| Item | | Specifications |
|-----------------------------|-----------------|--|
| Type | | Strut |
| Shock absorber | Type | Cylindrical double-acting (Oil-filled) |
| Stabilizer | Type | Torsion bar |
| | Diameter | mm {in} |
| Wheel alignment (Unladen)*1 | Total toe-in | mm {in} |
| | | degree |
| | Camber angle *3 | |
| | Thrust angle *2 | |

*1 • Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position



• Adjust to the median when carrying out wheel alignment

*2 Indicates measurements made by using the 4-wheel alignment tester

*3 Difference between left and right must not exceed 1.5°

TROUBLESHOOTING GUIDE

| Problem | Possible cause | Remedy | Page |
|--|---|----------------------|-----------|
| Body "rolls" | Weak stabilizer | Replace | R-20, 35 |
| | Damaged or worn stabilizer bushing, control link | Replace | R-20, 35 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| | Malfunction of shock absorber | Replace | R-11, 27 |
| Poor riding comfort | Weak coil spring | Replace | R-12, 30 |
| | Malfunction of shock absorber | Replace | R-11, 29 |
| Body leans | Weak coil spring | Replace | R-12, 30 |
| | Damaged or worn stabilizer bushing, control link | Replace | R-24, 35 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| Abnormal noise from suspension system | Poor lubrication or wear of thrust bearing | Replace | R-12 |
| | Poor lubrication or wear of lower arm ball joint | Lubricate or replace | R-16 |
| | Looseness of peripheral connections | Tighten | — |
| | Malfunction of shock absorber | Replace | R-11, 29 |
| | Damaged or worn stabilizer, control link and stabilizer bracket | Replace | R-24, 35 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| General driving instability | Weak coil spring | Replace | R-12, 30 |
| | Malfunction of shock absorber | Replace | R-11, 29 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| | Damaged or worn stabilizer bushing, control link | Replace | R-24, 35 |
| | Improperly adjusted wheel alignment | Adjust | R-7 |
| | Damaged lower arm ball joint | Replace | R-18 |
| | Malfunction of steering system | — | Section N |
| | Damaged or unbalanced wheel(s) | — | Section Q |
| Heavy steering | Poor lubrication or wear of lower arm ball joint | Lubricate or replace | R-18 |
| | Improperly adjusted wheel alignment | Adjust | R-7 |
| | Malfunction of steering system | — | Section N |
| | Damaged or unbalanced wheel(s) | — | Section Q |
| Steering wheel pulls to one side | Weak coil spring | Replace | R-12, 30 |
| | Damaged or worn stabilizer bushing, control link | Replace | R-24, 35 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| | Damaged lower arm ball joint | Replace | R-18 |
| | Improperly adjusted wheel alignment | Adjust | R-7 |
| | Malfunction of steering system | — | Section N |
| | Malfunction of braking system | — | Section P |
| Damaged or unbalanced wheel(s) | — | Section Q | |
| "Shimmy" occurs (Steering wheel vibrates left/right) | Damaged lower arm ball joint | Replace | R-18 |
| | Malfunction of shock absorber | Replace | R-12, 29 |
| | Loose shock absorber mounting | Tighten | R-12, 29 |
| | Worn or deteriorated lower arm bushing | Replace | — |
| | Damaged or worn stabilizer bushing, control link | Replace | R-24, 35 |
| | Damaged and oil leakage lower arm bushing (rear) | Replace | R-18 |
| | Improperly adjusted wheel alignment | Adjust | R-7 |
| | Damaged or worn wheel bearing | Replace | Section M |
| | Malfunction of steering system | — | Section N |
| | Damaged or unbalanced wheel(s) | — | Section Q |
| Steering wheel doesn't return properly | Stuck or damaged lower arm ball joint | Replace | R-18 |
| | Improperly adjusted wheel alignment | Adjust | R-7 |
| | Malfunction of steering system | — | Section N |
| | Damaged or unbalanced wheel(s) | — | Section Q |



WHEEL ALIGNMENT

PRE-INSPECTION

1. Check the tire inflations and set to the recommended pressure, if necessary.
2. Inspect the front wheel bearing play; replace the bearing if necessary.
3. Inspect the wheel and tire runout.
4. Inspect the ball joints and steering linkage for any excessive looseness.
5. The vehicle must be on level ground and have no luggage or passenger load.
6. The difference in height between the left and right sides from the center of the wheel to the fender brim must not exceed **10 mm {0.39 in}**.
7. Shake the vehicle to check operation of the shock absorbers.

FRONT WHEEL ALIGNMENT Specifications (Unladen) *1

| Item | | Specifications |
|------------------------|---------|---------------------|
| Maximum steering angle | Inner | 39°31' ± 2° |
| | Outer | 32°54' ± 2° |
| Total toe-in | mm {in} | 3 ± 4 {0.12 ± 0.15} |
| | Degree | 0.3° ± 0.4° *2 |
| Camber angle *3 | | -0°58' ± 1° |
| Caster angle *3 | | 2° 46' ± 1° |
| SAI *4 | | 14° 16' |


*1 • Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position

• Adjust to the median when carrying out wheel alignment

*2 Indicates measurements made by using the 4-wheel alignment tester

*3 Difference between left and right must not exceed 1.5°


*4 SAI : Steering Axis Inclination



**Adjustment
Maximum steering angle**

1. Loosen the left and right tie rod locknuts, then turn the tie rods equally.

Maximum left/right difference: 3 mm {0.12 in}




2. Tighten the tie rod locknuts.

Tightening torque:


35–50 N·m {3.5–5.1 kgf·m, 26–36 ft·lbf}

3. Adjust the toe-in after adjusting the steering angle.
4. Inspect and adjust the toe-in after adjusting the turning angle.




Camber and caster

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the mounting block nuts.



3. Push the mounting block downward, and turn it to the desired position.


| Direction indicator position | Difference from standard position | |
|------------------------------|-----------------------------------|--------------|
| | Camber angle | Caster angle |
| A | +14' | +14' |
| B | +29' | 0° |
| C | +14' | -14' |



4. Install and tighten the mounting nuts to the specified torque.

Tightening torque:

47–62 N·m {4.7–6.4 kgf·m, 34–46 ft·lbf}




Total toe-in

1. Remove the steering gear boot clamps.
2. Loosen the left and right tie rod locknuts, and turn the tie rods equally. Both tie rods are right threaded, so turning the right tie rod toward the front of the vehicle and the left toward the rear increases toe-in.

Note

- Turning both tie rods one complete turn changes toe-in by about 6mm (0.24 in).



3. Tighten the tie rod locknuts.

Tightening torque:
 35–50 N·m {3.5–5.1 kgf·m, 26–36 ft·lbf}

REAR WHEEL ALIGNMENT
Specifications (*1 Unladen)


| Item | | Specifications |
|-----------------|---------|---------------------|
| Total toe-in | mm {in} | 2 ± 4 {0.08 ± 0.15} |
| | Degree | 0.2° ± 0.4° *2 |
| Camber angle *3 | | -0°57' ± 1° |
| Thrust angle | | 0° ± 0.8° *2 |

*1 • Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position

• Adjust to the median when carrying out wheel alignment

*2 Indicates measurements made by using the 4-wheel alignment tester

*3 Difference between left and right must not exceed 1.5°



Adjustment
Total toe-in

Note

- The rear toe-in setting be adjusted to maintain a thrust angle within specified limits.
- If the thrust angle is not within specification, check the body dimensions.

Thrust angle: 0° ± 0.8°


1. Loosen the lateral link locknuts.
2. Turn the lateral link adjustment link to adjust.

Note

- One turn of the link changes 11.3 mm {0.44 in}.















3. Tighten the lateral link locknuts to the specified torque.

Tightening torque:
 55–63 N·m {5.6–6.5 kgf·m, 41–47 ft·lbf}



FRONT SUSPENSION (STRUT)


PREPARATION
SST

| | | | |
|---|---|--|--|
| <p>49 G034 1A0</p> <p>Compressor, coil spring</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 0107 680A</p> <p>Engine stand</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 G034 101</p> <p>Body (Part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 G034 102</p> <p>Screw (part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 1243 785</p> <p>Installer, boot</p>  | <p>For removal and installation of ball joint dust boot</p> | <p>49 G034 103</p> <p>Arm (Part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 0180 510B</p> <p>Attachment, preload measuring</p>  | <p>For measurement of ball joint preload</p> | <p>49 B034 201</p> <p>Support block</p>  | <p>For removal and installation of lower arm bushing</p> |
| <p>49 T034 1A0</p> <p>Compressor, coil spring</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 T034 101</p> <p>Compressor, spring (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 T034 102</p> <p>Stand (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 T034 103</p> <p>Hook (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 T034 104</p> <p>Support (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 T034 105</p> <p>Attachment</p>  | <p>For disassembly and assembly of coil spring</p> |

FRONT SHOCK ABSORBER AND SPRING


Removal / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal, referring to **Installation Note**.
5. Install the wheels. **(Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})**
6. After installation, measure the front wheel alignment, and adjust it if necessary. (Refer to page R-7.)



1. Clip
2. Nuts
3. Bolts
4. Nuts

5. Front shock absorber and spring
 Installation Note below
 Disassembly / Inspection /
 Assembly page R-12



Installation Note

Front shock absorber and spring


Face the direction indicator of the mounting block inboard, and install the shock absorber and spring.

Note

- When facing the indicator outboard, camber is adjusted to + 29'.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Visually inspect each part and replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.



1. Nut

Disassembly Note page R-13

Assembly Note page R-17

2. Mounting block

Inspect for damage, deterioration
and weakness

Assembly Note page R-14

3. Thrust bearing

Inspect for damage, wear and poor
lubrication

4. Upper spring seat

Inspect for damage and cracks

5. Rubber spring seat

Inspect for damage and deterioration

6. Dust cover

Inspect for damage and deterioration

7. Bound stopper

Inspect for damage and cracks

8. Coil spring


Inspect for damage deterioration,
and weakness

Assembly Note page R-14

9. Shock absorber

Inspection page R-14


Disposal of shock absorber page R-14



Disassembly Note Nut


Warning

- Removing the nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SSTs before removing the nut.




When using SST(49 G034 1A0)

1. Secure the mounting block in a vise.
2. Loosen the nut a few turns, but do not remove the nut.
3. Compress the coil spring by using the SSTs.
4. Remove the nut.
5. Remove the coil spring.




When using SST(49 T034 1A0)

1. Secure the mounting block in a vise.
2. Loosen the nut a few turns, but do not remove the nut.
3. Assemble the SSTs.
4. Secure the shock absorber in the SSTs.
5. Compress the coil spring by using the SSTs and remove the nut.


**Inspection****Shock absorber**

Check the following and replace if necessary.


1. Inspect for damage and oil leakage.
2. Secure a handle to the piston rod, and compress and expand the shock piston at least three times. Verify that the operational force does not change and that there is no unusual noise.

**Assembly Note****Coil spring / Mounting block****When using SST (49 G034 1A0)**


1. Secure the shock absorber in a vise.
2. Install the coil spring, fitting the end of the coil into the step of the lower seat.




3. Compress the coil spring by using the SSTs.
4. Install the bound stopper.



5. Apply the rubber lubricant to the bound stopper and the upper spring seat contact surfaces.
6. Install the dust cover.
7. Install the rubber spring seat. Install the upper spring seat, facing the direction indicator as shown in the figure.




8. Install the thrust bearing.
9. Install the mounting block, facing the direction indicator as shown in the figure.
10. Loosely tighten the nut.
11. Verify that the coil spring is correctly seated in the upper and lower seats.
12. Carefully loosen, and remove the SSTs.




When using SST (49 T034 1A0)


1. Temporarily assemble the upper spring seat and coil spring to the shock absorber, as shown.
2. Mark the upper spring seat and coil spring for proper reassembly.




3. Install the rubber spring seat to the upper spring seat.
4. Align the marks of the upper spring seat and coil spring. Protect the upper spring seat and the coil spring with a piece of cloth; then assemble the **SSTs**.
5. Use the **SSTs** to compress the spring.
6. Install the bound stopper.
7. Install the dust cover.



8. Install the shock absorber, fitting the end of the coil into the step of the lower seat.



9. Install the mounting block facing the direction indicator as shown.
10. Tighten the nut several turns.
11. Remove the **SSTs**.
12. Verify that the lower coil of the spring is seated on the step of the lower seat.

**Nut**

1. Secure the mounting block in a vise.
2. Tighten the nut.


Tightening torque:

78–109 N·m {8.0–11.2 kgf·m, 58–81 ft·lbf}


FRONT LOWER ARM

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Loosely tighten the lower arm bolt and nuts. Tighten all other nuts and bolts to the specified torque.
7. Install the wheels. **(Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})**
8. Lower the vehicle.
9. With the vehicle unloaded, tighten the lower arm bolt and nuts to the specified torque.
10. After installation, measure the front wheel alignment, and adjust it, if necessary. (Refer to page R-7.)



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Stabilizer control link nut 2. Nut 3. Bolt 4. Bolt and washer 5. Bolt 6. Front lower arm assembly 7. Ball joint dust boot Inspect for damage and deterioration Removal Note page R-19 Installation Note page R-19 8. Lower arm ball joint Inspect for damage Inspection page R-19 | <ol style="list-style-type: none"> 9. Stopper Inspect for damage and deterioration 10. Lower arm bushing (front) Inspect for damage and deterioration Removal Note page R-19 Installation Note page R-19 11. Lower arm bushing (rear) Inspect for damage, oil leakage and deterioration 12. Front lower arm Inspect for damage and deterioration |
|---|--|



Inspection

Lower arm ball joint

Check the following and replace the ball joint if necessary.


1. Inspect for damage.
2. Attach the **SST** to the ball stud, and measure the torque with a pull scale.

Rotation torque:

2.0–3.4 N·m {20–35 kgf·cm, 18–30 in·lbf}
(While ball stud rotating)

Pull scale reading:


20–34 N {2.0–3.5 kgf, 4.4–7.7 lbf}



Removal Note

Ball joint dust boot

1. Secure the ball joint in vise.
2. Carefully remove the dust boot from the ball joint with a chisel.




Lower arm bushing (front)

1. Cut away the protecting rubber of the bushing.
2. Remove the bushing by using the **SST** and a suitable socket as shown.

Note


- If the bushing is not easily removed, burn and cut the outer circumference to release the tension.



Installation Note

Ball joint dust boot

1. Wipe the grease off the ball stud.
2. Apply general-purpose grease to the new dust boot.
3. Install the dust boot to the ball joint, and press it on by using the **SST**.
4. Wipe off the leaked grease.




Lower arm bushing (front)

1. Apply soapy water to the new bushing.
2. Press it into the lower arm by using the **SST** and a suitable socket as shown.

FRONT STABILIZER (K8 DOHC)


Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove the undercover.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Visually inspect each part and replace as necessary.
6. Install in reverse order of removal, referring to **Installation Note**.
7. Loosely tighten the stabilizer bracket bolts. Tighten all other nuts and bolts to the specified torque.
8. Install the wheels. **{Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf}}**
9. Lower the vehicle.
10. With the vehicle unloaded, tighten the stabilizer bracket bolts to the specified torque.
11. After installation, measure the front wheel alignment, and adjust it, if necessary. (Refer to page R-7.)
12. Bleed the air from the power steering system. (Refer to section N.)




1. Tie-rod end/Steering knuckle
Service section N
2. Transverse member
3. Engine mounting member
Service section B2
4. Front exhaust pipe
5. Stabilizer nuts
6. Insulator
7. Steering gear and linkage
Service section N
8. Bolts and nuts

9. Lower arm and front crossmember assembly
10. Bolts
11. Stabilizer brackets
12. Stabilizer bar
Inspect for damage
Removal Note page R-21
13. Stabilizer bushings
Inspect for damage
Installation Note page R-21

**Removal Note****Stabilizer bar**

1. Support the crossmember with a jack, and remove the bolts and nuts.
2. Remove the stabilizer bracket.
3. Lower the crossmember slowly, and remove the stabilizer bar from the crossmember.


**Installation Note****Stabilizer bushing**

Align the bushing with the installation position painted on the stabilizer bar.


FRONT STABILIZER (B6 DOHC)

Removal / Inspection / Installation


1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove the undercover.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Visually inspect each part and replace as necessary.
6. Install in the reverse order of removal, referring to **Installation Note**.
7. Loosely tighten the stabilizer bracket bolts. Tighten all other nuts and bolts to the specified torque.
8. Install the wheels. (**Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf}**)
9. Lower the vehicle.
10. With the vehicle unloaded, tighten the stabilizer bracket bolts to the specified torque.
11. After installation, measure the front wheel alignment, and adjust it, if necessary. (Refer to page R-7.)
12. Bleed the air from the power steering system. (Refer to section N.)



- | | |
|--|--|
| 1. Tie-rod end/Steering knuckle Service section N | 8. Bolts |
| 2. Engine mounting member Service section B1 | 9. Stabilizer brackets |
| 3. Front exhaust pipe | 10. Stabilizer bar Inspect for damage Removal Note page R-23 |
| 4. Stabilizer nuts | 11. Stabilizer bushings Inspect for damage Installation Note page R-23 |
| 5. Steering gear and linkage Service section N | |
| 6. Bolts and nuts | |
| 7. Lower arm and front crossmember assembly | |

**Removal Note****Stabilizer bar**


1. Support the crossmember with a jack, and remove the bolts and nuts.
2. Remove the stabilizer bracket.
3. Lower the crossmember slowly, and remove the stabilizer bar from the crossmember.

**Installation Note****Stabilizer bushing**

Align the bushing with the installation position painted on the stabilizer bar.


STABILIZER CONTROL LINK**Removal / Inspection / Installation**

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheels. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})



1. Nuts
2. Stabilizer control link

Inspection Below

**Inspection**

Check the following and replace if necessary

Stabilizer control link


1. Inspect for bending and damage.
2. Shake the ball joint stud 10 times.
3. Rotate the ball joint stud 10 times.
4. Measure the preload with a suitable hexagon wrench and torque wrench.

Preload:

0.2–1.4 N·m (2.0–15.0 kgf·cm, 1.8–13.0 in·lbf)

TRANSVERSE MEMBER (K8 DOHC)**Removal / Inspection / Installation**

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove in the order shown in the figure.
3. Visually inspect each part and replace as necessary.
4. Install in the reverse order of removal.



94-126 (9.5-12.9, 69-93)

N.m (kgf.m, ft.lbf)


1. Bolts
2. Washers

3. Transverse member
Inspect for bending and damage


FRONT CROSSMEMBER

Removal / Inspection / Installation

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove the undercover.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Visually inspect each part and replace as necessary.
6. Install in the reverse order of removal.
7. Loosely tighten the lower arm bolts and the stabilizer bracket bolts. Tighten all other nuts and bolts to the specified torques.
8. Install the wheels. **(Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lb})**
9. Lower the vehicle.
10. With the vehicle unloaded, tighten the lower arm bolts and the stabilizer bracket bolts to the specified torque.
11. Adjust the front wheel alignment. (Refer to page R-7.)
12. Bleed the air from the power steering system. (Refer to section N.)



- | | |
|--|---|
| <ul style="list-style-type: none"> 1. Tie-rod end / Steering knuckle Service section N 2. Transverse member (K8 DOHC) 3. Engine mounting member Service section B1, B2 4. Front exhaust pipe 5. Stabilizer nuts 6. Insulator (K8 DOHC) 7. Steering gear and linkage Service section N 8. Bolts and nuts 9. Front lower arm assembly Removal / Inspection / Installation page R-18 | <ul style="list-style-type: none"> 10. Bolts 11. Nuts 12. Front crossmember Removal Note below Inspect for damage 13. Stabilizer bolts 14. Stabilizer brackets 15. Stabilizer bar Removal Note page R-21, 23 16. Stabilizer bushings Installation Note page R-21, 23 |
|--|---|















Removal Note

Front Crossmember

1. Support the crossmember with a jack, and remove the bolts and nuts.
2. Remove the front crossmember.

REAR SUSPENSION (STRUT)

PREPARATION SST

| | | | |
|---|--|---|--|
| <p>49 G034 1A0 Compressor, coil spring</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 G034 102 Screw (Part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 G034 101 Body (Part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 G034 103 Arm (Part of 49 G034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 0259 770B Wrench, flare nut</p>  | <p>For removal and installation of brake pipe</p> | <p>49 T034 1A0 Compressor, coil spring</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 T034 101 Compressor, spring (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of brake pipe</p> | <p>49 T034 103 Hook (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 T034 102 Stand (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 T034 105 Attachment</p>  | <p>For disassembly and assembly of coil spring</p> |
| <p>49 T034 104 Support (Part of 49 T034 1A0)</p>  | <p>For disassembly and assembly of coil spring</p> | <p>49 0107 680A Engine stand</p>  | <p>For disassembly and assembly of coil spring</p> |


REAR SHOCK ABSORBER AND SPRING

Removal / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove the rear speaker cover and rear seat belt. (Refer to section S.)
4. Remove in the order as shown in the figure.
5. Install in the reverse order of removal.
6. Install the rear speaker cover and rear seat belt. (Refer to section S.)
7. Install the wheels.

(Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})

8. After installation, measure the rear wheel alignment, if necessary. (Refer to page R-9.)




1. Clip
2. Nut
3. Bolt
4. Nut

5. Shock absorber and spring
Disassembly / Inspection /
Assembly

..... page R-30


Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Visually inspect each part and replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.



1. Cap
2. Nut and washer
Disassembly Note below
3. Retainer
4. Mounting block
Inspect for damage weakness
5. Stopper seat
6. Bound stopper
Inspect for damage and cracks

7. Coil spring
Assembly Note page R-31
Inspect for damage and weakness
8. Lower spring seat
Inspect for damage and cracks
9. Shock absorber
Inspection page R-14
Disposal of shock absorber page R-14




Disassembly Note Nut and washer

Warning


- Removing the nut is dangerous. The shock absorber and spring could fly off under tremendous pressure and cause serious injury or death. Secure the shock absorber in the SSTs before removing the nut.

1. Secure the mounting block in a vise.
2. Loosen the nut several turns, but do not remove it.




When using SST (49 G034 1A0)

3. Assemble the SSTs.
4. Compress the coil spring by using the SSTs.
5. Remove the nut.
6. Remove the coil spring.



When using SST (49 T034 1A0)

3. Assemble the SSTs.
4. Secure the shock absorber in the SSTs.
5. Compress the coil spring by using the SSTs and remove the nut.




Assembly Note


Coil spring

When using SST (49 G034 1A0)


1. Secure the shock absorber in a vise.
2. Install the lower spring seat.
3. Install the coil spring, fitting the end of the coil into the step of the lower seat.



4. Compress the coil spring by using the SSTs.
5. Install the bound stopper and the stopper seat.




6. Install the mounting block, aligning the studs of the mounting block and the lower bracket of the shock absorber as shown in the figure.
7. Install the retainer and washer.
8. Loosely tighten the nut.
9. Carefully loosen and remove the **SSTs**.
10. Verify that the coil spring is correctly seated in the mounting block and lower spring seat.




When using SST (49 T034 1A0)


1. Temporarily assemble the mounting block and coil spring to the shock absorber, as shown.
2. Mark the mounting block and coil spring for proper reassembly.



3. Align the marks of the mounting block and coil spring. Protect the mounting block and the coil spring with a piece of cloth; then assemble the **SSTs**.
4. Use the **SSTs** to compress the spring.



5. Install the lower spring seat.
6. Install the bound stopper.
7. Install the dust cover.
8. Install the shock absorber, fitting the end of the coil into the step of the lower seat.
9. Install the retainer and washer.
10. Loosely tighten the nut.
11. Carefully loosen and remove the **SSTs**.
12. Verify that the coil spring is correctly seated in the mounting block and lower spring seat.



13. Secure the mounting block in a vise.
14. Install the retainer and washer.
15. Tighten the nut to the specified torque.

Tightening torque:


55–67 N·m {5.6–6.9 kgf·m, 41–49 ft·lb}

16. Install the cap over the nut.


PERFORMANCE ROD, LATERAL LINK AND TRAILING LINK

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of removal, referring to **Installation Note**.
6. Loosely tighten the lateral link and trailing link bolts. Tighten all other nuts and bolts to the specified torque.
7. Install the wheels. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})
8. Lower the vehicle.
9. With the vehicle unloaded, tighten the lateral link and trailing link bolts to the specified torque.
10. After installation, measure the rear wheel alignment, and adjust it if necessary. (Refer to page R-9.)



- | | |
|-----------------------------------|---------------------------------|
| 1. Nut | 12. Lateral link (rear) |
| 2. Washer | Inspect for deformation |
| 3. Performance rod (K8 DOHC) | Inspect for weakness of bushing |
| Inspect for bending and damage | 13. Lateral link (front) |
| Installation Note page R-36 | Inspect for deformation |
| 4. Stabilizer nut | Inspect weakness of bushing |
| 5. Cap | 14. Bolt |
| 6. Bolt | 15. Bolt |
| 7. Washer | 16. Washer |
| 8. Nut | 17. Trailing link |
| 9. Washer | Inspect for deformation |
| 10. Bolt | Inspect weakness of bushing |
| 11. Retainer | |




Installation Note
Performance rod

Install the performance rod with the "A" toward the rear crossmember.

REAR STABILIZER


Removal/Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of removal.
6. Loosely tighten the stabilizer bracket bolts. Tighten other nuts to the specified torque.
7. Install the wheels. (Tightening torque: 89-117 N·m {9.0-12.0 kgf·m, 66-86 ft·lbf})
8. Lower the vehicle.
9. With the vehicle unloaded, tighten the stabilizer bracket bolts to the specified torque.



1. Nuts
2. Protectors
3. Bolts
4. Stabilizer brackets

5. Stabilizer bushings
Inspect for damage and weakness
Installation Note page R-36
6. Stabilizer bar
Inspect for damage and deformation



Installation Note


Stabilizer bushing

Align the bushing with the installation position line painted on the stabilizer bar.

STABILIZER CONTROL LINK


Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with the safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of removal.
6. Install the wheels. (Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})



1. Nuts
2. Protector

3. Stabilizer control link
Inspection Below



Inspection

Stabilizer control link

Check the following and replace if necessary

1. Inspect for bending and damage.
2. Shake the ball joint stud 10 times.
3. Rotate the ball joint stud 10 times.
4. Measure the preload with a suitable hexagon wrench and a torque wrench.


Preload:

0.2–1.4 N·m {2.0–15.0 kgf·cm, 1.7–13.0 in·lbf}


REAR CROSSMEMBER

Removal / Inspection / Installation

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Remove in the order shown in the figure, referring to **Removal Note**.
4. Visually inspect each part and replace as necessary.
5. Install in the reverse order of the removal, referring to **Installation Note**.
6. Loosely tighten the stabilizer bracket, lateral link and performance rod bolts and nuts. Tighten all other bolts and nuts to the specified torque.
7. Bleed the air from the Brake System. (Refer to section P.)
8. Install the wheels. **(Tightening torque: 89–117 N·m {9.0–12.0 kgf·m, 66–86 ft·lbf})**
9. Lower the vehicle.
10. With the vehicle unloaded, tighten the stabilizer bracket, lateral link and performance rod bolts to the specified torque.
11. After installation, measure the rear wheel alignment, and adjust it, if necessary. (Refer to page R-9.)



- | | |
|--|---|
| <p>1. Brake pipe Removal / Installation Note page R-38</p> <p>2. Rear stabilizer Removal / Inspection / Installation page R-36</p> <p>3. Performance rod (K8 DOHC) Removal / Inspection / Installation page R-34</p> | <p>4. Lateral link (front and rear) Removal/Inspection / Installation page R-34</p> <p>5. Bolts</p> <p>6. Rear crossmember Inspect for damage</p> |
|--|---|

**Removal/Installation Note****Brake pipe**

Disconnect/connect the brake pipes by using the SST.

Tightening torque:

12.8–21.5 N·m { 130–220 kgf·cm, 113–190 in·lb}


Before beginning any service procedure, refer to the 1995 MX-3 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings.

BODY


| | | | |
|---|------|------------------------------------|------|
| INDEX | S- 2 | LIFTGATE GLASS | S-45 |
| HOOD | S- 5 | PREPARATION | S-45 |
| COMPONENTS | S- 5 | COMPONENTS | S-45 |
| DOOR | S- 7 | VERTICAL WINDOW GLASS | S-49 |
| PREPARATION | S- 7 | PREPARATION | S-49 |
| COMPONENTS | S- 8 | COMPONENTS | S-49 |
| WINDOW REGULATOR AND GLASS ... | S-10 | SLIDING SUNROOF | S-53 |
| COMPONENTS | S-10 | COMPONENTS | S-53 |
| DOOR LOCK AND OPENER | S-12 | SUNROOF DRIVE UNIT | S-57 |
| COMPONENTS | S-12 | DASHBOARD AND CONSOLE | S-61 |
| LIFTGATE | S-13 | COMPONENTS | S-61 |
| COMPONENTS | S-13 | TRIM | S-65 |
| LIFTGATE LOCK AND OPENER | S-15 | COMPONENTS | S-65 |
| COMPONENTS | S-15 | FLOOR COVERING | S-69 |
| FUEL-FILLER LID AND OPENER | S-16 | COMPONENTS | S-69 |
| COMPONENTS | S-16 | HEADLINER | S-70 |
| FRONT BUMPER | S-17 | COMPONENTS | S-70 |
| COMPONENTS | S-17 | SEAT BELT | S-73 |
| REAR BUMPER | S-19 | COMPONENTS | S-73 |
| COMPONENTS | S-19 | SEAT BELT | S-74 |
| EXTRACTOR CHAMBER | S-21 | SEAT | S-75 |
| COMPONENTS | S-21 | PREPARATION | S-75 |
| MOLDING | S-22 | COMPONENTS | S-75 |
| PREPARATION | S-22 | | |
| WINDSHIELD MOLDING | S-22 | | |
| LIFTGATE MOLDING / | | | |
| VERTICAL WINDOW MOLDING | S-25 | | |
| ROOF MOLDING | S-30 | | |
| BELTLINE MOLDING | S-31 | | |
| REAR SPOILER | S-32 | | |
| COMPONENTS | S-32 | | |
| COWL GRILLE | S-33 | | |
| COMPONENTS | S-33 | | |
| POWER OUTSIDE MIRROR | S-34 | | |
| COMPONENTS | S-34 | | |
| WINDSHIELD WIPER AND WASHER ... | S-36 | | |
| COMPONENTS | S-36 | | |
| WINDSHIELD WIPER MOTOR | S-38 | | |
| REAR WIPER AND WASHER | S-39 | | |
| COMPONENTS | S-39 | | |
| WINDSHIELD | S-41 | | |
| PREPARATION | S-41 | | |
| COMPONENTS | S-41 | | |

NOTE: Refer to the 1995 MX-3 Body Electrical Troubleshooting Manual (1474-10-94H) for servicing of the body electrical components.

INDEX




- | | |
|--------------------------------|-----------|
| 1. Hood | |
| Removal / Installation | page S- 5 |
| Adjustment | page S- 6 |
| 2. Door | |
| Removal / Installation | page S- 8 |
| Adjustment | page S- 9 |
| 3. Window regulator and glass | |
| Removal / Installation | page S-10 |
| 4. Front bumper | |
| Removal / Installation | page S-17 |
| Disassembly / Assembly | page S-18 |
| 5. Molding | |
| Removal / Installation | page S-22 |
| 6. Cowl grille | |
| Removal / Installation | page S-33 |
| 7. Power outside mirror | |
| Removal / Installation | page S-34 |
| 8. Windshield wiper and washer | |
| Removal / Installation | page S-36 |
| Adjustment | page S-37 |
| 9. Windshield | |
| Removal / Installation | page S-41 |



S

- 1. Door lock and opener
Removal / Installation page S-12
- 2. Liftgate
Removal / Installation page S-13
Adjustment page S-14
- 3. Liftgate lock and opener
Removal / Installation page S-15
- 4. Fuel-filler lid and opener
Removal / Installation page S-16
- 5. Rear bumper
Removal / Installation page S-19
Disassembly / Assembly page S-20
- 6. Extractor chamber
Removal / Installation page S-21
- 7. Molding
Removal / Installation page S-22

- 8. Rear spoiler
Removal / Installation page S-32
- 9. Rear wiper and washer
Removal / Installation page S-39
Adjustment page S-40
- 10. Liftgate glass
Removal / Installation page S-45
- 11. Vertical window glass
Removal / Installation page S-49
- 12. Sliding sunroof
Removal / Installation page S-53
Disassembly / Assembly page S-57



- 1. Liftgate lock and opener
Removal / Installation page S-15
- 2. Fuel-filler lid and opener
Removal / Installation page S-16
- 3. Dashboard and console
Removal / Installation page S-61
- 4. Trim
Removal / Installation page S-65
- 5. Floor covering
Removal / Installation page S-69


- 6. Headliner
Removal / Installation page S-70
- 7. Seat belt
Removal / Installation page S-73
Inspection page S-74
- 8. Seat
Removal / Installation page S-75
Disassembly / Assembly page S-77

HOOD


COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



- | | |
|-------------------------------|---------------------------|
| 1. Windshield washer pipe | 6. Hood hinge |
| 2. Surround seal weatherstrip | 7. Hood stay |
| 3. Hood deflector | 8. Hood lock |
| 4. Hood insulator | Adjustment page S-6 |
| 5. Hood | 9. Hood release cable |
| Adjustment page S-6 | |


**Adjustment****Hood**

Adjust the hood laterally and vertically by loosening the hood to hinge mounting bolts and repositioning the hood.

Clearance: 2.3–4.7 mm {0.09–0.18 in}

Tightening torque:

19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}

**Hood lock**

1. Verify that the hood is properly aligned. (Refer above.)
2. Loosen the hood lock mounting bolts and nut, and align the hood lock with the striker on the hood.

Tightening torque

Bolt: 7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}

Nut: 19–25 N·m {1.9–2.6 kgf·m, 14–18 ft·lbf}


DOOR

PREPARATION


| | |
|-----------------|---|
| TORX tool (T40) | For removal / installation of door lock striker |
|-----------------|---|

TORX TOOL (T40)

1. ILLUSTRATION




2. USAGE



COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the checker, remove the door trim and door screen.
(Refer to page S-10.)
3. Install in the reverse order of removal.



1. Harness connector

2. Checker pin

3. Door


Adjustment page S-9

4. Door hinge

5. Checker

6. Door lock striker

Adjustment page S-9


**Adjustment****Door**

Adjust the door laterally and vertically by loosening the door-hinge-to-body mounting bolts and repositioning the door.

Clearance: ① 3–5 mm {0.12–0.20 in}
 ② 4–8 mm {0.16–0.31 in}

Tightening torque:

22–30 N·m {2.2–3.1 kgf·m, 16–22 ft·lbf}

**Door lock striker**

1. Verify that the door can be closed easily and that there is no looseness. If there is a problem, loosen the striker mounting screws and move the striker horizontally or vertically.
2. Verify the rear offset of the door to the body. If there is a problem, move the door lock striker vertically.

Tightening torque:

18–26 N·m {1.8–2.7 kgf·m, 14–19 ft·lbf}

WINDOW REGULATOR AND GLASS

COMPONENTS


Removal / Installation

1. Lower the door glass 280 mm {11.0 in} from the fully closed position.
2. Disconnect the negative battery cable, if equipped with power windows.

Note


- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal, referring to **Installation note**.



1. Regulator handle
Removal note page S-11
Installation note page S-11
2. Inner handle cover
3. Door trim
Removal / Installation page S-65
4. Pull handle
5. Power window subswitch


6. Inner handle
7. Sealing pad
8. Door screen
9. Glass run channel
10. Door glass
11. Power window regulator
12. Manual window regulator



Removal note

Regulator handle

Remove the regulator handle clip by using a rag as shown.



Installation note

Regulator handle

Install the clip in the handle and push the regulator handle on as shown.

DOOR LOCK AND OPENER

COMPONENTS


Removal / Installation

1. Raise the front door glass fully.
2. Disconnect the negative battery cable.

Note

- Remove the door screen carefully so that it may be reused.

3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Inner handle cover

2. Door trim

Removal / Installation page S-65

3. Inner handle

4. Sealing pad

5. Door screen

6. Door lock actuator

7. Door lock

8. Outer handle

9. Lock cylinder retainer


10. Lock cylinder

LIFTGATE

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the liftgate hinges, remove the headliner. (Refer to page S-70.)
3. Install in the reverse order of removal.



1. Liftgate side trim
Removal / Installation page S-65
2. Liftgate upper trim
Removal / Installation page S-65
3. Liftgate lower trim
Removal / Installation page S-65

4. Rear washer pipe
5. Stay damper
6. Liftgate
Adjustment page S-14
7. Liftgate hinge




Adjustment Liftgate

Adjust the liftgate laterally and vertically by loosening the liftgate-to-hinge mounting nuts shown in the figure.

Clearance: ① 4.5–7.5 mm {0.18–0.29 in}
 ② –0.2–1.8 mm {–0.01–0.07 in}
 ③ 2.5–5.5 mm {0.10–0.22 in}

Tightening torque:
 18–29 N·m {1.8–3.0 kgf·m, 14–21 ft·lbf}



Liftgate lock

1. Verify that the liftgate is properly aligned. (Refer above.)
2. Remove the service cover from the trunk end trim.
3. Loosen the liftgate lock mounting bolts, and align the lock with striker on the liftgate.


Tightening torque:
 16–22 N·m {1.6–2.3 kgf·m, 12–16 ft·lbf}

LIFTGATE LOCK AND OPENER

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N·m (kgf·m, ft·lb)

Liftgate lock

1. Liftgate lower trim
Removal / Installation page S-65
2. Liftgate striker
3. Trunk end trim
Removal / Installation page S-65
4. Liftgate lock
Adjustment page S-14

Liftgate opener, liftgate opener cable

5. Rear speaker cover
Removal / Installation page S-65


6. Trunk side trim
Removal / Installation page S-65
7. Rear seat
Removal / Installation page S-76
8. Quarter trim
Removal / Installation page S-65
9. Opener bezel
10. Opener lever
11. Liftgate opener cable

FUEL-FILLER LID AND OPENER

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



Fuel-filler lid

1. Fuel-filler lid
2. Lift spring
3. Fuel-filler lid opener

Fuel-filler lid opener lever and cable

4. Trunk end trim
Removal / Installation page S-65
5. Rear speaker cover
Removal / Installation page S-65


6. Trunk side trim
Removal / Installation page S-65
7. Rear seat
Removal / Installation page S-76
8. Quarter trim
Removal / Installation page S-65
9. Opener bezel
10. Opener lever
11. Fuel-filler lid opener cable

FRONT BUMPER

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. (Refer to the 1995 MX-3 Body Electrical Troubleshooting Manual, section E, when removing the front combination lights and front side marker lights.)
3. Install in the reverse order of removal.




1. Front combination light
2. Front side marker light

3. Front bumper
Disassembly / Assembly page S-18

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Front bumper reinforcement
2. Set plate


3. Center mesh
4. Front bumper fascia
5. Front air dam

REAR BUMPER

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. (Refer to the 1995 MX-3 Body Electrical Troubleshooting Manual, section E, when removing the rear combination lights.)
3. Install in the reverse order of removal.




1. Rear combination light
 2. Trunk end trim
 Removal / Installation page S-65

3. Rear bumper
 Disassembly / Assembly page S-20

Disassembly / Assembly

1. Disassemble in the order shown in the figure. (Refer to the 1995 MX-3 Body Electrical Troubleshooting Manual, section E, when removing the rear side marker lights.)
2. Assemble in the reverse order of disassembly.




1. Rear bumper reinforcement
2. Rear bumper bracket
3. Energy-absorbing foam

4. Rear side marker light
5. Rear bumper fascia
6. Rear bumper retainer

EXTRACTOR CHAMBER**COMPONENTS****Removal / Installation**

1. Remove in the order shown in the figure.
2. install in the reverse order of removal.





1. Rear bumper
Removal / Installation page S-19

2. Extractor chamber


MOLDING

PREPARATION SST


| | | | |
|---|--|--|------------------------------|
| 49 0305 870A Tool set, window  | For removal / installation of molding | 49 G050 1A0 Remover, sealant  | For removal of sealant |
|---|--|--|------------------------------|

WINDSHIELD MOLDING Removal / Installation


1. Remove in the order shown in the figure, referring to **Removal note**.
2. Install in the reverse order of removal, referring to **Installation note**.




- 1. Windshield molding
Removal note page S-23
Installation note page S-23

**Removal note****Windshield molding**


The upper molding is attached to the windshield by sealant as shown.

**Installation note****Windshield molding**


1. Apply protective tape along the edge of the body to protect it from damage.
2. Cut the sealant by using a razor knife as shown.




3. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the body as shown.




4. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the glass as shown.




5. Remove as much sealant as possible from between the body and the glass.
6. Carefully clean around the edge of the glass and the adhesion surface at the body.




7. If the protector is damaged, replace it with a new one.
8. Apply primer onto the bonding area of the glass, body, and new windshield molding by using a brush. Use only glass primer on the glass and body primer on the body and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.



10. Apply a 3 mm {0.12 in} bead of repair sealant between the glass and the body.



11. Reshape the repair sealant as shown if necessary.



12. Install the windshield molding before the sealant hardens.
 - ① Align the marks on the molding to the roof inner line.
 - ② Install the top of the molding.
 - ③ Install the corners of the molding.
 - ④ Install the sides of the molding, starting from the top and then toward the bottom.

Hardening time of repair sealant


| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

13. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.

LIFTGATE MOLDING / VERTICAL WINDOW MOLDING


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal note**.
2. Install in the reverse order of removal, referring to **Installation note**.




1. Liftgate lower trim
Removal / Installation page S-65
2. Rear spoiler
Removal / Installation page S-32


3. Liftgate molding
Removal note page S-26
Installation note page S-26
4. Vertical window molding
Removal note page S-26
Installation note page S-28

**Removal note****Liftgate molding**


The molding is attached to the liftgate glass by sealant as shown.

**Vertical window molding**


The molding is attached to the vertical window by sealant as shown.

**Installation note****Liftgate molding**


1. Apply protective tape along the upper edge of the liftgate to protect it from damage.
2. Cut the upper sealant by using a razor knife as shown.




3. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the liftgate as shown.




4. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the glass as shown.




5. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the glass as shown.




6. Apply primer onto the bonding area of the glass, liftgate, and new liftgate molding by using a brush. Use only glass primer on the glass and body primer on the liftgate and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.



7. Apply a **3 mm {0.12 in}** bead of repair sealant between the glass and the liftgate.



8. Reshape the repair sealant as shown if necessary.




9. Install the liftgate molding before the sealant hardens.
- ① Align the mark on the glass to that on the molding.
 - ② Install the top of the molding.
 - ③ Install the corners of the molding.
 - ④ Install the sides of the molding, starting from the top and then toward the bottom.

Hardening time of repair sealant


| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

10. Check for water leaks. If a leak is found, wipe the water off well and repeat the installation.




Vertical window molding





1. Cut the sealant by using a razor knife as shown.



2. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the body as shown.



3. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the glass as shown.



4. Insert the blade of the **SST** into the sealant, and pull on the bar to cut the sealant near the glass as shown.

5. Apply primer to the bonding area of the glass, liftgate, and new vertical window molding by using a brush. Use only glass primer on the glass and body primer on the liftgate and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.

6. Apply a **3 mm {0.12 in}** bead of repair sealant between the glass and the liftgate.

7. Remove the protective liner paper of the double-sided adhesive tape of the vertical window molding.

8. Install the vertical window molding before the sealant hardens.

- ① Align the mark of the molding to that on the glass.
- ② Starting from the center, press the molding into place toward both ends.


Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

ROOF MOLDING


Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation note**.



1. Roof molding
Installation note below


2. Clip



Installation note

Roof molding

1. Remove the clips from the roof panel.
2. Clean and degrease the clip installation points.
3. Install new clips to the roof panel.




4. Remove the protective liner paper of the double-sided adhesive tape at the rear end of the molding. Align the rear end of the molding to the clip and press the clip area ①.
5. Press the molding down firmly, especially the rear end of the molding ②.

BELTLINE MOLDING


Removal / Installation

1. Lower the door glass fully.
2. Remove the power outside mirror. (Refer to page S-34.)
3. Remove in the order shown in the figure, referring to **Removal note**.
4. Install in the reverse order of removal.



1. Fastener

2. Beltline molding
Removal note below



Removal note

Beltline molding


Pull the beltline molding upward to remove the clips from the body.

REAR SPOILER

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



1. Liftgate lower trim
Removal / Installation page S-65


2. Rear spoiler

COWL GRILLE

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



N.m (kgf-cm, In-lbf)

1. Windshield wiper arm and blade
Removal / Installation page S-36

2. Cowl cap
3. Cowl grille

POWER OUTSIDE MIRROR

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.

Note

- Remove the door screen carefully so that it may be reused.

2. Remove in the order shown in the figure.

3. Install in the reverse order of removal.




Power outside mirror

1. Door trim
Removal / Installation page S-65
2. Door screen
3. Inner garnish

4. Power outside mirror
Replacement of mirror glass . . . page S-35


Power outside mirror switch

5. Meter hood
Removal / Installation page S-61
6. Power outside mirror switch




Replacement of Mirror Glass

1. Warm the frame and the mirror glass by using a hot-air blower.




2. Insert a scraper between the mirror glass and the frame, and pry the glass loose.

3. Remove the remaining adhesive.



4. Warm the adhesive surface of the frame and the mirror by using a hot-air blower.




5. Install the glass in the frame and gently press it in to secure it.

WINDSHIELD WIPER AND WASHER

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal, referring to **Installation note**.

**Windshield wiper**

1. Windshield wiper arm cover
Installation note page S-37
Adjustment page S-37
2. Windshield wiper arm and blade
3. Cowl grille
4. Baffle
5. Windshield wiper motor
Disassembly / Assembly page S-38
6. Windshield wiper link

Windshield washer


7. Windshield washer tank
8. Windshield washer motor
9. Windshield washer pipe
10. Windshield washer nozzle
Adjustment page S-37



Installation note

Windshield wiper arm and blade

Clean the wiper arm connector shafts with a wire brush before installing the wiper arms.




Adjustment

Windshield wiper arm and blade

1. Turn the ignition switch to ON and turn the wiper switch on to operate the wipers.
2. Turn the wiper switch off to set the wipers in the park position.
3. Set the wiper arm height as shown in the figure.

Tightening torque:

9.81–13.7 N·m {100–140 kgf·cm, 86.8–121 in·lbf}




Windshield washer nozzle

Insert a needle or similar object into the nozzle hole and move the nozzle to adjust the spray direction.

| Clearance mm {in} | |
|-------------------|--------------|
| ① 30 {1.2} | ⑩ 160 {6.30} |
| ② 40 {1.6} | ⑪ 170 {6.69} |
| ③ 50 {2.0} | ⑫ 200 {7.87} |
| ④ 55 {2.2} | ⑬ 231 {9.09} |
| ⑤ 60 {2.4} | ⑭ 249 {9.80} |
| ⑥ 75 {3.0} | ⑮ 260 {10.2} |
| ⑦ 80 {3.1} | ⑯ 336 {13.2} |
| ⑧ 90 {3.5} | ⑰ 360 {14.2} |
| ⑨ 145 {5.71} | |

WINDSHIELD WIPER MOTOR**Disassembly / Assembly**

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Wiper motor
2. Brush plate holder


3. Motor gear assembly

REAR WIPER AND WASHER

COMPONENTS

Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure. To remove the rear washer pipe, remove the liftgate upper trim (page 65) and the rear portion of the headliner (page S-70).
3. Install in the reverse order of removal, referring to **Installation note**.



Rear wiper


1. Rear wiper arm and blade
Installation note page S-40
Adjustment page S-40
2. Outer bushing
3. Rear wiper cover
4. Rear wiper motor

Rear washer


5. Trunk end trim
Removal / Installation page S-65
6. Rear speaker cover
Removal / Installation page S-65

7. Trunk side trim

- Removal / Installation page S-65
8. Quarter trim
Removal / Installation page S-65
 9. B-pillar trim
Removal / Installation page S-65
 10. Rear washer pipe
 11. Rear washer tank
 12. Rear washer motor
 13. Rear washer nozzle
Adjustment page S-40

**Installation note****Rear wiper arm and blade**


Clean the wiper arm connector shaft with a wire brush before installing the wiper arm.

**Adjustment****Rear wiper arm and blade**

1. Set the motor shaft to the park position by turning the rear wiper switch on and off.
2. Set the wiper arm height as shown in the figure.

Tightening torque:

5.9–9.80 N·m {60–100 kgf·cm, 53–86.7 in·lbf}


**Rear washer nozzle**

Insert a needle or similar object into the nozzle hole and move the nozzle to adjust the spray direction.

WINDSHIELD

PREPARATION


SST

| | | |
|--|---|--|
| <p>49 0305 870A Tool set, window</p> |  | <p>For removal / installation of glass</p> |
|--|---|--|

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.




- 1. Sunvisor and adapter
- 2. Rearview mirror
- 3. Overhead console
- 4. A-pillar trim
Removal / Installation page S-65
- 5. Windshield wiper arm and blade
Removal / Installation page S-36
- 6. Cowl grille
Removal / Installation page S-33


- 7. Windshield molding
Removal / Installation page S-22
- 8. Windshield
Removal note page S-42
Installation note page S-42
- 9. Spacer
- 10. Dam
- 11. Protector

**Removal note****Windshield**


1. Apply protective tape along the front edge of the headliner to protect it from damage.
2. Apply protective tape along the edge of the body to protect it from damage.

**If the glass will not be reused**


3. Use a tool like that shown in the figure and insert the blade into the sealant.
4. Pull through the sealant around the edge of the glass.
5. If the protector is damaged, remove it.
6. Remove the glass.

**If the glass will be reused**


3. Make a hole through the sealant from the inside of the vehicle by using an awl.
4. Pass piano wire through the hole.




5. Wind each end of the wire around a bar.
6. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
7. Remove the glass.

**Installation note****Windshield**


1. Cut away the old sealant by using a razor knife so that 1 to 2 mm {0.04 to 0.08 in} of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it 30 minutes to dry. Then apply new sealant to create a 2 mm {0.08 in} layer.
2. Carefully clean an area 50 mm {2.0 in} wide around the circumference of the glass and the bonding area on the body.




3. Securely bond a new dam 7 mm {0.28 in} from the edge of the glass as shown. Allow it to dry completely.




4. Install the spacers onto the body. If a spacer is damaged, replace it.
5. Temporarily install the glass onto the body and adjust the glass-to-body clearance.
6. Make a mark on the glass directly above the V-notch of the spacers.
7. Remove the glass.




8. Apply primer onto the bonding area of the glass, body, and molding by using a brush. Use only glass primer on the glass and body primer on the body and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow it to dry for approximately 30 minutes.




9. After the primer has dried, apply an 11 mm {0.43 in} high bead of repair sealant around the circumference of the glass as shown. Keep the bead of sealant smooth and even, reshaping it with a spatula where necessary. If the windshield is being reused, apply new repair sealant over the original.




10. If the protector was removed, bond a new one onto the body as shown.



11. Align the glass marks with the notches in the spacers and install the glass onto the body.
12. Press firmly on the glass to compress the sealant. Verify that the body-to-glass clearance is as shown.



13. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Adjust the upper and side sealant as shown, if necessary.



14. Install the windshield molding before the sealant hardens.
 - ① Align the marks on the molding to the roof inner line.
 - ② Install the top of the molding.
 - ③ Install the corners of the molding.
 - ④ Install the sides of the molding, starting from the top and then toward the bottom.

15. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |

16. Check for water leaks. If a leak is found, wipe the water off well and reinstall the windshield.

LIFTGATE GLASS

PREPARATION


SST

| | | |
|--|---|--|
| <p>49 0305 870A Tool set, window</p> |  | <p>For removal / installation of glass</p> |
|--|---|--|

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.




1. Liftgate lower trim
Removal / Installation page S-65
2. Rear spoiler
Removal / Installation page S-32
3. Rear wiper arm and blade
Removal / Installation page S-39


4. Liftgate molding
Removal / Installation page S-25
5. Liftgate glass
Removal note page S-46
Installation note page S-46
6. Dam

**Removal note****Liftgate glass**

1. Apply protective tape along the edge of the liftgate to protect it from damage.
2. Using an awl, make a hole through the sealant from the inside of the vehicle.
3. Pass piano wire through the hole.

**Note**


- ◆ Three locating bolts and a locating pin are installed on the liftgate glass. Use a razor knife from inside the vehicle to cut the sealant around the bolts and pin.



4. Wind each end of the wire around a bar.

5. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.


6. Remove the glass.


**Installation note****Liftgate glass**

1. Cut away the old sealant with a razor knife so that 1 to 2 mm {0.04 to 0.08 in} of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply primer after degreasing, and allow it 30 minutes to dry. Then apply new sealant to create a 2 mm {0.08 in} layer.


2. Carefully clean an area 50 mm {2.0 in} wide around the circumference of the glass and the bonding area on the liftgate.

3. Securely bond a new dam along the circumference of the glass 7 mm {0.28 in} from the edge. Allow it to dry completely.






4. Apply primer with a brush to the bonding area of the glass, body, and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately **30 minutes**.




5. After the primer has dried, apply an **11 mm {0.43 in}** high bead of repair sealant around the circumference of the glass as shown. Keep the bead of sealant smooth and even, reshaping it with a spatula where necessary.




6. Align the glass via the locating pin and bolts and install the glass onto the body. Verify that the clearance between the top of the glass and the liftgate is **8 mm {0.31 in}**.
7. Press firmly on the glass to compress the sealant and install the nuts onto the bolts.

Tightening torque:

4.0–5.8 N·m {40–60 kgf·cm, 35–52 in·lb}



8. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Adjust the upper and side sealant as shown, if necessary.



9. Install the liftgate molding before the sealant hardens.
- ① Align the mark on the glass to that on the molding.
 - ② Install the top of the molding.
 - ③ Install the corners of the molding.
 - ④ Install the sides of the molding, starting from the top and then toward the bottom.

10. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C (41°F) | Approx. 1.5 hr | 12 hr |
| 20°C (68°F) | Approx. 1 hr | 4 hr |
| 35°C (95°F) | Approx. 10 min | 2 hr |

11. Check for water leaks. If a leak is found, wipe the water off well and reinstall the liftgate glass.

VERTICAL WINDOW GLASS

PREPARATION


SST

| | | |
|--|---|--|
| <p>49 03058 70A Tool set, window</p> |  | <p>For removal / installation of glass</p> |
|--|---|--|

COMPONENTS


Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.



- | | |
|----------------------------|-----------------|
| 1. Liftgate lower trim | |
| Removal / Installation | page S-65 |
| 2. Rear spoiler | |
| Removal / Installation | page S-32 |
| 3. Vertical window molding | |
| Removal / Installation | page S-25 |


- | | |
|--------------------------|-----------------|
| 4. Vertical window glass | |
| Removal note | page S-50 |
| Installation note | page S-50 |
| 5. Dam | |

**Removal note****Vertical window glass**


1. Apply protective tape along the edge of the liftgate to protect it from damage.

If the glass will not be reused


2. Use a tool like that shown in the figure and insert the blade into the sealant.
3. Pull through the sealant around the edge of the glass.
4. Remove the glass.

**If the glass will be reused**


1. Using an awl, make a hole through the sealant from the inside of the vehicle.
2. Pass piano wire through the hole.

**Note**


- Two locating clips are installed on the vertical window glass. Use a razor knife to cut the sealant around the clips.




4. Wind each end of the wire around a bar.
5. Working with another person, saw through the sealant around the edge of the glass. Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
6. Remove the glass.

**Installation note****Vertical window glass**


1. Cut away the old sealant by using a razor knife so that 1 to 2 mm {0.04 to 0.08 in} of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it 30 minutes to dry. Then apply new sealant to create a 2 mm {0.08 in} layer.
2. Carefully clean an area 50 mm {2.0 in} wide around the circumference of the glass and the bonding area on the liftgate.




3. Securely bond a new dam 7 mm {0.28 in} from the edge of the glass as shown. Allow it to dry completely.




4. Apply primer to the bonding area of the glass, body, and molding by using a brush. Use only glass primer on the glass and body primer on the body and molding. Keep the area free of dirt and grease, and do not touch the surface. Allow the primer to dry for approximately 30 minutes.




5. After the primer has dried, apply an 11 mm {0.43 in} high bead of repair sealant around the circumference of the glass as shown. Keep the bead of sealant smooth and even, reshaping it with a spatula where necessary.



6. Align the glass via the locating clips and install the glass onto the body.
7. Press firmly on the glass to compress the sealant.



8. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact. Adjust the lower and side sealant as shown, if necessary.



9. Install the vertical window molding before the sealant hardens.

- ① Align the mark of the molding to that on the glass.
- ② Starting from the center, press the molding into place toward both ends.

10. To prevent the glass from being pushed out by air pressure if a door is closed, open all of the windows until the repair sealant has hardened.

Hardening time of repair sealant

| Temperature | Surface hardening time | Time required until car can be put into service |
|-------------|------------------------|---|
| 5°C {41°F} | Approx. 1.5 hr | 12 hr |
| 20°C {68°F} | Approx. 1 hr | 4 hr |
| 35°C {95°F} | Approx. 10 min | 2 hr |


11. Check for water leaks. If a leak is found, wipe the water off well and reinstall the vertical window glass.

SLIDING SUNROOF

COMPONENTS


Removal / Installation

1. Open the slide panel 100 mm {3.9 in} from the fully closed position.
2. Disconnect the negative battery cable.
3. Remove in the order shown in the figure, referring to **Removal note**. To remove the sunroof drive unit, remove the headliner. (Refer to page S-70.)
4. Install in the reverse order of removal, referring to **Installation note**.




| | |
|-------------------------|-----------|
| 1. Sunroof trim | |
| Removal note | page S-54 |
| Installation note | page S-56 |
| 2. Slide panel | |
| Removal note | page S-54 |
| Installation note | page S-55 |
| 3. Sunroof shim | |


| | |
|------------------------------|-----------|
| 4. Drain hose | |
| Installation note | page S-55 |
| 5. Sunroof drive unit | |
| Removal note | page S-54 |
| Installation note | page S-54 |
| Disassembly / Assembly | page S-57 |

**Removal note****Sunroof trim**


1. Tilt up the slide panel.
2. Remove the fasteners on the front side of the sunroof trim.
3. Pull down the trim and remove it from the sunroof panel.
4. Pull out the sunroof trim from between the slide panel and the roof.

**Slide panel**


1. Fully close the slide panel by using an allen wrench.
2. Remove the slide panel fixing nuts. Push up the slide panel from inside and remove it from the lower panel.

**Sunroof drive unit**


1. Remove the bolts C.
2. Loosen the nuts B.
3. Loosen the height adjusting nuts A and remove the sunroof drive unit from the body.

**Installation note****Sunroof drive unit**

1. Align the locator pins and set the sunroof drive unit to the roof panel.




2. Loosely install the sunroof drive unit to the roof panel with the height adjusting nuts.



- Loosen the set bracket attaching nuts. Position the set bracket so that it touches the roof panel fixing bracket. Tighten the fixing bracket bolts, and then tighten the nuts.

Tightening torque:


7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}



- Affix the rear of the sunroof frame to the roof panel.

Tightening torque:

7.9–10.7 N·m {80–110 kgf·cm, 70–95.4 in·lbf}




Slide panel

Install the slide panel to the lower panel. If the height difference between the slide panel and the roof panel is greater than 2.0 mm {0.08 in}, loosen the slide panel attaching nuts and insert shims between the panels.

Tightening torque:

6.4–8.8 N·m {65–90 kgf·cm, 57–78 in·lbf}




Drain hose


Note

- Apply soapy water to the drain hose and insert it fully into the sunroof frame.


- On the A-pillar side, insert one end of the hose into the sunroof frame, set the hose along the A-pillar, and insert the other end into the cowl side panel hole.
- On the B-pillar side, insert one end of the hose into the sunroof frame, and insert the other end into the rear fender panel hole via the hole in the upper part of the B-pillar.

**Sunroof trim**

1. Tilt up the slide panel. Insert the sunroof trim between the slide panel and the roof panel from the rear of the vehicle.




2. To locate the trim, match the sunroof trim guide pin and notch in the slide panel trim bracket.
3. Install the sunroof trim fasteners to the slide panel.




Disassembly note
Sunroof motor assembly

1. Remove the screws and remove the motor assembly from the sunroof frame.
2. Disconnect the sunroof motor assembly harness connector.




Rear guide

1. Remove the cable holder from the sunroof frame.
2. Remove the shutting attaching screw and spring. Remove the shutting from the guide rail.




3. Pull the rear guide rearward and remove it from the guide rail.
4. Pull the lower panel rearward and remove it from the guide rail.




Front guide

- Remove the E-ring and remove the front guide from the lower panel.




Guide rail


1. Remove the guide rail attaching screws.
2. Pry the guide rail from the sealant on the sunroof frame by using a protected screwdriver.

**Assembly note****Guide rail**


1. Clean and degrease the sunroof contact area between the sunroof frame and the guide rail.
2. Apply approximately 2 mm {0.08 in} of sealant to the sunroof frame.
3. Install the guide rail to the sunroof frame with the screws.
4. Clean any excessive sealant by using white gasoline.

**Front guide**

Install the front guide to the lower panel with the E-ring.


**Rear guide**

1. Install the lower panel to the guide rail.
2. Install the rear guide to the guide rail.








3. Install the shutter to the guide rail.

4. Install the cable holder to the sunroof frame.

**Sunroof motor assembly**

Remove the motor cover. Position the mark on the timing gear as shown in the figure by using an allen wrench.



Adjustment Slide panel Height

Adjust the height difference between the slide panel and the roof panel by using the following procedure.

Allowable height difference: 2.0 mm {0.08 in} max.

1. Remove the headliner. (Refer to page S-70.)
2. Loosen the set bracket attaching nuts.

Note

- Clockwise rotation raises the frame.

3. Turn the height adjusting nuts and adjust the sunroof frame height.
4. After adjustment, securely install the sunroof frame to the roof panel.

Gap

1. Verify that the slide panel does not interfere with the roof panel when operated.
2. If it interferes, loosen the slide panel attaching nuts and move the panel as necessary.
3. If the above adjustment is not enough, loosen the attaching screws and bolts of the sunroof frame and set bracket and carry out adjustment. (Refer to page S-54, Installation note for the sunroof drive unit.)

Moving load

1. Measure the operation time of the slide panel from fully opened to fully closed or vice versa.

Specified time: 4-7 sec.

2. If not as specified, adjust it by turning the locknut on the sunroof motor assembly.

- (1) Remove the housing cover attaching screw and the E-ring. Remove the housing cover from the motor.
- (2) Unfold the pole washers indicated by arrows.
- (3) Hold the motor shaft by using an allen wrench and turn the locknut to adjust the torque.
- (4) Fold the pole washers.

DASHBOARD AND CONSOLE

COMPONENT


Removal / Installation

1. Disconnect the negative battery cable.

Warning


- Handling the air bag module improperly can accidentally deploy the air bag, which may seriously injure you. Read **SERVICE WARNINGS** in the Body Electrical Troubleshooting Manual, section S, before handling the air bag module.

2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal.




N·m (kgf·m, lbf)


- | | |
|---|--|
| 1. Side panel Removal note below | 11. Driver-side air bag module Removal / Installation 1995 Body Electrical Troubleshooting Manual, section S |
| 2. Hood release lever Removal note below | 12. Steering wheel Removal / Installation section N |
| 3. Lower panel Removal note below | 13. Column cover |
| 4. Rear console Removal note page S-63 | 14. Combination switch Removal / Installation 1995 Body Electrical Troubleshooting Manual, section Z4 |
| 5. Ashtray | 15. Meter hood Removal note page S-64 |
| 6. Front console panel Removal note page S-63 | 16. Instrument cluster Removal / Installation 1995 Body Electrical Troubleshooting Manual, section C1 |
| 7. Front console Removal / note page S-63 | 17. Steering shaft |
| 8. Glove compartment Removal note page S-63 | 18. Upper gamish Removal note page S-64 |
| 9. Glove compartment cover | 19. Dashboard |
| 10. Passenger-side air bag module Removal / Installation 1995 Body Electrical Troubleshooting Manual, section S | |

**Removal note****Side panel**


1. Pull the front edge of the side panel forward to remove the clips from the body.
2. Pull the side panel forward to remove the hook from the body.

**Hood release lever**

Loosen the hood release lever mounting nut.


**Lower panel**

1. Remove the lower panel installation screws.
2. Pull the lower panel forward to disengage the clips.




Rear console

Remove the rear console installation screws.




Front console panel

1. Remove the front console panel installation screws.
2. Pull the front console panel forward to disengage the clips.
3. Disconnect the harness connectors.




Front console

Remove the front console installation screws and fasteners.




Glove compartment


1. Open the glove compartment and pull up on the right side.



2. Slide the glove compartment to the right to remove it.

**Meter hood**

1. Remove the meter hood installation screws.
2. Pull the meter hood forward to disengage the clips.

**Upper garnish**


1. Remove the center hole cover.
2. Remove the upper garnish installation bolt.
3. Pull the upper garnish up to disengage the clips.

TRIM

COMPONENTS


Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal note**.
2. Install in the reverse order of removal.




1. A-pillar trim
Removal note page S-66
2. Scuff plate
Removal note page S-66
3. Front side trim
4. Quarter trim
Removal note page S-66
5. B-pillar trim
Removal note page S-66
6. Door trim
Removal note (driver side) page S-66
Removal note (passenger side) page S-67


7. Rear package trim
8. Trunk end trim
Removal note page S-67
9. Rear speaker cover
10. Trunk side trim
11. Liftgate side trim
Removal note page S-67
12. Liftgate upper trim
Removal note page S-68
13. Liftgate lower trim
Removal note page S-68

**Removal note****A-pillar trim**


1. Remove the seaming welt.
2. Pull the A-pillar trim to remove the clips from the body.
3. Pull the A-pillar trim upward to remove the hook from the body.

**Scuff plate**


Pull the scuff plate to remove the clips from the body.

**Quarter trim**


1. Remove the rear seat back. (Refer to page S-76.)
2. Remove the scuff plate. (Refer above.)
3. Remove the quarter trim installation fastener.
4. Pull the quarter trim to remove the clips from the body.

**B-pillar trim**


1. Remove the seaming welt.
2. Remove the front seat belt upper anchor. (Refer to page S-73.)
3. Pull the B-pillar trim to remove the clips from the body.

**Door trim****Driver side**

1. Remove the regulator handle. (Refer to page S-11.)
2. Remove the inner handle cover.
3. Remove the door trim installation screws.




4. Pull the door trim to remove the clips from the body.
5. Lift the door trim to remove it.
6. Disconnect the harness connectors, if equipped.




Passenger side

1. Remove the regulator handle. (Refer to page S-11.)
2. Remove the inner handle.
3. Remove the cap and door trim mounting screws.




4. Pull the door trim to remove the clips from the body.
5. Lift up the door trim to remove it.
6. Disconnect the harness connectors, if equipped.




Trunk end trim

1. Remove the installation fastener.
2. Pull the trunk end trim to remove the clips from the body.
3. Lift the trunk end trim to remove it.




Liftgate side trim

Pull the liftgate side trim to remove the clips from the body.

**Liftgate upper trim**


1. Remove the liftgate side trim. (Refer to page S-67.)
2. Pull the liftgate upper trim to remove the clips from the body.

**Liftgate lower trim**

1. Remove the liftgate side trim. (Refer to page S-67.)
2. Remove the rear wiper motor or high-mount brake light cover from the body.
3. Remove the fastener.
4. Pull the liftgate lower trim to remove the clips from the body.
5. Pull the liftgate lower trim upward to remove the hook from the body.

FLOOR COVERING**COMPONENTS****Removal / Installation**

1. Disconnect the negative battery cable.
2. Remove the following:
 - a. Front seats and rear seat cushion (Refer to page S-75, 76.)
 - b. Front side trim (Refer to page S-65.)
 - c. Quarter trim (Refer to page S-65.)
 - d. Front and rear consoles (Refer to page S-61.)
3. Remove as shown in the figure.
4. Install in the reverse order of removal.




1. Cabin carpet

HEADLINER

COMPONENTS

Removal / Installation


1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal note**.
3. Install in the reverse order of removal, referring to **Installation note**.




1. Rearview mirror
2. Sunvisor and adapter
3. Overhead console
4. Assist handle
5. Seaming welt
6. A-pillar trim
Removal / Installation page S-65
7. Quarter trim
Removal / Installation page S-65

8. B-pillar trim
Removal / Installation page S-65
9. Fastener
10. Headliner
Removal note page S-72
11. Insulator

WITH SLIDING SUNROOF




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Rearview mirror 2. Sunvisor and adapter 3. Overhead console 4. Assist handle 5. Seaming welt (door) 6. A-pillar trim Removal / Installation page S-65 7. Quarter trim Removal / Installation page S-65 | <ul style="list-style-type: none"> 8. B-pillar trim Removal / Installation page S-65 9. Fastener 10. Seaming welt (sliding sunroof) 11. Headliner Removal note page S-72 Installation note page S-72 |
|---|--|

**Removal note****Headliner****Without sliding sunroof**

1. Remove the fasteners on the front side of the headliner.
Remove the clips on the rear and sides of the headliner.
2. Remove the headliner.

With sliding sunroof

1. Remove the fasteners on the front side of the headliner.
Remove the clips on the rear and sides of the headliner.
2. Remove the seaming welt and unfold the hooks at the sunroof frame flange.
3. Remove the headliner.

**Installation note****Headliner****With sliding sunroof model**

1. Fold the headliner hooks on the sunroof frame flange.
2. Install the seaming welt, and then install the headliner.

SEAT BELT


COMPONENTS

Removal / Installation

Caution

- The ELR (emergency locking retractor) has a spring that will unwind if the retractor's cover is removed. The spring cannot be rewound by hand. If this occurs, the ELR will not work properly. Therefore, do not disassemble the retractor.

1. Removal in the order shown in the figure.
2. Install in the reverse order of removal.



Front seat belt


1. Scuff plate
Removal / Installation page S-65
2. Quarter trim
Removal / installation page S-65
3. Upper anchor
4. Front seat belt
Installation page S-74
5. Front buckle

Rear seat belt


6. Rear speaker cover
7. Rear seat belt
Inspection page S-74
8. Rear seat cushion
Removal / Installation page S-76
9. Rear buckle

SEAT BELT**Inspection****Webbing**


1. Inspect the webbing for scars, tears, and wear.
2. Inspect the fittings for deformation.
2. If a problem is found, replace the seat belt assembly.

**Emergency locking retractor**


1. Verify that the belt can be pulled out smoothly, and that it moves smoothly when worn.
2. Verify that the retractor locks when the belt is quickly pulled.



3. Remove the retractor.
4. Hold the retractor as it would be installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at approximately 30 degrees inclination.
7. If not as specified, replace the seat belt assembly.



REAR SEAT

**Rear seat**


1. Rear seat cushion
2. Rear seat back
Disassembly / Assembly page S-79
3. Rear seat back hinge

Rear seat back striker

4. Trunk end trim
Removal / Installation page S-65
5. Rear speaker cover
6. Trunk side trim
Removal / Installation page S-65
7. Rear seat back striker


Disassembly / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly note**.
2. Assemble in the reverse order of disassembly.



- | | |
|--------------------|----------------------------------|
| 1. Headrest | 11. Recliner knuckle |
| 2. Tilt knob cap | 12. Seat back trim |
| 3. Tilt knob | Disassembly note page S-80 |
| 4. Lift knob cap | 13. Pole guide |
| 5. Lift knob | 14. Seat back pad |
| 6. Recliner knob | 15. Seat back frame |
| 7. Front buckle | 16. Seat cushion trim |
| 8. Slide adjuster | Disassembly note page S-80 |
| 9. Seat side cover | 17. Seat cushion pad |
| 10. Tilt lever | 18. Seat cushion frame |

PASSENGER SEAT




N.m (kgf-m, ft-lbf)

- 1. Headrest
- 2. Recliner knob
- 3. Seat side cover
- 4. Front buckle
- 5. Slide adjuster
- 6. Recliner knuckle
- 7. Seat back trim


- 8. Pole guide
- 9. Seat back pad
- 10. Seat back frame
- 11. Seat cushion trim
- Disassembly note page S-80
- 12. Seat cushion pad
- 13. Seat cushion frame

REAR SEAT




1. Trunk carpet


2. Rear seat back catch lock
3. Rear seat back catch knob

**Disassembly note****Seat back trim**


1. Remove the hog rings from the lower part of the seat back trim.




2. Pull the seat back trim away from the padding and remove the remaining hog rings.



3. Remove the pole guide by using pliers as shown in the figure.

**Seat cushion trim**

1. Remove the hog rings from the bottom of the seat cushion trim.



2. Pull the seat cushion trim away from the padding and remove the remaining hog rings.

SPECIAL TOOLS

| | |
|---|-------|
| GENERAL INFORMATION | ST- 2 |
| ENGINE (K8 DOHC, B6 DOHC) | ST- 3 |
| CLUTCH AND MANUAL TRANSAXLE (F25M-R, G25M-R) | ST- 4 |
| AUTOMATIC TRANSAXLE (FA4A-EL) | ST- 6 |
| FRONT AND REAR AXLES | ST- 7 |
| STEERING SYSTEM | ST- 8 |
| BRAKING SYSTEM | ST-10 |
| FRONT AND REAR SUSPENSIONS | ST-12 |
| AIR CONDITIONER SYSTEM | ST-12 |
| CHECKER AND OTHER EQUIPMENT | ST-12 |

GENERAL INFORMATION

The letters A and B in the priority column indicate the degree of importance of each tool.









A . . . Necessary for performing operation. All service shops should have these tools.









B . . . Selective

Not as necessary as tools ranked A, but these tools will help to perform repairs more easily and efficiently.

When ordering tool sets, check the List in the Parts Catalogue to make sure that some tools in the set are duplicated in other sets you may already have. If they are, instead of ordering the set, order only the tools that are needed.

ENGINE (K8 DOHC, B6 DOHC)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|--|
| 49 0107 680A Engine stand Ⓐ | A |  |
| 49 L010 1A0 Hanger set, engine stand Ⓒ | A |  |
| 49 E010 1A0 Hanger set engine (K8 DOHC) Ⓔ | A |  |
| 49 E010 1A1 Hanger set engine (with 49 L010 1A0 K8 DOHC) Ⓔ | A |  |
| 49 0636 100B Arm, valve spring lifter | A |  |
| 49 L012 0A0 Installer set, valve seal & valve guide | A |  |
| 49 B012 005 Remover & installer, valve guide | A |  |
| 49 L011 0A0B Setting tool set, piston pin (K8 DOHC) | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 E011 1A1 Holder (K8 DOHC) | A |  |
| 49 D011 102 Lock tool, crankshaft (B6 DOHC) | A |  |
| 49 S120 710 Holder, coupling flange | A |  |
| 49 E011 1A0 Brake set, ring gear | A |  |
| 49 1285 071 Puller, needle bearing | A |  |
| 49 S120 170 Remover, valve seal | A |  |
| 49 B012 0A2 Pivot | A |  |
| 49 E011 002 Screw (K8 DOHC) | A |  |

ST






Note SST Ⓐ, Ⓔ, Ⓒ and Ⓓ are used in the following combinations.





• Use Ⓐ + Ⓔ.

• Use Ⓐ + Ⓒ + Ⓓ.



Either combination can be used.



ENGINE (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 E011 001 Guide, piston pin (K8 DOHC) | A |  |
| 49 H018 001 Knock sensor wrench (K8 DOHC) | A |  |
| 49 0221 061A Installer, Piston Pin (B6 DOHC) | A |  |
| 49 W033 105 Installer, oil seal (B6 DOHC) New SST | A |  |
| 49 H010 401 Installer, oil seal (K8 DOHC) New SST | A |  |









| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 G014 001 Wrench, oil filter | A |  |
| 49 9200 145 Adapter, radiator cap tester | A |  |
| 49 E301 144 Removing plate | A |  |
| 49 B014 001 Installer, oil seal (K8 DOHC) New SST | A |  |








CLUTCH AND MANUAL TRANSAXLE (F25M-R, G25M-R)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 G017 5A0 Engine support | A |  |
| 49 SE01 310A Clutch disc centering tool | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 G030 440 Holder, primary shaft (G25M-R) | A |  |
| 49 G030 455 Holder, differential side gear (G25M-R) | A |  |



CLUTCH AND MANUAL TRANSAXLE (CONT'D)



| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|--|
| 49 G030 370 Removing plate | A |  |
| 49 0636 145 Puller, fan pulley boss | A |  |
| 49 G017 1A0 Remover set, bearing | A |  |
| 49 G030 380D Shim selector set | A |  |
| 49 F401 440 Holder, primary shaft (F25M-R) | A |  |
| 49 0187 520 Bearing puller, rear axle shaft (F25M-R) | A |  |
| 49 G019 0A0 Hanger, transaxle | A |  |
| 49 FT01 361 Remover, bearing New SST | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 F401 330B Installer set, bearing | A |  |
| 49 B001 795 Installer, oil seal | A |  |
| 49 B017 102 Preload adapter (G25M-R) | A |  |
| 49 G017 202 Preload adapter (G25M-R) | A |  |
| 49 0839 425C Puller set, bearing | A |  |
| 49 G030 338 Attachment E (G25M-R) New SST | A |  |
| 49 F401 381B Selector ø60 (F25M-R) New SST | A |  |






ST






CLUTCH AND MANUAL TRANSAXLE (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 G019 019 Bolt set (F25M-R) New SST | A |  |
| 49 B092 369 Attachment C (F25M-R) New SST | A |  |






| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 B027 002A Preload Adapter (F25M-R) New SST | A |  |
| 49 B092 371 Attachment E (F25M-R) (FA4A-EL) New SST | A |  |






AUTOMATIC TRANSAXLE(FA4L-EL)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|------------------------------------|----------|---|
| 49 G030 795 Installer, oil seal | A |  |
| 49 G019 029 Nut | A |  |
| 49 B019 002 Body | A |  |
| 49 H019 002 Adapter | A |  |
| 49 B019 008 Leak checker | A |  |



| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 0378 400B Gauge set, oil pressure | A |  |
| 49 B019 901 Oil pressure gauge | A |  |
| 49 G019 017 installer, oil seal | A |  |
| 49 S120 765 Installer, dust boot | A |  |
| 49 B019 004 Adapter (B6 DOHC) | B |  |



AUTOMATIC TRANSAXLE (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 FT01 439 Holder, idler gear shaft | A |  |
| 49 G019 0A2 Holder, turbine shaft | A |  |
| 49 G019 025 Body B | A |  |
| 49 G019 027 Attachment A | A |  |
| 49 FT01 384 Collar | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|----------------------------------|----------|---|
| 49 B019 005 Adapter (K8 DOHC) | B |  |
| 49 G019 013 Remover, bearing | A |  |
| 49 G019 026 Plate | A |  |
| 49 B019 007 Preload adaptor | A |  |
| 49 D019 001 Bolt | A |  |





FRONT AND REAR AXLES





| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|------------------------------|----------|--|
| 49 G033 102 Handle | A |  |
| 49 H034 201 Support block | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---------------------------------------|----------|---|
| 49 V001 795 Installer, oil seal | A |  |
| 49 F027 0A1 Installer set, bearing | A |  |




ST




FRONT AND REAR AXLES (CONT'D)

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 F026 102 Installer bearing | A |  |
| 49 W027 003 Installer bearing | A |  |
| 49 H027 002 Remover bearing | A |  |
| 49 B025 004 Installer dust seal (B6 DOHC) | A |  |

















| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 F026 103 Puller, wheel hub | A |  |
| 49 E033 101 Installer, dust cover | A |  |
| 49 G030 727 Attachment | A |  |
| 49 B025 005 Installer dust cover (K8 DOHC) | A |  |

STEERING SYSTEM

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|--|
| 49 T028 3A0 Puller set, ball joint New SST | A |  |
| 49 H002 671 Adapter | A |  |
| 49 1232 670A Gauge set, power steering | A |  |















| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 B032 321 Adapter (B6 DOHC) | A |  |
| 49 F032 301 Hanger, power steering pump (K8 DOHC) | B |  |
| 49 E032 303 Installer, bearing (K8 DOHC) | A |  |

STEERING SYSTEM (CONT'D)








| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION | TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|--|--|----------|---|
| 49 G032 3A4 Adapter, power steering gauge (K8 DOHC) New SST | A |  | 49 E032 304 Installer, pinion seal (K8 DOHC) | A |  |
| 49 E032 301 Installer, oil seal (K8 DOHC) | A |  | 49 G032 3A1 Joint hose set | A |  |
| 49 E032 302 Installer guide, oil seal and spacer (K8 DOHC) | A |  | 49 G032 3A0 Repair set, power steering | A |  |
| 49 B032 311 Protector, slipper seal (B6 DOHC) | A |  | 49 B032 315 Installer, oil seal (B6 DOHC) | A |  |
| 49 B032 309 Installer body, pinion seal (B6 DOHC) | A |  | 49 B032 316 Support block, plug (B6 DOHC) | A |  |
| 49 B032 310 Protector, pinion seal (B6 DOHC) | A |  | 49 B032 317 Remover, bearing & oil seal (B6 DOHC) | A |  |
| 49 B032 306 Wrench, plug (B6 DOHC) | A |  | 49 B032 312 Protector, slipper seal (B6 DOHC) | A |  |
| 49 B032 320 Wrench (B6 DOHC) | A |  | 49 G030 797 Handle (B6 DOHC) | A |  |








ST

STEERING SYSTEM (CONT'D)





| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION | TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|--|----------|---|
| 49 B032 314 Slipper seal former (B6 DOHC) | A |  | 49 H032 301 Wrench (K8 DOHC) | A |  |
| 49 B032 307 Wrench, outer box (B6 DOHC) | A |  | 49 B032 304 Adapter (B6 DOHC) | A |  |
| 49 B032 313 Protector, outer box (B6 DOHC) | A |  | 49 B032 318 Guide, rod seal (B6 DOHC) | A |  |
| 49 B032 308 Remover body, rod seal (B6 DOHC) | A |  | 49 B032 319 Protector body, rod seal (B6 DOHC) | A |  |
| 49 G032 335 Installer, oil seal (B6 DOHC) | A |  | 49 B032 305 Holder, power steering pump (B6 DOHC) | A |  |
| 49 0259 770B Wrench, flare nut | A |  | 49 E043 001A Gauge, push rod (K8 DOHC) | A |  |
| 49 Z043 0A0 Adjuster set piston (K8 DOHC) | A |  | 49 E043 002A Installer, retainer (K8 DOHC) | A |  |




BRAKING SYSTEM

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|--|
| 49 0221 600C Expand tool, disc brake | A |  |
| 49 Z043 001 Wrench, cap nut (K8 DOHC) | A |  |
| 49 M005 796 Installer bearing (K8 DOHC) (ABS) | A |  |
| 49 G025 001 Sensor rotor installer (K8 DOHC) | A |  |
| 49 0208 701A Air out tool, boot | B |  |
| 49 B025 003 Sensor rotor installer (B6 DOHC) | A |  |
| 49 U043 0A0 Gauge set oil pressure | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 E043 003 Lock tool, turning | A |  |
| 49 B043 004 Socket wrench (K8 DOHC) | A |  |
| 49 Z043 002 Adapter (K8 DOHC) | A |  |
| 49 F043 001 Adjust gauge (B6 DOHC) | A |  |
| 49 R015 002 Hose, pressure (K8 DOHC) | A |  |
| 49 B043 001 Adjust gauge (B6 DOHC) | A |  |
| 49 FA18 602 Wrench disc brake piston | A |  |

FRONT AND REAR SUSPENSIONS


| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|---|
| 49 1243 785 Installer, dust boot | A |  |
| 49 0180 510B Attachment preload | B |  |
| 49 T034 1A0 Compressor set, coil spring ⓑ New SST | A |  |
| 49 T034 101 Compressor, coil spring ⓓ New SST | A |  |


| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|---|----------|--|
| 49 G034 1A0 Compressor, coil spring ⓐ | A |  |
| 49 B034 201 Support block | B |  |
| 49 T034 105 Attachment ⓒ New SST | B |  |

Note SST ⓐ, ⓑ, ⓒ and ⓓ are used in the following combinations.


- Use ⓐ only.
- Use ⓑ only.
- Use ⓒ + ⓓ + 49 0107 680A Engine stand
Either combination can be used.


AIR CONDITIONER SYSTEM

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|-------------------------------------|----------|---|
| 49 B061 005 Replacer, seal plate | A |  |

















| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|-------------------------------------|----------|---|
| 49 B061 006 Replacer, shaft seal | A |  |

CHECKER AND OTHER EQUIPMENT

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|--|----------|---|
| 49 0839 285 Checker, fuel & thermometer | A |  |

| TOOL NUMBER & DESCRIPTION | PRIORITY | ILLUSTRATION |
|------------------------------------|----------|---|
| 49 0187 280 Gauge, oil pressure | B |  |

CHECKER AND OTHER EQUIPMENT (CONT'D)

| | | | | | |
|--|---|--|---|---|---|
| 49 H018 9A1 Checker, self-diagnosis | A |  | 49 H066 002 Deployment tool | A |  |
| 49 9200 162A Monitor, engine signal | A |  | 49 9200 020A V-ribbed belt tension gauge | B |  |
| 49 G018 904 Sheet (EC-AT) | A |  | 49 E018 9A0 Injector checker (K8 DOHC) | B |  |
| 49 UN01 050 Radio Removing tool | A |  | 49 B019 9A0 System selector | A |  |
| 49 0305 870A Tool set, window | A |  | 49 G050 1A0 Remover, sealant | A |  |
| 49 L018 901 Injector checker (B6 DOHC) | A |  | 49 D019 902 Adapter harness (EC-AT) | A |  |
| 49 T018 902 Adapter harness (ECM) New SST | A |  | 49 G018 906 Sheet (ECM) New SST | A |  |
| 49 H066 004 Short circuit connector | A |  | 49 D088 008 Harness adapter power (ECM) New SST | A |  |

TECHNICAL DATA

| | |
|---|-------|
| B1. ENGINE (B6) | TD- 2 |
| B2. ENGINE (K8) | TD- 6 |
| D1. LUBRICATION SYSTEM (B6) | TD- 9 |
| D2. LUBRICATION SYSTEM (K8) | TD-10 |
| E1. COOLING SYSTEM (B6) | TD-10 |
| E2. COOLING SYSTEM (K8) | TD-11 |
| F1. FUEL AND EMISSION CONTROL SYSTEMS (B6) | TD-13 |
| F2. FUEL AND EMISSION CONTROL SYSTEMS (K8) | TD-14 |
| G. ENGINE ELECTRICAL SYSTEM | TD-15 |
| H. CLUTCH | TD-16 |
| J1 AND J2. MANUAL TRANSAXLE | TD-17 |
| K. AUTOMATIC TRANSAXLE | TD-19 |
| M. FRONT AND REAR AXLES | TD-23 |
| N. STEERING SYSTEM | TD-23 |
| P. BRAKING SYSTEM | TD-24 |
| Q. WHEELS AND TIRES | TD-25 |
| R. SUSPENSION | TD-25 |
| T. BODY ELECTRICAL SYSTEM | TD-27 |
| U. HEATER AND AIR CONDITIONER SYSTEMS | TD-27 |
| STANDARD BOLT AND NUT TIGHTENING TORQUES | TD-27 |

B1. ENGINE (B6)

| Item | | Engine | B6 DOHC | | |
|---|--|---|-----------------------------|-----------------------------|-----------------|
| Type | | | Gasoline, 4-cycle | | |
| Cylinder arrangement and number | | | In-line, 4-cylinders | | |
| Combustion chamber | | | Pentroof | | |
| Valve system | | | DOHC, belt-driven 16 valves | | |
| Bore × Stroke | | mm {in} | 78.0 × 83.6 {3.07 × 3.29} | | |
| Total piston displacement | | ml {cc, cu in} | 1,598 {1,598, 97.5} | | |
| Compression ratio | | | 9.4 | | |
| Compression pressure kPa {kgf/cm ² , psi}-rpm | | Standard | 1,324 {13.5, 192}-300 | | |
| | | Minimum | 932 {9.5, 135}-300 | | |
| | | Maximum difference between each cylinder | 196 {2.0, 28} | | |
| Valve timing | | IN | Open BTDC | 5° | |
| | | | Close ABDC | 51° | |
| | | EX | Open BBDC | 15° | |
| | | | Close ATDC | 55° | |
| Valve clearance mm {in} | | IN | 0: Maintenance-free | | |
| | | EX | 0: Maintenance-free | | |
| Cylinder head | | | | | |
| Height | | mm {in} | 133.8–134.0 {5.268–5.275} | | |
| Distortion | | mm {in} | 0.15 {0.006} max. | | |
| Grinding | | mm {in} | 0.10 {0.004} max. | | |
| Cylinder head-to-HLA clearance mm {in} | | Standard | 0.025–0.066 {0.0010–0.0026} | | |
| | | Maximum | 0.18 {0.0071} | | |
| Valve and valve guide | | | | | |
| Valve head diameter | | mm {in} | IN | 30.9–31.1 {1.217–1.224} | |
| | | EX | 26.1–26.3 {1.028–1.035} | | |
| Valve head margin thickness | | mm {in} | IN | 0.9–1.3 {0.035–0.051} | |
| | | EX | 1.0–1.4 {0.039–0.055} | | |
| Valve face angle | | | IN | 45° | |
| | | | EX | 45° | |
| Valve length | | mm {in} | IN | Standard | 105.29 {4.1452} |
| | | | | Minimum | 104.89 {4.1295} |
| | | EX | Standard | 105.39 {4.1492} | |
| | | | Minimum | 104.99 {4.1335} | |
| Valve stem diameter | | mm {in} | IN | 5.970–5.985 {0.2350–0.2356} | |
| | | EX | 5.965–5.980 {0.2348–0.2354} | | |
| Guide inner diameter | | mm {in} | | 6.01–6.03 {0.2366–0.2374} | |
| Valve stem-to-guide clearance | | mm {in} | IN | 0.025–0.060 {0.0010–0.0024} | |
| | | | EX | 0.030–0.065 {0.0012–0.0026} | |
| | | | Maximum | 0.20 {0.008} | |
| Guide projection (Height "A") | | mm {in} | IN | 16.8–17.4 {0.661–0.685} | |
| | | EX | 16.8–17.4 {0.661–0.685} | | |

| Item | | Engine | B6 DOHC | |
|---|----------------------|-----------------------|---|-----------------|
| Valve seat | | | | |
| Seat angle | | IN | 45° | |
| | | EX | 45° | |
| Seat contact width | | mm{in} | 0.8–1.4 {0.031–0.055} | |
| Seat sinking | mm {in} | Standard | 43.5 {1.713} | |
| | | Maximum | 45.0 {1.772} | |
| Valve spring | | | | |
| Free length | mm {in} | IN | 48.01 {1.8902} | |
| | | EX | 48.34 {1.9031} | |
| Minimum length | mm {in} | IN | 40.0 {1.575} with a set load of 217.0–245.6 N {22.13–25.05 kgf, 48.69–55.11 lbf} | |
| | | EX | 40.0 {1.575} with a set load of 209.6–242.2 N {21.37–24.70 kgf, 23.57–54.34 lbf} | |
| Out-of-square | mm {in} | IN | 1.68 {0.0661} max. | |
| | | EX | 1.69 {0.0665} max. | |
| Setting load/height | N {kgf, lbf}/mm {in} | IN | 217–246 {22.1–25.1, 48.6–55.2}/40.0 {1.575} | |
| | | EX | 174–196 {17.7–20.0, 38.9–44.0}/40.0 {1.575} | |
| Camshaft | | | | |
| Cam height | mm {in} | IN | Standard | 40.888 {1.6098} |
| | | | Minimum | 40.688 {1.6019} |
| | | EX | Standard | 40.886 {1.6097} |
| | | | Minimum | 40.686 {1.6018} |
| Journal diameter | mm {in} | Standard (No.1–No.5) | 33.961–34.000 {1.3370–1.3386} | |
| | | Out-of-round | 0.05 {0.002} max. | |
| Camshaft bearing oil clearance | mm {in} | Standard (No.1–No.5) | 0.035–0.081 {0.0014–0.0031} | |
| | | Maximum | 0.15 {0.006} | |
| Camshaft runout | | mm{in} | 0.03 {0.0012} max. | |
| Camshaft end play | mm {in} | Standard | 0.07–0.19 {0.0028–0.0074} | |
| | | Maximum | 0.20 {0.008} | |
| Cylinder block | | | | |
| Height | | mm {in} | 221.5 {8.720} | |
| Distortion | | mm {in} | 0.05 {0.002} max. | |
| Cylinder bore diameter | mm{in} | Standard size | 78.006–78.013 {3.0711–3.0713} | |
| | | 0.25{0.010} oversize | 78.256–78.263 {3.0809–3.0812} | |
| | | 0.50{0.020} oversize | 78.506–78.513 {3.0908–3.0910} | |
| Cylinder bore taper and out-of-round | | mm {in} | 0.019 {0.0007} max. | |
| Piston | | | | |
| Piston diameter Measured at 90° to pin bore axis and 16.5mm {0.650 in} below oil ring groove | mm {in} | Standard size | 77.954–77.974 {3.0690–3.0698} | |
| | | 0.25 {0.010} oversize | 78.211–78.217 {3.0792–3.0794} | |
| | | 0.50 {0.020} oversize | 78.461–78.467 {3.0890–3.0892} | |
| Piston-to-cylinder clearance | mm {in} | Standard | 0.039–0.052 {0.0015–0.0020} | |
| | | Maximum | 0.15 {0.006} | |

TD

| Item | | Engine | B6 DOHC |
|--|------------------------|------------|-------------------------------|
| Piston ring | | | |
| Thickness | mm {in} | Top | 1.47–1.49 {0.0579–0.0587} |
| | | Second | 1.47–1.49 {0.0579–0.0587} |
| End gap (Measured in cylinder) | mm {in} | Top | 0.15–0.30 {0.006–0.012} |
| | | Second | 0.30–0.45 {0.012–0.018} |
| | | Oil (rail) | 0.20–0.70 {0.008–0.028} |
| | | Maximum | 1.0 {0.039} |
| Ring groove width in piston | mm {in} | Top | 1.52–1.54 {0.0598–0.0606} |
| | | Second | 1.52–1.54 {0.0598–0.0606} |
| | | Oil | 4.02–4.04 {0.1583–0.1591} |
| Piston ring-to-ring groove clearance | mm {in} | Top | 0.03–0.07 {0.0012–0.0028} |
| | | Second | 0.03–0.07 {0.0012–0.0028} |
| | | Maximum | 0.15 {0.006} |
| Piston pin | | | |
| Diameter | mm {in} | | 19.987–19.993 {0.7869–0.7871} |
| Piston-to-pin clearance | mm {in} | | –0.005–0.013 {–0.0002–0.0005} |
| Connecting rod bush-to-piston pin clearance | mm {in} | | 0.010–0.027 {0.0004–0.0010} |
| Connecting rod and connecting rod bearing | | | |
| Length (Center to center) | mm {in} | | 132.85–132.95 {5.230–5.234} |
| Bending | mm {in} | | 0.075 {0.0030} max./50 {1.97} |
| Small end bore (Bush inner diameter) | mm {in} | | 20.003–20.014 {0.7875–0.7880} |
| Big end bore | mm {in} | | 48.000–48.016 {1.8898–1.8904} |
| Big end width | mm {in} | | 21.838–21.890 {0.8598–0.8618} |
| Connecting rod side clearance | mm {in} | Standard | 0.110–0.262 {0.0043–0.0103} |
| | | Maximum | 0.30 {0.012} |
| Crankshaft | | | |
| Crankshaft runout | mm {in} | | 0.04 {0.0016} max. |
| Main journal diameter | Standard size | Standard | 49.938–49.956 {1.9661–1.9668} |
| | | Minimum | 49.904 {1.9647} |
| | 0.25 {0.010} undersize | Standard | 49.704–49.708 {1.9568–1.9570} |
| | | Minimum | 49.652 {1.9548} |
| | 0.50 {0.020} undersize | Standard | 49.454–49.458 {1.9470–1.9472} |
| | | Minimum | 49.402 {1.9450} |
| | 0.75 {0.030} undersize | Standard | 49.204–49.208 {1.9372–1.9373} |
| | | Minimum | 49.152 {1.9351} |
| Main journal taper and out-of-round | mm {in} | | 0.05 {0.002} max. |
| Crankpin diameter | Standard size | Standard | 44.940–44.956 {1.7693–1.7699} |
| | | Minimum | 44.908 {1.7680} |
| | 0.25 {0.010} undersize | Standard | 44.690–44.706 {1.7594–1.7601} |
| | | Minimum | 44.658 {1.7582} |
| | 0.50 {0.020} undersize | Standard | 44.440–44.456 {1.7496–1.7502} |
| | | Minimum | 44.408 {1.7483} |
| | 0.75 {0.030} undersize | Standard | 44.190–44.206 {1.7398–1.7404} |
| | | Minimum | 44.158 {1.7385} |
| Crankpin taper and out-of-round | mm {in} | | 0.05 {0.002} max. |

| Item | | Engine | B6 DOHC |
|---|-----------------------|-----------------------------|--|
| Main bearing | | | |
| Main journal bearing oil clearance mm {in} | Standard | 0.018–0.036 {0.0007–0.0014} | |
| | Maximum | 0.10 {0.004} | |
| Available undersize bearing | | mm {in} | 0.25 {0.010}, 0.50 {0.020}, 0.75 {0.030} |
| Crankpin bearing | | | |
| Crankpin bearing oil clearance mm {in} | Standard | 0.028–0.068 {0.0011–0.0027} | |
| | Maximum | 0.10 {0.004} | |
| Available undersize bearing | | mm {in} | 0.25 {0.010}, 0.50 {0.020}, 0.75 {0.030} |
| Thrust bearing | | | |
| Crankshaft end play mm {in} | Standard | 0.080–0.282 {0.0031–0.0111} | |
| | Maximum | 0.30 {0.012} | |
| Bearing width mm {in} | Standard size | | 2.500–2.550 {0.0984–0.1004} |
| | 0.25 {0.010} oversize | | 2.625–2.675 {0.1033–0.1053} |
| | 0.50 {0.020} oversize | | 2.750–2.800 {0.1083–0.1102} |
| | 0.75 {0.030} oversize | | 2.875–2.925 {0.1132–0.1152} |
| Timing belt | | | |
| Belt deflection | mm {in} | 98 N {10 kgf, 22 lbf} | 9.0–11.5 {0.35–0.45} |

B2. ENGINE (K8)

| Item | | Engine | K8 DOHC |
|---|--|----------------|--------------------------------|
| Type | | | Gasoline, 4-cycle |
| Cylinder arrangement and number | | | 60° vconfiguration 6 cylinders |
| Combustion chamber | | | Pentroof |
| Valve system | | | DOHC, belt-driven 24 valves |
| Bore × Stroke | | mm {in} | 75 × 69.6 {2.95 × 2.74} |
| Total piston displacement | | ml {cc, cu in} | 1,844 {1,844, 112.4} |
| Compression ratio | | | 9.2 |
| Compression pressure kPa {kgf/cm ² , psi}-rpm | Standard | | 1,334 {13.6, 198-300} |
| | Minimum | | 981 {10.0, 142-300} |
| | Maximum difference between each cylinder | | 196 {2.0, 28} |
| Valve timing | IN | Open BTDC | 6° |
| | | Close ABDC | 37° |
| | EX | Open BBDC | 49° |
| | | Close ATDC | 6° |
| Valve clearance | mm {in} | IN | 0: Maintenance-free |
| | | EX | 0: Maintenance-free |
| Cylinder head | | | |
| Height | | mm {in} | 133.5-133.6 {5.252-5.259} |
| Distortion | | mm {in} | 0.10 {0.004} max. |
| Grinding | | mm {in} | 0.15 {0.006} max. |
| Cylinder head-to-HLA clearance | mm {in} | Standard | 0.025-0.066 {0.00099-0.00259} |
| | | Maximum | 0.18 {0.0071} |
| Valve and valve guide | | | |
| Valve head diameter | mm {in} | IN | 28.35-28.65 {1.117-1.127} |
| | | EX | 22.95-23.25 {0.904-0.915} |
| Valve head margin thickness | mm {in} | IN | 0.9 {0.035} min. |
| | | EX | 1.0 {0.039} min. |
| Valve face angle | | IN | 45° |
| | | EX | 45° |
| Valve length | IN | Standard | 94.11 {3.7051} |
| | | Minimum | 93.61 {3.6854} |
| | EX | Standard | 95.19 {3.7476} |
| | | Minimum | 94.69 {3.7279} |
| Valve stem diameter | mm {in} | IN | 5.970-5.985 {0.2351-0.2356} |
| | | EX | 5.965-5.980 {0.2349-0.2354} |
| Guide inner diameter | | mm {in} | 6.01-6.03 {0.2367-0.2374} |
| Valve stem-to-guide clearance | mm {in} | IN | 0.025-0.060 {0.0010-0.0023} |
| | | EX | 0.030-0.065 {0.0012-0.0025} |
| | | Maximum | 0.20 {0.008} |
| Guide projection (Height "A") | mm {in} | IN | 14.7-15.3 {0.579-0.602} |
| | | EX | 12.2-12.8 {0.481-0.503} |

| Item | | Engine | K8 DOHC | | | |
|--------------------------------------|--|------------------|-----------------------|---|-------------------------------|-------------------------------|
| Valve seat | | | | | | |
| Seat angle | | IN | 45° | | | |
| | | EX | 45° | | | |
| Seat contact width | | mm {in} | IN | 0.8-1.4 {0.032-0.055} | | |
| | | | EX | 0.8-1.4 {0.032-0.055} | | |
| Seat sinking | | mm {in} | IN | Standard | 41.5 {1.634} | |
| | | | | Maximum | 43.1 {1.697} | |
| | | EX | Standard | 41.5 {1.634} | | |
| | | | Maximum | 43.1 {1.697} | | |
| Valve spring | | | | | | |
| Free length | | Standard | mm {in} | 46.92 {1.847} | | |
| | | Minimum | mm {in}/ N {kgf, lbf} | 38.7 {1.524}/233-263 {23.75-26.88, 171.8-194.4} | | |
| Out-of-square | | | mm{in} | 1.63 {0.064} | | |
| Camshaft | | | | | | |
| Cam height | | mm {in} | IN | Standard | 42.665 {1.6797} | |
| | | | | Wear limit | 42.465 {1.6718} | |
| | | EX | Standard | 43.516 {1.7132} | | |
| | | | Wear limit | 43.318 {1.705} | | |
| Journal diameter | | Journal number | | No.1 | No.2, 3, 4 | |
| | | RH cylinder head | IN | 29.975-29.995 {1.1802-1.1809} | 25.910-25.930 {1.0201-1.0208} | 25.940-25.960 {1.0213-1.0220} |
| | | | EX | 25.940-25.960 {1.0213-1.0220} | | |
| | | LH cylinder head | IN | 25.940-25.960 {1.0213-1.0220} | | |
| | | | EX | 29.975-29.995 {1.1802-1.1809} | | |
| | | Out-of-round | | 0.02 {0.0008} | | |
| Camshaft bearing oil clearance | | mm {in} | RH cylinder head | IN | 0.040-0.081 {0.0016-0.0031} | |
| | | | | EX | | 0.070-0.111 {0.0028-0.0043} |
| | | LH cylinder head | IN | 0.040-0.081 {0.0016-0.0031} | | |
| | | | EX | | | |
| Maximum | | 0.150 {0.0059} | | | 0.120 {0.0047} | |
| Camshaft runout | | mm{in} | 0.02 {0.0008} max. | | | |
| Camshaft end play | | mm {in} | Standard | 0.05-0.10 {0.0020-0.0039} | | |
| | | | Maximum | 0.14 {0.006} | | |
| Cylinder block | | | | | | |
| Distortion | | | mm {in} | 0.15 {0.006} max. | | |
| Cylinder bore diameter | | mm {in} | Standard size | 75.000-75.022 {2.9528-2.9536} | | |
| | | | 0.25 {0.010} oversize | 75.250-75.272 {2.9626-2.9634} | | |
| | | | 0.50 {0.020} oversize | 75.500-75.522 {2.9725-2.9733} | | |
| Cylinder bore taper and out-of-round | | | mm {in} | 0.022 {0.0009} max. | | |
| Piston | | | | | | |
| Piston diameter | | mm {in} | Standard size | 74.953-74.985 {2.9509-2.9521} | | |
| | | | 0.25 {0.010} oversize | 75.203-75.235 {2.9608-2.9620} | | |
| | | | 0.50 {0.020} oversize | 75.453-75.485 {2.9706-2.9718} | | |
| Piston to cylinder clearance | | mm {in} | Standard | 0.028-0.056 {0.0011-0.0022} | | |
| | | | Maximum | 0.15 {0.006} | | |

TD

| Item | | Engine | K8 DOHC | |
|--|---------|------------------------|-------------------------------|-------------------------------|
| Piston ring | | | | |
| Thickness | mm {in} | Top | 1.47–1.50 {0.0579–0.0590} | |
| | | Second | 1.47–1.49 {0.0579–0.0586} | |
| End gap (Measured in the cylinder) | mm {in} | Top | 0.15–0.28 {0.006–0.011} | |
| | | Second | 0.25–0.38 {0.010–0.014} | |
| | | Oil (rail) | 0.20–0.70 {0.008–0.027} | |
| | | Maximum | 1.0 {0.039} | |
| Ring groove width in piston | mm {in} | Top | 1.520–1.535 {0.0599–0.0604} | |
| | | Second | 1.520–1.535 {0.0599–0.0604} | |
| | | Oil | 3.02–3.04 {0.1189–0.1196} | |
| Piston ring-to-ring groove clearance | mm {in} | Top | 0.020–0.065 {0.008–0.0025} | |
| | | Second | 0.030–0.065 {0.0012–0.0025} | |
| | | Maximum | 0.15 {0.006} | |
| Piston pin | | | | |
| Diameter | | mm {in} | 18.974–18.980 {0.7470–0.7472} | |
| Piston-to-piston pin clearance | | mm {in} | 0.008–0.026 {0.0004–0.0010} | |
| Connecting rod and connecting rod bearing | | | | |
| Length (Center to center) | | mm {in} | 140.60–140.70 {5.538–5.539} | |
| Bending | | mm {in} | 0.15 {0.059} / 100 {3.937} | |
| Small end bore (Bush inner diameter) | | mm {in} | 18.943–18.961 {0.7458–0.7464} | |
| Big end bore | | mm {in} | 51.000–51.015 {2.0079–2.0084} | |
| Big end width | | mm {in} | 21.338–21.390 {0.8401–0.8421} | |
| Connecting rod side clearance | mm {in} | Standard | 0.178–0.330 {0.0070–0.0129} | |
| | | Maximum | 0.40 {0.016} | |
| Crankshaft | | | | |
| Crankshaft runout | | mm {in} | 0.04 {0.0016} max. | |
| Main journal diameter | mm {in} | Standard size | Standard | 61.938–61.955 {2.4385–2.4391} |
| | | | Minimum | 61.931 {2.4382} |
| | | 0.25 {0.010} undersize | Standard | 61.688–61.705 {2.4287–2.4293} |
| Main journal taper and out-of-round | | | 0.05 {0.020} max. | |
| Crankpin diameter | mm {in} | Standard size | Standard | 47.940–47.955 {1.8874–1.8879} |
| | | | Minimum | 47.935 {1.8872} |
| | | 0.25 {0.010} undersize | Standard | 47.690–47.705 {1.8776–1.8781} |
| Crankpin taper and out-of-round | | | 0.05 {0.020} max. | |
| Main bearing | | | | |
| Main journal bearing oil clearance | mm {in} | Standard | 0.037–0.057 {0.0015–0.0022} | |
| | | Maximum | 0.064 {0.0025} | |
| Available undersized bearing | | mm {in} | 0.25 {0.010} | |
| Crankpin bearing | | | | |
| Crankpin bearing oil clearance | mm {in} | Standard | 0.023–0.043 {0.0009–0.0016} | |
| | | Maximum | 0.08 {0.0031} | |
| Available undersized bearing | | mm {in} | 0.25 {0.010} | |

D1. LUBRICATION SYSTEM (B6)

| Item | | Engine | B6 DOHC |
|--|---|-------------------------------------|---|
| Lubricating method | | | Force-fed |
| Oil pump | | | |
| Type | | | Trochoid gear |
| Relief pressure | | kPa {kgf/cm ² , psi} | 343-442 {3.5-4.5, 50-60} |
| Regulated pressure | | kPa {kgf/cm ² , psi}-rpm | 300-390 {3.0-4.0, 43-56}-3,000 |
| Inner rotor tooth tip to outer rotor clearance | mm {in} | Standard | 0.02-0.16 {0.0008-0.0063} |
| | | Maximum | 0.20 {0.0079} |
| Outer rotor to body clearance | mm {in} | Standard | 0.09-0.18 {0.0035-0.0071} |
| | | Maximum | 0.22 {0.0087} |
| Side clearance | mm {in} | Standard | 0.03-0.11 {0.0012-0.0043} |
| | | Maximum | 0.14 {0.0055} |
| Oil filler | | | |
| Type | | | Full-flow, paper element |
| Relief pressure differential | | kPa {kgf/cm ² , psi} | 79-117 {0.8-1.2, 12-17} |
| Engine oil | | | |
| Capacity L {US qt, Imp qt} | Total (dry engine) | | 3.4 {3.6, 3.0} |
| | Engine oil replacement (without oil filter) | | 3.0 {3.2, 2.6} |
| | Engine oil replacement (With oil filter) | | 3.3 {3.48, 2.90} |
| Grade | | | API service SG, SH energy conserving II (ECII) ILSAC |
| Viscosity number | Above -25°C {-13°F} | | SAE 10W-30 |
| | Below 0°C {32°F} | | SAE 5W-30 |

D2. LUBRICATION SYSTEM (K8)

| Item | | Engine | K8 DOHC |
|--|--|-------------------------------------|---|
| Lubricating method | | | Force-fed |
| Oil pump | | | |
| Type | | | Trochoid gear |
| Relief pressure | | kPa {kgf/cm ² , psi} | 491-589 {5.0-8.0, 71-85} |
| Regulated pressure | | kPa {kgf/cm ² , psi}-rpm | 196 {2.0, 28}-1,000 330-490 {3.4-5.0, 49-71}-3,000 |
| Inner rotor tooth tip to outer rotor clearance | mm {in} | Standard | 0.02-0.18 {0.0008-0.0070} |
| | | Maximum | 0.20 {0.0078} |
| Outer rotor to body clearance | mm {in} | Standard | 0.113-0.186 {0.0045-0.0073} |
| | | Maximum | 0.22 {0.0087} |
| Side clearance | mm {in} | Standard | 0.03-0.09 {0.0012-0.0035} |
| | | Maximum | 0.13 {0.0051} |
| Oil filler | | | |
| Type | | | Full-flow, paper element |
| Relief pressure differential | | kPa {kgf/cm ² , psi} | 79-117 {0.8-1.2, 12-17} |
| Engine oil | | | |
| Capacity L {US qt, Imp qt} | Total (dry engine) | | 4.9 {5.2, 4.3} |
| | Engine oil replacement | | 3.7 {3.9, 3.3} |
| | Engine oil replacement (with oil filter) | | 4.0 {4.2, 3.5} |
| Grade | | | API service SG, SH Energy conserving II (ECII) ILSAC |
| Viscosity number | Above -25°C {-13°F} | | SAE 10W-30 |
| | Below 0°C {32°F} | | SAE 5W-30 |

E1. COOLING SYSTEM (B6)

| Item | | Engine | B6 DOHC |
|-----------------------------------|--|---------------------------------|----------------------------------|
| Cooling method | | | Water-cooled, forced circulation |
| Water pump | | | |
| Type | | | Centrifugal, V-belt driven |
| Impeller diameter | | mm {in} | 75 {2.95} |
| Number of impeller blades | | | 6 |
| Speed ratio | | | 1 : 1.05 |
| Water seal type | | | Unified mechanical seal |
| Thermostat | | | |
| Type | | | Wax, two-stage |
| Opening temperature | | °C {°F} | Min: 88 {190} Sub: 85 {185} |
| Full-open temperature | | °C {°F} | 100 {212} |
| Full-open lift | | mm {in} | Min: 8 {0.31} Sub: 1.5 {0.06} |
| Radiator | | | |
| Type | | | Corrugated fin |
| Cap valve opening pressure | | kPa {kgf/cm ² , psi} | 74-103 {0.75-1.05, 11-15} |
| Cooling circuit checking pressure | | kPa {kgf/cm ² , psi} | 103 {1.05, 15} |

| Item | | Engine | B6 DOHC | | |
|----------------------------|---------------------|-------------------|---------------------|---------|---------------------------------|
| Coolant fan | | | | | |
| Type | | | Electric | | |
| Number of blades | | | 4 | | |
| Outer diameter | | mm {in} | 300 {11.8} | | |
| Capacity | | W-V | 80-12 | | |
| Current | | A | 5.6-7.6 | | |
| Water thermostwitch | | | | | |
| OFF ON | | °C {°F} | 97 {207} | | |
| Coolant | | | | | |
| Capacity | | L {US qt, Imp qt} | 6.0 {6.3, 5.3} | | |
| Antifreeze solution | Coolant protection | | Volume percentage % | | Specific gravity at 20°C {68°F} |
| | | | Water | Coolant | |
| | Above -16°C {3°F} | | 65 | 35 | 1.054 |
| | Above -26°C {-15°F} | | 55 | 45 | 1.066 |
| Above -40°C {-40°F} | | 45 | 55 | 1.078 | |

E2. COOLING SYSTEM (K8)

| Item | | Engine | K8 DOHC | | |
|-----------------------------------|--|---------------------------------|-----------------------------------|--|--|
| Cooling method | | | Water-cooled, forced circulation | | |
| Water pump | | | | | |
| Type | | | Centrifugal, V-ribbed belt-driven | | |
| Impeller diameter | | mm {in} | 60 {2.36} | | |
| Number of impeller blades | | | 6 | | |
| Speed ratio | | | 1 : 1.05 | | |
| Water seal type | | | Unified mechanical seal | | |
| Thermostat | | | | | |
| Type | | | Wax, bottom-bypass | | |
| Opening temperature | | °C {°F} | 80-84 {176-183} | | |
| Full-open temperature | | °C {°F} | 95 {203} | | |
| Full-open lift | | mm {in} | 8.5 {0.33} min. | | |
| Radiator | | | | | |
| Type | | | Corrugated fin | | |
| Cap valve opening pressure | | kPa {kgf/cm ² , psi} | 74-102 {0.75-1.05, 10.7-14.9} | | |
| Cooling circuit checking pressure | | kPa {kgf/cm ² , psi} | 103 {1.05, 15} | | |

| Item | | Engine/Transaxle | | K8 DOHC | | |
|---------------------|---------------------|-------------------|---------------------|----------------|---------------------------------|--|
| | | | | MTX | ATX | |
| Coolant fan | | | | | | |
| Type | | Electric | | | | |
| Fan | Number of blades | 5 | | | | |
| | Outer diameter | mm {in} | 340 {13.39} | | | |
| | Fan speed | | — | Low | High | |
| Motor | Capacity | W-V | 160-12 | | | |
| | Current | A | 11.0 | 12.0 | 16.8 | |
| Coolant | | | | | | |
| Capacity | | L {US qt, Imp qt} | | 7.5 {7.9, 6.6} | | |
| Antifreeze solution | Coolant protection | | Volume percentage % | | Specific gravity at 20°C {68°F} | |
| | | | Water | Coolant | | |
| | Above -16°C {3°F} | | 65 | 35 | 1.054 | |
| | Above -26°C {-15°F} | | 55 | 45 | 1.066 | |
| Above -40°C {-40°F} | | 45 | 55 | 1.078 | | |

F1. FUEL AND EMISSION CONTROL SYSTEMS (B6)

| Item | | Engine | B6 DOHC |
|--|--------------------|---------------------------------|---|
| Idle speed* | | rpm | 650-750 (700 ± 50)[MTX] 700-800 (750 ± 50)[ATX] |
| Ignition timing* | | BTDC | 9-11°(10 ± 1°) |
| Throttle body | | | |
| Type | | | Horizontal draft |
| Throat diameter | | mm{in} | 55 {2.2} |
| Fuel pump | | | |
| Type | | | Impeller (in-tank) |
| Output pressure | | kPa {kgf/cm ² , psi} | 441-589 {4.5-6.0, 64-85} |
| Fuel filter | | | |
| Type | Low-pressure side | | Nylon element (in fuel pump) |
| | High-pressure side | | Paper element |
| Pressure regulator | | | |
| Type | | | Diaphragm (Two stage type) |
| Regulating pressure | | kPa {kgf/cm ² , psi} | 284 {2.90, 41} |
| Fuel Injector | | | |
| Type | | | High-ohmic, top-feeding |
| Type of drive | | | Voltage |
| Resistance | | Ω | Approx. 13.8 (at 20°C {68°F}) |
| Idle air control valve | | | |
| Solenoid resistance | | Ω | 10.7-12.3 (at 20°C {68°F}) |
| Purge solenoid valve | | | |
| Solenoid resistance | | Ω | 23-27 (at 20°C {68°F}) |
| Camshaft position sensor | | | |
| Type | | | Hall effect |
| Mass airflow sensor | | | |
| Type | | | Hot wire type |
| Engine coolant temperature sensor | | | |
| Resistance | kΩ | 20°C {68°F} | 2.21-2.69 |
| | | 80°C {176°F} | 0.287-0.349 |
| Fuel Tank | | | |
| Capacity | | L {US gal, Imp gal} | 50 {13.2, 11.0} |
| Air cleaner element | | | |
| Element type | | | Oil permeated |
| Accelerator cable | | | |
| Free play | | mm{in} | 1-3 {0.039-0.118} |
| Fuel | | | |
| Specification | | | Unleaded -(R+M)/2 method 87 or higher |

* With System Selector (49 B019 9A0) test switch at "SELF TEST" or TEN terminal of data link connector grounded.

F2. FUEL AND EMISSION CONTROL SYSTEMS (K8)

| Item | | Engine | K8 DOHC | |
|---|--------------------------------|---|---|-------------|
| Idle speed* | | rpm | 640–700 {670 ± 30} | |
| Ignition timing* | | BDTC | 9–11° {10 ± 1°} | |
| Throttle body | | | | |
| Type | | | Horizontal draft | |
| Throat diameter | | mm{in} | 55 {2.2} | |
| Fuel pump | | | | |
| Type | | | Impeller (in-tank) | |
| Maximum output pressure | | kPa {kgf/cm ² , psi} | 637 {6.5,92} | |
| Fuel filter | | | | |
| Type | Low-pressure side | | Nylon element (in fuel pump) | |
| | High-pressure side | | Paper element | |
| Pressure regulator | | | | |
| Type | | | Diaphragm | |
| Regulating pressure | | kPa {kgf/cm ² , psi} | 284 {2.9,42} | |
| Fuel injector | | | | |
| Type | | | High-ohmic, side-feed | |
| Type of drive | | | Voltage | |
| Resistance | | Ω | Approx. 13.8 (at 20°C {68°F}) | |
| Idle air control valve | | | | |
| Solenoid resistance | | Ω | 10.7–12.3 (at 20°C {68°F}) | |
| Purge solenoid valve | | | | |
| Solenoid resistance | | Ω | 23–27 (at 20°C {68°F}) | |
| Camshaft position sensor (SGC, SGT signal) | | | | |
| Type | | | Hall element | |
| Volume airflow sensor | | | | |
| Type | | | Measuring core type | |
| Resistance | Ω | E ₂ ⇌V _S | Closed throttle position (at 20°C {68°F}) | 200–1,000 |
| | | | Wide open throttle (at 20°C {68°F}) | 20–800 |
| | E ₂ ⇌V _C | | 200–400 | |
| | | E ₂ ⇌THA (Intake air temperature sensor) | 20°C {68°F} | 2,000–3,000 |
| | 60°C {140°F} | | 400–700 | |
| Engine coolant temperature sensor | | | | |
| Resistance | kΩ | | 20°C {68°F} | 2.2–2.7 |
| | | | 80°C {176°F} | 0.28–0.35 |

*With System Selector (49 B019 9A0) test switch at "SELF TEST" or TEN terminal of data link connector grounded.

| Engine | | K8 DOHC |
|----------------------------|---------------------|--|
| Item | | |
| Fuel tank | | |
| Capacity | L {US gal, Imp gal} | 50 {13.2, 11.0} |
| Air cleaner element | | |
| Element type | | Oil permeated |
| Accelerator cable | | |
| Free play | mm {in} | 1-3 {0.039-0.118} |
| Fuel | | |
| Specification | | Unleaded regular (antiknock index of 87 or higher) |

G. ENGINE ELECTRICAL SYSTEM

| Engine | | B6 DOHC | K8 DOHC | |
|---|-------------------------------------|---|---|---|
| Item | | | | |
| Battery | Voltage | V | | |
| | Type and capacity (5-hour rate A-h) | 50D20L (40) 55D23L (48) | 50D20L (40) 65D23L (43) | |
| Dark current *1 | mA | Max. 20 | | |
| Alternator | Type | A.C. | | |
| | Output | V-A | 12-70 12-80 | |
| | Regulator type | Transistorized (built-in Voltage regulator) | | |
| | Regulated voltage | V | 14.1-14.7 | |
| | Brush length | mm {in} | Standard | 20.0 {0.79} 21.5 {0.85} |
| | | | Minimum | 5.0 {0.20} 8.0 {0.32} |
| | Drive belt deflection | mm {in}/9.8N {10kgf, 22lbf} | New | 5.5-7.0 {0.22-0.27} 5.5-6.5 {0.22-0.25} (with A/C) 6.0-7.0 {0.24-0.27} (without A/C) |
| Used | | | 6.0-7.5 {0.24-0.29} 6.5-7.5 {0.26-0.29} (with A/C) 7.0-8.0 {0.28-0.31} (without A/C) | |
| Limit | | | 8.0 {0.32} 8.0 {0.32} (with A/C) 9.0 {0.35} (without A/C) | |
| Starter | Type | Direct | MTX...Coaxial reduction ATX...Eccentric reduction | |
| | Output | V-kW | 12-0.8 MTX...12-1.4, ATX...12-1.4 MTX...12-1.7*3, ATX...12-1.6*3 | |
| | Brush length | mm {in} | Standard | 16 {0.7} MTX...17.5 {0.69}, ATX...17.0 {0.67} |
| | | | Minimum | 10 {0.4} MTX...12.0 {0.48}, ATX...11.5 {0.46} |
| Distributor | Spark advance type | ESA | | |
| Ignition timing (TEN terminal of data link connector grounded) | | BTDC | 9-11° | |
| Ignition coil | Resistance (at 20°C {68°F}) | Primary coil winding | 0.49-0.73Ω | |
| | | Secondary coil winding | 20-31kΩ | |
| Spark plug | Type | NGK | BKR5E-11 *2 BKR6E-11 | |
| | | NIPPON-DENSO | K16PR-U11*2 K20PR-U11 | |
| | Plug gap | mm {in} | 1.0-1.1 {0.040-0.043} | |
| Firing order | | 1-3-4-2 | 1-2-3-4-5-6 | |

*1 Dark current is the constant flow of current present when the ignition switch is OFF (i.e., audio unit, clock, etc.).

*2 Standard plug.

*3 Cold area.


H. CLUTCH

| Engine/Transaxle | | B6 DOHC | K8 DOHC |
|---|--------------|-----------------------------|-------------|
| | | F25M-R | G25M-R |
| Clutch control | | Hydraulic | |
| Clutch pedal | | | |
| Type | | Suspended | |
| Pedal ratio | mm {in} | 6.31 | |
| Full stroke | mm {in} | 130 {5.12} | |
| Height (from carpet) | mm {in} | 199-204 {7.83-8.03} | |
| Free play | mm {in} | 5-16 {0.19-0.63} | |
| Distance to carpet when clutch fully disengaged | mm {in} | Minimum | 39.5 {1.56} |
| Flywheel | | | |
| Runout limit | mm {in} | 0.2 {0.008} | |
| Clutch disc | | | |
| Type | | Single dry plate | |
| Runout limit | mm {in} | 0.7 {0.027} | |
| Wear limit | mm {in} | 0.3 {0.012} from rivet head | |
| Outer diameter | mm {in} | 200 {7.87} | 225 {8.86} |
| Inner diameter | mm {in} | 130 {5.12} | 150 {5.91} |
| Facing thickness | mm {in} | Flywheel side | 3.5 {0.138} |
| | | Pressure plate side | 3.8 {0.150} |
| Clutch cover | | | |
| Type | | Diaphragm spring | |
| Set load | N {kgf, lbf} | 4,310 {440, 968} | |

J1 and J2. MANUAL TRANSAXLE

| Item | | Engine | B6 DOHC | K8 DOHC |
|---|-----------|-------------------|--|--|
| Specification | | | | |
| Transaxle type | | | F25M-R | G25M-R |
| Transaxle control | | | Floor shift | |
| Transaxle shift control | | | Rod | |
| Synchronesh system | | | Forward: Synchronesh Reverse: Selective sliding and synchronesh | Forward: Synchronesh Reverse: Selective sliding and synchronesh |
| Gear ratio | 1st | | 3.416 | 3.307 |
| | 2nd | | 1.842 | 1.833 |
| | 3rd | | 1.290 | 1.310 |
| | 4th | | 0.918 | 1.030 |
| | 5th | | 0.731 | 0.795 |
| | Reverse | | 3.214 | 3.166 |
| Final gear ratio | | | 4.105 | 4.388 |
| Speedometer gear ratio (Driven gear/drive gear) | | | 0.88{22/25} | 0.84{21/25} |
| Oil | Grade | | API service GL-4 or GL-5 | API service GL-4 or GL-5 |
| | Viscosity | | All-season : SAE 75W-90 Above 10°C {50°F}: SAE 80W-90 | All-season :SAE 75W-90 Above 10°C {50°F}: SAE 80W-90 |
| | Capacity | L {US qt. Imp qt} | 2.68 {2.83, 2.36} | 2.70 {2.85, 2.38} |
| Runout | | | | |
| Primary shaft gear runout | | mm {in} | 0.05 {0.002} | 0.05 {0.002} |
| Secondary shaft gear runout | | mm {in} | 0.015 {0.0006} | 0.015 {0.0006} |
| Clearance | | | | |
| 1st (Gear inner dia. -shaft outer dia) | | mm {in} | 0.03-0.07 {0.001-0.0028} | 0.03-0.08 {0.001-0.003} |
| 2nd (Gear inner dia. -shaft outer dia) | | mm {in} | 0.03-0.07 {0.001-0.0028} | 0.03-0.08 {0.001-0.003} |
| 3rd (Gear inner dia. -shaft outer dia) | | mm {in} | 0.03-0.07 {0.001-0.0028} | 0.03-0.08 {0.001-0.003} |
| 4th (Gear inner dia. -shaft outer dia) | | mm {in} | 0.03-0.07 {0.001-0.0028} | 0.03-0.08 {0.001-0.003} |
| 5th (Gear inner dia. -sleeve outer dia) | | mm {in} | 0.03-0.08 {0.001-0.0028} | 0.03-0.08 {0.001-0.003} |
| 1-2 shift fork and reverse gear | mm{in} | Standard | 0.05-0.35 {0.002-0.013} | 0.10-0.45 {0.004-0.018} |
| | | Wear limit | 0.85 {0.033} | 0.95 {0.037} |
| 3-4 shift fork and clutch hub sleeve | mm{in} | Standard | 0.20-0.50 {0.008-0.020} | 0.10-0.40 {0.004-0.016} |
| | | Wear limit | 1.00 {0.039} | 0.90 {0.035} |
| 5th shift fork and clutch hub sleeve | mm{in} | Standard | 0.40-0.75 {0.016-0.030} | 0.10-0.36 {0.004-0.014} |
| | | Wear limit | 1.25 {0.049} | 0.86 {0.034} |
| Synchronizer ring and gear | mm{in} | Standard | 1.12-1.88 {0.044-0.074} | 1.50 {0.059} |
| | | Wear limit | 0.80 {0.031} | 0.80 {0.031} |
| Reverse idler gear and reverse lever | mm{in} | Standard | 0.10-0.32 {0.004-0.013} | 0.10-0.32 {0.004-0.013} |
| | | Wear limit | 0.82 {0.032} | 0.82 {0.032} |

| Item | | Engine | B6 DOHC | K8 DOHC |
|---------------------------------------|---------|---|---|--|
| Thrust clearance | | | | |
| 1st gear | mm {in} | Standard | 0.05–0.28 {0.002–0.011} | 0.05–0.28 {0.002–0.011} |
| | | Limit | 0.33 {0.013} | 0.33 {0.013} |
| 2nd gear | mm {in} | Standard | 0.18–0.51 {0.007–0.020} | 0.18–0.46 {0.007–0.018} |
| | | Limit | 0.56 {0.022} | 0.51 {0.020} |
| 3rd gear | mm {in} | Standard | 0.06–0.21 {0.002–0.008} | 0.05–0.20 {0.002–0.008} |
| | | Limit | 0.26 {0.010} | 0.25 {0.010} |
| 4th gear | mm {in} | Standard | 0.14–0.39 {0.005–0.015} | 0.17–0.37 {0.007–0.015} |
| | | Limit | 0.44 {0.017} | 0.42 {0.017} |
| 5th gear | mm {in} | Standard | 0.08–0.15 {0.003–0.006} | 0.10–0.22 {0.004–0.009} |
| | | Limit | 0.20 {0.008} | 0.27 {0.011} |
| Primary shaft gear | mm {in} | Standard | 0.005–0.100 {0.0002–0.0039} | 0–0.05 {0–0.002} |
| | | Adjustment shims | 0.1 {0.004}, 0.2 {0.008}, 0.3 {0.012}, 0.4 {0.016}, 0.5 {0.020}, 0.6 {0.024} | 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028} |
| Secondary shaft gear | mm {in} | Standard | 0.03–0.08 {0.001–0.003} | 0.03–0.08 {0.001–0.003} |
| | | Adjustment shims | 0.15 {0.006}, 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028} | 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028} |
| Bearing preload | | | | |
| Differential side bearing preload | mm {in} | Bearing preload N·m {kgf·cm, in·lbf} | 0.03–0.74 {0.3–7.6, 0.26–6.60} | 1.4–2.0 {14–20, 13–17} |
| | | Adjustment shims mm {in} | 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022} | 0.10 {0.004}, 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028}, 0.75 {0.030}, 0.80 {0.031}, 0.85 {0.033}, 0.90 {0.035}, 0.95 {0.037}, 1.00 {0.039}, 1.05 {0.041}, 1.10 {0.043}, 1.15 {0.045}, 1.20 {0.047} |
| Differential | | | | |
| Backlash of side gear and pinion gear | mm {in} | Standard | 0–0.1 {0–0.004} | 0–0.1 {0–0.004} |
| | | Adjustment washers | 2.0 {0.079}, 2.1 {0.083}, 2.2 {0.087} | — |
| Note | | | | |
| Synchronizer ring outer diameter | mm {in} | 1st and 2nd | 61.7 {2.429} | 75.6 {2.98} |
| | | 3rd and 4th | 61.7 {2.429} | 75.6 {2.98} |
| | | 5th and reverse | 49.7 {1.957} | 63.6 {2.50} |
| Synchronizer key dimension | mm {in} | 1st and 2nd | ① 19.0 {0.748}, ② 4.25 {0.167}, ③ 5.0 {0.197} | ① 19.0 {0.748}, ② 4.25 {0.167}, ③ 5.0 {0.197} |
| | | 3rd and 4th | ① 17.0 {0.669}, ② 4.25 {0.167}, ③ 5.0 {0.197} | ① 17.0 {0.669}, ② 4.25 {0.167}, ③ 5.0 {0.197} |
| | | 5th and reverse | ① 17.0 {0.669}, ② 4.25 {0.167}, ③ 5.0 {0.197} | ① 17.0 {0.669}, ② 4.25 {0.167}, ③ 5.0 {0.197} |



K. AUTOMATIC TRANSAXLE

| Item | | Engine/Transaxle | | B6 DOHC | K8 DOHC |
|---|---|--|-----------------------|--------------------------------|-------------|
| | | | | FA4A-EL (F4A-EL) | |
| Torque converter stall torque ratio | | | | 2.000:1 | |
| Gear ratio | | 1GR | | 2.800 | |
| | | 2GR | | 1.540 | |
| | | 3GR | | 1.000 | |
| | | 4GR | | 0.700 | |
| | | Reverse | | 2.333 | |
| Final gear ratio | | | | 3.833 | 4.058 |
| Automatic transaxle fluid (ATF) | Type | | | Dexron® II or M-III | |
| | Capacity L {US qt, Imp qt} | | | 5.8 {6.1, 5.1} | |
| Engine stall speed rpm | | All ranges and R position | | 2,100-2,400 | 2,450-2,750 |
| Time lag sec. | | N D range | | 0.5-0.6 | |
| | | N R position | | 0.6-0.7 | |
| Line pressure kPa {kgf/cm ² , psi} | At idle | All ranges | | 430-550 {4.3-5.7, 62-81} | |
| | | R position | | 730-870 {7.4-8.9, 110-120} | |
| | At stall | All ranges | | 920-1040 {9.3-10.7, 140-152} | |
| | | R position | | 1500-1700 {15.2-17.4, 217-247} | |
| Throttle pressure kPa {kgf/cm ² , psi} | At idle | D range | | 68-116 {0.69-1.19, 9.9-16.9} | |
| | At stall | D range | | 420-510 {4.2-5.3, 60-75} | |
| Oil pump | Outer and inner rotor clearance mm {in} | Standard | | 0.02-0.04 {0.00079-0.00157} | |
| | | Maximum | | 0.05 {0.00197} | |
| | Spool outer diameter mm {in} | Standard | | 14.00 {0.551} | |
| | | Minimum | | 13.98 {0.550} | |
| | Between oil pump boss and inner rotor clearance mm {in} | Standard | | 0.04-0.115 {0.00157-0.00453} | |
| | | Maximum | | 0.125 {0.00492} | |
| 3-4 clutch | Number of drive/driven plates | | 3/3 | | |
| | Drive plate thickness mm {in} | Standard | | 1.6 {0.063} | |
| | | Minimum | | 1.4 {0.055} | |
| | 3-4 clutch clearance mm {in} | | 1.3-1.6 {0.051-0.063} | | |
| Snap ring size mm {in} | | 1.4 {0.055}, 1.6 {0.063}, 1.8 {0.071}, 2.0 {0.079}, 2.2 {0.087}, 2.4 {0.094} | | | |
| Forward clutch | Number of drive/driven plates | | 3/3 | | |
| | Drive plate thickness mm {in} | Standard | | 1.6 {0.063} | |
| | | Minimum | | 1.4 {0.055} | |
| | Forward clutch clearance mm {in} | | 1.0-1.2 {0.039-0.047} | | |
| Snap ring size mm {in} | | 1.8 {0.071}, 1.95 {0.077}, 2.1 {0.083}, 2.25 {0.089}, 2.4 {0.094}, 2.55 {0.100}, 2.7 {0.106}, 2.85 {0.112} | | | |
| Coasting clutch | Number of drive/driven plates | | 2/2 | | |
| | Drive plate thickness mm {in} | Standard | | 1.6 {0.063} | |
| | | Minimum | | 1.4 {0.055} | |
| | Coasting clutch clearance mm {in} | | 1.0-1.2 {0.039-0.047} | | |
| Snap ring size mm {in} | | 1.60 {0.063}, 1.75 {0.069}, 1.90 {0.075}, 2.05 {0.081}, 2.20 {0.087}, 2.35 {0.093}, 2.50 {0.098}, 2.65 {0.104} | | | |
| Reverse clutch | Number of drive/driven plates | | 2/2 | | |
| | Drive plate thickness mm {in} | Standard | | 1.6 {0.063} | |
| | | Minimum | | 1.4 {0.055} | |
| | Reverse clutch clearance mm {in} | | 1.0-1.3 {0.039-0.051} | | |
| Snap ring size mm {in} | | 2.0 {0.079}, 2.2 {0.087}, 2.4 {0.094}, 2.6 {0.102}, 2.8 {0.110}, 3.0 {0.118} | | | |

| Engine/Transaxle | | B6 DOHC | | K8 DOHC | |
|----------------------------------|---|---|--|----------------------|--|
| | | FA4A-EL (F4A-EL) | | | |
| Low and reverse brake | Number of drive/driven plates | | 4/4 | | |
| | Drive plate thickness mm {in} | Standard | 1.6 {0.063} | | |
| | | Minimum | 1.4 {0.055} | | |
| | Low and reverse brake clearance mm {in} | | 2.1–2.4 {0.083–0.094} | | |
| Snap ring size mm {in} | | 2.0 {0.079}, 2.2 {0.087}, 2.4 {0.094}, 2.6 {0.102}, 2.8 {0.110}, 3.0 {0.118} | | | |
| Carrier hub | Clearance between pinion washer and planet carrier mm {in} | Maximum | 0.2–0.7 {0.008–0.028} | | |
| Sun gear drum | Bushing inner diameter mm {in} | Maximum | 30.425 {1.198} | | |
| Small sun gear | Bushing inner diameter mm {in} | Maximum | 21.021 {0.828} | | |
| Gear assembly | | | | | |
| Total end play | | mm {in} | 0.25–0.50 {0.010–0.020} | | |
| End play adjustment race | | mm {in} | 1.2 {0.047}, 1.4 {0.055}, 1.6 {0.063}, 1.8 {0.071}, 2.0 {0.079}, 2.2 {0.087} | | |
| Idler gear bearing preload | | N·m {kgf·cm, in·lbf} | 0.03–0.8 {0.3–9.0, 0.27–7.8} | | |
| Preload adjustment shims | | mm {in} | 3.80 {0.150}, 3.85 {0.152}, 3.90 {0.154}, 3.95 {0.156}, 4.00 {0.157}, 4.05 {0.159}, 4.10 {0.161}, 4.15 {0.163}, 4.20 {0.165}, 4.25 {0.167}, 4.30 {0.169}, 4.35 {0.171}, 4.40 {0.173}, 4.45 {0.175}, 4.50 {0.177}, 4.55 {0.179}, 4.60 {0.181}, 4.65 {0.183}, 4.70 {0.185}, 4.75 {0.187} | | |
| Output gear bearing preload | | N·m {kgf·cm, in·lbf} | 0.03–0.8 {0.3–9.0, 0.27–7.8} | 0.9–1.7 {9–18, 8–15} | |
| Preload adjustment shims | | mm {in} | 0.50 {0.020}, 0.525 {0.021}, 0.55 {0.022}, 0.575 {0.023}, 0.60 {0.024}, 0.625 {0.025}, 0.65 {0.026}, 0.675 {0.027}, 0.70 {0.028}, 0.725 {0.029}, 0.75 {0.030}, 0.775 {0.031}, 0.80 {0.031}, 0.825 {0.032}, 0.85 {0.033}, 0.875 {0.034}, 0.90 {0.035}, 0.925 {0.036}, 0.95 {0.037}, 0.975 {0.038}, 1.00 {0.039}, 1.025 {0.040}, 1.05 {0.041}, 1.075 {0.042}, 1.10 {0.043}, 1.125 {0.044}, 1.15 {0.045}, 1.175 {0.046}, 1.20 {0.047}, 1.225 {0.048}, 1.25 {0.049}, 1.275 {0.050}, 1.30 {0.051}, 1.325 {0.052}, 1.35 {0.053}, 1.375 {0.054}, 1.40 {0.055}, 1.425 {0.056}, 1.45 {0.057} | | |
| Differential | | | | | |
| Bearing preload | | N·m {kgf·cm, in·lbf} | 3.0–3.9 {30–40, 27–34} | | |
| Preload adjustment shims | | mm {in} | 0.50 {0.020}, 0.525 {0.021}, 0.55 {0.022}, 0.575 {0.023}, 0.60 {0.024}, 0.625 {0.025}, 0.65 {0.026}, 0.675 {0.027}, 0.70 {0.028}, 0.725 {0.029}, 0.75 {0.030}, 0.775 {0.031}, 0.80 {0.031}, 0.825 {0.032}, 0.85 {0.033}, 0.875 {0.034}, 0.90 {0.035}, 0.925 {0.036}, 0.95 {0.037}, 0.975 {0.038}, 1.00 {0.039}, 1.025 {0.040}, 1.05 {0.041}, 1.075 {0.042}, 1.10 {0.043}, 1.125 {0.044}, 1.15 {0.045}, 1.175 {0.046}, 1.20 {0.047}, 1.225 {0.048}, 1.25 {0.049}, 1.275 {0.050}, 1.30 {0.051}, 1.325 {0.052}, 1.35 {0.053}, 1.375 {0.054}, 1.40 {0.055}, 1.425 {0.056}, 1.45 {0.057} | | |
| Backlash of side gear and pinion | mm {in} | Standard | 0.025–0.1 {0.001–0.004} | | |
| | | Maximum | 0.5 {0.020} | | |
| Torque converter | | | | | |
| Bushing inner diameter | mm {in} | Standard | 53.030 {2.083} | | |
| | | Maximum | 53.076 {2.089} | | |

Spring Specification

| Spring name | | Outer diameter mm{In} | | Free length mm {in} | No. of coils | Wire diameter mm {in} |
|------------------------------|------------------------------|--------------------------|---------------|------------------------|--------------|--------------------------|
| Upper control valve body | Throttle modulator spring | 8.1 {0.319} | | 43.4 {1.709} | 10.5 | 0.8 {0.031} |
| | Throttle spring | 5.4 {0.213} | | 46.2 {1.819} | 29.0 | 0.88 {0.035} |
| | Throttle assist spring | 5.15 {0.203} | | 26.88 {1.058} | 16.2 | 0.6 {0.024} |
| Main control valve body | Pressure regulator spring | 11.5 {0.453} | | 34.2 {1.346} | 9.5 | 1.0 {0.039} |
| | 1-2 shift spring | 8.7 {0.343} | | 41.3 {1.626} | 13.5 | 1.0 {0.039} |
| | Low reducing spring | 7.9 {0.311} | | 34.5 {1.358} | 11.0 | 0.8 {0.031} |
| | 2-3 timing spring | 8.6 {0.339} | | 28.3 {1.114} | 8.6 | 1.2 {0.047} |
| | 3-2 timing spring | 8.0 {0.315} | | 29.98 {1.180} | 10.0 | 0.8 {0.031} |
| | 3-4 shift spring | 8.7 {0.343} | | 41.3 {1.626} | 13.5 | 1.0 {0.039} |
| Premain control valve body | Bypass spring | 4.9 {0.193} | | 30.5 {1.201} | 23.0 | 0.55 {0.022} |
| | 2-3 shift spring | 8.7 {0.343} | | 41.3 {1.626} | 13.5 | 1.0 {0.039} |
| | Converter relief spring | 8.6 {0.339} | | 68.4 {2.693} | 27.5 | 1.2 {0.047} |
| | TCC control spring | 5.0 {0.197} | | 30.1 {1.185} | 21.5 | 0.55 {0.022} |
| Control valve body | Throttle relief spring | 6.6 {0.260} | | 21.6 {0.850} | 11.5 | 0.8 {0.032} |
| Oil pump | Spring | 11.8 {0.465} | 11.8 {0.465} | 53.0 {2.087} | 12.0 | 1.2 {0.047} |
| Accumulator | 2-3 accumulator small spring | B6DOHC | 10.0 {0.394} | 67.8 {2.669} | 20.0 | 1.3 {0.051} |
| | | K8DOHC | 11.6 {0.457} | 59.7 {2.350} | 16.9 | 1.8 {0.071} |
| | 2-3 accumulator large spring | B6DOHC | 15.0 {0.591} | 69.5 {2.736} | 15.8 | 2.0 {0.079} |
| | | K8DOHC | | 71.8 {2.827} | 9.8 | 1.2 {0.047} |
| | 1-2 accumulator small spring | B6DOHC | 11.2 {0.441} | 84.7 {3.335} | 25.5 | 1.5 {0.059} |
| | | K8DOHC | 11.0 {0.433} | 81.7 {3.217} | 25.9 | 1.4 {0.055} |
| | 1-2 accumulator large spring | B6DOHC | 16.0 {0.630} | 84.7 {3.335} | 19.5 | 1.9 {0.075} |
| | | K8DOHC | | 82.1 {3.232} | 18.0 | 2.0 {0.079} |
| | N-D accumulator small spring | 10.8 {0.425} | | 101.2 {3.984} | 28.2 | 1.2 {0.047} |
| | N-D accumulator large spring | 15.0 {0.591} | | 94.2 {3.709} | 16.5 | 1.6 {0.063} |
| N-R accumulator small spring | 9.8 {0.386} | | 93.2 {3.669} | 31.5 | 1.3 {0.051} | |
| N-R accumulator large spring | 14.0 {0.551} | | 106.5 {4.193} | 23.0 | 1.7 {0.067} | |
| 3-4 clutch | Return spring | 74.4 {2.929} | | 40.5 {1.594} | 1.0 | 5.0 {0.197} |
| Coasting clutch | Return spring | 7.3 {0.287} | | 20.45 {0.805} | 10.0 | 1.0 {0.039} |
| Low and reverse brake | Return spring | 5.55 {0.219} | | 14.3 {0.563} | 12.0 | 0.75 {0.030} |
| Servo | Return spring | 27.7 {1.091} | | 43.25 {1.703} | 4.5 | 3.2 {0.126} |
| Orifice | Check spring | 7.5 {0.295} | | 32.8 {1.291} | 10.1 | 0.6 {0.024} |
| | | 8.3 {0.327} | | | | |

Vehicle Speed at Shift point Table

| Mode | Range | Throttle condition (throttle position sensor voltage) | Shift | Vehicle speed km/h (mph) | |
|--------|----------|---|-------------------------------|--------------------------|---------------------|
| | | | | B6 DOHC | K8 DOHC |
| Normal | D | Wide open throttle (3.1-4.4 V) | D ₁ D ₂ | 58-64 (36-40) | 59-65 (37-40) |
| | | | D ₂ D ₃ | 102-110 (63-68) | 101-109 (62.7-67.5) |
| | | | D ₃ D ₄ | 166-176 (103-109) | 167-177 (104-109) |
| | | Half throttle (1.7-2.7 V) | D ₁ D ₂ | 34-43 (22-26) | 39-48 (25-29) |
| | | | D ₂ D ₃ | 60-77 (37-48) | 70-88 (44-54) |
| | | | D ₃ D ₄ | 104-130 (64-81) | 127-153 (78.8-94.8) |
| | | | TCC operation | 99-124 (61-77) | 127-153 (78.8-94.8) |
| | | Closed throttle posi- tion (0.1-1.1 V) | D ₄ D ₃ | 29-35 (18-22) | 27-33 (17-20) |
| | | | D ₃ D ₁ | 9-15 (5.6-9.3) | 12-18 (7.5-11) |
| | | Kickdown | D ₄ D ₃ | 142-152 (88.1-94.2) | 155-165 (96.1-102) |
| | | | D ₃ D ₂ | 82-90 (51-55) | 94-102 (59-63.2) |
| | | | D ₂ D ₁ | 42-48 (27-29) | 52-58 (33-35) |
| | S | Wide open throttle (3.1-4.4 V) | S ₁ S ₂ | 58-64 (36-40) | 59-65 (37-40) |
| | | | S ₂ S ₃ | 102-110 (63-68) | 101-109 (62.7-67.5) |
| | | Half throttle (1.7-2.7 V) | S ₁ S ₂ | 34-43 (22-26) | 39-48 (25-29) |
| | | | S ₂ S ₃ | 60-77 (37-48) | 70-88 (44-54) |
| | | Closed throttle posi- tion (0.1-1.1 V) | S ₄ S ₃ | 166-172 (103-107) | 167-173 (104-107) |
| | | | S ₃ S ₁ | 9-15 (5.6-9.3) | 12-18 (7.5-11) |
| | Kickdown | S ₃ S ₂ | 82-90 (51-55) | 94-102 (59-63.2) | |
| | | S ₂ S ₁ | 42-48 (27-29) | 52-58 (33-35) | |
| | L | Wide open throttle (3.1-4.4 V) | L ₁ L ₂ | 58-64 (36-40) | 59-65 (37-40) |
| | | | L ₁ L ₂ | 34-43 (22-26) | 39-48 (25-29) |
| | | Closed throttle posi- tion (0.1-1.1 V) | L ₂ L ₁ | 9-15 (5.6-9.3) | 12-18 (7.5-11) |
| | | | L ₂ L ₁ | 42-48 (27-29) | 52-58 (33-35) |
| Hold | D | — | D ₁ D ₂ | 27-33 (17-20) | 27-33 (17-20) |
| | | | D ₂ D ₃ | 40-50 (25-31) | 40-50 (25-31) |
| | | | D ₄ D ₃ | 166-172 (103-107) | 167-173 (104-107) |
| | | | D ₃ D ₁ | 9-15 (5.6-9.3) | 12-18 (7.5-11) |
| | S | — | S ₄ S ₃ | 166-172 (103-107) | 167-173 (104-107) |
| | | | S ₃ S ₂ | 101-107 (62-66) | 100-106 (62-65.7) |
| | L | — | L ₂ L ₁ | 43-49 (27-30) | 52-58 (33-35) |

M. FRONT AND REAR AXLES

| Item | Engine/Transaxle | B6 DOHC | | K8 DOHC | |
|---|------------------|--------------|---------------|---------------|---------------|
| | | MTX | ATX | MTX | ATX |
| Front axle | | | | | |
| Maximum wheel bearing play | mm {in} | 0.05 {0.002} | | | |
| Rear axle | | | | | |
| Maximum wheel bearing play mm {in} | Drum brake type | 0.05 {0.002} | | | |
| | Disc brake type | 0.05 {0.002} | | | |
| Drive shaft | | | | | |
| Length of joint (between center of joint) mm {in} | Right side | NON ABS | 380.5 {14.98} | 388.9 {15.31} | 384.5 {15.14} |
| | | ABS | | 384.9 {15.15} | |
| | Left side | NON ABS | 397.0 {15.63} | 379.5 {14.94} | 396.0 {15.59} |
| | | ABS | | 375.5 {14.78} | |
| Shaft diameter mm {in} | Right side | 23.0 {0.91} | | 25.0 {0.98} | |
| | Left side | 21.5 {0.85} | | 25.0 {0.98} | |

N. STEERING SYSTEM

| Item | Engine | B6 DOHC | K8 DOHC |
|---|---------------------------------|--|---------------------|
| Steering wheel | | | |
| Outer diameter | mm {in} | 370 {14.6}, 380 {14.96} (With air bag) | |
| Free play | mm {in} | 0-30 {0-1.18} | |
| Wheel effort | N {kgf, lbf} | 29 {3.0,6.6} or less | |
| Lock-to-lock | turns | 3.1 | 2.7 |
| Steering Shaft | | | |
| Shaft type | | Collapsible | |
| Joint type | | 2-cross joint | |
| Power steering system | | | |
| Power assist type | | Engine speed sensing | |
| Gear type | | Rack-and-pinion | |
| Gear ratio | | 15.0 | |
| Rack stroke | mm {in} | 140 {5.51} | |
| Power steering fluid | | ATF M-III or Dexron®-II | |
| Fluid capacity | L {US qt, Imp qt} | 0.8 {0.85,0.70} | 1.2 {1.27,1.06} |
| Fluid pressure | kPa {kgf/cm ² , psi} | 7,846-8,335 {80.0-85.0, 1,138-1,208} | |
| Drive belt deflection mm {in}/9.8N {10 kgf, 22 lbf} | New | 8.0-9.0 {0.32-0.35} | 6.0-7.0 {0.24-0.27} |
| | Used | 9.0-10.0 {0.36-0.39} | 7.0-8.0 {0.28-0.31} |
| | Limit | 11.5 {0.45} | 9.0 {0.35} |

P. BRAKING SYSTEM

| Item | Engine | | B6 DOHC | K8 DOHC |
|-------------------------------------|--|---------------|---|---|
| | | | | |
| Brake pedal | Height (with carpet) | mm {in} | 193-196 {7.60-7.71} | |
| | Free play | mm {in} | 4-7 {0.16-0.27} | |
| | Reserve travel (without carpet, clearance when pedal is depressed at 589 N {60 kgf, 132 lbf}) | mm {in} | 70 {2.76} | |
| Master cylinder | Type | | Tandem | |
| | Bore | mm {in} | 22.22 {0.875} | 23.81 {0.937} |
| | Fluid type | | SAEJ1703 or FMVSS116, DOT-3 | |
| Front brake (Disc) | Type | | Disc (Ventilated) | |
| | Thickness of pad mm {in} | Standard | 10.0 {0.39} | |
| | | Limit | 2.0 {0.08} | |
| | Thickness of disc plate mm {in} | Standard | 22.0 {0.87} | |
| | | Limit | 20.0 {0.79} | |
| | Disc plate runout | mm {in} | 0.05 {0.002} max. | |
| Cylinder bore | mm {in} | 53.97 {2.125} | | |
| Rear brake (Drum) | Type | | Drum (Leading-trailing) | — |
| | Clearance between shoe and drum | | Self-adjusting | — |
| | Thickness of lining mm {in} | Standard | 4.0 {0.16} | — |
| | | Minimum | 1.0 {0.04} | — |
| | Width of lining | mm {in} | 35.0 {1.38} | — |
| | Length of lining | mm {in} | 191.9 {7.56} | — |
| | Inner diameter of drum mm {in} | Standard | 200.0 {7.87} | — |
| Maximum | | 201.0 {7.91} | — | |
| Wheel cylinder bore | mm {in} | 17.46 {0.687} | — | |
| Rear brake (Disc) | Type | | — | Disc (Solid) |
| | Thickness of pad mm {in} | Standard | — | 7.5 {0.3} |
| | | Limit | — | 1.0 {0.04} |
| | Thickness of disc plate mm {in} | Standard | — | 9.0 {0.35} |
| | | Limit | — | 8.0 {0.31} |
| | Disc plate runout | mm {in} | 0.05 {0.002} max. | |
| Cylinder bore | mm {in} | — | 30.2 {1.19} | |
| Parking brake | Lever notches (Pulled at 98N {10 kgf, 22 lbf}) | | 5-7 | |
| Power brake unit | Type | | Single diaphragm | Tandem diaphragm |
| | Diameter | mm {in} | 214.0 {8.4} | 188.4+215.2 {7.4+8.5} |
| | Push rod-to-piston clearance | mm {in} | With vacuum applied to unit (approx. 66.7 kPa {500 mmHg, 19.7 inHg}) 0.1-0.4 {0.004-0.0016} | With vacuum applied to unit (approx. 66.7 kPa {500 mmHg, 19.7 inHg}) 0 {0} |
| | Fluid pressure per treading force kPa {kgf/cm ² , psi}/196N {20 kgf, 44lbf} | | 589 {6.85} min. at 0 kPa {0 mmHg, 0 inHg} MTX: 6,082 {62,882} min at 66.7kPa {500 mmHg, 19.7 inHg} ATX: 6,769 {69,981} min at 66.7kPa {500 mmHg, 19.7 inHg} | 392 {4, 57} min. at 0 kPa {0 mmHg, 0 inHg} 7,063 {72,1024} min. at 66.7kPa {500 mmHg, 19.7 inHg} |
| Rear wheel hydraulic control system | Type | | Dual Proportioning valve | |
| | Bend portion (Rear brake pressure) kPa {kgf/cm ² , psi} | | 2,943 {30,427} | ABS: 1,962 {20,284} non ABS: 2,453 {25, 356} |

Q. WHEEL AND TIRES

| Item | | | Specifications | | |
|-------|---|---------|-------------------------|----------------|--------------------|
| | | | B6 DOHC | | K8 DOHC |
| Wheel | Size | | 14x5 1/2JJ | | 15x6JJ |
| | Offset | mm {in} | 45 {1.77} | | 45 {1.77} |
| | Pitch circle diameter | mm {in} | 100 {3.94} | | 100 {3.94} |
| | Material | | Steel or aluminum alloy | | Aluminum alloy |
| Tire | Size | | P185/65R14 85S | P205/55R15 87V | P205/55R15 87V M+S |
| | Air pressure kPa {kgf/cm ² , psi} | Front | 216 {2.2,32} | 196 {2.0, 28} | 216{2.2, 32} |
| | | Rear | 216 {2.2,32} | 196 {2.0, 28} | 216 {2.2, 32} |

Temporary spare tire

| Item | | | Specifications | |
|-------|---|---------|----------------|------------|
| | | | B6 DOHC | K8 DOHC |
| Wheel | Size | | 15 × 4T | |
| | Offset | mm {in} | 45 {1.77} | |
| | Pitch circle diameter | mm {in} | 100 {3.94} | |
| | Material | | Steel | |
| Tire | Size | | T115/70D14 | T115/70D15 |
| | Air pressure kPa {kgf/cm ² , psi} | | 415 {4.2,60} | |

R. SUSPENSION

Front Suspension

| Item | | | Model | | K8 DOHC |
|---|-----------------------------|--|---------------------|-----|---------|
| | | | B6 DOHC | | |
| | | | NON ABS | ABS | |
| Type | Strut | | | | |
| Shock absorber | Type | Cylindrical double-acting (Oil-filled) | | | |
| Stabilizer | Type | Torsion bar | | | |
| | Diameter | mm {in} | 22.0 {0.87} | | |
| Wheel alignment (Untaden)* ¹ | Maximum steering angle | Inner | 39° ± 2° | | |
| | | Outer | 33° ± 2° | | |
| | Total toe-in | mm {in} | 3 ± 4 {0.12 ± 0.15} | | |
| | | degree* ² | 0.3° ± 0.4° | | |
| | Camber angle * ³ | -0°58' ± 10 | | | |
| | Caster angle * ³ | 2°46' ± 10 | | | |
| SAI * ⁴ | 14°16' | | | | |

*¹ ● Fuel tank full: radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position

● Adjust to the median when carrying out wheel alignment

*² Indicates measurements made by using the 4-wheel alignment tester

*³ Difference between left and right must not exceed 1.5°

*⁴ SAI: Steering Axis Inclination

Rear Suspension

| Item | | Specifications |
|-----------------------------|-----------------|--|
| Type | | Strut |
| Shock absorber | Type | Cylindrical double-acting (Oil-filled) |
| Stabilizer | Type | Torsion bar |
| | Diameter | mm {in} |
| Wheel alignment (Unladen)*1 | Total toe-in | mm {in} |
| | | degree*2 |
| | Camber angle *3 | |
| | Thrust angle | degree*2 |

*1 ● Fuel tank full; radiator coolant and engine oil at specified level, and spare tire, jack and tools in designated position

● Adjust to the median when carrying out wheel alignment

*2 Indicates measurements made by using the 4-wheel alignment tester

*3 Difference between left and right must not exceed 1.5°

T. BODY ELECTRICAL SYSTEM

| Item | | Specification (W) |
|------------------------------|------------------------------------|-------------------|
| Exterior lights | Headlight | 65/45 (9004) |
| | Front combination light | 27/8 (1157) |
| | Front side marker light | 3.8 (194) |
| | Brake light/Taillight | 27/8 (1157) |
| | Rear side marker light | 3.8 (194) |
| | Rear turn and hazard warning light | 27 (1156) |
| | High-mount brake light | 18.4 (921) |
| | Back-up light | 27 (1156) |
| | License plate light | 5 (168) |
| Interior lights | Interior light | 5 (168) |
| | Cargo compartment light | 5 (168) |
| | Ignition key illumination | 1.4 |
| Indicator and warning lights | High beam indicator light | 3.4 |
| | Turn indicator light | 3.4 |
| | Brake system warning light | 1.4 |
| | HOLD indicator light | 3.4 |
| | Alternator warning light | 3.4 |
| | Oil pressure warning light | 1.4 |
| | ABS warning light | 3 |
| | Seat belt warning light | 3 |
| | Instrument cluster illumination | 3.4,1.4 |
| | Malfunction indicator lamp | 3 |
| | Fuel-level warning light | 3.4 |
| Air bag system warning light | 1.4 | |

U. HEATER AND AIR CONDITIONER SYSTEMS

| Item | | Specifications |
|----------------------|---|---|
| Refrigerant amount | g {oz} | 750 {26.5} |
| Refrigerant pressure | MPa {kgf/cm ² , psi} | High: 1.23-1.61 {12.5-16.5, 178-234} Low: 0.14-0.16 {1.4-1.7, 20-24} |
| A/C compressor | Discharge capacity ml {cc, fl oz} / rev | 130 {130, 4.39} |
| | Compressor oil amount ml {cc, fl oz} | 175-185 {175-185, 5.92-6.25} |

STANDARD BOLT AND NUT TIGHTENING TORQUE

| Diameter mm {in} | Pitch mm {in} | 4T | | | 6T | | | 8T | | |
|------------------|---------------|---------|-----------|----------|---------|----------|---------|----------|---------|---------|
| | | N·m | kgf·m | ft·lbf | N·m | kgf·m | ft·lbf | N·m | kgf·m | ft·lbf |
| 6 {0.236} | 1 {0.039} | 4.3-6.1 | 0.43-0.63 | 3.2-4.5 | 6.9-9.8 | 0.7-1.0 | 5.0-7.2 | 7.9-11.7 | 0.8-1.2 | 5.8-8.6 |
| 8 {0.315} | 1.25 {0.049} | 10-14 | 1.0-1.5 | 7.3-10.8 | 16-22 | 1.6-2.3 | 12-16 | 18-26 | 1.8-2.7 | 13-19 |
| 10 {0.394} | 1.25 {0.049} | 20-28 | 2.0-2.9 | 15-20 | 32-46 | 3.2-4.7 | 24-33 | 37-53 | 3.7-5.5 | 27-39 |
| 12 {0.472} | 1.5 {0.059} | 35-50 | 3.5-5.1 | 26-36 | 55-80 | 5.6-8.2 | 41-59 | 63-93 | 6.4-9.5 | 47-68 |
| 14 {0.551} | 1.5 {0.059} | — | — | — | 76-102 | 7.7-10.5 | 56-75 | 98-137 | 10-14 | 73-101 |
| 16 {0.630} | 1.5 {0.059} | — | — | — | 118-156 | 12-16 | 87-115 | 157-215 | 16-22 | 116-159 |
| 18 {0.709} | 1.5 {0.059} | — | — | — | 167-225 | 17-23 | 123-166 | 226-304 | 23-31 | 167-224 |
| 20 {0.787} | 1.5 {0.059} | — | — | — | 236-313 | 24-32 | 174-231 | 305-421 | 31-43 | 225-311 |
| 22 {0.866} | 1.5 {0.059} | — | — | — | 314-421 | 32-43 | 232-311 | 422-568 | 43-58 | 311-419 |
| 24 {0.945} | 1.5 {0.059} | — | — | — | 403-549 | 41-56 | 297-405 | 540-725 | 55-74 | 398-535 |

Before beginning any service procedure, refer to section S of this manual for air bag system service warnings.

EXTERIOR LIGHTING SYSTEM

| | |
|--|------|
| STRUCTURAL VIEW..... | E- 2 |
| AIMING..... | E- 4 |
| TROUBLESHOOTING | E- 5 |
| HEADLIGHT AND FRONT COMBINATION LIGHT..... | E-32 |
| REAR COMBINATION LIGHT AND REAR SIDE MARKER LIGHT | E-33 |
| FRONT SIDE MARKER LIGHT..... | E-34 |
| LICENCE PLATE LIGHT | E-35 |
| DRL RESISTOR (CANADA)..... | E-36 |
| PARKING BRAKE SWITCH..... | E-36 |


Before beginning any service procedure, refer to section S of this manual for air bag system service warnings.

HEATER AND AIR CONDITIONER SYSTEMS

| | |
|--|------|
| INDEX | G- 2 |
| HEATER | G- 2 |
| AIR CONDITIONER | G- 3 |
| CAUTIONARY POINTS FOR MAINTENANCE | G- 4 |
| REFRIGERANT-134a (R-134a) | G- 4 |
| SERVICE WARNINGS | G- 6 |
| SERVICE CAUTIONS | G- 6 |
| TROUBLESHOOTING | G- 7 |
| FLOW OF TROUBLESHOOTING..... | G- 7 |
| CHECKLIST | G- 7 |
| WIRING DIAGRAM | G- 8 |
| FLOWCHARTS | G-12 |
| HEATER | G-36 |
| STRUCTURAL VIEW | G-36 |
| HEATER UNIT | G-37 |
| AIRFLOW MODE ACTUATOR..... | G-39 |
| BLOWER UNIT | G-40 |
| BLOWER MOTOR | G-42 |
| RESISTOR | G-42 |
| AIR INTAKE ACTUATOR | G-42 |
| BLOWER RELAY | G-42 |
| HEATER CONTROL UNIT | G-43 |
| AIR INTAKE WIRE | G-47 |
| AIRFLOW MODE WIRE..... | G-47 |
| AIR MIX WIRE | G-48 |
| AIR CONDITIONER | G-49 |
| STRUCTURAL VIEW | G-49 |
| REFRIGERANT SYSTEM SERVICE PROCEDURES | G-50 |
| A/C COMPRESSOR | G-54 |
| MAGNETIC CLUTCH | G-62 |
| CONDENSER FAN | G-63 |
| CONDENSER | G-64 |
| RECEIVER / DRIER | G-65 |
| REFRIGERANT PRESSURE SWITCH | G-65 |
| COOLING UNIT | G-67 |
| RELAYS | G-70 |
| REFRIGERANT LINES | G-71 |
| CONNECTOR LOCATIONS..... | G-72 |


INDEX

HEATER



| | | | |
|-------------------------------|-----------|------------------------------|-----------|
| 1. Heater unit | | 3. Heater control unit | |
| Removal / Installation | page G-37 | Removal / Installation | page G-43 |
| Disassembly / Inspection / | | Disassembly / Assembly | page G-44 |
| Assembly | page G-38 | Inspection | page G-46 |
| Airflow mode actuator | | Air intake wire | |
| Inspection | page G-39 | Adjustment | page G-47 |
| 2. Blower unit | | Airflow mode wire | |
| Removal / Installation | page G-40 | Adjustment | page G-47 |
| Disassembly / Assembly | page G-41 | Air mix wire | |
| Blower motor (in blower unit) | | Adjustment | page G-48 |
| Inspection | page G-42 | | |
| Resistor (in blower unit) | | | |
| Inspection | page G-42 | | |
| Air intake actuator | | | |
| Inspection | page G-42 | | |
| Blower relay | | | |
| Removal / Installation | page G-42 | | |
| Inspection | page G-42 | | |

AIR CONDITIONER



G

| | |
|---------------------------------|-----------|
| 1. A/C compressor | |
| Removal / Installation | page G-54 |
| Disassembly / Assembly | page G-56 |
| 2. Magnetic clutch | |
| Disassembly / Assembly | page G-62 |
| Inspection | page G-62 |
| 3. Condenser fan | |
| Removal / Installation | page G-63 |
| Inspection | page G-63 |
| 4. Condenser | |
| Removal / Installation | page G-64 |
| Inspection | page G-64 |
| 5. Receiver/drier | |
| Removal / Installation | page G-65 |
| 6. Refrigerant pressure switch | |
| Removal / Installation..... | page G-65 |
| Inspection | page G-65 |
| 7. Cooling unit | |
| Removal / Installation..... | page G-67 |
| Disassembly / Assembly | page G-68 |
| Replacement (expansion valve) . | page G-68 |
| 8. Relays | |
| Removal / Installation | page G-70 |
| Inspection | page G-70 |
| 9. Refrigerant lines | |
| On-vehicle Inspection..... | page G-71 |
| Removal / Installation..... | page G-71 |

CAUTIONARY POINTS FOR MAINTENANCE

REFRIGERANT-134a (R-134a)

Outline

- R-12 and other fluorocarbons now used in air conditioners can destroy the ozone layer in the stratosphere. The result is an increase in hazardous ultraviolet rays which over time can adversely affect both human health and the biosphere. Because of this concern, Mazda has chosen to use Refrigerant-134a (R-134a), a hydrofluorocarbon-based refrigerant that does not deplete the ozone layer, in this vehicle.
- R-12 and R-134a are not interchangeable; system parts and system service tools also differ. The table below compares the two systems.

Refrigerant systems

| Part | R-12 system | R-134a system | Remarks |
|----------------|---|---|--|
| Refrigerant | Chlorofluorocarbon-12 (CFC-12) (CCl ₂ F ₂) | Hydrofluorocarbon-134a (HFC-134a) (CH ₂ FCF ₃) | If the refrigerants are mixed or one refrigerant is used in a system that requires the other, the compressor oil will separate from the refrigerant and not circulate within the system. This can damage the A/C compressor and cause abnormal A/C compressor vane noise. In addition, mixing R-134a with R-12 or using R-134a instead of R-12 in an R-12 system can lower the durability of the NBR O-ring and dissolve the fluorine rubber O-rings. If the fluorine rubber O-rings are dissolved, refrigerant may leak. |
| Compressor oil | Mineral oil | Polyalkylene glycol oil (PAG oil) [ATMOS GU10] | Special compressor oils for R-134a air conditioning systems are developed by each air conditioning vendor. Therefore, use only the specified oil for each model vehicle. If a PAG oil other than the specified type is used, the A/C compressor and refrigerant system can be damaged. If the compressor oils are mixed or one compressor oil is used in a system that requires the other, the compressor oil will separate from the refrigerant and not circulate within the system. This can damage the A/C compressor and cause abnormal A/C compressor vane noise. Mixing PAG oil with mineral oil or using PAG oil instead of mineral oil in an R-12 system can lower the durability of the NBR and fluorine rubber O-rings. |
| O-ring | Nitrile butadiene rubber (NBR) Fluorine rubber | High-rotated nitrile butadiene rubber (HNBR) | If an NBR O-ring is used in an R-134a system, the PAG oil and R-134a will lower the durability of the O-ring. If a fluorine rubber O-ring is used in an R-134a system, the R-134a will dissolve the O-ring and cause the refrigerant to leak. |

(Cont'd)

| Part | R-12 system | R-134a system | Remarks |
|----------------|--|--|--|
| Joint nuts | Inch threads | Metric threads | Thread standards for joint nuts connecting cooler pipes and hoses have been changed to avoid connecting R-12 system parts with R-134a system parts. |
| Joint blocks | Refer to remarks | | The bolt sizes and part measurements for joint blocks connecting cooler pipes and cooler hoses have been changed to avoid connecting R-12 system parts with R-134a system parts. |
| Charging valve | Screw-on type Hi: 3/8-24 UNF Lo: 7/16-20 UNF | Quick-connect type Hi: 16 mm {0.6 in} dia. Lo: 13 mm {0.5 in} dia. | The shape of the charging valve differs for each system to avoid confusion. The quick-connect charging valve prevents refrigerant from leaking when the charging hose is connected to the valve. |

Service tools

| Part | R-12 system | R-134a system | Remarks |
|-----------------------|---|---|---|
| Tool joints | Inch threads | Metric threads | Thread standards for tool joints have been changed to avoid connecting R-12 system tools with R-134a system tools. |
| Charging valve joints | Screw-on type Hi: 3/8-24 UNF Lo: 7/16-20 UNF | Quick-connect type Hi: 16 mm {0.6 in} dia. Lo: 13 mm {0.5 in} dia. | The shape of the charging valve joints differs for each system to avoid confusion. The quick-connect charging valve joint prevents refrigerant from leaking when the charging hose is connected to the valve. |
| Manifold gauge | High-pressure-side maximum reading: 2.9 MPa {30 kg/cm ² , 430 psi} | High-pressure-side maximum reading: 3.5 MPa {35 kg/cm ² , 500 psi} | R-134a requires a higher pressure to condense than R-12. |
| Leak tester | Gas type Electric type | Electric type | A gas leak tester reacts with chlorine in R-12 to indicate the location of a leak. This kind of tester does not work with an R-134a system, however, because R-134a has no chlorine. Two kinds of electric testers are available: those that work exclusively with one system or the other and those that work with both. |

SERVICE WARNINGS


Using/Handling Unapproved Refrigerant

- * Using a flammable refrigerant, such as OZ-12, in this vehicle is dangerous. In an accident, the refrigerant may catch fire, resulting in serious injury or death. When servicing this vehicle, use only R-134a.
- * Checking for system leaks on a vehicle that has been serviced with flammable refrigerant, such as OZ-12, is dangerous. Conventional leak detectors use an electronically generated arc which can ignite the refrigerant, causing serious injury or death. If a flammable refrigerant may have been used to service the system, or if you suspect a flammable refrigerant has been used, contact the local fire marshall or EPA office for information on handling the refrigerant.




Storing Refrigerant

- The refrigerant container is highly pressurized. If it is subjected to high heat, it could explode, scattering metal fragments and liquid refrigerant that can seriously injure you. Store the refrigerant at temperatures below 40 °C {104 °F}.



Handling Refrigerant


- Handling liquid refrigerant is dangerous. A drop of it on the skin can result in localized frostbite. When handling the refrigerant, wear gloves and safety goggles. If refrigerant splashes into the eyes, immediately wash them with clean water and consult a doctor.



SERVICE CAUTIONS

Compressor Oil (ATMOS GU10)


- Do not spill compressor oil on the vehicle. A drop of compressor oil on the vehicle surface can eat away at the paint. If oil gets on the vehicle, wipe it off immediately.
- PAG oil (ATMOS GU10) has a higher moisture absorption efficiency than the previously used mineral oil. If moisture mixes with the compressor oil, the refrigerant system could be damaged. Therefore, install caps immediately after using the compressor oil or removing refrigerant system parts to prevent moisture absorption.



TROUBLESHOOTING

FLOW OF TROUBLESHOOTING

Follow the steps below to troubleshoot the heater and air conditioner.




CHECKLIST







- When inspecting the heater or air conditioner, warm up the engine before each operational check. The engine coolant temperature must be 40 °C {104 °F} or higher.
- The air conditioner is composed of an electrical system as well as a refrigerant system. Because some refrigerant system components require the evacuation of refrigerant gas before replacement, inspect the electrical system first.

| Operational check | Symptom | Flowchart No. |
|--|---|---------------|
| Check motor operation when fan switch is turned to 1st, 2nd, 3rd, and 4th respectively. | Blower motor does not operate at any fan switch position | 1 |
| | Blower motor does not operate with fan switch at specific position | 2 |
| Turn on fan switch and A/C switch on; check operation of magnetic clutch and condenser fan. | Magnetic clutch and condenser fan do not operate | 3 |
| | Magnetic clutch does not operate, but condenser fan operates normally | 4 |
| | Condenser fan does not operate, but magnetic clutch operates normally | 5 (K8) |
| | | 6 (B6) |
| | Airflow is not cool; magnetic clutch and condenser fan operate | 13 |
| Engine overheats at high load; A/C operates normally | 7 (K8) | |
| | 8 (logic type) | |
| Move mode switch or lever to each mode and verify that air outlets change accordingly. | 9 (w re type) | |
| | 10 (logic type) | |
| Move REC/FRESH switch or lever and verify that recirculation and fresh change accordingly | 11 (w re type) | |
| | 12 | |
| Move temperature control lever from MAX COLD to MAX HOT and verify that airflow temperature changes. | Airflow temperature does not change | 12 |
| Check refrigerant amount. (Refer to page G-53.) | Airflow is not cool; magnetic clutch and condenser fan operate | 13 |

WIRING DIAGRAM


G-1 B6 DOHC ■ CONDENSER FAN SYSTEM CANADA









| | | | |
|--|--|---|---|
| <p>G1-01 A/C RELAY (AC)</p>  | <p>G1-02 CONDENSER FAN RELAY (AC)</p>  | <p>G1-03 MAGNETIC CLUTCH (AC)</p>  | <p>G1-04 CONDENSER FAN (AC)</p>  |
| <p>G1-05 CONNECTION BL. W/IN ENGINE (L) AND A/C (AC)</p>  | <p>G1-06 CONNECTION BL. W/IN ENGINE (L) AND A/C (AC)</p>  | | |

G-2 K8 DOHC ■ CONDENSER FAN SYSTEM


© J.I.C. CANADA















| | | | |
|---|---|---|---|
| <p>G2-01 A/C RELAY (AC)</p>  | <p>G2-02 CONDENSER FAN RELAY NO. 1 (AC)</p>  | <p>G2-03 CONDENSER FAN RELAY NO. 2 (AC)</p>  | <p>G2-04 CONDENSER FAN RELAY NO. 3 (AC)</p>  |
| <p>G2-05 MAGNETIC CLUTCH (AC)</p>  | <p>G2-06 CONDENSER FAN RELAY NO. 3 (AC)</p>  | | |

G


G-3 WIRE TYPE ■ HEATER AND AIR CONDITIONER (B6 DOHC ONLY)




| | | | | | |
|--|---|---|---|---|--|
| <p>G3-02 REFRIGERANT PRESSURE SWITCH (G3-02)</p>  | <p>G3-03 EVAPORATOR PRESSURE SENSOR (G3-03)</p>  | <p>G2-04 BLOWER RELAY (G2-04)</p>  | <p>G2-03 BLOWER RELAY (G2-03)</p>  | <p>G2-02 HEATER RELAY (G2-02)</p>  | <p>G3-04 CIRCUIT BREAKER (G3-04)</p>  |
| <p>G3-02 REFRIGERANT PRESSURE SWITCH (G3-02)</p>  | <p>G3-03 EVAPORATOR PRESSURE SENSOR (G3-03)</p>  | <p>G2-04 BLOWER RELAY (G2-04)</p>  | <p>G2-03 BLOWER RELAY (G2-03)</p>  | <p>G2-02 HEATER RELAY (G2-02)</p>  | <p>G3-04 CIRCUIT BREAKER (G3-04)</p>  |

FLOWCHARTS


| | |
|---------------|---|
| Flowchart No. | SymptomBlower motor does not operate at any fan switch position Related components ...Fuse, blower relay, blower motor, resistor, fan switch, wiring harness |
| 1 | |

**System Operation**

- Blower motor speed is controlled by the fan switch and resistor in the blower unit. When the fan switch is in the OFF position, the motor ground circuit is open and the blower motor does not operate. When the switch is in the first position, current flow from the blower motor is restricted by the resistor, and the blower motor turns at low speed.
- Changing the fan switch to the second, third, or fourth positions causes the circuit resistance to decrease and the blower speed to increase.

**Step 1**


1. Check the HEATER 30A fuse (circuit breaker) in the joint box.
2. If the reset button is not out, go to Step 2.
3. If the reset button is out, check for a short circuit in the harness. Repair as necessary, and then depress the reset button to reset the circuit breaker.



Step 2

Check the REAR WIPER 10A fuse in the fuse block.

| Fuse | Action |
|-------|--|
| OK | Go to Step 3 |
| Burnt | Replace fuse after checking and repairing wiring harness |




Step 3

1. Turn the ignition switch to ON.
2. Set the fan switch to the fourth position.
3. Measure the voltage at the following terminal wires of the blower relay connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|--|
| (GY) | B+ | Measure voltage at (L/W) wire |
| | Other | Repair wiring harness (REAR WIPER 10A fuse—Blower relay) |
| (L/W) | B+ | Measure voltage at (B) wire |
| | Other | Repair wiring harness (Circuit breaker—Blower relay) |
| (B) | B+ | Repair wiring harness (Blower relay—GND) |
| | Other | Measure voltage at (L) wire |
| (L) | B+ | Go to Step 4 |
| | Other | Replace blower relay (Refer to page G-42) |




Step 4

1. Verify that the ignition switch is at ON and that the fan switch is in the fourth position.
2. Measure the voltage at the following terminal wires of the blower motor connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|---|
| (L) | B+ | Measure voltage at (L/W) wire |
| | Other | Repair wiring harness (Blower relay—Blower motor) |
| (L/W) | 0V | Replace blower motor (Refer to page G-41) |
| | Other | Go to Step 5 |




Step 5

Measure the voltage at the (L/W) terminal wire of the resistor connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|---|
| 0V | Repair wiring harness (Blower motor—Resistor) |
| Other | Go to Step 6 |




Step 6

1. Turn the fan switch off.
2. Measure the voltage at the (L/W) terminal wire of the resistor connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|---------------------------------------|
| E+ | Go to Step 7 |
| Other | Replace resistor (Refer to page G-41) |





Step 7

1. Turn the ignition switch to OFF.
2. Remove the heater control unit and disconnect the fan switch connector. (Refer to page G-43.)
3. Check for continuity between the (B) terminal wire of the fan switch connector and ground.

| Continuity | Action |
|------------|---|
| Yes | Replace fan switch (Refer to page G-44 or G-45) |
| No | Repair wiring harness (Fan switch—GND) |

| | |
|----------------------|--|
| Flowchart No. | Symptom Blower motor does not operate with fan switch at specific position |
| 2 | Related components ... Resistor, fan switch, wiring harness |




Step 1

1. Turn the ignition switch to ON.
2. Verify that the fan switch is off.
3. Measure the voltage at the following terminal wires of the resistor connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|---------------------------------------|
| (L/W) | B+ | Measure voltage at (L) wire |
| | Other | Replace resistor (Refer to page G-41) |
| (L) | B+ | Measure voltage at (L/R) wire |
| | Other | Replace resistor (Refer to page G-41) |
| (I/R) | B+ | Measure voltage at (L/Y) wire |
| | Other | Replace resistor (Refer to page G-41) |
| (L/Y) | B+ | Go to Step 2 |
| | Other | Replace resistor (Refer to page G-41) |


**Step 2**

1. Verify that the ignition switch is ON.
2. Verify that the fan switch is off.
3. Measure the voltage at the following terminal wires of the fan switch connector.

B+: Battery positive voltage


| Wire | Voltage | Action |
|-------|---------|--|
| (L/W) | B+ | Measure voltage at (L) wire |
| | Other | Repair wiring harness (Resistor—Fan switch) |
| (L) | B+ | Measure voltage at (L/R) wire |
| | Other | Repair wiring harness (Resistor—Fan switch) |
| (L/R) | B+ | Measure voltage at (L/Y) wire |
| | Other | Repair wiring harness (Resistor—Fan switch) |
| (L/Y) | B+ | Replace fan switch (Refer to page G-44 or G-45) |
| | Other | Repair wiring harness (Resistor—Fan switch) |

| | |
|---------------|--|
| Flowchart No. | SymptomMagnetic clutch and condenser fan do not operate |
| 3 | Related components ...Fuse, A/C relay, ECM, heater control unit, thermoswitch, refrigerant pressure switch |



System Operation

- Signals from the fan switch and A/C switch are sent to the ECM.
- The thermoswitch detects the evaporator temperature and opens or closes the circuit to keep the evaporator temperature at a certain level to protect against freezing.
- To help liquefy the refrigerant, the condenser fan rotates and sends airflow to the condenser when the A/C compressor is on.



Step 1






1. Check the following fuses.

| Fuse | Amperage (A) | Location |
|------------|--------------|---|
| REAR WIPER | 10 | Fuse block |
| AD FAN | 40 [20] | Main fuse block No.2 [Main fuse block No.1] |

() B6

2. If the fuses are OK, go to Step 2.

3. If a fuse is burnt, check for a short circuit in the wiring harness before replacing the fuse.



Step 2

1. Turn the ignition switch to ON.
2. Measure the voltage at the following terminal wires of the A/C relay connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|------|---------|---|
| (LY) | B+ | Measure voltage at (GY) wire |
| | Other | Repair wiring harness (AD FAN 40A [K8], AD FAN 20A [B6] fuse—A/C relay) |
| (GY) | B+ | Go to Step 3 |
| | Other | Repair wiring harness (REAR WIPER 10A fuse—A/C relay) |

Step 3

1. Turn the ignition switch to OFF.
2. Remove the A/C relay.
3. Connect battery positive voltage and check for continuity between the terminals of the A/C relay.

B+: Battery positive voltage

| Connection | | Terminal | | | |
|------------|-----|----------|---|-----|-----|
| B+ | GND | A | B | C | D |
| — | — | ○ | ○ | | |
| A | B | | | ○—○ | ○—○ |



○—○ : Continuity

4. If correct, reinstall the A/C relay and go to Step 4.
5. If not as specified, replace the A/C relay.

Step 4

1. Disconnect the ECM connector.
2. Connect a jumper wire between the terminal wires of the ECM connector and ground.
3. Start the engine and verify that the magnetic clutch and condenser fan operate.

| Wire | Magnetic clutch, condenser fan | Action |
|-------|--------------------------------|---|
| (L/B) | Operate | Remove jumper wire, reconnect ECM connector, and go to Step 6 |
| | Do not operate | Remove jumper wire and go to Step 5 |



| Wire | Condenser fan | Action |
|-------|-----------------------|---|
| (Y/B) | Operates (low speed) | Remove jumper wire, reconnect ECM connector, and go to Step 6 |
| | Does not operate | Remove jumper wire and go to Step 5 |
| (P/B) | Operates (high speed) | Remove jumper wire, reconnect ECM connector, and go to Step 6 |
| | Does not operate | Remove jumper wire and go to Step 5 |

Step 5


1. Verify that the engine is running.
2. Measure the voltage at the following terminal wires of the ECM connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|--|
| (L/B) | B+ | Reconnect ECM connector, and go to Step 6 [B6] or measure voltage at (Y/B) wire [K8] |
| | Other | Repair wiring harness (A/C relay—ECM) |
| (Y/B) | B+ | Measure voltage at (P/B) wire |
| | Other | Repair wiring harness (Condenser fan relay No.1—ECM) |
| (P/B) | B+ | Go to Step 6 |
| | Other | Repair wiring harness (Condenser fan relay No.2—ECM) |

Step 6


1. Turn the ignition switch to OFF and disconnect the refrigerant pressure switch connector.
2. Connect a jumper wire between terminals A and B of the refrigerant pressure switch connector.
3. Start the engine.
4. Turn the fan switch and A/C switch on and check the operation of the magnetic clutch and condenser fan.








| Magnetic clutch, condenser fan | Action |
|--------------------------------|---|
| Operate | Go to Step 7 |
| Do not operate | Remove jumper wire, reconnect refrigerant pressure switch connector, and go to Step 8 |

Step 7

1. Connect a manifold gauge set to the charging valves. (Refer to page G-5C.)
2. Measure the high-pressure side pressure.



| Refrigerant pressure | Action |
|---|--|
| 0.21- 2.9 MPa {2.1—30 kgf/cm ² , 30—430 psi} | Replace refrigerant pressure switch (Refer to page G-65) |
| Other | Check for leaks (Refer to page G-51) |



Step 8

1. Verify that the ignition switch and fan switch are on.
2. Measure the voltage at the (G) terminal wire of the heater control unit connector.

B+: Battery positive voltage

| Engine | A/C switch | Voltage (V) | Action |
|--------|------------|-------------|-------------------------------------|
| K8 | ON | 1.5—3.5 | Measure voltage with A/C switch off |
| | | Other | Go to Step 10 |
| | OFF | 4.5—5.5 | Go to Step 9 |
| | | Other | Go to Step 10 |
| B6 | ON | Below 2.5 | Measure voltage with A/C switch off |
| | OFF | Other | Go to Step 10 |
| | | B+ | Go to Step 9 |
| | | Other | Go to Step 10 |

Step 9

1. Measure the voltage at the (GY) terminal wire of the heater control unit connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|---|
| B+ | Replace heater control unit (Refer to page G-43) |
| Other | Repair wiring harness (REAR W PER 10A—Heater control unit) |

Step 10

1. Remove the glove compartment and glove compartment cover.
(Refer to the 1995 MX-3 Workshop Manual, section S.)
2. Measure the voltage at the (G) terminal wire of the thermoswitch connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|---|
| B+ | Go to Step 11 |
| Other | Repair wiring harness (Thermoswitch—Heater control unit) |

Step 11

1. Measure the voltage at the (B/R) terminal wire of the refrigerant pressure switch connector.


B+: Battery positive voltage

| Voltage | Action |
|---------|---------------|
| B+ | Go to Step 13 |
| Other | Go to Step 12 |

Step 12

1. Disconnect the thermoswitch connector.
2. Check for continuity between terminals A and B of the thermoswitch.

| Continuity | Action |
|------------|---|
| Yes | Repair wiring harness (Refrigerant pressure switch—Thermoswitch) |
| No | Replace thermoswitch (Refer to page G-68) |




Step 13

Measure the voltage at the (BR) terminal wire of the ECM connector.

B+: Battery positive voltage


| Voltage | Action |
|---------|--|
| B+ | Check ECM (Refer to 1995 MX-3 Workshop Manual, sections F1 and F2) |
| Other | Repair wiring harness (ECM—Refrigerant pressure switch) |

| | |
|----------------------|--|
| Flowchart No. | SymptomMagnetic clutch does not operate, but condenser fan operates normally |
| 4 | Related componentsMagnetic clutch, wiring harness |



System Operation

- When the fan switch and A/C switch are turned on, the ECM receives a signal that the A/C switch and fan switch are on and creates a ground circuit. The A/C relay is magnetized and the contact is closed. Battery positive voltage is applied to the magnetic clutch and the clutch locks.
- The ECM also controls the condenser fan depending on engine load.





Remedy

1. Turn the fan switch and A/C switch on.
2. Measure the voltage at the (R) terminal wire of the magnetic clutch connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|--|
| B+ | Check magnetic clutch (Refer to page G-52) |
| Other | Repair wiring harness (A/C relay—Magnetic clutch) |


| | |
|----------------------|---|
| Flowchart No. | SymptomCondenser fan does not operate, but magnetic clutch operates normally [K8] |
| 5 | Related components...Fuse, condenser fan relay No.1, condenser fan, ECM, wiring harness |



Step 1

Check the ENGINE 10A fuse in the fuse block.

| Fuse | Action |
|-------|--|
| OK | Go to Step 2 |
| Burnt | Replace fuse after checking and repairing wiring harness |



Step 2

1. Disconnect the ECM connector.
2. Connect a jumper wire between the (Y/B) terminal wire of the ECM connector and ground.
3. Turn the ignition switch to ON.
4. Verify that the condenser fan operates.



| Condenser fan | Action |
|------------------|--|
| Operates | Check ECM (Refer to 1985 MX-3 Workshop Manual, section F2) |
| Does not operate | Remove jumper wire and go to Step 3. |

Step 3

1. Verify that the ECM connector is disconnected.
2. Verify that the ignition switch is at ON.
3. Measure the voltage at the following terminal wires of the condenser fan relay No.1 connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|--|
| (B/W) | B+ | Measure voltage at (Y/B) wire |
| | Other | Repair wiring harness (ENGINE 10A fuse—Condenser fan relay No.1) |
| (Y/B) | B+ | Measure voltage at (L/Y) wire |
| | Other | Replace condenser fan relay No.1 |
| (L/Y) | B+ | Measure voltage at (L/R) wire |
| | Other | Repair wiring harness (AD FAN 4CA fuse—Condenser fan relay No.1) |
| (L/R) | B+ | Go to Step 4 |
| | Other | Replace condenser fan relay No.1 |



Step 4

1. Verify that the ignition switch is at ON.
2. Measure the voltage at the (Y/B) terminal wire of the ECM connector.

B+: Battery positive voltage


| Voltage | Action |
|---------|--|
| B+ | Go to Step 5 |
| Other | Repair wiring harness (Condenser fan relay No.1—ECM) |

Step 5



Measure the voltage at the following terminal wires of the condenser fan connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|--|
| (L/R) | B+ | Measure voltage at (B) wire |
| | Other | Repair wiring harness (Condenser fan relay No.1—Condenser fan) |
| (B) | 0V | Check condenser fan (Refer to page G-63) |
| | Other | Repair wiring harness (Condenser fan—GND) |



| | |
|----------------------|---|
| Flowchart No. | SymptomCondenser fan does not operate, but magnetic clutch operates normally [B6] |
| 6 | Related components ...Condenser fan relay, condenser fan, wiring harness |



Step 1

1. Start the engine.
2. Turn the fan switch and A/C switch on.
3. Measure the voltage at the following terminal wires of the condenser fan relay connector.


B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|---|
| (R) | B+ | Measure voltage at (B) wire |
| | Other | Repair wiring harness (A/C relay - Condenser fan relay) |
| (B) | 0V | Measure voltage at (L/Y) wire |
| | Other | Repair wiring harness (Condenser fan relay—GND) |
| (L/Y) | B+ | Measure voltage at (B/L) wire |
| | Other | Repair wiring harness (AD FAN 20A fuse - Condenser fan relay) |
| (B/L) | B+ | Go to Step 2 |
| | Other | Replace condenser fan relay |

Step 2


Measure the voltage at the following terminal wires of the condenser fan connector.

B+: Battery positive voltage



| Wire | Voltage | Action |
|-------|---------|---|
| (B/L) | B+ | Measure voltage at (B) wire |
| | Other | Repair wiring harness (Condenser fan relay - Condenser fan) |
| (B) | 0V | Check condenser fan (Refer to page G-63) |
| | Other | Repair wiring harness (Condenser fan—GND) |

| | |
|---------------------------|--|
| Flowchart No. 7 | SymptomEngine overheats at high load; A/C operates normally [K8] Related components ...ECM, condenser fan, condenser fan relay No.2, condenser fan relay No.3, wiring harness |
|---------------------------|--|




Normal Operation

To keep the engine from overheating, engine speed is controlled in two phases by combining condenser fan operation and engine coolant temperature as shown below. This operation is controlled by the condenser fan relay No.1, condenser fan relay No.2, and condenser fan relay No.3.

Condition


| Condenser fan rotation speed | Condenser fan relay | | | Engine coolant temperature |
|------------------------------|---------------------|------|------|----------------------------|
| | No.1 | No.2 | No.3 | |
| Low | ON | OFF | OFF | above 100°C {212°F} |
| High | ON | ON | ON | above 108°C {226°F} |



Step 1

1. Connect a jumper wire between the (R/Y) terminal wire of the condenser fan relay No.2 connector and ground.
2. Turn the ignition switch to ON.
3. Verify that the condenser fan operates at high speed.

| Condenser fan speed | Action |
|---------------------|--|
| High | Check ECM (Refer to 1995 MX-3 Workshop Manual, section F2) |
| Low | Go to Step 4 |
| Does not operate | Go to Step 2 |




Step 2

1. Verify that the jumper wire is connected and the ignition switch is at ON.
2. Measure the voltage at the (L) terminal wire of the condenser fan connector.

B+: Battery positive voltage

| Voltage | Action |
|---------|--|
| B+ | Check condenser fan (Refer to page G-63) |
| Other | Go to Step 3 |




Step 3

1. Verify that the jumper wire is connected and the ignition switch is at ON.
2. Measure the voltage at the following terminal wires of the condenser fan relay No.2 connector.

B+: Battery positive voltage


| Wire | Voltage | Action |
|-------|---------|--|
| (GY) | B+ | Measure voltage at (L/Y) wire |
| | Other | Repair wiring harness (REAR WIPER 10A fuse—Condenser fan relay No.2) |
| (L/Y) | B+ | Measure voltage at (L) wire |
| | Other | Repair wiring harness (AD FAN 40A fuse—Condenser fan relay No.2) |
| (L) | B+ | Repair wiring harness (Condenser fan relay No.2—Condenser fan) |
| | Other | Replace condenser fan relay No.2 |



Step 4

1. Verify that the jumper wire is connected and the ignition switch is at ON.
2. Measure the voltage at the (L/G) terminal wire of the condenser fan connector.

| Voltage | Action |
|---------|--|
| 0V | Check condenser fan (Refer to page G-63) |
| Other | Go to Step 5 |




Step 5


1. Verify that the jumper wire is connected and the ignition switch is at ON.
2. Measure the voltage at the following terminal wires of the condenser fan relay No.3 connector.

B+: Battery positive voltage

| Wire | Voltage | Action |
|-------|---------|---|
| (GY) | B+ | Measure voltage at (R/Y) wire |
| | Other | Repair wiring harness (REAR WIPER 10A fuse—Condenser fan relay No.3) |
| (R/Y) | 0V | Measure voltage at (L/G) wire |
| | Other | Repair wiring harness (Condenser fan high relay—Condenser fan relay No.3) |
| (L/G) | 0V | Repair wiring harness (Condenser fan—Condenser fan relay No.3) |
| | Other | Measure voltage at (B) wire |
| (B) | 0V | Replace condenser fan relay No.3 |
| | Other | Repair wiring harness (Condenser fan relay No.3—GND) |

| | |
|----------------------|--|
| Flowchart No. | SymptomAirflow mode does not change (logic type) |
| 8 | Related components ...Mode door assembly, airflow mode actuator, heater control unit, wiring harness |






Step 1

1. Disconnect the connecting rod from the mode main link.
2. Turn the ignition switch to ON and set the fan switch to the fourth position.
3. Check the outlet airflow while handling the airflow mode main link.

| Outlet airflow | Action |
|----------------|--|
| Normal | Go to Step 2 |
| Abnormal | Check heater unit (Refer to page G-38) |




Step 2

1. Turn the ignition switch to OFF.
2. Disconnect the airflow mode actuator connector.
3. Connect a jumper wire between the (L/W) and (BR/Y) terminal wires of the airflow mode actuator connector and ground.
4. Turn the ignition switch to ON.
5. Measure the voltage at the following terminal wires of the airflow mode actuator connector.

B+: Battery positive voltage


| Wire | GND | Voltage | Action |
|------|--------|---------|-----------------------------|
| (G) | (L/W) | B+ | Measure voltage at (Y) wire |
| | | Other | Go to Step 4 |
| (Y) | (BR/Y) | B+ | Go to Step 3 |
| | | Other | Go to Step 4 |



Step 3

1. Turn the ignition switch to OFF.
2. Check for continuity between the following terminal wires of the airflow mode actuator connector and ground while turning the mode switches on.

| Wire | Mode switch | Continuity | Action |
|-------|-------------|------------|--|
| (L/B) | VENT | Yes | Check for continuity at (O) wire |
| | | No | Go to Step 4 |
| (O) | B/L | Yes | Check for continuity at (G/O) wire |
| | | No | Go to Step 4 |
| (G/O) | H/LA1 | Yes | Check for continuity at (Y/R) wire |
| | | No | Go to Step 4 |
| (Y/R) | H/D | Yes | Check for continuity at (LG) wire |
| | | No | Go to Step 4 |
| (LG) | DEF | Yes | Replace airflow mode actuator (Refer to page G-38) |
| | | No | Go to Step 4 |




Step 4

1. Verify that the ignition switch is at OFF.
2. Disconnect the heater control unit connector.
3. Check for continuity between the terminal wires of the airflow mode actuator and heater control unit connectors.

| Wire | Continuity | Action |
|---|-----------------|---|
| (L/W) (L/B) (O) (G/O) (Y/R) (LG) (BR/Y) (Y) (G)-(V) | Yes (all) | Check heater control unit (Refer to page G-46) |
| | No (portion) | Repair faulty wiring harness |

| | |
|---------------------------|---|
| Flowchart No. 9 | SymptomAirflow mode does not change (wire type) |
| | Related components ...Airflow mode wire, mode door assembly, mode lever |



Step 1

Verify that the airflow mode wire is secured to the mode door link and that the outer tube is secured by the clip.



| Mode wire/outer tube | Action |
|----------------------|--|
| Secured | Go to Step 2 |
| Not secured | Connect airflow mode wire and/or outer tube (Refer to page G-47) |

Step 2

1. Turn the ignition switch to ON and set the fan switch to the fourth position.
2. Move the mode lever from VENT to DEF and verify that the mode door link operates and the air outlets change.

| Condition | Action |
|--|--|
| Mode door link does not operate | Check connection between mode door and airflow mode wire (Refer to page G-47) |
| Lever sticks, air outlets change | Check wire routing from mode door to mode door link Check lubrication of lever (Refer to page G-47) |
| Air outlets do not change; mode door link operates | Check mode door for damaged (Refer to page G-38) |
| Air outlets and lever indication do not match | Adjust outer tube and mounting (Refer to page G-47) |


| | |
|----------------------|--|
| Flowchart No. | Symptom Intake air mode does not change (logic type) |
| 10 | Related components ... Intake door assembly, air intake actuator, heater control unit, wiring harness |



Step 1

1. Disconnect the connecting rod from the intake door link.
2. Turn the ignition switch to ON and set the fan switch to the fourth position.
3. Check the inlet airflow while handling the intake door link.

| Outlet airflow | Action |
|----------------|--|
| Normal | Go to Step 2 |
| Abnormal | Check blower unit (Refer to page G-41) |




Step 2

Measure the voltage at the (GY) terminal wire of the air intake actuator connector.

B+: Battery positive voltage


| Voltage | Action |
|---------|--|
| B+ | Go to Step 3 |
| Other | Repair wiring harness (REAR WIPER 10A fuse—Air intake actuator) |



Step 3

1. Turn the ignition switch to OFF.
2. Disconnect the air intake actuator connector.
3. Check for continuity between the following terminal wires of the air intake actuator connector and ground while operating the REC/FRESH switch.

| Wire | Switch | Continuity | Action |
|-------|--------|------------|--|
| (L/W) | REC | Yes | Check (L/R) wire |
| | | No | Go to Step 4 |
| (L/R) | FRESH | Yes | Check air intake actuator (Refer to page G-42) |
| | | No | Go to Step 4 |




Step 4

1. Verify that the ignition switch is at OFF.
2. Disconnect the heater control unit connectors.
3. Check for continuity between the following terminal wires of the air intake actuator and heater control unit connectors.

| Wire | Continuity | Action |
|-------|------------|---|
| (L/R) | Yes | Check for continuity at (L/W)-(L) wire |
| | No | Repair wiring harness (Heater control unit—Air intake actuator) |
| (L/W) | Yes | Check heater control unit (Refer to page G-43) |
| | No | Repair wiring harness (Heater control unit—Air intake actuator) |

| | |
|---------------|--|
| Flowchart No. | SymptomIntake air mode does not change (wire type) Related components ...Air intake wire, intake door assembly, REC/FRESH lever |
| 11 | |

**Step 1**

Verify that the air intake wire is secured to the intake door link and that the outer tube is secured by the clip.


| Air intake wire/Outer tube | Action |
|----------------------------|---|
| Secured | Go to Step 2 |
| Not secured | Connect air intake wire and/or outer tube (Refer to page G-47) |

Step 2

Move the REC/FRESH lever from REC to FRESH and check the operation of the intake door.

| Condition | Action |
|---|--|
| Intake door link does not operate | Check connection between REC/FRESH lever and air intake wire (Refer to page G-47) |
| Lever sticks; intake door link operates | Check wire routing from REC/FRESH lever to intake door link Check lubrication on parts of lever (Refer to page G-47) |
| Intake door operates smoothly | Check intake door for damage (Refer to page G-41) |

| | |
|----------------------|--|
| Flowchart No. | SymptomAirflow temperature does not change |
| 12 | Related components ...Air mix wire, mix door assembly, temperature control lever |



Step 1

Verify that the air mix wire is secured to the air mix door link and that the outer tube is secured by the clip.


| Air mix wire/outer tube | Action |
|-------------------------|---|
| Secured | Go to Step 2 |
| Not secured | Connect air mix wire and/or outer tube (Refer to page G-48) |

Step 2

Move the temperature control lever from MAX HOT to MAX COLD and check the operation of the air mix door.


| Condition | Action |
|---|--|
| Air mix door does not operate | Check connection between temperature control lever and air mix wire (Refer to page G-44) |
| Lever sticks; air mix door link operate | Check wire routing from temperature control lever to air mix door link Check lubrication of temperature control lever |
| Air mix door operates smoothly | Check air mix door for damage (Refer to page G-38) |

| | |
|----------------------|---|
| Flowchart No. | Symptom Airflow is not cool; magnetic clutch and condenser fan operate |
| 13 | Related components ... Refrigerant system |



Step 1

1. Install the manifold gauge set. (Refer to page G-50.)
2. Check the refrigerant pressure reading with the engine stopped.
3. Verify that the high- and low-pressure-side readings of the manifold gauge are at 493—788 kPa {5.02—8.04 kgf/cm², 72—114 psi}. If the pressure readings are lower than specified, recharge the refrigerant amount. (Refer to page G-50.) If the pressure readings are within specification but there is insufficient cooling, go to the next step. If the pressure readings are within specification and there are no leaks, the refrigerant amount is OK.
4. Start the engine and run it at a constant 2,000 rpm.
5. Turn the A/C switch on, set the fan switch at MAX-HI, and set the air intake mode at recirculate.
6. If the A/C compressor is short-cycling, note the low-pressure-side reading at which the magnetic clutch kicks out.
7. If the pressure is 170 kPa {1.7 kgf/cm², 24 psi} or lower, evacuate and recharge the refrigerant system with the proper amount of refrigerant. (Refer to page G-50.) If the pressure is 210 kPa {2.1 kgf/cm², 30 psi} or higher, inspect the thermostic switch. (Refer to page G-69.)



Step 2


1. Install the manifold gauge set. (Refer to page G-50.)
2. Shut all doors and windows.
3. Warm up the engine and run it at a constant 1,500 rpm.
4. Set the fan switch to the fourth position.
5. Turn the A/C switch on.
6. Set the REC/FRESH switch (logic type) or REC/FRESH lever (wire type) at recirculate.
7. Set the mode switch (logic type) or mode lever (wire type) at VENT.
8. Set the temperature control lever at MAX COLD.
9. Measure the ambient temperature and the high- and low-pressure-side readings of the manifold gauge.
10. If the high- and low-pressure-side readings are in the shaded zones shown in the figure, the refrigerant system is normal.
11. If not as specified, refer to "Refrigerant pressure flowchart" and repair the air conditioning system. (Refer to page G-35.)

Refrigerant pressure flowchart

| Pressure condition | Step | Procedure | Cause and action |
|---|------|---|--|
| High- and low-pressure-side readings are higher than normal | — | Check condenser fins. (Refer to page G-54) Are they clogged or damaged? | Yes • Insufficient condenser refrigeration Clean or repair condenser fins (Refer to page G-64) |
| | | | No • Too much refrigerant Discharge refrigerant and recharge to proper amount (Refer to page G-50) |
| High- and low-pressure-side readings are lower than normal | 1 | Check all connections. Are there any oil stains? | Yes • Insufficient refrigerant because of leakage Repair leaks and recharge refrigerant to proper amount (Refer to page G-50) |
| | | | No Go to Step 2 |
| | 2 | Check for leakage (Refer to page G-51) Are there any leaks? | Yes • Insufficient refrigerant because of leakage Repair leaks and recharge refrigerant to proper amount (Refer to page G-50) |
| | | | No • Insufficient charging Recharge refrigerant to proper amount (Refer to page G-50) |
| High-pressure-side reading is a little lower than normal; low-pressure-side reading is a little higher than normal | — | Check heat-sensing tube. Is it in its proper position and securely connected to evaporator outlet pipe? | Yes • Expansion valve opening too wide because of expansion valve malfunction Replace expansion valve (Refer to page G-68) |
| | | | No • Expansion valve opening too wide because heat-sensing tube is improperly installed Reinstall heat-sensing tube properly (Refer to page G-68) |
| High-pressure-side reading rises to normal pressure range and then drops below range; low-pressure-side reading is negative | 1 | 1. Turn A/C compressor off for about 10 minutes. 2. Turn A/C compressor on and immediately check pressure reading. Is pressure reading normal? | Yes • Expansion valve clogged because of freezing by moisture Discharge refrigerant and replace receiver/drier (Refer to page G-65) |
| | | | No Go to Step 2 |
| | 2 | Check heat-sensing tube. Is it properly installed? | Yes • Expansion valve clogged with foreign material • Expansion valve opening too wide because of expansion valve malfunction or heat-sensing tube leakage Replace expansion valve (Refer to page G-68) |
| | | | No • Expansion valve opening too narrow because heat-sensing tube is improperly installed Reinstall heat-sensing tube properly (Refer to page G-68) |
| No difference between high- and low-pressure-side readings | — | — | • Improper compression of A/C compressor Repair or replace A/C compressor (Refer to page G-54) |

HEATER

STRUCTURAL VIEW




| | | | |
|-------------------------------|-----------|------------------------------|-----------|
| 1. Heater unit | | 3. Heater control unit | |
| Removal / Installation..... | page G-37 | Removal / Installation..... | page G-43 |
| Disassembly / Inspection / | | Disassembly / Assembly | page G-44 |
| Assembly..... | page G-38 | Inspection..... | page G-46 |
| Airflow mode actuator | | Air intake wire | |
| Inspection..... | page G-39 | Adjustment | page G-47 |
| 2. Blower unit | | Airflow mode wire | |
| Removal / Installation..... | page G-40 | Adjustment | page G-47 |
| Disassembly / Assembly | page G-41 | Air mix wire | |
| Blower motor (in blower unit) | | Adjustment..... | page G-48 |
| Inspection..... | page G-42 | | |
| Resistor (in blower unit) | | | |
| Inspection | page G-42 | | |
| Air intake actuator | | | |
| Inspection..... | page G-42 | | |
| Blower relay | | | |
| Removal / Installation..... | page G-42 | | |
| Inspection..... | page G-42 | | |

HEATER UNIT

Removal / Installation

1. Drain the engine coolant. (Refer to the 1995 MX-3 Workshop Manual, section E.)
2. Remove the dashboard. (Refer to the 1995 MX-3 Workshop Manual, section S.)
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



- 1. Seal plate
Removal note below
- 2. Hose connector
- 3. Heater hose
Removal note below
Installation note below

- 4. Heater unit
Disassembly / Inspection /
Assembly..... page G-38

Removal note

Seal plate

Release the clamp and remove the seal plate together with the heater unit.

Heater hose

When disconnecting the heater hose from the heater core, unlock the hose connector from the heater core side.


Installation note

Heater hose

After installing the heater hose to the heater core, verify that the hose connector is securely locked.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure.
2. Check for the following and repair or replace the heater core as necessary.
 - ① Cracks, damage, and water leakage
 - ② Bent fins
 - ③ Distorted and bent inlet
3. Assemble in the reverse order of disassembly.



1. Airflow mode actuator

Inspection..... page G-39

2. Mode door link

3. Air mix link

4. Mode door assembly

5. Mix door assembly

6. Heater core



7. Heater unit case

AIRFLOW MODE ACTUATOR

Inspection

1. Remove the cooling unit. (Refer to page G-67.)
2. Disconnect the airflow mode actuator connector.
3. Connect battery positive voltage to terminals L and J and check the operation of the airflow mode actuator.

B+: Battery positive voltage



| Connection | | Actuator operation |
|------------|-----|-------------------------------|
| B+ | GND | |
| L | J | VENT → B/L → HEAT → H/D → DEF |
| J | L | DEF → H/D → HEAT → B/L → VENT |

4. If not as specified, replace the airflow mode actuator. (Refer to page G-38.)
5. Check for continuity between the terminals of the airflow mode actuator.


| Airflow mode | Terminal | | | | | | |
|--------------|----------|---|---|---|---|---|---|
| | K | I | H | A | B | C | F |
| VENT | | | ○ | ○ | ○ | ○ | ○ |
| B/L | ○ | ○ | | ○ | ○ | ○ | ○ |
| HEAT | ○ | ○ | ○ | | ○ | ○ | ○ |
| H/D | ○ | ○ | ○ | ○ | | ○ | ○ |
| DEF | ○ | ○ | ○ | ○ | ○ | | |

○—○ : Continuity

6. If not as specified, replace the airflow mode actuator. (Refer to page G-38.)

BLOWER UNIT**Removal / Installation**

1. Remove the glove compartment. (Refer to the 1995 MX-3 Workshop Manual, section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.



1. Duct

2. Seal plate

Removal note below

3. Blower unit


Disassembly / Assembly page G-41

Removal note**Seal plate**

Release the clamp and remove the seal plate together with the blower unit.


Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Air intake actuator (logic type)
Inspection..... page G-42
2. Intake door link
3. Blower relay
Inspection..... page G-42


4. Resistor
Inspection..... page G-42
5. Blower unit case
6. Blower motor
Inspection..... page G-42
7. Intake door assembly



BLOWER MOTOR

Inspection

1. Disconnect the blower motor connector.
2. Connect battery positive voltage to terminal A and ground to terminal B of the blower motor. Verify that the motor operates.
3. If not as specified, replace the blower motor. (Refer to page G-41.)



RESISTOR


Inspection

1. Disconnect the resistor connector.
2. Check for continuity between the resistor terminals.

| Terminal | | | |
|----------|-------|-------|-------|
| A (D) | B (C) | C (A) | D (B) |
| ○ | ○ | | |
| ○ | | ○ | |
| ○ | | | ○ |

○-○ : Continuity () : Wire type

3. If not as specified, replace the resistor. (Refer to page G-41.)



AIR INTAKE ACTUATOR


Inspection

1. Disconnect the air intake actuator connector.
2. Connect battery positive voltage to the following terminals and check the operation of the air intake actuator.

B+: Battery positive voltage

| Connection | | Actuator operation |
|------------|-----|--------------------|
| B+ | GND | |
| D | C | REC → FRESH |
| D | A | FRESH → REC |

3. If not as specified, replace the air intake actuator. (Refer to page G-41.)



BLOWER RELAY

Removal / Installation

1. Remove the blower unit. (Refer to page G-40.)
2. Disconnect the blower relay connector.
3. Remove the blower relay from the blower unit.
4. Install in the reverse order of removal.

Inspection


1. Remove the blower relay.
2. Check for continuity between the relay terminals.

B+: Battery positive voltage

| Connection | | Terminal | | | |
|------------|-----|----------|---|---|---|
| B+ | GND | A | B | C | D |
| — | — | ○ | ○ | | |
| A | B | | | ○ | ○ |

○-○ : Continuity


3. If not as specified, replace the blower relay.



HEATER CONTROL UNIT

Removal / Installation

1. Remove the side panel, lower panel, rear console, console panel, front console, and meter hood.
(Refer to the 1995 MX-3 Workshop Manual, section S.)
2. Remove the air mix wire from the mix door link.
3. Remove in the order shown in the figure.
4. Install in the reverse order of removal.



1. Heater control unit


Disassembly / Assembly page G-44

Inspection page G-46

Disassembly / Assembly


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.

LOGIC TYPE




- | | |
|---------------------------|------------------------------|
| 1. Knob | 5. Temperature control lever |
| 2. Switch panel | 6. Bulb |
| 3. Fan switch | 7. Heater control unit |
| Inspection..... page G-46 | Inspection..... page G-46 |
| 4. Air mix wire | |
| Adjustment..... page G-48 | |

WIRE TYPE



- | | |
|------------------------------|-----------|
| 1. Knob | |
| 2. Switch panel | |
| 3. A/C switch | |
| Inspection..... | page G-46 |
| 4. Air intake wire | |
| Adjustment..... | page G-47 |
| 5. Airflow mode wire | |
| Adjustment..... | page G-47 |
| 6. Air mix wire | |
| Adjustment..... | page G-48 |
| 7. REC/FRESH lever | |
| 8. Mode lever | |
| 9. Temperature control lever | |
| 10. Fan switch | |
| inspection..... | page G-46 |
| 11. Heater control unit | |



Inspection

Fan switch

1. Check for continuity between the terminals of the fan switch.

| Switch position | B | D | F | E | G | H |
|-----------------|-----|---|-----|-----|-----|-----|
| OFF | | | | | | |
| 1 | ○—○ | | | | | |
| 2 | ○—○ | | ○—○ | | | ○—○ |
| 3 | ○—○ | | | ○—○ | | ○—○ |
| 4 | ○—○ | | | | ○—○ | ○—○ |

○—○ : Continuity

2. If not as specified, replace the fan switch.
(Refer to page G-44 or G-45.)

A/C switch (Logic type)

1. Check for continuity between the terminals of the heater control unit.

| A/C switch | B | D |
|------------|-----|-----|
| OFF | | |
| ON | ○—○ | ○—○ |

○—○ : Continuity

2. If not as specified, replace the heater control unit.
(Refer to page G-43.)

(Wire type)

1. Remove the A/C switch from the switch panel.
(Refer to page G-45.)
2. Check for continuity between the terminals of the A/C switch.

| A/C switch | D | E |
|------------|-----|-----|
| OFF | | |
| ON | ○—○ | ○—○ |

○—○ : Continuity

3. If not as specified, replace the A/C switch.
(Refer to page G-45.)

REC switch

1. Remove the heater control unit.
(Refer to page G-43.)
2. Operate the REC switch and check for continuity between terminals C and J of the heater control unit.

| REC switch | Continuity |
|------------|------------|
| OFF | No |
| ON | Yes |





3. If not as specified, replace the heater control unit.
(Refer to page G-43.)


FRESH switch

1. Remove the heater control unit.
(Refer to page G-43.)
2. Operate the FRESH switch and check for continuity between terminals A and J of the heater control unit.

| FRESH switch | Continuity |
|--------------|------------|
| OFF | No |
| ON | Yes |

3. If not as specified, replace the heater control unit.
(Refer to page G-43.)






MODE switch

1. Remove the heater control unit.
(Refer to page G-43.)
2. Press the MODE switch and check for continuity between the terminals of the heater control unit.

| MODE switches | Terminal | | | | | |
|---------------|----------|---|---|---|---|---|
| | J | T | S | Q | O | M |
| VLNI | ○ | ○ | | | | |
| B/L | ○ | | ○ | | | |
| HEAT | ○ | | | ○ | | |
| H/D | ○ | | | | ○ | |
| DEF | ○ | | | | | ○ |

○-○ : Continuity


3. If not as specified, replace the heater control unit.
(Refer to page G-43.)



AIR INTAKE WIRE

Adjustment

1. Set the REC/FRESH lever to FRESH.
2. Connect the air intake wire to the intake door link.
3. Set the door at the FRESH position and clamp the wire into place.
4. Verify that the REC/FRESH lever moves its full stroke.




AIRFLOW MODE WIRE

Adjustment


1. Set the mode lever at DEFROST.
2. Remove the airflow mode wire from clip A.
3. Align set pin hole B of the link with the corresponding hole of the heater unit. Insert a 6mm {0.24 in} pin to fix the link in the correct position.
4. Verify that the mode lever is in the defrost position.

Caution

- Do not push the inner wire of the airflow mode wire when setting. If pushed, the wire may be deformed, preventing the correct setting.




5. Set the airflow mode wire against clip A as shown. Pull the airflow mode wire slightly in direction a. Press areas b and c simultaneously when setting the wire into the clip.
6. Remove the set pin.
7. Verify that the mode lever functions correctly. If not, pull the airflow mode wire 2 mm {0.08 in} in direction a.
8. Verify that the mode lever functions correctly.

**AIR MIX WIRE****Adjustment**


1. Set the temperature control lever to MAX COLD.
2. Connect the air mix wire to the mix door link.
3. Set the door to MAX COLD and clamp the wire into place.
4. Verify that the temperature control lever moves its full stroke.

AIR CONDITIONER

STRUCTURAL VIEW




| | | | |
|-----------------------------|-----------|---------------------------------|-----------|
| 1. A/C compressor | | 6. Refrigerant pressure switch: | |
| Removal / installation..... | page G-54 | Removal / installation..... | page G-65 |
| Disassembly / Assembly..... | page G-56 | Inspection..... | page G-65 |
| 2. Magnetic clutch | | 7. Cooling unit | |
| Disassembly / Assembly..... | page G-62 | Removal / installation..... | page G-67 |
| Inspection..... | page G-62 | Disassembly / Assembly..... | page G-68 |
| 3. Condenser fan | | Replacement..... | page G-68 |
| Removal / Installation..... | page G-63 | 8. Relays | |
| Inspection..... | page G-63 | Removal / installation..... | page G-70 |
| 4. Condenser | | Inspection..... | page G-70 |
| Removal / Installation..... | page G-64 | 9. Refrigerant lines | |
| Inspection..... | page G-64 | On-vehicle inspection..... | page G-71 |
| 5. Receiver drier | | Removal / Installation..... | page G-71 |
| Removal / Installation..... | page G-65 | | |



REFRIGERANT SYSTEM SERVICE PROCEDURES

Manifold Gauge Set Installation


1. Fully close the valves of the manifold gauge.
2. Connect charging hoses to the high- and low-pressure side joints of the manifold gauge.
3. Connect quick couplers to the ends of the charging hoses.
4. Remove the caps from the charging valves of the high- and low-pressure side cooler pipes.
5. Connect the quick couplers to the charging valves of the cooler pipes.




Charging

1. Install the manifold gauge set.
2. Connect the tap pin side of the charging hose to the air purge valve of the manifold gauge.
3. Connect the vacuum pump hose to the center joint of the manifold gauge.
4. Connect the vacuum pump hose to the vacuum pump.
5. Connect can puncture valves to a 4-way joint.
6. Fully open the can puncture valves and connect service cans to the valves.


Regular amount of refrigerant: 750g {26.5 oz}




7. Fully close any can puncture valve that is not connected to a service can.
8. Connect the 4-way joint to the charging hose that is connected to the gauge set air purge valve.
9. Open all the valves of the manifold gauge.
10. Start the vacuum pump and let it operate for **15 minutes**.



11. After 15 minutes, verify that the high- and low-pressure-side readings of the manifold gauge are at **-101 kPa {-760 mmHg, -29.9 inHg}**. Close each valve of the manifold gauge.
12. Stop the vacuum pump and wait for about **5 minutes**.
13. After 5 minutes, check the low-pressure-side reading of the manifold gauge. If the reading has changed, check for leaks and then repeat from step 9. If reading has not changed, go to step 14.




14. Open the service cans by using the can puncture valves.
15. Open the high-pressure side valve to the manifold gauge and charge with refrigerant until the low-pressure -side reading is at **100 kPa {1 kg/cm², 10 psi}**.




16. Close the high-pressure side valve of the manifold gauge.

17. Check for leaks by using a gas leak tester. If there are no leaks, go to step 18. If a leak is found at a loose joint, tighten the joint and check for leaks again. If there is still a leak at the same joint, discharge the refrigerant and then repair the joint. Repeat the charging procedure from step 9. If there are no leaks after tightening the joint, go to step 18.




18. Open the high-pressure side valve of the manifold gauge and charge with half the regular amount of refrigerant.



19. Close the high-pressure side valve of the manifold gauge.

Warning

- Running the engine with the high-pressure side valve open is dangerous. Pressure within the service cans will increase and the cans could explode, scattering metal fragments and liquid refrigerant that can seriously injure you. Therefore, do not open the high-pressure side valve while the engine is running.



20. Start the engine and actuate the A/C compressor.

21. Open the low pressure side valve of the gauge set and charge with the remaining refrigerant.


22. Close the low-pressure side valve of the manifold gauge.


23. Stop the engine and A/C compressor.

24. Check for leaks by using a gas leak tester. If there are no leaks, go to step 25. If a leak is found at a loose joint, tighten the joint and check for leaks again. If there is still a leak at the same joint, discharge the refrigerant and then repair the joint. Repeat the charging procedure from step 9. If there are no leaks after tightening the joint, go to step 25.

25. Disconnect the high- and low-pressure side quick couplers from the charging valves.

26. Install the caps to the charging valves.





Performance Test

After servicing the refrigerant system, test its performance.

1. Install the manifold gauge set. (Refer to page G-50.)
2. Place a dry-bulb thermometer in the center ventilator outlet.
3. Place a wet-and-dry-bulb thermometer at the blower inlet.
4. Open all doors and windows.
5. Warm up the engine and run it at constant 1,500 rpm.
6. Set the fan switch at the fourth position.
7. Turn the A/C switch on.
8. Set the REC/FRESH lever (wire type) or REC/FRESH switch (logic type) at recirculate.
9. Set the mode lever (wire type) or mode switch (logic type) to VENT.
10. Set the temperature control lever to MAX COLD.
11. Wait until the air conditioner output temperature stabilizes.

Stabilized condition

Blower inlet temperature: 25—35 °C {77—95 °F}

High-pressure-side reading:



1380—1660 kPa {14.0—17.0 kg/cm², 200—241 psi}

12. After the air conditioner stabilizes, read the wet-and-dry-bulb thermometer, and then calculate the relative humidity by using the graph below.

HOW TO READ THE GRAPH:


After measuring the temperatures of wet- and dry-bulb thermometers at the evaporator air inlet, relative humidity (%) can be obtained.

Example Supposing dry- and wet-bulb temperatures at evaporator air inlet are 25°C and 19.5°C respectively the point of intersection of the dotted lines in the graph and is 60%.




13. Read the dry thermometer at the air outlet, and calculate the difference between the inlet dry-bulb and outlet dry-bulb temperatures.

14. Verify that the intersection of the relative humidity and temperature difference is in the shaded zone.




Checking Refrigerant Charge

1. Install the manifold gauge set. (Refer to page G-50.)
2. Check the refrigerant pressure reading with the engine stopped.
3. Verify that the high- and low-pressure-side readings of the manifold gauge are at 493—788 kPa {5.02—8.04 kgf/cm², 72—114 psi}. If the pressure readings are lower than specified, recharge the refrigerant amount. (Refer to page G-50.) If the pressure readings are within specification but there is insufficient cooling, go to the next step. If the pressure readings are within specification and there are no leaks, the refrigerant amount is OK.
4. Start the engine and run it at a constant 2,000 rpm.
5. Turn the A/C switch on, set the fan switch at MAX-HI, and set the air intake mode at recirculate.
6. If the A/C compressor is short-cycling, note the low-pressure-side reading at which the magnetic clutch kicks out.
7. If the pressure is 170 kPa {1.7 kgf/cm², 24 psi} or lower, evacuate and recharge the refrigerant system with the proper amount of refrigerant. (Refer to page G-50.) If the pressure is 210 kPa {2.1 kgf/cm², 30 psi} or higher, inspect the thermostat. (Refer to page G-69.)



Checking Refrigerant Pressure

1. Install the manifold gauge set. (Refer to page G-50.)
2. Shut all doors and windows.
3. Warm up the engine and run it at constant 1,500 rpm.
4. Set the fan switch at the fourth position.
5. Turn the A/C switch on.
6. Set the REC/FRESH lever (wire type) or REC/FRESH switch (logical type) at recirculate.
7. Set the mode lever (wire type) or mode switch (logic type) at VENT.
8. Set the temperature control lever at MAX COLD.
9. Measure the ambient temperature and the high- and low-pressure side readings of manifold gauge.
10. If the high- and low-pressure-side readings are in the shaded zones shown in the figure, the refrigerant system is normal.




**A/C COMPRESSOR
Removal / Installation**

1. Discharge the refrigerant from the system.
2. Remove the drive belt as follows.


K8

- 1) Loosen the idle pulley locknut.
- 2) Loosen the adjusting bolt and remove the drive belt.




B6

- 1) Loosen bolt A.
- 2) Loosen nut C.
- 3) Loosen nut B.
- 4) Loosen adjusting bolt D and remove the drive belt.



3. Remove the lower cover.
4. Disconnect the hoses from the A/C compressor.



5. Remove the bolts and remove the A/C compressor.
6. Install in the reverse order of removal. When replacing the A/C compressor with a new one, remove the following amount of compressor oil from the new A/C compressor.

Removed oil amount cm³ {cc, fl oz}

$$= 175 - \left[\text{oil from old A/C compressor} + \left\{ 15^{+5}_{-0}, 0.5^{+0.2}_{-0} \right\} \right]$$

7. Adjust the drive belt deflection as follows:

K8


- 1) Loosen the locknut.
- 2) Turn the adjusting bolt to adjust the drive belt deflection to specification.


| Drive belt | Deflection when applying moderate pressure 98 N {10kgf, 22lbf} |
|------------|--|
| New | 8.0—9.0 mm {0.32—0.35 in} |
| Used | 9.0—10.0 mm {0.36—0.39 in} |

- 3) Tighten the locknut.

Tightening torque:

32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}





B6

- 1) Loosen bolt A, nut B, and nut C.
- 2) Turn the adjusting bolt D and adjust the drive belt deflection to specification.

| Drive belt | Deflection when applying moderate pressure 98 N {10kgf, 22lbf} |
|------------|--|
| New | 8.0—9.0 mm {0.32—0.35 in} |
| Used | 9.0—10.0 mm {0.36—0.39 in} |

- 3) Tighten bolt A, nut B, and nut C.



Tightening torque

- Bolt A:** 37—53 N·m {3.7—5.5 kgf·m, 27—39 ft·lbf}
- Nut B:** 38—51 N·m {3.8—5.3 kgf·m, 28—38 ft·lbf}
- Nut C:** 32—46 N·m {3.2—4.7 kgf·m, 24—33 ft·lbf}


Disassembly / Assembly

Preparation


SST

| | | | |
|---|--|---|--------------------------------------|
| <p>49 B061 005</p> <p>Replacer seal plate</p>  | <p>For replacement of shaft seal plate</p> | <p>49 B061 006</p> <p>Remover and installer, seal</p>  | <p>For replacement of shaft seal</p> |
|---|--|---|--------------------------------------|

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




- | | |
|---|---|
| <p>1. Compressor body</p> <p>2. Pressure relief valve</p> <p>3. Shaft seal and seal plate Disassembly note..... page G-57 Assembly note..... page G-60</p> <p>4. Head cover Assembly note..... page G-59</p> <p>5. Thermal protector Disassembly note..... page G-58 Assembly note..... page G-58</p> | <p>6. Discharge valve and valve stopper Assembly note..... page G-58</p> <p>7. Rear case</p> <p>8. Oil control valve</p> <p>9. Spring stopper</p> <p>10. Compression spring</p> <p>11. Anti-valve</p> |
|---|---|




Disassembly note

Shaft seal and seal plate


1. Remove the armature plate.
2. Remove the felt seal and snap ring.




3. Remove the shim(s).
4. Align the cutout of the **SST** with the groove of the shaft seal plate and insert the **SST** into the A/C compressor.
5. Rotate the **SST** counterclockwise to make sure that the cutout is engaged with the seal plate.




6. Pull out the shaft seal plate.




7. Align the cutout of the **SST** with the metal pawl of the shaft seal and insert the **SST** into the A/C compressor.
8. Rotate the **SST** counterclockwise to make sure that the cutout is engaged with the metal pawl.



9. Pull out the shaft seal.

**Thermal protector**


Remove the snap ring and push the protector out from its back side to remove it. Do not pull on the wiring harness.

**Assembly note****Discharge valve and valve stopper**


1. Replace the O-ring and gasket.
2. Make sure the compressor body and surfaces of the discharge valve and valve stopper are free from foreign material before installing them.

Tightening torque: 2.9 N·m {30 kgf·cm, 26 in·lbf}


3. Plug the suction and discharge ports with the caps.

**Thermal protector**


1. Make sure the O-ring is free from foreign material. Apply compressor oil to the O-ring and fit it into the groove securely.
2. Check for continuity between the protector terminals.
3. Install the snap ring so that its chamfered edge faces the thermal protector. Make sure the snap ring is seated securely in its groove.



4. Install the thermal protector so that its two lead wire outlet sections are horizontal, as shown on the left.

**Head cover**


1. Replace the head cover packing with new ones. Apply compressor oil to the new head cover packing and assemble them. Make sure the top side of the gasket faces upward.



2. Carefully install the head cover on the A/C compressor. Tighten socket head bolts A, and then tighten bolts B in a diagonal manner.


Tightening torque:

- A: 9.81 N·m {100 kgf·cm, 86.8 in·lbf}
- B: 9.81 N·m {100 kgf·cm, 86.8 in·lbf}



Shaft seal and seal plate

1. Clean the shaft seal contacting face of the A/C compressor with cleaning solvent. Do not use a cloth. Keep dirt and solvent out of the A/C compressor. If refrigerant oil spills from the A/C compressor, refill with the same amount of oil.
2. Clean the new shaft seal thoroughly with cleaning solvent.
3. Lubricate the shaft seal with clean compressor oil (ATMOS GU10) and install it on the **SST**. Do not touch the sealing surfaces of the shaft seal after lubrication.
4. Liberally lubricate the compressor shaft with compressor oil.
5. Align the seal case flats with the shaft flats and install the shaft seal onto the compressor shaft.




6. Clean the shaft seal plate with cleaning solvent.
7. Lubricate the seal plate with clean refrigerant oil (ATMOS GU10). Do not touch the sealing surface of the seal plate after lubrication.
8. Slide the seal plate into the A/C compressor by hand as far as possible.
9. Press the seal plate with the grip side of the **SST**.
10. Install the snap ring with its chamfered edge inside.
11. Press the snap ring with the grip side of the **SST**, and then install the felt seal. Make sure the snap ring is seated correctly in its groove.
12. Install the shim(s).
13. Install the pressure plate.
14. Measure the clearance between the pulley and the pressure plate all the way around. If the clearance is not as specified, add or remove the shim(s) as required.

Clearance: 0.4—0.5 mm {0.016—0.020 in}

Shim


| Shim part number | Thickness mm {in} |
|------------------|-------------------|
| B455 61 L15 | 0.2 {0.008} |
| B456 61 L15 | 0.5 {0.020} |



Inspection

Because the A/C compressor is a rotary vane type, an irregular noise may be heard when the refrigerant is charged from the low-pressure side or after replacing components without adjusting the amount of compressor oil. Noise is produced when the vanes are not properly pressed against the inner wall of the rotor housing.

A/C compressor noise troubleshooting



Procedure ①

Check the entire refrigerant system for compressor oil and refrigerant leaks. If leakage is found, repair or replace as necessary.

Procedure ②

Run the engine at a constant 3000—4000 rpm; then alternately switch the A/C compressor on and off (turn the A/C switch on and off). If the noise remains, turn the ignition switch to OFF for 1—2 minutes. Start the engine again, hold its speed at 3000—4000 rpm, and alternately switch the A/C compressor on and off (turn the A/C switch on and off).

Procedure ③


After replacing parts, add compressor oil as shown in the following table.

| Replaced part | Oil supplement |
|------------------|--------------------------|
| Condenser | 30 ml {30 cc, 1.0 fl oz} |
| Cooling unit | 60 ml {60 cc, 2.0 fl oz} |
| Piping hose/pipe | 5 ml {5 cc, 0.2 fl oz} |
| Receiver/dryer | 10 ml {10 cc, 0.3 fl oz} |

MAGNETIC CLUTCH

Disassembly / Assembly

1. Disassemble in the order as shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Pressure plate

Assembly note below


2. Shim

3. Snap ring

4. Rotor pulley

5. Stator

Inspection below



Assembly note



Pressure plate

1. Measure the clearance between the pressure plate and the rotor pulley.
 - (1) Set the A/C compressor on a level block.
 - (2) Fix a dial gauge on a magnetic base and set the measuring probe on the pressure plate surface.
 - (3) Alternately apply and remove battery positive voltage as shown in the figure. The clearance is the difference in the dial gauge readings.
 - (4) Compare the measured clearance with the specified clearance below.

Clearance: 0.4—0.5 mm {0.016—0.020 in}

2. If not as specified, install shims to adjust the clearance.


| Shim part number | Thickness mm (in) |
|------------------|-------------------|
| 3455 61 L15 | 0.2 {0.008} |
| 3456 61 L15 | 0.5 {0.020} |



Inspection

Stator


1. Set the ohmmeter to the $\times 1,000\Omega$ range.
2. Verify that there is continuity between the stator terminal and the A/C compressor body.
3. If there is no continuity, replace the stator.



CONDENSER FAN

Removal / Installation

1. Remove the fresh-air duct.
2. Remove the upper seal board.
3. Disconnect the condenser fan connector.
4. Remove the condenser fan as shown in the figure.
5. Install in the reverse order of removal.



Inspection


K8

1. Disconnect the condenser fan connector.
2. Connect battery positive voltage and check the operation of the condenser fan.

B+: Battery positive voltage

| Connection | | Condenser fan operation |
|------------|------|-------------------------|
| B+ | GND | |
| C | D | Low speed |
| A, C | B, D | High speed |

3. If not as specified, replace the condenser fan.



B6

1. Disconnect the condenser fan connector.
2. Connect battery positive voltage to terminal A and connect terminal B to ground. Verify that the condenser fan operates.
3. If the condenser fan does not operate, replace it.

CONDENSER


Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the fresh-air duct.
3. Remove the upper seal board.
4. Disconnect the cooler pipes from the condenser.
5. Insert a protector, such as cardboard, between the condenser and the radiator.
6. Remove in the order shown in the figure.
7. Install in the reverse order of removal. Apply clean compressor oil to the O-rings before connecting the fittings; do not apply compressor oil to the fitting nuts. When installing a new condenser, add 30 ml {30 cc, 1.0 fl oz} of compressor oil through the high-pressure-side of the A/C compressor.

Tightening torque


Condenser inlet: 15—24 N·m {1.5—2.5 kgf·m, 11—18 ft·lbf}

Condenser outlet: 10—19 N·m {1.0—2.0 kgf·m, 8—14 ft·lbf}



1. Condenser bracket


2. Condenser
Inspection below



Inspection

Check for the following and repair or replace the condenser as necessary.

1. Cracks, damage, or refrigerant leakage
2. Bent fins
3. Distorted or damaged condenser inlet or outlet



RECEIVER/DRIER

Removal / Installation

1. Discharge the refrigerant from the system.
2. Remove the airflow meter.
3. Remove the coolant reservoir.
4. Disconnect the cooler pipes from the receiver/drier.
5. Remove the receiver/drier from the bracket.
6. Install in the reverse order of removal. Apply clean compressor oil to the O-rings before connecting the fittings. When installing a new receiver/drier, add 10 ml {10 cc, 0.3 fl oz} compressor oil through the high-pressure side of the A/C compressor.


Tightening torque:

Receiver/drier inlet:

10—19 N·m {1.0—2.0 kgf·m, 8—14 ft·lb}

Receiver/drier outlet:

15—24 N·m {1.5—2.5 kgf·m, 11—18 ft·lb}




REFRIGERANT PRESSURE SWITCH

Removal / Installation


1. Discharge the refrigerant from the system.
2. Disconnect the refrigerant pressure switch connector and remove the refrigerant pressure switch.
3. Before installing the refrigerant pressure switch, wrap sealing tape on the threads of the switch and replace the O-ring. Then install in the reverse order of removal.

Tightening torque: 9.81 N·m {100 kgf·cm, 86.8 in·lb}



Inspection

If problems occur in the refrigerant system that cause abnormally high pressure or abnormally low pressure, the refrigerant pressure switch will cut power to the magnetic clutch to protect the mechanical components. If the pressure recovers to within normal operating range, the power will be restored. These operating values are shown in the figure.




1. Turn the ignition switch to OFF.
2. Connect the manifold gauge set and measure the high-pressure-side reading. (Refer to page G-50.)

High-pressure-side reading:

Above 450 kPa {4.6 kgf·cm², 65 psi}

3. If not as specified, refer to page G-53 and check the refrigerant system.



4. If correct, disconnect the refrigerant pressure switch connector.
5. Check for continuity between the switch terminals.
6. If there is no continuity, replace the refrigerant pressure switch. (Refer to page G-65.)


COOLING UNIT**Removal / Installation**

1. Discharge the refrigerant from the system.
2. Remove the glove compartment and glove compartment cover.
(Refer to the 1995 MX-3 Workshop Manual, section S.)
3. Disconnect the thermostatic switch connector.
4. Unlock the seal plate and slice the seal plate toward the heater unit and blower unit.
5. Disconnect the cooler pipes from the cooling unit.
6. Remove as shown in the figure.
7. Install in the reverse order of removal. Apply clean compressor oil to the O-rings before connecting the fittings; do not apply compressor oil to the fitting nuts. When installing a new cooling unit, add 60 ml {60 cc, 2.0 fl oz} of compressor oil through the high-pressure side of the A/C compressor.

Tightening torque

Outlet pipe: 20—29 N·m {2.0—3.0 kgf·m, 15—21 ft·lbf}

Inlet pipe: 10—19 N·m {1.0—2.0 kgf·m, 8—14 ft·lbf}




1. Cooling unit

Disassembly / Assembly page G-68

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Cooling unit case

2. Thermoswitch

On-vehicle inspection..... page G-69


Inspection..... page G-69

3. Evaporator

Inspection..... page G-69

4. Expansion valve

Replacement:..... below

**Replacement****Expansion valve**

1. Inspect the refrigerant system before replacing the expansion valve. (Refer to page G-53.)
2. Remove the cooling unit. (Refer to page G-67.)
3. Disassemble the cooling unit. (Remove the evaporator and expansion valve as an assembly.)
4. Disconnect the inlet and outlet pipes.
5. Remove the heat-sensing tube from the outlet pipe and remove the expansion valve.
6. Install in the reverse order of removal. Apply clean compressor oil to the O-rings before connecting the fittings.

Tightening torque





Inlet pipe:

11.8—14.7 N·m

{120—150 kgf·cm, 105—130 in·lbf}

Outlet pipe:

30—34 N·m {3.0—3.5 kgf·m, 22—25 ft·lbf}



**On-vehicle Inspection
Thermostat**

1. Remove the glove compartment and glove compartment cover.
2. Run the engine at idle.
3. Turn the A/C switch off and set the fan switch off to the fourth position to operate the blower fan for a few minutes.

4. After a few minutes, turn the fan switch off and stop the engine.

Note

- The thermostat contacts will be open if the evaporator temperature is below $0.4 \pm 0.7 \text{ }^\circ\text{C}$ ($32.5 \pm 1.0 \text{ }^\circ\text{F}$)

5. Disconnect the thermostat connector and check for continuity between the switch terminals.
6. If there is no continuity, replace the thermostat.
(Refer to page G-68.)

**Inspection
Thermostat**

1. Immerse the sensing bulb in a container of ice water.
2. Check for continuity between the switch terminals.

| Temperature | Continuity |
|-------------------------|------------|
| Above 5°C | Yes |
| Below 5°C | No |


3. If not as specified, replace the thermostat.
(Refer to page G-68.)

Evaporator

Caution

- If water is used to clean the evaporator, the water may freeze inside the pipes and block the flow of refrigerant. Do not use water to clean the evaporator.


1. Check the evaporator fins for blockage. If the fins are clogged, clean them with compressed air.
2. Check the fittings for cracks and other damage. Replace the evaporator if necessary.
(Refer to page G-68.)



RELAYS

Removal / Installation

1. Remove the relays from the relay bracket.
2. Disconnect the relay connector and remove the relays.
3. Install in the reverse order of removal. Lower the relay boots after connecting the relay connector.



Inspection

1. Remove the relays.
2. Check for continuity between the relay terminals.

B+: Battery positive voltage

| Connection | | Terminal | | | |
|------------|-----|----------|---|---|---|
| B+ | GND | A | B | C | D |
| — | — | ○ | ○ | | |
| A | B | | | ○ | ○ |

○—○ : Continuity

3. If not as specified, replace the relay.

Note

- The same type of relays are used for the A/C relay, condenser fan relay No.1, condenser fan relay No.2, and condenser fan relay No.3.


REFRIGERANT LINES

On-vehicle Inspection


Check for leakage at all connections by using a gas leak tester. (Refer to page G-51.)
 Repair or replace as necessary.

Removal / Installation


1. Discharge the refrigerant from the system.
2. Remove as shown in the figure. Immediately plug all open fittings to keep moisture out of the system.
3. Install in the reverse order of removal. Apply clean compressor oil to the O-rings before connecting the fittings; do not apply compressor oil to the fitting nuts. When installing a new pipe or hose, add 5 ml {5 cc, 0.2 fl oz} of compressor oil through the high pressure side of the A/C compressor.
4. Evacuate, charge, and test the refrigeration system.




CONNECTOR LOCATIONS



G-2





G-3

Before beginning any service procedure, refer to section S of this manual for air bag system service warnings.


AUDIO

| | |
|--------------------------------|------|
| PREPARATION..... | J- 2 |
| STRUCTURAL VIEW | J- 2 |
| SYSTEM DESCRIPTION | J- 3 |
| CONNECTOR SPECIFICATIONS | J- 4 |
| TROUBLESHOOTING..... | J- 5 |
| AUDIO UNIT | J-20 |
| SPEAKER..... | J-20 |
| ROOF ANTENNA | J-21 |


AUDIO

PREPARATION

SST

| | | |
|---|---|----------------------------------|
| <p>49 UN01 050</p> <p>Tool, radio removal</p> |  | <p>For removal of audio unit</p> |
|---|---|----------------------------------|


STRUCTURAL VIEW



| | |
|------------------------------|-----------|
| 1. Audio unit | |
| Removal | page J-20 |
| Installation | page J-20 |
| 2. Speaker | |
| Removal / Installation | page J-20 |
| Inspection | page J-21 |

| | |
|--------------------|-----------|
| 3. Roof antenna | |
| Removal | page J-21 |
| Installation | page J-21 |
| Inspection | page J-22 |

SYSTEM DESCRIPTION
System Diagram




CONNECTOR SPECIFICATIONS


Audio Unit

AM-FM tuner / cassette tape deck

FRONT VIEW



REAR VIEW




12-pin connector



| | |
|----|---------------------|
| 1A | ACC |
| 1B | |
| 1C | Backup power (B+) |
| 1D | Antenna SW (13.2V) |
| 1E | TNS |
| 1F | Illumination ⊖ |
| 1H | |
| 1J | Amp control (13.2V) |
| 1K | Door speaker (LH) ⊕ |
| 1L | Door speaker (LH) ⊖ |
| 1M | Door speaker (RH) ⊕ |
| 1N | Door speaker (RH) ⊖ |


DIN connector (13-pin)



B+: Battery positive voltage


| | |
|----|-----------------------|
| 1 | Output LH ⊕ |
| 2 | Input LH ⊕ |
| 3 | Output RH ⊕ |
| 4 | Input RH ⊕ |
| 5 | Signal ground |
| 6 | TNS |
| 7 | ACC |
| 8 | Backup power (B+) |
| 9 | System on |
| 10 | Illumination ⊕ |
| 11 | System off |
| 12 | System control (play) |
| 13 | Mute (input) |
| E | Shield ground |

8-pin connector



| | |
|----|---------------------|
| 2A | Rear speaker (LH) ⊕ |
| 2B | Rear speaker (LH) ⊖ |
| 2C | ACC |
| 2D | Amp control (13.2V) |
| 2F | Rear speaker (RH) ⊕ |
| 2H | Rear speaker (RH) ⊖ |
| 2I | System mute |
| 2J | |

1-pin connector




| | |
|----|--------|
| 3A | Ground |
|----|--------|

Specifications


| | |
|------------------|--|
| Rated voltage | 12V |
| Frequency band | AM 530—1,710 kHz FM 87.75—107.9 MHz |
| Output impedance | 25W × 4 |

TROUBLESHOOTING
Circuit Diagram



J

Connector Locations



Preinspection

An audio system malfunction can be caused by external factors such as noise or improper operation. Before troubleshooting, refer to the list below and correct any external factors.

| Problem | Possible cause | | |
|--|---|---|--|
| | Radio | Cassette deck | Other |
| No speakers operate | Volume control knob turned down | Player in pause mode | |
| Some speakers do not operate | Sound control knobs not set properly | | Speaker(s) damaged |
| Sound distorted (noise occurs) | <ul style="list-style-type: none"> • Incorrect tuning • Antenna not extended • Radio obstacle (fading or multi-path receiving) | <ul style="list-style-type: none"> • Faulty tape • Long-playing tape (90 min. or 120 min.) | <ul style="list-style-type: none"> • Volume too high • Door glass resonating • Speaker(s) damaged |
| Poor sound quality or stereophonic function does not operate | <ul style="list-style-type: none"> • Incorrect tuning • Sound control knobs not set properly | <ul style="list-style-type: none"> • Faulty tape • Long-playing tape (90 min. or 120 min.) • Dolby mode playback for non-Dolby recorded tape | Speaker(s) damaged |


Checklist

| Symptom | Flowchart No. |
|---|---------------|
| No speakers operate | 1 |
| Some speakers do not operate | 2 |
| Poor sound quality only when radio is played | 3 |
| Poor sound quality only when cassette tape is played | 4 |
| Poor sound quality when radio or cassette tape is played | 5 |
| Noise occurs | 6 |
| Cassette tape does not unload or reverse function works unintentionally | 7 |
| Cassette tape does not load or playback is not possible | 8 |

| | | |
|-----------------------|----------------|---------------------|
| Flowchart No.1 | Symptom | No speakers operate |
|-----------------------|----------------|---------------------|

Possible cause


- Burnt RADIO 15 A fuse
- Burnt ROOM 15 A fuse
- Damaged audio unit
- Open or short circuit in wiring harness
- Poor connection of connector



Step 1


Check the RADIO 15 A fuse and ROOM 15 A fuse in the fuse block.

| Fuse | Action |
|-------|--|
| OK | Go to Step 2 |
| Burnt | Replace fuse after checking and repairing wiring harness |



Step 2

1. Remove the audio unit. (Refer to page J-20.)
2. Verify that the audio unit connector is properly connected. Reconnect it if necessary.
3. If the connections are OK, go to Step 3.



Step 3

1. Turn the ignition switch to ACC.
2. Measure the voltage at the terminals of the audio unit connector.


B+: Battery positive voltage

| Terminal | Voltage | Action |
|----------|---------|--|
| 1A | B+ | Measure voltage at terminal 1C |
| | Other | Repair wiring harness (RADIO 15 A fuse—Audio unit) |
| 1C | B+ | Turn ignition switch to LOCK and go to Step 4 |
| | Other | Repair wiring harness (ROOM 15 A fuse—Audio unit) |

Step 4

1. Disconnect the audio unit connector.
2. Check for continuity between terminal 3A (B) of the audio unit connector and ground.


| Continuity | Action |
|------------|--|
| Yes | Replace audio unit |
| No | Repair wiring harness (Audio unit—GND) |



| | | |
|-----------------------|----------------|------------------------------|
| Flowchart No.2 | Symptom | Some speakers do not operate |
|-----------------------|----------------|------------------------------|

Possible cause

- Damaged speaker
- Damaged audio unit
- Open or short circuit in wiring harness
- Poor connection of connector



Step 1

1. Turn the ignition switch to ACC.
2. Turn the audio system power on.
3. Insert a recorded tape and set the volume to a comfortable level.
4. Set the bass/balance control knob and the treble/fader control as specified in Table 1.
5. Check the performance of each speaker. Refer to table 2 and follow the appropriate action.


Table 1

| Speaker | Fader | Balance | Speaker operates | Judgement |
|------------|-------|---------|--|--|
| Right door | Front | Right | Yes | Right door speaker circuit OK |
| | | | No | Right door speaker circuit malfunction |
| Left | | Yes | Left door speaker circuit OK | |
| | | No | Left door speaker circuit malfunction | |
| Right rear | Left | Right | Yes | Right rear speaker circuit OK |
| No | | | Right rear speaker circuit malfunction | |
| Left rear | | Left | Yes | Left rear speaker circuit OK |
| | | | No | Left rear speaker circuit malfunction |

J


Table 2

| Symptom | | | | Action |
|------------|-----------|------------|-----------|--------------|
| Right door | Left door | Right rear | Left rear | |
| × | | | | Go to Step 2 |
| | × | | | Go to Step 2 |
| | | × | | Go to Step 6 |
| | | | × | Go to Step 6 |



Step 2


1. Remove the door speaker. (Refer to page J-20.)
2. Verify that the door speaker connector is properly connected. Reconnect it if necessary.
3. If the connection is OK, go to Step 3.



Step 3


1. Disconnect the door speaker connector.
2. Measure the resistance between the terminals of the door speaker.

| Resistance | Action |
|------------|--|
| 3.6 Ω | Go to Step 4 |
| Other | Replace door speaker (Refer to page J-20.) |



Step 4

1. Remove the audio unit. (Refer to page J-20.)
2. Verify that the audio unit connector is properly connected. Reconnect it if necessary.
3. If the connections are OK, go to Step 5.




Step 5


1. Disconnect the audio unit connector and the door speaker connector.
2. Check for continuity between terminals of the audio unit connector and the door speaker connector.

| Speaker | Audio unit | Door speaker | Continuity |
|------------|-------------|--------------|------------|
| Right door | Terminal 1M | ↔ Terminal B | Yes |
| | Terminal 1N | ↔ Terminal A | Yes |
| Left door | Terminal 1K | ↔ Terminal B | Yes |
| | Terminal 1L | ↔ Terminal A | Yes |

3. If correct, go to Step 6.
4. If not as specified, repair the wiring harness (Audio unit—Door speaker).


**Step 6**

1. Remove the rear speaker. (Refer to page J-20.)
2. Verify that the rear speaker connector is properly connected. Reconnect it if necessary.
3. If the connection is OK, go to Step 7.

**Step 7**

1. Disconnect the rear speaker connector.
2. Measure the resistance between the terminals of the rear speaker.

| Resistance | Action |
|------------|---|
| 4 Ω | Go to Step 8 |
| Other | Replace door speaker (Refer to page J-20) |


**Step 8**

1. Remove the audio unit. (Refer to page J-20.)
2. Verify that the audio unit connector is properly connected. Reconnect it if necessary.
3. If the connections are OK, repair the wiring harness (Audio unit—Rear speaker).

| | | |
|-----------------------|----------------|--|
| Flowchart No.3 | Symptom | Poor sound quality only when radio is played |
|-----------------------|----------------|--|

Possible cause


- Damaged antenna
- Damaged audio unit
- Damaged antenna feeder
- Open or short circuit in wiring harness
- Poor connection of connector



Step 1

Check for continuity between the antenna mast and ground.


| Continuity | Action |
|------------|----------------------|
| Yes | Replace roof antenna |
| No | Go to Step 2 |



Step 2

Verify that the antenna base is securely installed.


| Antenna base | Action |
|--------------|----------------------|
| OK | Go to Step 3 |
| Loose | Correct or reinstall |



Step 3

1. Remove the audio unit. (Refer to page J-20.)
2. Verify that the antenna jack is properly connected.

| Connection | Action |
|------------|---------------------|
| OK | Go to Step 4 |
| Loose | Reconnect connector |



Step 4


1. Disconnect the antenna jack.
2. Check for continuity between the outer surface and at the center of the antenna jack.

| Continuity | Action |
|------------|----------------------|
| Yes | Replace roof antenna |
| No | Replace audio unit |

| | | |
|-----------------------|----------------|--|
| Flowchart No.4 | Symptom | Poor sound quality only when cassette tape is played |
|-----------------------|----------------|--|

Possible cause


- Damaged cassette tape
- Damaged audio unit
- Dirty heads and pinchroller



Step 1

Play a known good cassette tape and check the sound quality.

| Sound quality | Action |
|---------------|--|
| Normal | Replace original cassette tape (audio unit OK) |
| Poor | Go to Step 2 |




Step 2

1. Clean the heads and pinchroller by using a cassette tape player cleaning kit (commercially available).
2. Play the tape and check the sound quality.
3. If the sound quality is still poor, replace the audio unit.

| | | |
|-----------------------|----------------|--|
| Flowchart No.5 | Symptom | Poor sound quality when radio or cassette tape is played |
|-----------------------|----------------|--|


Possible cause

- Damaged speaker
- Open or short circuit in wiring harness
- Poor connection of connector



Step 1


1. Remove the audio unit. (Refer to page J-20.)
2. Verify that the audio unit connector is properly connected. Reconnect it if necessary.
3. If the connections are OK, go to Step 2.



Step 2

Verify that the audio unit mounting screws are securely installed.


| Screws | Action |
|--------|----------------|
| OK | Go to Step 3 |
| Loose | Tighten screws |



Step 3


1. Disconnect the audio unit connector.
2. Check for continuity between terminal 3A (B) of the audio unit connector and ground.

| Continuity | Action |
|------------|--|
| Yes | Go to Step 4 |
| No | Repair wiring harness (Audio unit—GND) |



Step 4

1. Remove the all speaker. (Refer to page J-20.)
2. Verify that the door speaker connector and rear speaker connector is properly connected. Reconnect it if necessary.
3. If the connection is OK, go to Step 5.

**Step 5**

1. Disconnect the speaker connector.
2. Measure the resistance between the terminals of the speaker.

| Speaker | Resistance |
|---------|------------|
| Door | 3.6 Ω |
| Rear | 4 Ω |



3. If correct, repair the wiring harness (Audio unit—Speaker).
4. If not as specified, replace the speaker.

| | | |
|----------------|---------|--------------|
| Flowchart No.6 | Symptom | Noise occurs |
|----------------|---------|--------------|

Possible cause

- Defective or improperly installed audio unit
- Ambient noise
- Outside noise (vehicle-induced noise)

1. Defective or improperly installed audio unit

| Problem | Action |
|---|---|
| <p>Noise occurs only when radio is played</p>  | <ol style="list-style-type: none"> 1. Troubleshoot according to flowchart No.3. (Refer to page J-12.) 2. Secure audio unit antenna feeder away from other wiring harnesses. |
| <p>Noise occurs only when cassette tape is played</p> | <p>Troubleshoot according to flowchart No.4. (Refer to page J-13.)</p> |
| <p>Noise occurs when radio or cassette tape is played</p>  | <ol style="list-style-type: none"> 1. Troubleshoot according to flowchart No.5. (Refer to page J-14.) 2. Secure harness between audio unit and speakers away from other wiring harnesses. |

2. Ambient noise

(1) Fading (AM)

As the distance between the source and the receiver increases, AM radio waves from other sources, reflecting off the ionosphere, interfere with the original source radio waves. Reception strength is lowered and sound quality is reduced. This effect is called fading.

(2) Fast fading (FM)

Fast fading is noise or sound distortion caused by mountains or buildings obstructing the FM radio waves.


(3) Multipath noise (FM)

Multipath noise occurs when the radio antenna picks up a direct wave and a reflected wave at the same time.

Since ambient noise is a temporary occurrence, it will be solved when vehicle location changes.

3. Outside noise (vehicle-induced noise)

| Name of noise | | Condition |
|--|---|--|
| Noise when engine is started | Fuel pump noise | Noise occurs immediately after ignition switch is turned to ON |
| | Ignition noise | Consecutive noise Tone changes when acceleration pedal is depressed |
| | Alternator noise | Whizzing noise occurs when acceleration pedal is depressed |
| Noise when electrical parts are operated | Wiper motor noise | Howling noise occurs synchronized with wiper operation |
| | Washer motor noise | Noise occurs when window washer is operated |
| | Power window noise | Noise occurs when power window is operated |
| | Fan motor noise | Noise occurs when fan is operated |
| | Stoplight noise | Noise occurs at beginning or end of brake operation |
| | Turn signal noise | Clicking noise occurs synchronized with signal flash |
| | Horn switch noise | Whizzing noise occurs when acceleration pedal is depressed |
| Air conditioner noise | Howling noise occurs when air conditioner is operated | |



Although it is difficult to eliminate these noises, they can be reduced by installing a noise suppressor or noise-preventive capacitor near the electrical system which emits the noise current. For example, to reduce wiper motor noise, install noise-preventive capacitors near the wiper motor. If there is no change after installing the capacitors, make sure the circuit is properly ground.

| | | |
|-----------------------|----------------|---|
| Flowchart No.7 | Symptom | Cassette tape does not unload or reverse function works unintentionally |
|-----------------------|----------------|---|

Note


- A loosely wound or stretched cassette tape can become tangled in the cassette deck and make unloading impossible.

| Problem | Possible cause | Action |
|---|--|--|
| Cassette tape playback not possible (eject function works normally) | 1. Cassette tape is cut | Use good cassette tape |
| | 2. Cassette tape is loosely wound | Eliminate sag in cassette tape by using pencil |
| | 3. Cassette tape is stretched | Use good cassette tape |
| Cassette tape cannot be ejected | 1. Cassette tape playback/fast-forward/rewind not possible (Cassette label is peeled off and is keeping cassette caught in system) (Damaged cassette deck) | Contact sales shop |
| | 2. Only cassette deck does not operate (Cassette tape is tangled in system) (Damaged cassette deck) | |
| Reverse function works unintentionally | Cassette tape roughly wound | Fast forward or rewind cassette tape to wind it uniformly and firmly |

| | | |
|-----------------------|----------------|---|
| Flowchart No.8 | Symptom | Cassette tape does not load or playback is not possible |
|-----------------------|----------------|---|

Possible cause


- Damaged cassette tape
- Damaged audio unit
- Open or short circuit in wiring harness
- Poor connection of connector



Step 1


Replace the cassette tape with a known good one and verify that the tape loads and operates normally.

| Original tape | Good tape | Action |
|---------------|---------------|--|
| Does not load | Does not load | Go to Step 3 |
| | Loads | Replace original cassette tape (system OK) |
| Does not play | Does not play | Go to Step 2 |
| | Plays | Replace original cassette tape (system OK) |



Step 2

1. Clean the heads and pinchroller by using a cassette tape player cleaning kit (commercially available).
2. Play the cassette tape and check the sound quality.
3. If the cassette tape still does not play, go to Step 3.




Step 3

1. Turn the ignition switch to ACC.
2. Measure the voltage at the terminals of the audio unit connector.

B+: Battery positive voltage






| Terminal | Voltage | Action |
|----------|---------|--|
| 1A | B+ | Measure voltage at terminal 1C |
| | Other | Repair wiring harness (RADIO 15 A fuse—Audio unit) |
| 1C | B+ | Turn ignition switch to LOCK and go to Step 4 |
| | Other | Repair wiring harness (ROOM 15 A fuse—Audio unit) |



Step 4

1. Disconnect the audio unit connector.
2. Check for continuity between terminal 3A (B) of the audio unit connector and ground.

| Continuity | Action |
|------------|--|
| Yes | Replace audio unit |
| No | Repair wiring harness (Audio unit—GND) |

**AUDIO UNIT****Removal**

1. Pry out the audio unit service hole covers by using a protected screwdriver. Keep the hole covers for reinstallation.
2. With the beveled parts of the **SST** facing inward, insert them into the audio unit.
3. Pull the **SST** outward and rearward to slide out the audio unit.
4. Disconnect the connector and antenna jack.

Installation


1. Install the audio unit service hole covers.
2. Connect the audio unit connectors and antenna jack.
3. Insert the audio unit until each clip clicks. Verify that the wiring harness and antenna feeder are not caught between the audio unit and the dashboard.

SPEAKER**Removal / Installation****Door speaker**

1. Remove the door speaker cover by using a protected screwdriver.
2. Remove the 3 screws and the door speaker.
3. Install in the reverse order of removal.

Rear speaker

1. Remove the rear speaker cover.
2. Remove the 3 screws and the rear speaker.
3. Install in the reverse order of removal.

**Inspection**

1. Measure the resistance between the speaker terminals.


Door speaker: 3.6 Ω

Rear speaker: 4 Ω

2. Touch the leads of an ohmmeter to the speaker terminals and verify that the speaker clicks.

Range: $\times 1 \Omega$


3. If not as specified, replace the speaker.

**ROOF ANTENNA****Removal**

1. Remove the dashboard.


(Refer to the 1995 MX-3 Workshop Manual, section S.)

2. Remove the front side trim.




3. Remove the antenna feeder from the clip.

4. Remove the screws and the antenna assembly.


**Installation**

1. Extend the antenna. Insert the antenna feeder and the drain pipe through the hole in the roof toward the front pillar.

2. Fix the antenna feeder.



3. Install the antenna base in the order shown in the figure.

**Inspection**

1. Disconnect the antenna jack.
2. Measure the resistance at the antenna jack terminals.

Resistance: Infinite

3. If not as specified, replace the antenna feeder.

ELECTRICAL WIRING SCHEMATIC




| | |
|-----------------|------|
| B6 ENGINE | W- 2 |
| K8 ENGINE | W- 3 |

K8 ENGINE


W-2 WITH AIR BAG SYSTEM ■ ELECTRICAL WIRING SCHEMATIC

NOTE: 1. ...ATS 2. ...K8 DCPC 3. ...CURRENT FROM BATTERY 4. ...CURRENT FROM ACC 5. ...OTHERS



Mazda MX-3

1995
Wiring Diagram



mazda

SYSTEM INDEX

ENGINE-RELATED SYSTEMS

STARTING SYSTEM

- MTX..... Z 28
- ATX..... Z-30

CHARGING SYSTEM

- MTX..... Z-28
- ATX..... Z-30

ENGINE CONTROL SYSTEM

- B6 DOHC..... Z-32
- K8 DOHC..... Z 40

IGNITION SYSTEM

- B6 DOHC..... Z-32
- K8 DOHC..... Z-40

FUEL CONTROL SYSTEM..... Z-48

COOLANT FAN SYSTEM

- B6 DOHC, K8 DOHC MTX..... Z-50
- K8 DOHC ATX..... Z 52

CHASSIS-RELATED SYSTEMS

EC-AT CONTROL SYSTEM

- B6 DOHC..... Z-88
- K8 DOHC..... Z-90

SHIFT-LOCK SYSTEM..... Z-94

4 WHEEL ANTILOCK BRAKE

- SYSTEM (4WABS)..... Z-112

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER

- B6 DOHC..... Z 54
- K8 DOHC..... Z 58

BODY-RELATED SYSTEMS

WINDSHIELD WIPER AND

- WASHER..... Z-62

REAR WIPER AND WASHER..... Z 64

HORN..... Z 78

REAR WINDOW DEFROSTER..... Z-96

POWER WINDOW SYSTEM..... Z-104

POWER DOOR LOCK SYSTEM..... Z 106

POWER OUTSIDE MIRROR..... Z 108

SLIDING SUNROOF..... Z-110

CRUISE CONTROL SYSTEM

- K8 DOHC..... Z 116

AIR BAG SYSTEM..... Z 122

CENTRAL PROCESSING UNIT

- (CPU)..... Z 124

INTERIOR LIGHTING SYSTEMS

ILLUMINATION LIGHTS..... Z-98

INTERIOR LIGHT..... Z-100

CARGO COMPARTMENT LIGHT..... Z-100

IGNITION KEY ILLUMINATION..... Z-124

EXTERIOR LIGHTING SYSTEMS

HEADLIGHTS

WITHOUT AIR BAG SYSTEM..... Z-66

WITH AIR BAG SYSTEM..... Z-68

DRL CONTROL SYSTEM..... Z-70

PARKING LIGHTS..... Z-72

FRONT SIDE MARKER LIGHTS..... Z-72

TAILLIGHTS..... Z-72

LICENCE PLATE LIGHTS..... Z-72

REAR SIDE MARKER LIGHTS..... Z-72

TURN AND HAZARD WARNING

LIGHTS..... Z-74

BRAKE LIGHTS..... Z-76

HIGH-MOUNT BRAKE LIGHT..... Z-76

BACK-UP LIGHTS..... Z-76

AIR CONDITIONING-RELATED SYSTEMS

CONDENSER FAN SYSTEM

B6 DOHC..... Z-80

K8 DOHC..... Z-82

HEATER AND AIR CONDITIONER

WIRE TYPE..... Z-84

LOGIC TYPE..... Z 86

ACCESSORIES

CIGARETTE LIGHTER..... Z-96

DIGITAL CLOCK..... Z-98

AUDIO SYSTEM..... Z-102

OTHERS

DATA LINK CONNECTOR

B6 DOHC..... Z 128

K8 DOHC..... Z-130

1995 Mazda MX-3 Wiring Diagram

FOREWORD

This wiring diagram incorporates the wiring schematics of the basic vehicle and available optional equipment. Actual vehicle wiring may vary slightly depending on optional equipment or local specifications, or both. All information in this booklet is based on information available at the time of printing. Mazda Motor Corporation reserves the right to make changes without previous notice.

Mazda Motor Corporation
HIROSHIMA, JAPAN

APPLICATION:

This manual applies to vehicles beginning with the Vehicle Identification Numbers (VIN) on the following page.

CONTENTS

| | |
|--|------------|
| GENERAL INFORMATION | GI |
| GROUND POINTS | Y |
| ELECTRICAL WIRING SCHEMATIC | W |
| SYSTEM CIRCUIT DIAGRAM/ CONNECTOR LOCATIONS | A~U |
| COMMON CONNECTORS | X |
| JOINT BOX COMPLETE WIRING SYSTEM | JB |
| PARTS LOCATION | PL |
| INDEX | PI |

Z

VEHICLE IDENTIFICATION NUMBERS (VIN) (CHASSIS NUMBER)

JM1 EC433*S0 400001~

JM1 EC434*S0 400001~

WIRING COLOR CODE

| Color | Code | Color | Code |
|-------------|------|----------|------|
| Blue | L | Orange | O |
| Black | B | Pink | P |
| Brown | BR | Red | R |
| Dark Blue | DL | Purple | PU |
| Dark Green | DG | Sky Blue | SB |
| Green | G | Tan | T |
| Gray | GY | White | W |
| Light Blue | LB | Yellow | Y |
| Light Green | LG | Violet | V |
| Natural | N | | |

GENERAL INFORMATION

Wiring Diagrams

| | |
|----------------------------------|------|
| Contents of wiring diagrams..... | GI-2 |
| Using wiring diagrams..... | GI-2 |

Reading Wiring Diagrams


| | |
|--|-------|
| Ground points..... | GI-3 |
| System circuit diagram/connector diagram | GI-4 |
| Routing diagram | GI-6 |
| Harness symbols..... | GI-7 |
| Symbols | GI-8 |
| Logic symbols | GI-10 |
| Abbreviations used in this booklet..... | GI-10 |

Troubleshooting

| | |
|---|-------|
| Precautions to take when servicing an electrical system | GI-11 |
| Handling connectors | GI-12 |
| Using electrical measuring equipment | GI-13 |
| Measuring voltage..... | GI-14 |
| Measuring continuity/resistance..... | GI-15 |
| Finding short circuits | GI-16 |






Contents of wiring diagrams

- This document comprises the 8 groups shown below. The main components are summarized in the components location diagram at the end of the document.

| | | | |
|--|-----|--|---|
|  | GI | General Information | A how-to on using and reading wiring diagrams, using test equipment, checking harnesses and connectors, and finding trouble spots |
| | Y | Ground points | Ground routes from and to the battery |
| | W | Electrical wiring schematics | Shows main fuses and other fuses for each system |
| | A-U | Circuit diagrams for individual systems | Shows circuit and connector diagrams and component and connector location diagrams |
| | X | Common connectors | Shows connectors common throughout system |
| | JB | Joint box complete wiring system | Shows internal circuits and connectors |
| | PL | Parts location | Shows location of major electrical parts |
| | PI | Index | Gives page number of circuit diagram for each component |

Using wiring diagrams

- The use of the wiring diagram depends on its application.

| Application | Use | Application | Use |
|---|---|--|---|
| For checking circuits of individual systems |  <p>Open to page with circuit diagram and harness routing to be used and fold out common connector diagram or joint box diagram.</p> | For checking fuse connections |  <p>Open to electrical wiring schematic.</p> |
| For checking ground circuit of individual systems |  <p>Open to page with ground point diagram and fold out common connector diagram or joint box diagram.</p> | For finding page numbers of systems and components | <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Parts Index</p>  </div> <div style="text-align: center;"> <p>System Index</p>  </div> </div> <p>or</p> <p>Open to parts Index or system index.</p> |


System circuit diagram/connector diagram

- These show the circuits for each system, from the power supply to the ground. The power supply side is on the upper part of the page, the ground side on the lower part. The diagrams describe circuits with the ignition switch off.

Below is an explanation of the various points in the diagram.

System code

System name



Connector code

The prefix letter indicates the system in which the connector is used.

- JB** : Joint box connections
- X** : Common connectors
- A** : Charging system/starting system connectors
- B** : Engine control system connectors
- C** : Gauge control system connectors
- D** : Wiper system connectors
- E** : Lighting system connectors
- F** : Signal system connectors
- G** : Air-conditioning system connectors
- H** : Transmission control system connectors
- I** : Interior lamp system connectors
- J** : Audio/radio connectors
- K** : Power window/power door lock system connectors
- L** : Remote control mirror system connectors
- M** : Sliding sunroof system connectors
- N** : Power steering/4-wheel steering system connectors
- O** : Anti-lock brake system connectors
- P** : Power seat/seat heater system connectors
- Q** : Auto cruise control system connectors
- R** : Auto adjusting suspension system connectors
- S** : Passive shoulder belt control/air bag system connectors
- T** : Others
- Y** : Ground connector

Ground numbers

A harness ground is represented differently than a unit ground.

| Types of grounds | Symbol |
|----------------------------------|--------|
| <p>Harness</p> | |
| <p>Unit</p> <p>Sensor</p> | |

The number indicates that the circuit continues to the related system diagram.

Current symbol

Current flows in the direction of the arrow.

Indicates shielded wire.*

*Shielded wire:
Prevents signal disturbances from electrical interference.
Wire is covered by a metal meshing for grounding.


Connector symbols

Male and female connectors are represented as follows in the circuit and connector diagrams.


| | Circuit diagram symbol | Connector diagram symbol |
|--------|------------------------|--------------------------|
| Male | | |
| Female | | |

- Like connectors are linked by dashed lines between the connector symbols.
- Connector diagrams show connectors on the harness side. The terminal indicates the view from the harness side.

(Example)



- Colors for connectors except milk-white are given in locations.
- Unused terminals are indicated by *.




Wire color code (harness symbol)

- Two-color wires are indicated by a two-letter symbol. The first indicates the base color of the wire, the second the color of the stripe.

For example:

W/R is a white wire with a red strip

BR/Y is a brown wire with a yellow strip



- The harness symbol is in () following the harness symbols (refer to GI-7).

Routing diagram

- The routing diagram shows where electrical components are on the system circuit diagram by call out line and connector symbols.
- Specified values are listed beside the routing diagram or on the following page.

Connector symbol

Shows the system that uses the connector.

(Example)

| Connector | Symbol |
|-------------------|--------|
| Joint box | JB-04 |
| Common connectors | X-19 |
| System connectors | I-03 |

Component name

Shows the names of components in routing diagrams.

Ground symbol

Shows the ground in system diagrams.

Engine control unit terminal (unit side)





















| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|


































| Terminal No. | Input | Output | Connection to | Test condition | Voltage | Remarks |
|--------------|-------|--------|-----------------------------------|---|-------------------|--------------------|
| 1K | C | | Diagnostic Connector | All Systems detect the test switch "ON" | Approx. 12V | |
| 1R | C | | Throttle sensor (Idle point) | Accelerator pedal released | Approx. 0V | Ignition switch ON |
| 1Q | C | | Brake pedal switch | Brake pedal released | 0V | |
| 1P | C | | P/S cruise switch | Ignition switch ON P/S ON (or OFF) | Approx. 12V 0V | |
| 1K | C | | Pan switch | Fan operating (engine coolant temperature over 90°C/194°F) or (ignition switch terminal 16A grounded) | Approx. 0V | |
| 1U | C | | Headlight switch | Headlights ON (Low, parking, low beam or high beam) | Approx. 12V | |
| 1V | C | | Repetition clutch switch | Headlight position is clutch pedal depressed | Approx. 0V | |
| 2r | - | - | Ground (Right) | Constant | 0V | |
| 2s | - | - | Ground (Left) | Constant | 0V | |
| 2t | - | - | Ground (Front) | Constant | 0V | |
| 2u | - | - | Ground (Rear) | Constant | 0V | |
| 2v | C | | Engine speed sensor (RPM sensor) | Ignition switch ON | Approx. 0V or 5V | |
| 2w | C | | Crash sensor (G sensor) | Ignition switch ON | Approx. 0V or 5V | |
| 2x | C | | Ground | Constant | 0V | |
| 2K | C | | Airflow sensor | Constant | 1.5-1.8V | |
| 2L | C | | Throttle sensor (Power 1st stage) | Accelerator pedal released | Approx. 0V | |
| 2M | C | | Throttle sensor (Power 2nd stage) | Accelerator pedal fully depressed | Approx. 0V | |
| 2N | C | | Dryden sensor | Ignition switch ON Idle (Cold engine) Idle (After warm up) Increase engine speed (After warm up) | 0V 0V 0V-1V | |
| 2O | C | | Airflow sensor | Ignition switch ON | 0-0.8V | |
| 2P | C | | Airflow sensor (Power 1st stage) | Ignition switch ON | Approx. 1.5V | |
| 2Q | C | | Airflow sensor (Power 2nd stage) | Ignition switch ON | Approx. 1.5V | |
| 2R | C | | Airflow sensor (Power 3rd stage) | Ignition switch ON | Approx. 1.5V | |
| 2S | C | | Airflow sensor (Power 4th stage) | Ignition switch ON | Approx. 1.5V | |
| 2T | C | | Airflow sensor (Power 5th stage) | Ignition switch ON | Approx. 1.5V | |
| 2U | C | | Airflow sensor (Power 6th stage) | Ignition switch ON | Approx. 1.5V | |
| 2V | C | | Airflow sensor (Power 7th stage) | Ignition switch ON | Approx. 1.5V | |
| 2W | C | | Airflow sensor (Power 8th stage) | Ignition switch ON | Approx. 1.5V | |
| 2X | C | | Airflow sensor (Power 9th stage) | Ignition switch ON | Approx. 1.5V | |
| 2Y | C | | Airflow sensor (Power 10th stage) | Ignition switch ON | Approx. 1.5V | |
| 2Z | C | | Airflow sensor (Power 11th stage) | Ignition switch ON | Approx. 1.5V | |
| 3A | C | | Airflow sensor (Power 12th stage) | Ignition switch ON | Approx. 1.5V | |
| 3B | C | | Airflow sensor (Power 13th stage) | Ignition switch ON | Approx. 1.5V | |
| 3C | C | | Airflow sensor (Power 14th stage) | Ignition switch ON | Approx. 1.5V | |
| 3D | C | | Airflow sensor (Power 15th stage) | Ignition switch ON | Approx. 1.5V | |
| 3E | C | | Airflow sensor (Power 16th stage) | Ignition switch ON | Approx. 1.5V | |
| 3F | C | | Airflow sensor (Power 17th stage) | Ignition switch ON | Approx. 1.5V | |
| 3G | C | | Airflow sensor (Power 18th stage) | Ignition switch ON | Approx. 1.5V | |
| 3H | C | | Airflow sensor (Power 19th stage) | Ignition switch ON | Approx. 1.5V | |
| 3I | C | | Airflow sensor (Power 20th stage) | Ignition switch ON | Approx. 1.5V | |
| 3J | C | | Airflow sensor (Power 21st stage) | Ignition switch ON | Approx. 1.5V | |
| 3K | C | | Airflow sensor (Power 22nd stage) | Ignition switch ON | Approx. 1.5V | |
| 3L | C | | Airflow sensor (Power 23rd stage) | Ignition switch ON | Approx. 1.5V | |
| 3M | C | | Airflow sensor (Power 24th stage) | Ignition switch ON | Approx. 1.5V | |
| 3N | C | | Airflow sensor (Power 25th stage) | Ignition switch ON | Approx. 1.5V | |
| 3O | C | | Airflow sensor (Power 26th stage) | Ignition switch ON | Approx. 1.5V | |
| 3P | C | | Airflow sensor (Power 27th stage) | Ignition switch ON | Approx. 1.5V | |
| 3Q | C | | Airflow sensor (Power 28th stage) | Ignition switch ON | Approx. 1.5V | |
| 3R | C | | Airflow sensor (Power 29th stage) | Ignition switch ON | Approx. 1.5V | |
| 3S | C | | Airflow sensor (Power 30th stage) | Ignition switch ON | Approx. 1.5V | |
| 3T | C | | Airflow sensor (Power 31st stage) | Ignition switch ON | Approx. 1.5V | |
| 3U | C | | Airflow sensor (Power 32nd stage) | Ignition switch ON | Approx. 1.5V | |
| 3V | C | | Airflow sensor (Power 33rd stage) | Ignition switch ON | Approx. 1.5V | |
| 3W | C | | Airflow sensor (Power 34th stage) | Ignition switch ON | Approx. 1.5V | |
| 3X | C | | Airflow sensor (Power 35th stage) | Ignition switch ON | Approx. 1.5V | |
| 3Y | C | | Airflow sensor (Power 36th stage) | Ignition switch ON | Approx. 1.5V | |
| 3Z | C | | Airflow sensor (Power 37th stage) | Ignition switch ON | Approx. 1.5V | |
| 4A | C | | Airflow sensor (Power 38th stage) | Ignition switch ON | Approx. 1.5V | |
| 4B | C | | Airflow sensor (Power 39th stage) | Ignition switch ON | Approx. 1.5V | |
| 4C | C | | Airflow sensor (Power 40th stage) | Ignition switch ON | Approx. 1.5V | |
| 4D | C | | Airflow sensor (Power 41st stage) | Ignition switch ON | Approx. 1.5V | |
| 4E | C | | Airflow sensor (Power 42nd stage) | Ignition switch ON | Approx. 1.5V | |
| 4F | C | | Airflow sensor (Power 43rd stage) | Ignition switch ON | Approx. 1.5V | |
| 4G | C | | Airflow sensor (Power 44th stage) | Ignition switch ON | Approx. 1.5V | |
| 4H | C | | Airflow sensor (Power 45th stage) | Ignition switch ON | Approx. 1.5V | |
| 4I | C | | Airflow sensor (Power 46th stage) | Ignition switch ON | Approx. 1.5V | |
| 4J | C | | Airflow sensor (Power 47th stage) | Ignition switch ON | Approx. 1.5V | |
| 4K | C | | Airflow sensor (Power 48th stage) | Ignition switch ON | Approx. 1.5V | |
| 4L | C | | Airflow sensor (Power 49th stage) | Ignition switch ON | Approx. 1.5V | |
| 4M | C | | Airflow sensor (Power 50th stage) | Ignition switch ON | Approx. 1.5V | |

Specified values









Shows values for determining whether an electrical component is good.

Symbols

| Symbol | Meaning | Symbol | Meaning | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|---|------------|-------|-------|-------|-------|--|-------------------|--|------------|-----------|-------|---|---|---------------|--|-------|---|---|---------------|--|-----|---|---|---------------|--|--------|---|---|---------------|--|--------|---|---|---------------|--|-------|---|---|---------------|--|------|---|---|---------------|--|--------|---|---|---------------|--|------|---|---|---------------|--|-------|---|---|---------------|--|------|--|--|------------------|-----------|--------|--|--|------------------|------------|---|--|--|--|------------|
| Battery  | <ul style="list-style-type: none"> Generates electricity through chemical reaction. Supplies direct current to circuits. | Resistance  | <ul style="list-style-type: none"> A resistor with a constant value. Mainly used to protect electrical components in circuits by maintaining rated voltage. Reading resistance values. <p>< Colored ></p>  <table border="1"> <thead> <tr> <th>Color</th> <th>No. 1</th> <th>No. 2</th> <th>No. 3</th> <th>No. 4</th> </tr> <tr> <td></td> <td colspan="2">Resistance values</td> <td>Multiplier</td> <td>Tolerance</td> </tr> </thead> <tbody> <tr><td>Black</td><td>0</td><td>0</td><td>$\times 10^0$</td><td></td></tr> <tr><td>Brown</td><td>1</td><td>1</td><td>$\times 10^1$</td><td></td></tr> <tr><td>Red</td><td>2</td><td>2</td><td>$\times 10^2$</td><td></td></tr> <tr><td>Orange</td><td>3</td><td>3</td><td>$\times 10^3$</td><td></td></tr> <tr><td>Yellow</td><td>4</td><td>4</td><td>$\times 10^4$</td><td></td></tr> <tr><td>Green</td><td>5</td><td>5</td><td>$\times 10^5$</td><td></td></tr> <tr><td>Blue</td><td>6</td><td>6</td><td>$\times 10^6$</td><td></td></tr> <tr><td>Purple</td><td>7</td><td>7</td><td>$\times 10^7$</td><td></td></tr> <tr><td>Grey</td><td>8</td><td>8</td><td>$\times 10^8$</td><td></td></tr> <tr><td>White</td><td>9</td><td>9</td><td>$\times 10^9$</td><td></td></tr> <tr><td>Gold</td><td></td><td></td><td>$\times 10^{-1}$</td><td>$\pm 5\%$</td></tr> <tr><td>Silver</td><td></td><td></td><td>$\times 10^{-2}$</td><td>$\pm 10\%$</td></tr> <tr><td>—</td><td></td><td></td><td></td><td>$\pm 20\%$</td></tr> </tbody> </table> <p>< Numerical ></p>  | Color | No. 1 | No. 2 | No. 3 | No. 4 | | Resistance values | | Multiplier | Tolerance | Black | 0 | 0 | $\times 10^0$ | | Brown | 1 | 1 | $\times 10^1$ | | Red | 2 | 2 | $\times 10^2$ | | Orange | 3 | 3 | $\times 10^3$ | | Yellow | 4 | 4 | $\times 10^4$ | | Green | 5 | 5 | $\times 10^5$ | | Blue | 6 | 6 | $\times 10^6$ | | Purple | 7 | 7 | $\times 10^7$ | | Grey | 8 | 8 | $\times 10^8$ | | White | 9 | 9 | $\times 10^9$ | | Gold | | | $\times 10^{-1}$ | $\pm 5\%$ | Silver | | | $\times 10^{-2}$ | $\pm 10\%$ | — | | | | $\pm 20\%$ |
| Color | No. 1 | No. 2 | No. 3 | No. 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Resistance values | | Multiplier | Tolerance | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Black | 0 | 0 | $\times 10^0$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Brown | 1 | 1 | $\times 10^1$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Red | 2 | 2 | $\times 10^2$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Orange | 3 | 3 | $\times 10^3$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Yellow | 4 | 4 | $\times 10^4$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Green | 5 | 5 | $\times 10^5$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Blue | 6 | 6 | $\times 10^6$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Purple | 7 | 7 | $\times 10^7$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Grey | 8 | 8 | $\times 10^8$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| White | 9 | 9 | $\times 10^9$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Gold | | | $\times 10^{-1}$ | $\pm 5\%$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Silver | | | $\times 10^{-2}$ | $\pm 10\%$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| — | | | | $\pm 20\%$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Ground (1)  | <ul style="list-style-type: none"> Connecting point to vehicle body or other ground wire where current flows from positive to negative terminal of battery. Ground (1) indicates a ground point to body through wire harness. Ground (2) indicates point where component is grounded directly to body. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Ground (2)  | <p>Remarks</p> <ul style="list-style-type: none"> Current will not flow through a circuit if ground is faulty. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fuse (1)  | <ul style="list-style-type: none"> Melts when current flow exceeds that specified for circuit, interrupts current flow. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (box)  | <p>Precautions</p> <ul style="list-style-type: none"> Do not replace with fuses exceeding specified capacity. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fuse (2)  | <p>< Blade type > < Tube type ></p>  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (Cartridge)  | <p>< Cartridge type > < Fusible link ></p>  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Main fuse/ Fusible link  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Transistor (1) Collector (C)  NPN Emitter (E) | <ul style="list-style-type: none"> Electrical switching component. Turns on when voltage is applied to the base (B). <p>Collector indication mark</p>  | Motor  | <ul style="list-style-type: none"> Converts electrical energy into mechanical energy. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Transistor (2) Collector (C)  PNP Emitter (E) | <ul style="list-style-type: none"> Reading code. <p>2 S C 828 A</p> <p>Semiconductor Revision mark</p> <p>Number of terminals A: High-frequency PNP B: Low-frequency PNP C: High-frequency NPN D: Low-frequency NPN</p> | Pump  | <ul style="list-style-type: none"> Pulls in and discharges gases and liquids. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lamp  | <ul style="list-style-type: none"> Emits light and generates heat when current flows through filament. | Cigarette lighter  | <ul style="list-style-type: none"> Electrical coil that generates heat. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Symbol | Meaning | Symbol | Meaning | | | | | | | | | |
|---|---|--|---|-----------------|--------------------------|---|--|----------------------------|--|---|--|--|
| Horn  | <ul style="list-style-type: none"> Generates sound when current flows. | Switch (1)  Normally open (NO) | <ul style="list-style-type: none"> Allows or breaks current flow by opening and closing circuits. | | | | | | | | | |
| Speaker  | | Switch (2)  Normally closed (NC) | | | | | | | | | | |
| Heater  | <ul style="list-style-type: none"> Generates heat when current flows. | Harness  (Not connected) | <ul style="list-style-type: none"> Unconnected intersecting harness.  <ul style="list-style-type: none"> Connected intersecting harness.  | | | | | | | | | |
| Speed sensor  | <ul style="list-style-type: none"> Movement of magnet in speedometer turns contact within sensor on and off. |  (Connected) | | | | | | | | | | |
| Ignition switch  | <ul style="list-style-type: none"> Turning ignition key switches circuit to operate various component. <p>(NOTE) Ignition switch is called engine switch on diesel vehicles.</p> | | | | | | | | | | | |
| Relay (1)  Normally open (NO) | <ul style="list-style-type: none"> Current flowing through coil produces electromagnetic force causing contact to open or close. <table border="1" style="width: 100%; text-align: center; border-collapse: collapse;"> <thead> <tr> <th></th> <th>No current to coil</th> <th>Current to coil</th> </tr> </thead> <tbody> <tr> <td>Normally open relay (NO)</td> <td>  No flow </td> <td>  Flow </td> </tr> <tr> <td>Normally closed relay (NC)</td> <td>  Flow </td> <td>  No flow </td> </tr> </tbody> </table> | | No current to coil | Current to coil | Normally open relay (NO) |  No flow |  Flow | Normally closed relay (NC) |  Flow |  No flow | | |
| | | No current to coil | Current to coil | | | | | | | | | |
| Normally open relay (NO) |  No flow |  Flow | | | | | | | | | | |
| Normally closed relay (NC) |  Flow |  No flow | | | | | | | | | | |
| Relay (2)  Normally closed (NC) | | | | | | | | | | | | |
| Sensor (variable)  | <ul style="list-style-type: none"> Resistance changes with other components operation. | Diode  | <ul style="list-style-type: none"> Known as a semiconductor rectifier, the diode allows current flow in one direction. <p>Cathode (K) —> Anode (A) — Flow of electric current</p> <p>K —> A K —> A K —> A</p> | | | | | | | | | |
| Sensor (thermistor)  | <ul style="list-style-type: none"> Resistance changes with temperature. | Light-emitting diode (LED)  | <ul style="list-style-type: none"> A diode that lights when current flows. Unlike ordinary bulbs, the diode does not generate heat when lit. <p>Cathode (K) —> Anode (A)</p>  Flow of current | | | | | | | | | |
| Capacitor  | <ul style="list-style-type: none"> Component that temporarily stores electrical charge. | Reference diode (Zener diode)  | <ul style="list-style-type: none"> Allows current to flow in one direction up to a certain voltage; allows current to flow in the other direction once that voltage is exceeded. | | | | | | | | | |
| Solenoid  | <ul style="list-style-type: none"> Current flowing through coil generates electromagnetic force to operate plungers. | | | | | | | | | | | |

Logic symbols

| Types of logic symbols | Operation | Expressing output | Simple relay circuits |
|---|---|---|--|
| <p>OR</p>  | Input to A or B will produce output at C. | Low electrical potential (L) at A and B → no output (L) at C High electrical potential (H) at A or B → output (H) at C |  |
| <p>AND</p>  | Input to A and B will produce output at C. | High electrical potential (H) at A and B → output (H) at C Low electrical potential (L) at A or B → no output (L) at C |  |
| <p>INV</p>  | No input to A will produce an output at B. An input to A will not produce an output at B. | Low electrical potential (L) at A → no ground (H) B High electrical potential (H) at A → grounds (L) B |  |
| <p>PROCESS</p>  | Simplified representation of complex functions within circuit describes main function. 1. Signal detector for engine control unit, cooling unit, and tachometer. 2. Signal converter for turn and hazard flasher unit and igniter unit. | | <p>(Examples) Igniters</p>  |


Abbreviations used in this booklet

| | | |
|--------------------------------------|---|--|
| 3GR Third Gear | ECM Engine Control Module | MTX Manual Transaxle |
| 4GR Fourth Gear | ECPS Electronically Controlled Power Steering | NC Normally Closed |
| A Ampere | ECT Engine Coolant Temperature | NO Normally Open |
| A/C Air Conditioning | EGR Exhaust Gas Recirculation | O2S Oxygen Sensor |
| A/F Air Fuel | EI Electronic Ignition | OBD On-Board Diagnostic |
| A/R Auto Reverse | ELEC Electric | OFF Switch Off |
| AAS Autoadjusting Suspension | ELR Emergency Locking Retractor | ON Switch On |
| ABS Antilock Brake System | ETR Electronic Tuner | P Power |
| ACC Accessory | F Front | P/S Power Steering |
| ACV Air Control Valve | F/I Fuel Injector | PAIR Pulsed Secondary Air Injection |
| ADD Additional | FC Fan Control | PCM Powertrain Control Module |
| AIR Secondary Air Injection | FICB Fast-Idle Cam Breaker | PNP Park/Neutral Position |
| AIS Air Injection System | FM Frequency Modulation | PRCV Pressure Regulator Control Solenoid Valve |
| ALL Automatic Load Leveling | FP Fuel Pump | PRG Purge Solenoid Valve |
| AM Amplitude Modulation | FPR Fuel Pump Relay | PSP Power Steering Pressure |
| AMP Amplifier | GEN Generator | PTC Positive Temperature Coefficient Heater |
| ANT Antenna | GND Ground | QSS Quick-Start System |
| AP Accelerator Pedal | H/D Heater/Defroster | R Rear |
| AS Autostop | HEAT Heater | REC Recirculation |
| ASV Air Supply Valve | HEI High-Energy Ignition | RF Right Front |
| AT Automatic transmission | HI High | RH Right Hand |
| ATX Automatic Transaxle | HQ2S Heated Oxygen Sensor | RPM Engine Speed |
| B+ Battery Positive Voltage | IAC Idle Air Control | RR Rear Right |
| BAC Bypass Air Control Valve | IAT Intake Air Temperature | SAPV Secondary Air Pulse Valve |
| BARO Barometric Pressure | ICM Ignition Control Module | SFI Sequential Multipoint Fuel Injection |
| CAC Charge Air Cooler | IG Ignition | SOL Solenoid |
| CARB Carburetor | ILLUMI Illumination | ST Start |
| CCT Circuit | INT Intermittent | SW Switch |
| CIGAR Cigarette | JB Joint Box | TC Turbocharger |
| CIS Continuous Fuel Injection System | KS Knock Sensor | TCM Transmission (Transaxle) Control Module |
| CKP Crankshaft Position Sensor | LCD Liquid Crystal Display | TCV Twin Scroll Turbocharger Solenoid Valve |
| CLS Closed Loop System | LF Left Front | TEMP Temperature |
| CMP Camshaft Position Sensor | LH Left Hand | TICS Triple Induction Control System |
| COMBI Combination | LO Low | TP Throttle Position Sensor |
| CON Conditioner | LR Left Rear | TR Transmission Range |
| CONT Control | M Motor | TR Transmission (Transaxle) Range |
| CPU Central Processing Unit | MAF Mass Air Flow Sensor | TWS Total Wiring System |
| CSD Cold Start Device | MAP Manifold Absolute Pressure | V Volt |
| CTP Closed Throttle Position | MFI Multiport Fuel Injection | VAF Volume Air Flow Sensor |
| DEF Defroster | MID Middle | VENT Ventilation |
| DI Distributor Ignition | MIL Malfunction Indicator Lamp | VOL Volume |
| DLC Data Link Connector | MIN Minute | VR Voltage Regulator |
| DLI Distributorless Ignition | MIX Mixture | VRIS Variable Resonance Induction System |
| DOHC Double-Overhead Camshaft | MPX Multiplex | VSS Vehicle Speed Sensor |
| DTC Diagnostic Trouble Code(s) | MT Manual Transmission | W Watt(s) |
| DTM Diagnostic Test Mode | MTR Mechanical Tuning Radio | WOT Wide Open Throttle |


Precautions to take when servicing an electrical system

- Note the following items when servicing the electrical system.
- Do not alter the wiring or electrical equipment in any way; this may damage the vehicle or cause a fire from short-circuiting a circuit or overloading it.

- The negative (-) battery cable must be removed first and installed last.



- Do not replace with fuses exceeding specified capacity.




Caution

- Be sure that the Ignition and other switches are off before disconnecting or connecting the battery cables.

Failure to do so may damage the semiconductor components.



- Secure harnesses with provided clamps to take up slack.



Caution

- Replacing a fuse with one of a larger capacity than designated may damage components or cause a fire.


- Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.





Caution

- Clamp all harnesses near vibrating components (for example, the engine) to remove slack and to prevent contact resulting from vibration.

- Do not handle electrical components roughly or drop them.




























- Disconnect heat-sensitive parts (for example, relays and ECU) when performing maintenance (such as welding) where temperatures may exceed 80°C (176°F).














Handling connectors

Caution

- Be sure to grasp the connectors, not the wires, when disconnecting them.


| Connector removal | | Checking connector contacts | Checking for loose terminals | Replacing terminal |
|-------------------|---|--|--|---|
| Push type |  | <p>Caution Improperly engaged connectors will cause poor terminal contact.</p>  <p>When using a matching male terminal, make sure there is no looseness in the female terminal.</p> | <p>Caution A loose terminal will cause poor terminal contact.</p>  <p>Make sure the terminals are not pushed out of the connector when engaged.</p>  <p>Pull lightly on individual wires to check that they are secured in the terminal.</p> | <p><CPU connector></p>  <ol style="list-style-type: none"> 1. Raise the rear cover. 2. Lift the tab with a thin piece of metal and remove the terminal.  |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| |  | | | |
| Pull-up type |  | | | <p><General connector></p>  <p>Lift the tab with a thin piece of metal and remove the terminal.</p> |
| |  | | | |
| |  | | | |
| |  | | | |
| Spring type |  | | | <p><Round connectors></p>  <ol style="list-style-type: none"> 1. Raise the cover. 2. Lift the terminal to remove it. 3. Make sure the terminal is securely mounted in the connector when installing.  <p><Common ground connectors></p>  <ol style="list-style-type: none"> 1. Raise the cover. 2. Remove A. 3. Lift the tab with a thin piece of metal and remove the terminal.  |

Using electrical measuring equipment

| Equipment | Use | Operation | Handling precautions |
|--|--|--|--|
| Test lamp  | Test to find open or shorted circuits. | <ul style="list-style-type: none"> Connect the test lamp between the circuit being measured and a ground. The lamp will light if the circuit is energized to the point tested.  | <ul style="list-style-type: none"> Test lamps use 12V 1.4W or 3.4W bulbs or light-emitting diodes (LEDs). Using a large-capacity bulb may damage the CPU. |
| Jumper wire  | Used to create a temporary circuit. | <ul style="list-style-type: none"> Connect the jumper wire between the terminals of a circuit to bypass a switch.  | <ul style="list-style-type: none"> Do not connect the jumper wire from the power source line to a ground; this may cause burning or other damage to harnesses or electronic components. |
| Voltmeter  | Used for measuring the voltage of a circuit to locate possible opens or shorts. | <ul style="list-style-type: none"> Connect the positive (+) probe to the point where voltage is to be measured and the negative (-) probe to a ground.  | <ul style="list-style-type: none"> Connect the voltmeter in parallel with the circuit. Set the range to the desired voltage. Use the service hole when measuring the voltage at the diagnosis connector. Tie a thin wire to the positive (+) probe to access narrow terminals.  |
| Ohmmeter  | Used to find opens and shorts in the circuit, to confirm continuity and to measure resistance. | <ul style="list-style-type: none"> Zero the ohmmeter. Verify that voltage is not applied to the circuit. Connect the probes between two points in a circuit.  | <ul style="list-style-type: none"> Zero the meter after switching to the measuring range. Before using the ohmmeter, make sure the ignition switch is off or the negative (-) battery cable is disconnected to prevent burning or otherwise damaging the ohmmeter. |
| Ammeter  | Used to check alternator output, current supplied to the starter, and dark current within a circuit. Note Dark current is the constant flow of current while the ignition switch is OFF. | <ul style="list-style-type: none"> Connect the ammeter in series with the circuit by touching the positive (+) probe to the power-side terminal and the negative (-) probe to the ground-side terminal.  | <ul style="list-style-type: none"> Set the range to the desired amperage. Connect the ammeter in series with the circuit. The ammeter may be burned or otherwise damaged if it is connected in parallel. |

Measuring voltage

Checks




1. Connect a voltmeter or test lamp to the measuring points.

| Measuring points | Circuit operation (normal) | | | |
|------------------|----------------------------|---------------------|-------------------|--|
| | Ignition switch: OFF | Ignition switch: ON | | |
| | | Thermo switch: OFF | Thermo switch: ON | |
| A | 0V x | 12V O | 12V O | |
| B | 0V x | 12V O | 0V x | |
| C | 0V x | 0V x | 0V x | |
| D | 12V O | 12V O | 12V O | |
| E | 0V x | 0V x | 12V O | |
| F | 0V x | 0V x | 0V x | |

O : Test lamp ON
x : Test lamp OFF


Precautions during checks

Measuring voltage of connectors



A voltmeter probe may momentarily connect a terminal when inserted into the connector and give an erroneous reading when checking for improperly engaged connectors, poor terminal contacts, or loose terminals.


Measuring voltage of ground unit



Touch the voltmeter probe to the ground wire when checking the ground circuit.

Measuring continuity/resistance


Checking switches



Touch the ohmmeter probes to the switch terminals to check continuity.

Caution
Verify the operating state of the switch before checking continuity because readings vary accordingly.

Checking diodes




Note
The negative (-) probe of the ohmmeter is connected to the positive terminal of the internal ohmmeter battery, the positive (+) probe to the negative terminal of the battery.

Continuity is checked according to the direction of the positive (+) and negative (-) probes of the ohmmeter in the circuit containing the diode.

| Connection | Continuity |
|---|------------|
| <p>A diagram showing an analog ohmmeter connected to a diode. The positive (+) probe is connected to the anode and the negative (-) probe to the cathode. The needle on the meter is deflected, indicating continuity.</p> | Yes |
| <p>A diagram showing an analog ohmmeter connected to a diode. The positive (+) probe is connected to the cathode and the negative (-) probe to the anode. The needle on the meter is at zero, indicating no continuity.</p> | No |


Checking sensors and solenoid valves



Connect the ohmmeter probes to the sensor or solenoid valve terminals to check resistance.

Caution
Verify the operating state of the sensor before checking resistance because readings vary accordingly.

Checking condensers



1. Short between the terminals with a jumper wire to discharge the capacitor.
2. Set the ohmmeter range to $\times 10k\Omega$ and connect it to the capacitor terminals.
3. The capacitor is good if the needle of the ohmmeter swings once and returns to its original position.

Finding short circuits

Shorts occur between the power (positive) and ground (negative) sides of a circuit. Therefore, finding a short circuit requires determining how the circuit is routed.

Circuits not connected to control unit

| | Examples | | Finding short circuit |
|-----------|---|---|-----------------------|
| | Short location | Symptom | |
| Short (A) | <ul style="list-style-type: none"> Fuse melts. | <p>Test lamp</p> <p>A short has occurred where the voltmeter reading changes or the test lamp comes on.</p> | |
| Short (B) | <ul style="list-style-type: none"> Main fuse melts. | | |
| Short (C) | <ul style="list-style-type: none"> The motor operates regardless of whether the thermostat is ON or OFF when the ignition switch is ON. The fuse is not melted. | | |
| Short (D) | <ul style="list-style-type: none"> The main fuse melts when the ignition switch and thermostat are ON and the relay is operating. | | |

Circuits connected to control unit

| | Examples | | Finding short circuit |
|-----------|---|---|-----------------------|
| | Short location | Symptom | |
| Short (A) | <ul style="list-style-type: none"> Fuse melts. | <p>Test lamp</p> <p>A short has occurred where the voltmeter reading changes or the test lamp comes on.</p> | |
| Short (B) | <ul style="list-style-type: none"> Solenoid A operates when the ignition switch is ON. | | |
| Short (C) | <ul style="list-style-type: none"> The CPU transistor burns out when the ignition switch is turned ON. | | |
| Short (D) | <ul style="list-style-type: none"> The CPU thinks the switch is ON because the same conditions exist as when the switch is ON. | | |
| Short (E) | <ul style="list-style-type: none"> The CPU senses the sensor to be 0Ω because the same conditions exist as when the resistance value is 0Ω. The CPU equipped with the self-diagnosis function outputs the code. | | |


Z WIRING DIAGRAM

Y-1 B6 DOHC ■ GROUND POINTS

NOTE: WIRING ORDER INTO THE JOINT CONNECTOR MAY BE CHANGED

◀ ...WITH AIR BAG SYSTEM
◀ ...WITH ABS

() ...AIX
| ...CANADA



Z WIRING DIAGRAM

Y-2 K8-DOHC ■ GROUND POINTS

NOTE: WIRING ORDER INTO THE JOINT CONNECTOR MAY BE CHANGED

< > ... WITH AIR BAG SYSTEM
< > ... WITH ABS




() ... ATX
| | ... CANADA

JC-01 JOINT CONNECTOR (F)

JC-02 JOINT CONNECTOR (F)






JC-03 JOINT CONNECTOR (F)

JC-04 JOINT CONNECTOR (EM)



JC-08 JOINT CONNECTOR (RA)

JC-09 JOINT CONNECTOR (RB)




W

Z WIRING DIAGRAM


W-1 WITHOUT AIR BAG SYSTEM ■ ELECTRICAL WIRING SCHEMATIC

NOTE: — CURRENT FROM BATTERY — CURRENT FROM ACC
 ()...ATX — CURRENT FROM IG1 — OTHERS
 < >...K8 DOHC — CURRENT FROM IG2



W-2 WITH AIR BAG SYSTEM ■ ELECTRICAL WIRING SCHEMATIC

NOTE: — CURRENT FROM BATTERY — CURRENT FROM ACC
 ()...ATX — CURRENT FROM IG1 — OTHERS
 < >...K8 DOHC — CURRENT FROM IG2



| SECTION | SYSTEM CIRCUIT |
|----------|--|
| A-1, A-2 | STARTING SYSTEM CHARGING SYSTEM |
| B-1, B-2 | ENGINE CONTROL SYSTEM IGNITION SYSTEM |
| B-3 | FUEL CONTROL SYSTEM |
| B-4, B-5 | COOLANT FAN SYSTEM |
| C-1, C-2 | INSTRUMENT CLUSTER |
| D-1 | WINDSHIELD WIPER AND WASHER |
| D-2 | REAR WIPER AND WASHER |
| E-2 | HEADLIGHTS |
| E-3 | CANADA ORL CONTROL SYSTEM |
| F-4 | PARKING LIGHTS FRONT SIDE MARKER LIGHTS TAIL LIGHTS LICENCE PLATE LIGHTS REAR SIDE MARKER LIGHTS |
| F-1 | TURN AND HAZARD WARNING LIGHTS |
| F-2 | BRAKE LIGHTS HIGH-MOUNT BRAKE LIGHTS BACK-UP LIGHTS |
| F-3 | HORN |

| SYSTEM CIRCUIT | SECTION |
|--|----------|
| CONDENSER FAN RELAY | G-1, G-2 |
| HEATER AND AIR CONDITIONER | G-3, G-4 |
| EC-AT CONTROL SYSTEM | H-1, H-2 |
| SHIFT-LOCK SYSTEM | H-3 |
| REAR WINDOW DEFROSTER CIGARETTE LIGHTER | I-1 |
| ILLUMINATION LIGHTS DIGITAL CLOCK | I-2 |
| INTERIOR LIGHT CARGO COMPARTMENT LIGHT | I-3 |
| AUDIO SYSTEM | J |
| POWER WINDOW SYSTEM | K-1 |
| POWER DOOR LOCK SYSTEM | K-2 |
| POWER OUTSIDE MIRROR | L |
| SLIDING SUNROOF | M |
| 4 WHEEL ANTILOCK BRAKE SYSTEM (4WABS) | Q |
| K8 DOHC CRUISE CONTROL SYSTEM | Q |
| AIR BAG SYSTEM | S |
| IGNITION KEY ILLUMINATION CENTRAL PROCESSING UNIT (CPU) | T |
| DATA LINK CONNECTOR | U-1, U-2 |

SYSTEM CIRCUIT DIAGRAM/ CONNECTOR LOCATIONS

ENGINE-RELATED SYSTEMS

STARTING SYSTEM

| | |
|----------|------|
| MTX..... | Z-28 |
| ATX..... | Z-30 |

CHARGING SYSTEM

| | |
|----------|------|
| MTX..... | Z-28 |
| ATX..... | Z-30 |

ENGINE CONTROL SYSTEM

| | |
|--------------|------|
| B6 DOHC..... | Z-32 |
| K8 DOHC..... | Z-40 |

IGNITION SYSTEM

| | |
|--------------|------|
| B6 DOHC..... | Z-32 |
| K8 DOHC..... | Z-40 |

FUEL CONTROL SYSTEM.....

| | |
|--|------|
| | Z-48 |
|--|------|

COOLANT FAN SYSTEM

| | |
|---------------------------|------|
| B6 DOHC, K8 DOHC MTX..... | Z-50 |
| K8 DOHC ATX..... | Z-52 |

CHASSIS-RELATED SYSTEMS

EC-AT CONTROL SYSTEM

| | |
|--------------|------|
| B6 DOHC..... | Z-88 |
| K8 DOHC..... | Z-90 |

SHIFT-LOCK SYSTEM.....

| | |
|--|------|
| | Z-94 |
|--|------|

4 WHEEL ANTILOCK BRAKE

| | |
|---------------------|-------|
| SYSTEM (4WABS)..... | Z-112 |
|---------------------|-------|

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER

| | |
|--------------|------|
| B6 DOHC..... | Z-54 |
| K8 DOHC..... | Z-58 |

BODY-RELATED SYSTEMS

WINDSHIELD WIPER AND

| | |
|-------------|------|
| WASHER..... | Z-62 |
|-------------|------|

REAR WIPER AND WASHER.....

| | |
|--|------|
| | Z-64 |
|--|------|

HORN.....

| | |
|--|------|
| | Z-78 |
|--|------|

REAR WINDOW DEFROSTER.....

| | |
|--|------|
| | Z-96 |
|--|------|

POWER WINDOW SYSTEM.....

| | |
|--|-------|
| | Z-104 |
|--|-------|

POWER DOOR LOCK SYSTEM.....

| | |
|--|-------|
| | Z-106 |
|--|-------|

POWER OUTSIDE MIRROR.....

| | |
|--|-------|
| | Z-108 |
|--|-------|

SLIDING SUNROOF.....

| | |
|--|-------|
| | Z-110 |
|--|-------|

CRUISE CONTROL SYSTEM

| | |
|--------------|-------|
| K8 DOHC..... | Z-116 |
|--------------|-------|

AIR BAG SYSTEM.....

| | |
|--|-------|
| | Z-122 |
|--|-------|

CENTRAL PROCESSING UNIT

| | |
|------------|-------|
| (CPU)..... | Z-124 |
|------------|-------|

INTERIOR LIGHTING SYSTEMS

ILLUMINATION LIGHTS.....

| | |
|--|------|
| | Z-98 |
|--|------|

INTERIOR LIGHT.....

| | |
|--|-------|
| | Z-100 |
|--|-------|

CARGO COMPARTMENT LIGHT.....

| | |
|--|-------|
| | Z-100 |
|--|-------|

IGNITION KEY ILLUMINATION.....

| | |
|--|-------|
| | Z-124 |
|--|-------|

EXTERIOR LIGHTING SYSTEMS

HEADLIGHTS

WITHOUT AIR BAG SYSTEM.....

| | |
|--|------|
| | Z-66 |
|--|------|

WITH AIR BAG SYSTEM.....

| | |
|--|------|
| | Z-68 |
|--|------|

DRL CONTROL SYSTEM.....

| | |
|--|------|
| | Z-70 |
|--|------|

PARKING LIGHTS.....

| | |
|--|------|
| | Z-72 |
|--|------|

FRONT SIDE MARKER LIGHTS.....

| | |
|--|------|
| | Z-72 |
|--|------|

TAILLIGHTS.....

| | |
|--|------|
| | Z-72 |
|--|------|

LICENCE PLATE LIGHTS.....

| | |
|--|------|
| | Z-72 |
|--|------|

REAR SIDE MARKER LIGHTS.....

| | |
|--|------|
| | Z-72 |
|--|------|

TURN AND HAZARD WARNING

LIGHTS.....

| | |
|--|------|
| | Z-74 |
|--|------|

BRAKE LIGHTS.....

| | |
|--|------|
| | Z-76 |
|--|------|

HIGH-MOUNT BRAKE LIGHT.....

| | |
|--|------|
| | Z-76 |
|--|------|

BACK-UP LIGHTS.....

| | |
|--|------|
| | Z-76 |
|--|------|

AIR CONDITIONING-RELATED SYSTEMS

CONDENSER FAN SYSTEM

B6 DOHC.....

| | |
|--|------|
| | Z-80 |
|--|------|

K8 DOHC.....

| | |
|--|------|
| | Z-82 |
|--|------|

HEATER AND AIR CONDITIONER

WIRE TYPE.....

| | |
|--|------|
| | Z-84 |
|--|------|

LOGIC TYPE.....

| | |
|--|------|
| | Z-86 |
|--|------|

ACCESSORIES

CIGARETTE LIGHTER.....

| | |
|--|------|
| | Z-96 |
|--|------|

DIGITAL CLOCK.....

| | |
|--|------|
| | Z-98 |
|--|------|

AUDIO SYSTEM.....

| | |
|--|-------|
| | Z-102 |
|--|-------|

OTHERS

DATA LINK CONNECTOR

B6 DOHC.....

| | |
|--|-------|
| | Z-128 |
|--|-------|


K8 DOHC.....

| | |
|--|-------|
| | Z-130 |
|--|-------|



A-1 MTX ■ STARTING SYSTEM ■ CHARGING SYSTEM




© ...CANADA
< >...KB DOHC




A1-01 STARTER (E)


A1-02 GENERATOR (E)

A1-03 STARTER INTERLOCK SWITCH (F)






A2-01 STARTER (E)



A2-02 GENERATOR (E)




A2-03 TRANSAXLE RANGE SWITCH (F)




B-1a B6 DOHC ■ ENGINE CONTROL SYSTEM ■ IGNITION SYSTEM

() ... CANADA
() ... CALIFORNIA




| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|------|-----|------|------|------|---|--|------|------------|------|---|-----|-----|---|------|-----|---|-----|-----|---|-----|-----|------|----|-----|------|-----|-----|-----|---|------|-----|-----|----|----|----|----|----|----|----|----|----|----|----|--|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|-----|---|----|---|------|-----|------|---|-----|---|------|-----|---|-----|-----|----|-----|-----|-----|---|-----|------------|------|-----|-----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|-----|---|-----|-----|---|--|
| <p>B1-01 ECM (EM)</p> <table border="1"> <tr> <td>1U</td><td>1S</td><td>1Q</td><td>1O</td><td>1M</td><td>1K</td><td>1J</td><td>1G</td><td>1E</td><td>1C</td><td>1A</td> </tr> <tr> <td>R/B</td><td>O/B</td><td>BR</td><td>IG/B</td><td>V/R</td><td>LG/Y</td><td>R/G</td><td>J</td><td>GY/R</td><td>V</td><td>L/R</td> </tr> <tr> <td>BR/Y</td><td>GY</td><td>W/V</td><td>BR/B</td><td>R/W</td><td>Y/B</td><td>L/B</td><td>W</td><td>GY/B</td><td>W/Y</td><td>W/R</td> </tr> <tr> <td>1V</td><td>1T</td><td>1R</td><td>1P</td><td>1N</td><td>1L</td><td>1J</td><td>1H</td><td>1F</td><td>1D</td><td>1B</td> </tr> </table> | 1U | 1S | 1Q | 1O | 1M | 1K | 1J | 1G | 1E | 1C | 1A | R/B | O/B | BR | IG/B | V/R | LG/Y | R/G | J | GY/R | V | L/R | BR/Y | GY | W/V | BR/B | R/W | Y/B | L/B | W | GY/B | W/Y | W/R | 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | <p>B1-02 MAIN RELAY (E)</p> <table border="1"> <tr> <td>2Y</td><td>2V</td><td>2U</td><td>2S</td><td>2Q</td><td>2O</td><td>2M</td><td>2K</td><td>2I</td><td>2G</td><td>2E</td><td>2C</td><td>2A</td> </tr> <tr> <td>Y/R</td><td>L/O</td><td>Y</td><td>LG</td><td>R</td><td>LG/B</td><td>L/W</td><td>LG/R</td><td>Y</td><td>V/W</td><td>G</td><td>B/LG</td><td>B/O</td> </tr> <tr> <td>L</td><td>W/V</td><td>Y/W</td><td>LG</td><td>G/O</td><td>P/B</td><td>R/L</td><td>G</td><td>W/O</td><td>D/L (LG/R)</td><td>B/LG</td><td>B/L</td><td>B/P</td> </tr> <tr> <td>2Z</td><td>2X</td><td>2V</td><td>2T</td><td>2R</td><td>2P</td><td>2N</td><td>2L</td><td>2J</td><td>2H</td><td>2F</td><td>2D</td><td>2B</td> </tr> </table> | 2Y | 2V | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | Y/R | L/O | Y | LG | R | LG/B | L/W | LG/R | Y | V/W | G | B/LG | B/O | L | W/V | Y/W | LG | G/O | P/B | R/L | G | W/O | D/L (LG/R) | B/LG | B/L | B/P | 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | <p>B1-03 HEATED OXYGEN SENSOR (EM)</p> <table border="1"> <tr> <td>R/L</td><td>B</td><td>B/W</td> </tr> <tr> <td>W/R</td><td>B</td><td></td> </tr> </table> | R/L | B | B/W | W/R | B | |
| 1U | 1S | 1Q | 1O | 1M | 1K | 1J | 1G | 1E | 1C | 1A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/B | O/B | BR | IG/B | V/R | LG/Y | R/G | J | GY/R | V | L/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| BR/Y | GY | W/V | BR/B | R/W | Y/B | L/B | W | GY/B | W/Y | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2Y | 2V | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Y/R | L/O | Y | LG | R | LG/B | L/W | LG/R | Y | V/W | G | B/LG | B/O | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L | W/V | Y/W | LG | G/O | P/B | R/L | G | W/O | D/L (LG/R) | B/LG | B/L | B/P | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/L | B | B/W | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| W/R | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>B1-04 DISTRIBUTOR (EM)</p> <table border="1"> <tr> <td>O</td><td>B/O</td><td>V/V</td><td>G</td><td>W/R</td><td>B/LG</td> </tr> </table> | O | B/O | V/V | G | W/R | B/LG | <p>B1-05 PURGE SOLENOID VALVE (EM)</p> <table border="1"> <tr> <td>Y/L</td><td>R</td><td>L</td> </tr> </table> | Y/L | R | L | <p>B1-06 IAC VALVE (EM)</p> <table border="1"> <tr> <td>W/V</td><td>W/R</td> </tr> </table> | W/V | W/R | <p>B1-07 FUEL INJECTOR NO.1 (INJ)</p> <table border="1"> <tr> <td>L/O</td><td>W/R</td> </tr> </table> | L/O | W/R | <p>B1-08 FUEL INJECTOR NO.2 (INJ)</p> <table border="1"> <tr> <td>Y</td><td>W/R</td> </tr> </table> | Y | W/R | <p>B1-09 FUEL INJECTOR NO.3 (INJ)</p> <table border="1"> <tr> <td>Y/W</td><td>W/R</td> </tr> </table> | Y/W | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| O | B/O | V/V | G | W/R | B/LG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Y/L | R | L | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| W/V | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/O | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Y | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Y/W | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>B1-10 MASS AIR FLOW SENSOR (EM)</p> <table border="1"> <tr> <td>B/LG</td><td>B/L</td><td>P/B</td><td>LG/B</td><td>W/R</td> </tr> </table> | B/LG | B/L | P/B | LG/B | W/R | <p>B1-11 ENGINE COOLANT TEMPERATURE SENSOR (EM)</p> <table border="1"> <tr> <td>B/L</td><td>R</td> </tr> </table> | B/L | R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/LG | B/L | P/B | LG/B | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/L | R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

B-1b B6 DOHC ■ ENGINE CONTROL SYSTEM



| | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--|--|---|--|-------------------------------------|--|--|--|---|--|--|--|--|--|--|--|--|--|------------------------------------|--|------------------------------------|--|
| B1-01 ECM (EM) ()...ATX ()...CALIFORNIA ()...CANADA MTX 1U 1S 1Q 1O 1M 1K 1J 1G 1E 1C 1A R/B O/B BR (G/B) V/R LG/Y (R/G) O GY/R V L/R BR/Y (P) GY W/Y BR/B R/W Y/B L/B W GY/B W/Y W/R 1V 1T 1R 1P 1N 1L 1J 1H 1F 1D 1B | | | | | | | | | | 2Y 2W 2U 2S 2Q 2O 2M 2K 2I 2G 2E 2C 2A Y/R L/O Y <*> R LG/B L/W LG/R Y V/W G B/LG B/O L W/Y Y/W LG G/O P/B R/L G W/O B/L (L.G/R) B/LG B/L B/P 2Z 2X 2V 2T 2R 2P 2N 2L 2J 2H 2F 2D 2B | | | | | | | | | | B1-12 FUEL INJECTOR NO.4 (INJ) | | B1-13 PRC SOLENOID VALVE (INJ) | |
| B1-14 PRC SOLENOID VALVE NO.2 (INJ) | | B1-15 EGR SOLENOID VALVE (VENT) (INJ) | | B1-16 EGR SOLENOID VALVE (VACUUM) (INJ) | | B1-17 VICS SOLENOID VALVE (INJ) | | B1-18 EGR VALVE POSITION SENSOR (EM) | | B1-19 THROTTLE POSITION SENSOR (EM) | | B1-20 NEUTRAL SWITCH (EM) (MTX ONLY) | | | | | | | | | | | |
| B1-21 CLUTCH SWITCH (F) (MTX ONLY) | | B1-22 POWER STEERING PRESSURE SWITCH (F) | | | | | | | | | | | | | | | | | | | | | |

B-1c B6 DOHC ■ ENGINE CONTROL SYSTEM



B1-01 ECM (EM) ()...ATX ()...CALIFORNIA < >...CANADA MTX

| | | | | | | | | | | |
|----------|-----|-----|------|-----|------|-----|----|------|-----|-----|
| 1U | 1S | 1J | 10 | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/B | O/B | BR | G/B | V/R | LG/Y | R/G | O | GY/R | V | L/R |
| BR/Y (P) | GY | W/V | BR/B | R/W | Y/B | L/B | W | GY/B | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|------|-----|------|-----|------------|------|------|-----|
| 2Y | 2W | 2U | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| Y/R | L/O | Y | <V> | R | LG/B | L/W | LG/R | Y | V/W | G | B/LG | B/O |
| L | W/V | Y/W | LG | G/O | P/B | R/L | G | W/O | O/L (LG/R) | B/LG | B/L | B/P |
| 2Z | 2X | 2V | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

B-1

Terminal voltage (reference data)

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|------------------------------------|--|-----------------|--|
| 1A | ○ | | Battery | Constant | B+ | For backup |
| 1B | ○ | | Main relay (FUEL INJ relay) | Ignition switch OFF | 0V | — |
| | | | | ON | B+ | |
| 1C | ○ | | Ignition switch (START) | Ignition switch ON | 0V | — |
| | | | | While cranking | Approx. 10V | |
| 1D | | ○ | Data link connector (MEN terminal) | Test switch at "SELF-TEST" Lamp illuminated for 3 sec. after ignition switch OFF → ON | 4.5-5.5V | With Self-Diagnosis Checker and System Selector |
| | | | | Lamp not illuminated after 3 sec. | B+ | |
| | | | | Test switch at "O ₂ MONITOR" at idle Monitor lamp illuminated | 4.5V-5.5V | |
| | | | | Test switch at "O ₂ MONITOR" at idle Monitor lamp not illuminated | B+ | |
| 1E | | ○ | Malfunction indicator lamp (MIL) | Lamp illuminated for 3 sec. after ignition switch OFF → ON | Below 2.5V | With System Selector test switch at "SELF-TEST" |
| | | | | Lamp not illuminated after 3 sec. | B+ | |
| | | | | Lamp illuminated | Below 2.5V | |
| | | | | Lamp not illuminated | B+ | |
| | | | Data link connector (FEN terminal) | Buzzer sounded for 3 sec. after ignition switch OFF → ON | Below 2.5V | <ul style="list-style-type: none"> • With Self-Diagnosis Checker and System Selector • With System Selector test switch at "SELF-TEST" |
| | | | | Buzzer not sounded after 3 sec. | B+ | |
| | | | | Buzzer sounded | Below 2.5V | |
| | | | | Buzzer not sounded after 3 sec. | B+ | |
| 1F | | ○ | VICS solenoid valve | Engine speed below 4,750 rpm | 0V | VICS: Variable Inertia Charging System |
| | | | | Engine speed above 4,750 rpm | B+ | |
| 1G | | ○ | Ignition control module | Ignition switch ON | 0V | — |
| | | | | Idle | Approx. 0.2V | |
| 1H | | ○ | PRC solenoid valve No.2 | Hot condition: Engine coolant temp. above 95°C (203°F) and Intake air temp. above 60°C (140°F) for 149 sec. after engine starting. | Below 1.0V | — |
| | | | | Other conditions (idle) | B+ | |
| 1I | | ○ | TCM (ATX) | Engine coolant temperature below 72°C (162°F) at idle | Below 2.5V | Ignition switch ON |
| | | | | Engine coolant temperature above 72°C (162°F) at idle | B+ | |
| 1J | | ○ | A/C relay | A/C switch ON at idle | Below 2.5V | Blower switch ON |
| | | | | A/C switch OFF at idle | B+ | |
| 1K | ○ | | Data link connector (TEN terminal) | System Selector test switch at O ₂ MONITOR | B+ | <ul style="list-style-type: none"> • With Self-Diagnosis Checker and System Selector • Ignition switch ON |
| | | | | System Selector test switch at SELF-TEST | 0V | |

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark | | |
|----------|-------|--------|--|--|---|---|------------|----------------|
| 1L | | ○ | Coolant fan relay | Ignition switch ON | B+ | — | | |
| | | | | Idle | Engine coolant temp. above 97°C (206.6°F) | | Below 1.0V | A/C sensor OFF |
| | | | | | Other conditions | | B+ | — |
| | | | | Ignition switch ON Ground data link connector TEN terminal Closed throttle position switch OFF | Below 1.0V | | — | |
| 1M | ○ | | Vehicle speed sensor | While driving | 2-5V | — | | |
| | | | | Vehicle stopped | 1 or 7V | | | |
| 1N | ○ | | Throttle position sensor (Closed throttle position switch) | Accelerator pedal released | 0V | Ignition switch ON | | |
| | | | | Accelerator pedal depressed | B+ | | | |
| 1O | ○ | | TCM*1 | At shifting | Below 1.0V | — | | |
| | | | | Other | B+ | | | |
| 1P | ○ | | Power steering pressure switch | Ignition switch ON | B+ | — | | |
| | | | | P/S ON at idle | 0V | | | |
| | | | | P/S OFF at idle | B+ | | | |
| 1Q | ○ | | Air conditioning switch | A/C switch ON | Below 2.5V | Ignition switch ON and blower switch ON | | |
| | | | | A/C switch OFF | B+ | | | |
| 1R | | ○ | EGR solenoid valve (vent) | Idle | B+ | *Engine Signal Monitor: Green and red lamps flash after warm | | |
| | | | | Driving | B+ | | | |
| 1S | ○ | | Fan switch | Fan switch OFF or 1st position | B+ | Ignition switch ON | | |
| | | | | Fan switch 2nd or higher position | 0V | | | |
| 1T | | ○ | EGR solenoid valve (vacuum) | Idle | B+ | *Engine Signal Monitor: Green and red lamps flash after warm up | | |
| | | | | Driving | B+ | | | |
| 1U | ○ | | TNS RELAY | Headlights ON | B+ | — | | |
| | | | | Headlights OFF | Below 1.0V | | | |

*1 Reduce torque signal


B-1

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|--|--|---------------------------|-----------------------|
| 1V | ○ | | Clutch switch Neutral switch (MTX) | Clutch pedal depressed | 0V | Ignition switch ON |
| | | | | Neutral position | 0V | |
| | | | | Others | B+ | |
| | | | Transaxle range switch (ATX) | N or P range | 0V | Ignition switch ON |
| Others | B+ | | | | | |
| 2A | — | — | Ground (Fuel injector) | Constant | 0V | — |
| 2B | — | — | Ground (Output) | Constant | 0V | — |
| 2C | — | — | Ground (CPU) | Constant | 0V | — |
| 2D | — | — | Ground (Input) | Constant | 0V | — |
| 2E | ○ | | Distributor (SGT signal) | Ignition switch ON | Approx. 0V or 4.5-5.5V | — |
| | | | | Idle | Approx. 2V | |
| 2F | ○ | | Mass air flow sensor (VGN signal) | Ignition switch ON | Below 1.0V | — |
| | | | | Idle | | |
| 2G | ○ | | Distributor (SGC signal) | Ignition switch ON | Approx. 0V or 4.5-5.5V | — |
| | | | | Idle | Approx. 1.5V | |
| 2H | ○ | | DRL relay (CANADA) | Parking brake pulled with ignition switch ON | B+ | — |
| | | | | Parking brake released with ignition switch ON | Below 2.5V | |
| | | | VREF (California) Open (Federal) | Ignition switch ON | Approx. 5V | |
| 2I | ○ | | Rear window defroster relay | Rear window defroster switch OFF | B+ | Ignition switch ON |
| | | | | Rear window defroster switch ON | Below 1.0V | |
| 2J | ○ | | EGR valve position sensor | Ignition switch ON | Approx. 1.0V | — |
| | | | | While running | Approx. 0-5V | |
| 2K | | ○ | VREF | Ignition switch ON | Approx. 5V | — |
| 2L | ○ | | Brake switch | Brake pedal released | Below 1.0V | — |
| | | | | Brake pedal depressed | B+ | |
| 2M | ○ | | Throttle position sensor | Accelerator pedal released | 0.1-1.1V | Ignition switch ON |
| | | | | Accelerator pedal fully depressed | 2.8-4.5V | |


B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remark |
|----------|-------|--------|--------------------------------------|---|-----------------|---|
| 2N | ○ | | Heated oxygen sensor | Ignition switch ON | 0V | — |
| | | | | Idle (Cold engine) | 0V | |
| | | | | Idle (After warm-up) | 0-1.0V | |
| | | | | Increasing engine speed (After warm-up) | 0.5-1.0V | |
| 2O | ○ | | Mass air flow sensor (VGP signal) | Ignition switch ON | Below 1.0V | — |
| | | | | Idle | 1.0-2.0V | |
| 2P | ○ | | Intake air temperature sensor | Ambient air temperature 20°C (68°F) | Approx. 2.5V | Built in mass air-flow sensor Ignition switch ON |
| 2Q | ○ | | Engine coolant temperature sensor | Engine coolant temperature 20°C (68°F) | Approx. 2.5V | Ignition switch ON |
| | | | | After warm-up | Below 0.5V | |
| 2R | ○ | | PRC solenoid valve | Hot condition: Engine coolant temperature between 85°C (185°F) and 95°C (203°F) and intake air temperature between 48°C (119°F) and 60°C (140°F) for 149 sec. after engine starting | Below 1.0V | — |
| | | | | Other condition at idle | B+ | |
| 2S | — | — | — | — | — | — |
| 2T | | ○ | Fuel pump relay | Ignition switch ON | B+ | — |
| | | | | During cranking or at idle | 0 | |
| 2U | | ○ | Fuel injector (No.1) | Ignition switch ON | B+ | *Engine Signal Monitor: Green and red lamps flash |
| | | | | *Idle | B+ | |
| | | | | Engine speed above 2,000 rpm on deceleration (After warm-up) | B+ | |
| 2V | | ○ | Fuel injector (No.2) | Ignition switch ON | B+ | *Engine Signal Monitor: Green and red lamps flash |
| | | | | *Idle | B+ | |
| | | | | Engine speed above 2,000 rpm on deceleration (After warm-up) | B+ | |
| 2W | | ○ | IAC valve | Ignition switch ON | Approx. 2.0V | — |
| | | | | Idle | Approx. 10V | |
| 2X | | ○ | Purge solenoid valve | Ignition switch ON | B+ | — |
| | | | | Idle | B+ | |
| 2Y | | ○ | Fuel injector (No.3) | Ignition switch ON | B+ | *Engine Signal Monitor: Green and red lamps flash |
| | | | | *Idle | B+ | |
| | | | | Engine speed above 2,000 rpm on deceleration (After warm-up) | B+ | |
| 2Z | | ○ | Fuel injector (No.4) | Ignition switch ON | B+ | *Engine Signal Monitor: Green and red lamps flash |
| | | | | *Idle | B+ | |
| | | | | Engine speed above 2,000 rpm on deceleration (After warm-up) | B+ | |



B-2a K8 DOHC ■ ENGINE CONTROL SYSTEM ■ IGNITION SYSTEM

C.D. ... CANADA



B2-01 ECM (EM) ()...ATX ()...CANADA ATX


< >...CANADA

B2-02 MAIN RELAY (E)

| | | | | | | | | | | | |
|-----------|-----------|------|-----|------|-------|------|-----|------|-----|-----|----|
| 1U | 1S | 1Q | 1P | 1M | 1K | 1J | 1I | 1G | 1E | 1C | 1A |
| B | * (E/W/L) | G | BR | V/R | (R/G) | LG/Y | O | GY/R | V | L/R | |
| * (L/G/B) | R/W | BP/Y | O/B | BR/B | L/B | B/L | W/R | * | W/Y | W/R | |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | |

| | | | | | | | |
|-------|-----|---------|------|---------|-----|-----|----|
| 20 | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| G/G | Y/L | R/B | LG/R | * | P/L | W | * |
| * (L) | * | * (O/L) | W/O | B (R/G) | L/W | R/L | R |
| 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

| | | | | | | | | | | | | |
|-----|-----|----|----|-----|------|-----|-----|------|-----|-----|------|-----|
| 3Y | 3W | 3U | 3S | 3Q | 3O | 3M | 3K | 3I | 3G | 3E | 3C | 3A |
| Y/R | Y/B | O | * | L/O | W/V | V | * | O/G | V/W | V/G | B/LG | B/O |
| GY | R | P | LG | * | GY/Y | P/B | Y/B | BR/W | L/G | L/Y | B/L | B/P |
| 3Z | 3X | 3V | 3T | 3R | 3P | 3N | 3L | 3J | 3H | 3F | 3D | 3B |



B2-03 DISTRIBUTOR (EM)



B2-04 FUEL INJECTOR RH (EM)

B2-05 FUEL INJECTOR LH (EM)

B2-06 IAC VALVE (EM)

B2-07 EGR SOLENOID VALVE (VENT) (EM)


B2-08 HEATED OXYGEN SENSOR LH (EM)




B2-09 HEATED OXYGEN SENSOR RH (EM)



B-2a




B-2b K8 DOHC ■ ENGINE CONTROL SYSTEM



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-------|----------|-----|------|-------|------|-----|------|-----|--|-----|-----|-----|------|-----|-----|-----|----|-----|--|----|----|-----|------|-----|-----|------|-----|-----|--|-----|----------|--|--|--|--|--|--|--|
| B2-01 ECM (EM) ()...ATX ()...CANADA ATX < >...CANADA | | | | | | | | | | B2-10 EGR SOLENOID VALVE (VACUUM) (EM) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1U | 1S | 1Q | 1O | 1M | 1K | 1J | 1G | 1E | 1C | 1A | 20 | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 3Y | 3W | 3U | 3S | 3Q | 3O | 3M | 3K | 3I | 3G | 3E | 3C | 3A | GY/Y W/R | | | | | | | |
| B (*) | (W/L) | G | BR | V/R | (R/G) | LG/Y | O | GY/R | V | L/R | G/O | Y/L | R/B | LG/R | * | P/L | V | * | Y/R | Y/B | O | * | L/O | W/V | V | * | O/G | V/W | V/G | B/LG | B/O | | | | | | | | |
| (LG/B) | R/W | BR/Y (P) | O/B | BR/B | L/B | B/L | W/R | * | W/Y | W/R | (L) | * | (L) | W/O | (L) | L/W | R/L | R | GY | R | P | LG | * | GY/Y | P/B | Y/B | BR/W | L/G | L/Y | B/L | B/P | | | | | | | | |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 3Z | 3X | 3V | 3T | 3R | 3P | 3N | 3L | 3J | 3H | 3F | 3D | 3B | | | | | | | | |
| B2-11 PURGE SOLENOID VALVE (EM) | | | | | | | | | | B2-12 VRIS SOLENOID VALVE NO.1 (EM) | | | | | | | | | | B2-13 VRIS SOLENOID VALVE NO.2 (EM) | | | | | | | | | | B2-14 PRC SOLENOID VALVE (EM) | | | | | | | | | |
| G/O W/R | | | | | | | | | | O/G W/R | | | | | | | | | | BR/W W/R | | | | | | | | | | V W/R | | | | | | | | | |
| B2-15 VOLUME AIR FLOW SENSOR (EM) | | | | | | | | | | B2-16 THROTTLE POSITION SENSOR (EM) | | | | | | | | | | B2-17 EGR VALVE POSITION SENSOR (EM) | | | | | | | | | | B2-18 ENGINE COOLANT TEMPERATURE SENSOR (EM) | | | | | | | | | |
| R/B B/L B/LG LG/R R | | | | | | | | | | B/L R/W L/W LG/R | | | | | | | | | | W/O B/L LG/R | | | | | | | | | | B/L P/L | | | | | | | | | |
| B2-19 NEUTRAL SWITCH (EM) | | | | | | | | | | B2-20 CLUTCH SWITCH (F) | | | | | | | | | | B2-01 ECM (EM) ()...ATX ()...CANADA ATX < >...CANADA | | | | | | | | | | B2-10 EGR SOLENOID VALVE (VACUUM) (EM) | | | | | | | | | |
| BR/Y B | | | | | | | | | | (MTX ONLY) B BR/Y | | | | | | | | | | GY/Y W/R | | | | | | | | | | | | | | | | | | | |

Z WIRING DIAGRAM

B-2c K8 DOHC ■ ENGINE CONTROL SYSTEM



B2-01 ECM (EM) ()...ATX ()...CANADA ATX ()...CANADA

| | | | | | | | | | | |
|---------|-------|----------|-----|------|-------|------|-----|------|-----|-----|
| 1U | 1S | 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| B (*) | (W/L) | G | BR | V/R | (R/G) | LG/Y | O | GY/R | V | L/R |
| (L/G/B) | R/W | BR/Y (P) | O/B | BR/B | L/B | B/L | W/R | * | W/Y | W/R |
| 1V | 1T | 1R | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| | | | | | | | |
|-----|-----|-------|------|-------|-----|-----|----|
| 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| G/O | Y/L | R/B | LG/R | * | P/L | W | * |
| (L) | * | (O/L) | W/O | (B/X) | L/W | R/L | R |
| 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B |

| | | | | | | | | | | | | |
|-----|-----|----|----|-----|------|-----|-----|------|-----|-----|------|-----|
| 3Y | 3W | 3U | 3S | 3Q | 3O | 3M | 3K | 3I | 3G | 3E | 3C | 3A |
| Y/R | Y/B | O | * | L/O | W/V | V | * | O/G | V/W | V/G | B/LG | B/O |
| GY | R | P | LG | * | GY/Y | P/B | Y/B | BR/W | L/G | L/Y | B/L | B/P |
| 3Z | 3X | 3V | 3T | 3R | 3P | 3N | 3L | 3J | 3H | 3F | 3D | 3B |

B2-21 CRANKSHAFT POSITION SENSOR (EM)



B2-22 KNOCK SENSOR (EM)



B2-23 POWER STEERING PRESSURE SWITCH (EM)



Terminal Voltage

B+: Battery positive voltage

| Terminal | Input | Out-put | Connection to | Test condition | Correct voltage | Remarks |
|----------|-------|---------|------------------------------------|--|-----------------|--|
| 1A | ○ | | Battery | Constant | B+ | For backup |
| 1B | ○ | | Main relay (FUEL INJ relay) | Ignition switch OFF | 0V | — |
| | | | | ON | B+ | |
| 1C | ○ | | Ignition switch (START) | While cranking | 10V | — |
| | | | | Ignition switch ON | Below 1.0V | |
| 1D | | ○ | Data link connector (MEN terminal) | Test switch at "SELF-TEST" Lamp illuminated for 3 sec. after ignition switch OFF→ ON | 4.5-5.5V | With Self-Diagnosis Checker and System Selector |
| | | | | Lamp not illuminated after 3 sec. | B+ | |
| | | | | Test switch at "O2 MONITOR" at idle Monitor lamp illuminated | 4.5-5.5V | |
| | | | | Test switch at "O2 MONITOR" at idle Monitor lamp not illuminated | B+ | |
| 1E | | ○ | Malfunction indicator light (MIL) | Light illuminated for 3 sec. after ignition switch OFF→ON | Below 2.5V | With System selector test Switch at "SELF-TEST" |
| | | | | Light not illuminated after 3 sec. | B+ | |
| | | | | Light illuminated | Below 2.5V | |
| | | | | Light not illuminated | B+ | |
| | | | Data link connector (FEN terminal) | Buzzer sounded for 3 sec. after ignition switch OFF→ON | Below 2.5V | • With Self-Diagnosis Checker and System Selector • With System Selector test switch at "SELF-TEST" |
| | | | | Buzzer not sounded after 3 sec. | B+ | |
| | | | | Buzzer sounded | Below 2.5V | |
| | | | | Buzzer not sounded | B+ | |
| 1F | — | — | — | — | — | — |
| 1G | | ○ | Ignition control module | Ignition switch ON | Approx. 0V | — |
| | | | | Idle | Approx. 0.6 | |
| 1H | ○ | | Headlight switch | Head light ON | B+ | — |
| | | | | Head light OFF | 0V | |
| 1I | ○ | | Data link connector (TEN terminal) | System Selector test switch at "O2 MONITOR" | B+ | • With Self-Diagnosis Checker and System Selector • Ignition switch ON |
| | | | | System Selector test switch at "SELF-TEST" | Below 1.0V | |
| 1J | ○ | | Rear window defroster relay | Rear window defroster switch OFF | B+ | Ignition switch ON |
| | | | | Rear window defroster switch ON | Below 1.5V | |
| 1K | | ○ | TCM | Engine coolant temperature below 60°C (140°F) | Below 1.0V | Ignition switch ON |
| | | | | Engine coolant temperature above 60°C (140°F) | B+ | |
| 1L | | ○ | A/C relay | A/C switch ON | Below 2.5V | Ignition switch ON |
| | | | | A/C switch OFF | B+ | |

B+: Battery positive voltage

| Terminal | Input | Out-put | Connection to | Test condition | Correct voltage | Remarks |
|----------|-------|---------|--|--|--------------------|--|
| 1M | ○ | | Vehicle speed sensor | Ignition switch ON | 0V or approx. 5.0V | — |
| | | | | Driving | Approx. 2.5V | |
| 1N | ○ | | P/S pressure switch | Ignition switch ON | B+ | — |
| | | | | P/S ON at idle | Below 1.0V | |
| | | | | P/S OFF at idle | B+ | |
| 1O | ○ | | A/C switch | A/C switch ON | 1.5-3.5V | Ignition switch ON and blower motor ON |
| | | | | A/C switch OFF | 4.5-5.5V | |
| 1P | ○ | | Fan switch | Fan speed control 2nd-4th position | Below 1.0V | Ignition switch ON and blower Motor ON |
| | | | | Fan speed control 1st position or fan switch OFF | B+ | |
| 1Q | ○ | | Brake switch | Brake pedal released | Below 1.0v | — |
| | | | | Brake pedal depressed | B+ | |
| 1R | ○ | | Neutral/Clutch switch (MTX) | Neutral position or clutch pedal depressed | Below 1.0V | Ignition switch ON |
| | | | | Others | B+ | |
| | | | TCM (ATX) | N or P range | Below 1.0V | — |
| Others | B+ | | | | | |
| 1S | ○ | | TCM (ATX) | At shifting | Approx. 2.5V | — |
| | | | | Others | B+ | |
| 1T | ○ | | Throttle position sensor (Closed throttle position switch) | Accelerator pedal released | Below 1.0V | Ignition switch ON |
| | | | | Accelerator pedal depressed | B+ | |
| 1U | ○ | | Ground (MTX) | Constant | 0V | — |
| 1V | ○ | | TCM | At shifting | 0V | — |
| | | | | Others | B+ | |
| 2A | — | — | — | — | — | — |
| 2B | ○ | | Volume air flow sensor | Ignition switch ON | Approx. 4V | — |
| | | | | Idle | Approx. 2.6V | |
| 2C | ○ | | Heated oxygen sensor (RH) | Ignition switch ON | 0V | — |
| | | | | idle (After warm-up) | 0-1.0V | |
| 2D | ○ | | Heated oxygen sensor (LH) | Increasing engine speed (After warm-up) | 0.5-1.0V | — |
| | | | | Deceleration | 0-0.4V | |
| 2E | ○ | | Engine coolant temperature sensor | Engine coolant temperature 20°C (68°F) | Approx. 3.1V | Ignition switch ON |
| | | | | After warm-up | Approx. 0.9V | |
| 2F | ○ | | Throttle position sensor | Closed throttle position | 0.1-1.1V | Ignition switch ON |
| | | | | Wide open throttle | 2.8-4.5V | |

B+: Battery positive voltage


| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remarks | |
|----------|-------|--------|---|---|------------------------------------|-----------------------------|------------|
| 2H | ○ | | — | Constant | Approx. 5V | — | |
| | | | Ground (California) | Constant | 0V | — | |
| 2I | ○ | | Throttle position sensor Volume airflow sensor EGR valve position sensor TCM | Constant | 5V | | |
| | | | | Ignition switch ON | Approx. 0.8V | | |
| 2J | ○ | | EGR valve position sensor | Engine running | Approx. 0.8-4.5V | | |
| | | | | Ambient air temperature 20°C (68°F) | Approx. 2.5V | | |
| 2K | ○ | | Intake air temperature sensor (Volume air flow sensor) | Ambient air temperature 20°C (68°F) | Approx. 2.5V | Ignition switch ON | |
| 2L | ○ | | DRL relay (Canada) | Parking brake pulled with ignition switch ON (DRL OFF) | B+ | DRL: Daytime Running Lights | |
| | | | | Idle (DRL ON) | Below 2.5V | | |
| 2M* | ○ | | Knock sensor | Ignition switch ON | Approx. 0.7V | | |
| | | | | Idle | Approx. 0.7V | | |
| 2N | — | — | — | — | — | — | |
| 2O | ○ | | Purge solenoid valve | Ignition switch ON or idle | B+ | | |
| 2P | ○ | | Coolant fan relay (ATX) | Engine coolant temp. 108°C (226°F) | Below 2V | | |
| | | | | Others | B+ | | |
| 3A | — | — | Ground (Output) | Constant | 0V | — | |
| 3B | — | — | Ground (Fuel injector) | Constant | 0V | — | |
| 3C | — | — | Ground (CPU) | Constant | 0V | — | |
| 3D | — | — | Ground (Input) | Constant | 0V | — | |
| 3E | ○ | | Camshaft position sensor (in distributor) (SGT signal) | Ignition switch ON | Approx. 0V or 5V | | |
| | | | | Idle | Approx. 2.5V | | |
| 3F | ○ | | Crankshaft position sensor (Crankshaft pulley) (Ground) | Constant | 0V | | |
| | | | | Ignition switch ON | Approx. 0V or 5V | | |
| 3G | ○ | | Camshaft position sensor (in distributor) (SGC signal) | Idle | Approx. 2.5V | | |
| | | | | Ignition switch ON | 0V | | |
| 3H | ○ | | Crankshaft position sensor (Crankshaft pulley) (NE signal) | Ignition switch ON | 0V | | |
| | | | | Idle | Approx. 0V | | |
| 3I | ○ | | VRIS solenoid valve No.1 | Engine speed 3,900-6,300 rpm | Approx. 1.2V | | |
| | | | | Others | B+ | | |
| 3J | ○ | | VRIS solenoid valve No.2 | Engine speed 4,700-6,300 rpm | Approx. 1.2V | | |
| | | | | Others | B+ | | |
| 3K | — | — | — | — | — | — | |
| 3L | ○ | | Coolant fan relay | Engine coolant temp. 100°C (212°F) | Below 1.0V | | |
| | | | | Others | B+ | | |
| 3M | ○ | | PRC solenoid valve | Hot condition: Engine coolant temp. above 70°C and intake air temp. above 75°C for 120 sec. after engine starting | Approx. 1.2V | | |
| | | | | Others | B+ | | |
| 3N | ○ | | Condenser fan relay | Ignition switch ON | B+ | | |
| | | | | Idle | Engine coolant temp. 108°C (226°F) | | Below 2.0V |
| | | | | Others | B+ | | |

*: Diagnostic Trouble Code No. 05 may be memorized by ECM when the Engine Signal Monitor is set to position 2M.

B+: Battery positive voltage

| Terminal | Input | Output | Connection to | Test condition | Correct voltage | Remarks | | | | | | | | | | | | |
|----------|-------|--------|-----------------------------|-----------------------------|-----------------|---|----|---|--------------------|----|---|--------------------|----|---|--------------------|----|---|--------------------|
| 3O | | ○ | EGR solenoid Valve (vent) | Idle | B+ | * Engine Signal Monitor: Green and red light flash | | | | | | | | | | | | |
| | | | | Initial acceleration* | B+ | | | | | | | | | | | | | |
| 3P | | ○ | EGR solenoid valve (vacuum) | Idle | B+ | | | | | | | | | | | | | |
| | | | | Initial acceleration* | B+ | | | | | | | | | | | | | |
| 3Q | | ○ | Idle air control valve | Ignition switch ON | Approx. 7V | | | | | | | | | | | | | |
| | | | | Idle | Approx. 9V | | | | | | | | | | | | | |
| 3R | — | — | — | — | — | — | | | | | | | | | | | | |
| 3S | — | — | — | — | — | — | | | | | | | | | | | | |
| 3T | | ○ | Fuel pump relay | Ignition switch ON | B+ | | | | | | | | | | | | | |
| | | | | Idle | Below 1.0V | | | | | | | | | | | | | |
| 3U | | ○ | Fuel injector No.1 | Ignition switch ON or Idle* | B+ | * Engine Signal Monitor: Green and red lights flash | | | | | | | | | | | | |
| | | | | | | | 3V | ○ | Fuel injector No.2 | | | | | | | | | |
| | | | | | | | | | | 3W | ○ | Fuel injector No.3 | | | | | | |
| | | | | | | | | | | | | | 3X | ○ | Fuel injector No.4 | | | |
| | | | | | | | | | | | | | | | | 3Y | ○ | Fuel injector No.5 |
| | | | | | | | | | | | | | | | | | | |


Control Unit Connector (Control Unit Side)




Z WIRING DIAGRAM

B-3 ■ FUEL CONTROL SYSTEM


MAIN RELAY
(SECTION B-1a,
B-2a)





B3-01 FUEL PUMP RELAY (EM)



B3-02 FUEL GAUGE SENDER UNIT





B3-03 CONNECTOR BETWEEN REAR A (RA) AND FUEL GAUGE SENDER UNIT




C-1b

MAIN FUSE BLOCK




X-13
(F)-(E)




BRAKE FLUID LEVEL SENSOR
C1-06

C1-04
OIL PRESSURE SWITCH



(BLACK)
(F)-(RA)
X-09

C1-05
PARKING BRAKE SWITCH



(BLACK)
INSTRUMENT CLUSTER
C1-01


INSTRUMENT CLUSTER
C1-01

INSTRUMENT CLUSTER
C1-01





X-09
(F)-(RA)
(BLACK)

B-5 K8 DOHC ATX ■ COOLANT FAN SYSTEM

() ... CANADA




B5-01 COOLANT FAN RELAY NO.1 (F) B5-02 COOLANT FAN MOTOR (F) B5-03 COOLANT FAN RELAY NO.2 (F) B5-04 COOLANT FAN RELAY NO.3 (F)





Z WIRING DIAGRAM

C-1a B6 DOHC ■ INSTRUMENT CLUSTER

< > ... CANADA
 () ... ATX < > ... WITH ABS
 [] ... WITH AIR BAG SYSTEM



C1-01 INSTRUMENT CLUSTER (F)




C1-02 WATER TEMPERATURE SENDER UNIT (INJ)




C1-03 VEHICLE SPEEDOMETER SENSOR (F)




C-1a



MAIN FUSE BLOCK




JOINT BOX






C-1b B6 DOHC ■ INSTRUMENT CLUSTER

< >...CANADA
 ()...ATX < >...WITH ABS
 []...WITH ATR BAG SYSTEM



C1-01 INSTRUMENT CLUSTER (F)



C1-04 OIL PRESSURE SWITCH (E)



C1-05 PARKING BRAKE SWITCH (RA)



C1-06 BRAKE FLUID LEVEL SENSOR (F)
 EXCEPT ABS




WITH ABS




C-1b

MAIN FUSE BLOCK




X-13
(F)-(E)

(BLACK)
(F)-(RA)
X-09




BRAKE FLUID
LEVEL SENSOR
C1-06

C1-04
OIL PRESSURE
SWITCH



C1-05
PARKING
BRAKE
SWITCH



(BLACK)
INSTRUMENT
CLUSTER
C1-01


INSTRUMENT
CLUSTER
C1-01

INSTRUMENT
CLUSTER
C1-01


X-09
(F)-(RA)
(BLACK)

C-2a K8 DOHC ■ INSTRUMENT CLUSTER


< >...CANADA < >...WITH ABS
 ()...AIX
 ()...WITH AIR BAG SYSTEM



C2-01 INSTRUMENT CLUSTER (F)




C2-02 WATER TEMPERATURE SENDER UNIT (EM)




C2-03 VEHICLE SPEEDOMETER SENSOR (EM)




C-2a



MAIN FUSE BLOCK




JOINT BOX




Z WIRING DIAGRAM

C-2b K8 DOHC ■ INSTRUMENT CLUSTER

< >... CANADA < >... WITH ABS
 1... ATX
 1... WITH AIR BAG SYSTEM





C2-01 INSTRUMENT CLUSTER (F)




| | | | | | | |
|--|---|--------------------------------------|--|--|--|--|
| <p>C2-04 PARKING BRAKE SWITCH (RA)</p> | <p>C2-05 BRAKE FLUID LEVEL SENSOR (F)</p> | <p>C2-06 OIL PRESSURE SWITCH (E)</p> | | | | |
| | | | | | | |

C-2b

MAIN FUSE BLOCK




X-13
(F)-(E)




C2-06
OIL PRESSURE
SWITCH
(BLACK)

(BLACK)
BRAKE FLUID
LEVEL SENSOR
C2-05



X-09
(F)-(RA)
(BLACK)

C2-04
PARKING
BRAKE
SWITCH



X-09
(F)-(RA)
(BLACK)

INSTRUMENT
CLUSTER
C2-01


(BLACK)
INSTRUMENT
CLUSTER
C2-01

INSTRUMENT
CLUSTER
C2-01

Z WIRING DIAGRAM

D-1 ■ WINDSHIELD WIPER AND WASHER

< > ... WITH AIR BAG SYSTEM
 U ... CANADA
 < > ... LIKE D38C



D1-01 WINDSHIELD WIPER AND WASHER SWITCH (F)

WITHOUT AIR BAG SYSTEM


WITH AIR BAG SYSTEM

| | | | | | | |
|-----|-----|-----|-----|-----|---|-----|
| L/Y | L/R | V | | B | O | Y/R |
| B | L | L/B | L/W | L/G | | |


| | | | | | | | | | | | |
|-----|-----|--------------|-----|-----|--|-----|-----|------------|----------|----------|-----|
| L/R | LG | B/Y | P | Y/L | | B | L/W | L/B | L/G | B | L/Y |
| V | R/L | R/G LH/YB | R/W | R | | W/P | I | Y/R (X) | R (X) | O (X) | |

U ... WE R... REAR WIPER AND WASHER


D1-02 WINDSHIELD WIPER MOTOR (F)




D1-03 WINDSHIELD WASHER MOTOR (F)




D-1



MAIN FUSE BLOCK




JOINT BOX




Z WIRING DIAGRAM

D-2 ■ REAR WIPER AND WASHER

* WITH AIR BAG SYSTEM
 * CANADA
 * DOKS DC-1



D2-01 REAR WIPER MOTOR (R3)





D2-02 REAR WASHER MOTOR (RB)



D1-01 REAR WIPER AND WASHER SWITCH (F)




WITHOUT AIR BAG SYSTEM

WITH AIR BAG SYSTEM





D-2

MAIN FUSE BLOCK




(WITHOUT AIR BAG SYSTEM)
REAR WIPER AND
WASHER SWITCH
D1-01

JOINT BOX




Z WIRING DIAGRAM


E-1 WITHOUT AIR BAG SYSTEM ■ HEADLIGHTS




E1-01 HEADLIGHT SWITCH (F)




E1-02 HEADLIGHT RELAY (F)




E1-03 HEADLIGHT LH (F)



E1-04 HEADLIGHT RH (F)




E-1




Z WIRING DIAGRAM

E-2 WITH AIR BAG SYSTEM ■ HEADLIGHTS


< > ... CANADA




E2-01 HEADLIGHT RELAY (F)




E2-02 HEADLIGHT LH (F)



E2-03 HEADLIGHT RH (F)




D1-01 HEADLIGHT SWITCH (F)



() ... WITHOUT REAR WIPER AND WASHER



E-2



E2-03
HEADLIGHT
RH

E2-02
HEADLIGHT
LH

MAIN FUSE BLOCK



JOINT
CONNECTOR
X-24


E2-01
HEADLIGHT
RELAY

D1-01
HEADLIGHT
SWITCH

Z WIRING DIAGRAM

E-3 CANADA ■ DRL CONTROL SYSTEM

© 1998 GM



E3-01 DRL CONTROL MODULE (F)

| | | | |
|-----|-----|----|-----|
| * | | GY | G/R |
| W/R | R/W | B | G/L |
| | | | G/Y |


E3-02 DRL RELAY (F)

| | | |
|-----|-----|-----|
| G/W | R/G | GY |
| R/Y | * | O/L |

E3-03 DRL RESISTOR (F)

| |
|-------|
| R |
| * G/W |


E-3



Z WIRING DIAGRAM

E-4 ■ PARKING LIGHTS ■ FRONT SIDE MARKER LIGHTS ■ TAILLIGHTS ■ LICENCE PLATE LIGHTS ■ REAR SIDE MARKER LIGHTS

< > . . . KB D0HC




BULB TRADE NUMBER
 PARKING LIGHT 1:57NA(8W)
 FRONT SIDE MARKER LIGHT: 194(3.8W)
 TAILLIGHT: 1157(8W)
 LICENCE PLATE LIGHT: 158(5W)
 REAR SIDE MARKER LIGHT: 194(3.8W)

| | | | | |
|---|---|---|---|---|
| <p>E4-01 TNS RELAY (F)</p> | <p>E4-02 FRONT COMBINATION LIGHT (PARKING LIGHT) LH/MARKER LIGHT CORD (F)</p> | <p>E4-03 FRONT COMBINATION LIGHT (PARKING LIGHT) RH/MARKER LIGHT CORD (F)</p> | <p>E4-04 FRONT SIDE MARKER LIGHT LH</p> | <p>E4-05 FRONT SIDE MARKER LIGHT RH</p> |
| <p>E4-06 REAR COMBINATION LIGHT (TAILLIGHT) LH (RB)</p> | <p>E4-07 REAR COMBINATION LIGHT (TAILLIGHT) RH (RB)</p> | <p>E4-08 LICENCE PLATE LIGHTS / MARKER LIGHT CORDS (RB)</p> | <p>E4-09 REAR SIDE MARKER LIGHT LH</p> | <p>E4-10 REAR SIDE MARKER LIGHT RH</p> |

E-4

MAIN FUSE BLOCK




FRONT SIDE MARKER LIGHT RH E4-05

E4-03 FRONT COMBINATION LIGHT (PARKING LIGHT) RH/ MARKER LIGHT CORD (BLACK)

E4-02 FRONT COMBINATION LIGHT (PARKING LIGHT) LH/ MARKER LIGHT CORD (BLACK)

E4-04 FRONT SIDE MARKER LIGHT LH

JOINT BOX



E4-01 TNS RELAY

REAR COMBINATION LIGHT (TAILLIGHT) LH E4-06

REAR COMBINATION LIGHT (TAILLIGHT) RH E4-07

REAR SIDE MARKER LIGHT RH E4-10

X-20 (RA)-(RB)


E4-09 REAR SIDE MARKER LIGHT LH

E4-08 LICENCE PLATE LIGHTS/MARKER LIGHT CORDS

Z WIRING DIAGRAM

F-1 ■ TURN AND HAZARD WARNING LIGHTS

< > ...K8 DOHC
 () ...CANADA
 () ...WITH AIR BAG SYSTEM









BULB TRADE NUMBER
 FRONT TURN LIGHT: 1-57VA(27W)
 REAR TURN LIGHT: 1-56(27W)

Male: WITH AIR BAG SYSTEM
 Female: WITHOUT AIR BAG SYSTEM

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----|-----------|-----|--|-----|-----|---|---|--|-----|-----|-----|-----|---|-----|-----|-----|----|-----|-----|-----|-----------|-----|-----|-----|---|-----|---|---|---|
| <p>F1-01 FLASHER UNIT (F)</p> <table border="1"> <tr><td>G/W</td><td>P</td><td>G/Y</td><td>B</td></tr> <tr><td>B/R</td><td>Y/L</td><td>G/B</td><td>*</td></tr> </table> | G/W | P | G/Y | B | B/R | Y/L | G/B | * | <p>F1-02 HAZARD WARNING SWITCH (I)</p> <table border="1"> <tr><td>R</td><td>B</td><td>G/Y</td><td>R/B</td></tr> </table> | R | B | G/Y | R/B | <p>E1-01 TURN SWITCH (F) WITHOUT AIR BAG SYSTEM</p> <table border="1"> <tr><td>R/Y</td><td>*</td><td><R></td><td>LG</td><td>R/L</td><td>W/R</td></tr> <tr><td>R/W</td><td>*</td><td></td><td>G/O</td><td>Y/L</td><td>P</td><td>B/Y</td><td>*</td><td>B</td><td>R</td></tr> </table> <p>< > ...WITH CRUISE CONTROL</p> | R/Y | * | <R> | LG | R/L | W/R | R/W | * | | G/O | Y/L | P | B/Y | * | B | R |
| G/W | P | G/Y | B | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/R | Y/L | G/B | * | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | B | G/Y | R/B | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/Y | * | <R> | LG | R/L | W/R | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/W | * | | G/O | Y/L | P | B/Y | * | B | R | | | | | | | | | | | | | | | | | | | | | |
| <p>E4-02 FRONT COMBINATION LIGHT (FRONT TURN LIGHT) LH (F)</p> <table border="1"> <tr><td>G/B</td><td>B</td><td>R/B</td></tr> </table> | G/B | B | R/B | <p>E4-03 FRONT COMBINATION LIGHT (FRONT TURN LIGHT) RH (F)</p> <table border="1"> <tr><td>G/W</td><td>B</td><td>R/B</td></tr> </table> | G/W | B | R/B | <p>E4-06 REAR COMBINATION LIGHT (REAR TURN LIGHT) LH (RB)</p> <table border="1"> <tr><td>R/B</td><td>G</td><td>G/B</td><td>B</td><td>R/G</td><td>*</td></tr> </table> | R/B | G | G/B | B | R/G | * | | | | | | | | | | | | | | | | |
| G/B | B | R/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| G/W | B | R/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/B | G | G/B | B | R/G | * | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>E4-07 REAR COMBINATION LIGHT (REAR TURN LIGHT) RH (RB)</p> <table border="1"> <tr><td>R/B</td><td>G</td><td>G/W</td><td>B</td><td>R/G</td><td>*</td></tr> </table> | R/B | G | G/W | B | R/G | * | <p>D1-01 TURN SWITCH (F) WITH AIR BAG SYSTEM</p> <table border="1"> <tr><td>L/R</td><td>LG</td><td>B/Y</td><td>P</td><td>Y/L</td><td>B</td><td>L/W</td><td>L/S</td><td>L/O</td><td>B</td><td>L/Y</td></tr> <tr><td>V</td><td>R/L</td><td>R/G (R/Y)</td><td>R/W</td><td>R</td><td>W/R</td><td>L</td><td>Y/R</td><td>B</td><td>O</td><td></td></tr> </table> <p>() ...WITHOUT REAR WIPER AND WASHER</p> | | L/R | LG | B/Y | P | Y/L | B | L/W | L/S | L/O | B | L/Y | V | R/L | R/G (R/Y) | R/W | R | W/R | L | Y/R | B | O | |
| R/B | G | G/W | B | R/G | * | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/R | LG | B/Y | P | Y/L | B | L/W | L/S | L/O | B | L/Y | | | | | | | | | | | | | | | | | | | | |
| V | R/L | R/G (R/Y) | R/W | R | W/R | L | Y/R | B | O | | | | | | | | | | | | | | | | | | | | | |

F-1








| | | | | | | |
|-------------------------------|--|--|---|--|---|--|
| <p>F2-01 BRAKE SWITCH (F)</p> | <p>F2-02 HIGH-MOUNT BRAKE LIGHT (R3)</p> | <p>F2-03 BACK-UP LIGHT SWITCH (F) MTX ONLY</p> | <p>E4-06 REAR COMBINATION LIGHT (BRAKE LIGHT/BACK-UP LIGHT) LH (RB)</p> | | <p>E4-07 REAR COMBINATION LIGHT (BRAKE LIGHT/BACK-UP LIGHT) RH (RB)</p> | |
| | | | | | | |
| | | | | | | |

F-2

MAIN FUSE BLOCK





F2-03
BACK-UP LIGHT
SWITCH
(MTX ONLY)



HIGH-MOUNT
BRAKE LIGHT
F2-02

REAR COMBINATION
LIGHT
(BRAKE LIGHT/
BACK-UP LIGHT) RH
E4-07

JOINT BOX



F2-01
BRAKE SWITCH

X-03
IGNITION
SWITCH

X-03
IGNITION
SWITCH
(BLACK)

X-09
(F)-(RA)
(BLACK)

X-09
(F)-(RA)
(BLACK)

X-21
(RA)-(R2)


X-20
(RA)-(RB)

E4-06
REAR COMBINATION
LIGHT
(BRAKE LIGHT/
BACK-UP LIGHT) LH


Z WIRING DIAGRAM

F-3 ■ HORN

< >...K8 DOHC




F3-01 HORN RELAY (F)



F3-02 HORN (F)




S-06 HORN SWITCH (AB)



WITH AIR BAG SYSTEM


S-07 PASSENGER-SIDE AIR BAG MODULE (AB)



E1-01 COMBINATION SWITCH (HORN SWITCH) (F)

< >...WITH CRUISE CONTROL


WITHOUT AIR BAG SYSTEM




Z WIRING DIAGRAM

G-1 B6 DOHC ■ CONDENSER FAN SYSTEM


U.S. ... CANADA



G1-01 A/C RELAY (AC)




G1-02 CONDENSER FAN RELAY (AC)



G1-03 MAGNETIC CLUTCH (AC)




G1-04 CONDENSER FAN (AC)



G1-05 CONNECTOR BETWEEN ENGINE (E) AND A/C (AC)
(E) (AC)




G-1




Z WIRING DIAGRAM

G-2 K8 DOHC ■ CONDENSER FAN SYSTEM


1 D... CANADA




G2-01 A/C RELAY (AC)




G2-02 CONDENSER FAN RELAY NO. 1 (AC)



G2-03 CONDENSER FAN RELAY NO. 2 (AC)




G2-04 CONDENSER FAN (AC)




G2-05 MAGNETIC CLUTCH (AC)



G2-06 CONDENSER FAN RELAY NO. 3 (AC)










G-2





Z WIRING DIAGRAM

G-3 WIRE TYPE ■ HEATER AND AIR CONDITIONER (B6 DOHC ONLY)





| | | | | | |
|--|---|--|--|--|---|
| G3-01 HEATER CONTROL UNIT (A/C SWITCH) (I)  | G3-02 HEATER CONTROL UNIT (FAN SWITCH) (I)  | G3-03 RESISTOR (I)  | G3-04 BLDWER MOTOR (F)  | G3-05 BLOWER RELAY (F)  | G3-06 CIRCUIT BREAKER (F)  |
|--|---|--|--|--|---|

| |
|--|
| G3-07 REFRIGERANT PRESSURE SWITCH (AC)  |
|--|

| |
|--|
| G3-08 THERMOSWITCH (F)  |
|--|

G-3









| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|------|------|-----------|------|---|-----|-----|-----|----------|-----|---|-----|------|---|---|-----|---|------|---|--|-----|-----|------|---|---|-----|-----------|---|-----|---|---|-----|----|------|---|--------|---|---|---|---|---|-----|-----|--|--|---|-----|---|---|---|------|----|-----|--|----|-----|---|-----|--|-----|----|---|---|--|-----|----|
| <p>G4-01 HEATER CONTROL UNIT (I)</p> <table border="1"> <tr> <td>S</td><td>Q</td><td>D</td><td>M</td><td colspan="2"></td><td>G</td><td>E</td><td>C</td><td>A</td> </tr> <tr> <td>O</td><td>G/O</td><td>Y/R</td><td>LG</td><td colspan="2"></td><td>R</td><td>R/R</td><td>I</td><td>L/R</td> </tr> <tr> <td>L/B</td><td>L/W</td><td>BR/Y</td><td>V</td><td>Y</td><td>B</td><td>*</td><td>GY</td><td>L/Y</td><td>G</td> </tr> <tr> <td>T</td><td>R</td><td>P</td><td>N</td><td>L</td><td>J</td><td>H</td><td>F</td><td>O</td><td>B</td> </tr> </table> | S | Q | D | M | | | G | E | C | A | O | G/O | Y/R | LG | | | R | R/R | I | L/R | L/B | L/W | BR/Y | V | Y | B | * | GY | L/Y | G | T | R | P | N | L | J | H | F | O | B | <p>G4-02 AIRFLOW MODE ACTUATOR (F)</p> <table border="1"> <tr> <td>L/W</td><td>L/B</td><td colspan="2"></td><td>*</td><td>G/O</td> </tr> <tr> <td>Y</td><td>G</td><td>O</td><td>BR/Y</td><td>LG</td><td>Y/R</td> </tr> </table> | L/W | L/B | | | * | G/O | Y | G | O | BR/Y | LG | Y/R | <p>G4-03 AIR INTAKE ACTUATOR (BL)</p> <table border="1"> <tr> <td>GY</td><td>L/W</td><td>*</td><td>L/R</td> </tr> </table> | GY | L/W | * | L/R | <p>G4-04 BLOWER RELAY (F)</p> <table border="1"> <tr> <td>L/W</td><td>GY</td> </tr> <tr> <td>L</td><td>B</td> </tr> </table> | L/W | GY | L | B | <p>G4-05 REFRIGERANT PRESSURE SWITCH (AC)</p> <table border="1"> <tr> <td>B/R</td><td>BR</td> </tr> </table> | B/R | BR |
| S | Q | D | M | | | G | E | C | A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| O | G/O | Y/R | LG | | | R | R/R | I | L/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/B | L/W | BR/Y | V | Y | B | * | GY | L/Y | G | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| T | R | P | N | L | J | H | F | O | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | L/B | | | * | G/O | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Y | G | O | BR/Y | LG | Y/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GY | L/W | * | L/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | GY | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/R | BR | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>G4-06 RESISTOR (I)</p> <table border="1"> <tr> <td>L</td><td>L/Y</td> </tr> <tr> <td>L/W</td><td>L/R</td> </tr> </table> | L | L/Y | L/W | L/R | <p>G4-07 FAN SWITCH (I)</p> <table border="1"> <tr> <td>O/B</td><td>L/R</td><td colspan="2"></td><td>L/Y</td><td>*</td><td>*</td> </tr> <tr> <td colspan="2">L/W</td><td>L</td><td colspan="2">B</td><td colspan="2"></td> </tr> </table> | O/B | L/R | | | L/Y | * | * | L/W | | L | B | | | | <p>G4-08 CIRCUIT BREAKER (F)</p> <table border="1"> <tr> <td>L/W</td><td>30A</td><td>B</td> </tr> </table> <p>HEATER</p> | L/W | 30A | B | <p>G4-09 THERMOSWITCH (F)</p> <table border="1"> <tr> <td>G</td> </tr> <tr> <td>B/R</td> </tr> </table> | G | B/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L | L/Y | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | L/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| O/B | L/R | | | L/Y | * | * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | | L | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | 30A | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| G | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>G4-10 CONNECTOR BETWEEN INSTRUMENT PANEL (I) AND BLOWER UNIT (BL)</p> <table border="1"> <tr> <td colspan="2">(I)</td> <td colspan="2">(BL)</td> </tr> <tr> <td>*</td><td colspan="2"></td><td>BR/Y O/B</td> </tr> <tr> <td>I/R</td><td>L</td><td>V</td><td>Y LG</td> </tr> </table> | | (I) | | (BL) | | * | | | BR/Y O/B | I/R | L | V | Y LG | <p>G4-11 CONNECTOR BETWEEN FRONT (F) AND BLOWER UNIT (BL)</p> <table border="1"> <tr> <td colspan="2">(F)</td> <td colspan="2">(BL)</td> </tr> <tr> <td>O/B</td><td colspan="2"></td><td>L</td> </tr> <tr> <td>GY</td><td>*</td><td>G</td><td>Y BR/Y LG</td> </tr> </table> | | (F) | | (BL) | | O/B | | | L | GY | * | G | Y BR/Y LG | <table border="1"> <tr> <td>L/W</td><td colspan="2"></td><td>O/B</td> </tr> <tr> <td>LG</td><td>BR/Y</td><td>Y</td><td>G V GY</td> </tr> </table> | L/W | | | O/B | LG | BR/Y | Y | G V GY | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (I) | | (BL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| * | | | BR/Y O/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| I/R | L | V | Y LG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (F) | | (BL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| O/B | | | L | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GY | * | G | Y BR/Y LG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | | | O/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LG | BR/Y | Y | G V GY | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

G-4


MAIN FUSE BLOCK



Z WIRING DIAGRAM

H-1 B6 DOHC ■ EC-AT CONTROL SYSTEM

© ... CANADA



H1-01 TCM (F)

| | | | | | | | |
|-----|-----|-----|------|-----|----|----|------|
| 10 | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| R/W | * | B/Y | * | W/B | Y | O | LG/Y |
| V/R | R/G | * | B/LG | V/W | G | P | BR/Y |
| 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

| | | | | | | | | | |
|-----|-----|------|-----|----|-----|-----|-----|------|------|
| 2S | 2Q | 2O | 2N | 2K | 2I | 2G | 2E | 2C | 2A |
| * | B/Y | L/R | G/B | L | W/G | L/Y | L/O | * | LG/R |
| L/W | * | B/LG | * | R | W | Y/W | Y/R | GY/R | B/L |
| 2T | 2R | 2P | 2M | 2L | 2J | 2H | 2F | 2D | 2B |

H1-02 SOLENOID VALVE (EC-AT) (F)

| | | |
|------|-----|-----|
| L | W/B | L/O |
| B/LG | W/G | L/Y |

H1-03 INPUT/TURBINE SPEED SENSOR (F)


| | |
|---|---|
| R | W |
|---|---|

H1-04 HOLD SWITCH (RA)


| | | |
|-----|-----|---|
| V/W | R/B | * |
| B | R | * |

A2-03 TRANSAXLE RANGE SWITCH (F)

| | | | | |
|-----|------|-----|-----|---|
| B/Y | GY/R | Y/W | R/G | * |
| B/L | Y/R | * | B/R | |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----|------|------|-----|-----|-----|------|------|------|---|-----|---|-----|---|---|------|-----|-----|---|------|-----|---|---|------|----|----|----|----|----|----|----|----|--|----|----|----|----|----|----|----|----|----|----|---|-----|-----|-----|---|-----|-----|-----|---|------|-----|---|------|---|---|---|-----|-----|------|-----|----|----|----|----|----|----|----|----|----|----|--|---|-----|-----|------|-----|-----|---|---|---|---|-----|-----|---|---|---|---|
| <p>H2-01 TCM (F)</p> <table border="1"> <tr> <td>10</td><td>1M</td><td>1K</td><td>1L</td><td>1G</td><td>1E</td><td>1C</td><td>1A</td> </tr> <tr> <td>R/W</td><td>*</td><td>B/Y</td><td>*</td><td>W/B</td><td>Y</td><td>O</td><td>LG/B</td> </tr> <tr> <td>V/R</td><td>R/G</td><td>*</td><td>B/LG</td><td>V/W</td><td>G</td><td>P</td><td>BR/Y</td> </tr> <tr> <td>1P</td><td>1N</td><td>1L</td><td>1J</td><td>1H</td><td>1F</td><td>1D</td><td>1B</td> </tr> </table> | 10 | 1M | 1K | 1L | 1G | 1E | 1C | 1A | R/W | * | B/Y | * | W/B | Y | O | LG/B | V/R | R/G | * | B/LG | V/W | G | P | BR/Y | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | <table border="1"> <tr> <td>2S</td><td>2Q</td><td>2O</td><td>2M</td><td>2K</td><td>2I</td><td>2G</td><td>2E</td><td>2C</td><td>2A</td> </tr> <tr> <td>*</td><td>B/Y</td><td>L/R</td><td>W/L</td><td>L</td><td>W/G</td><td>L/Y</td><td>L/Q</td><td>*</td><td>LG/R</td> </tr> <tr> <td>L/W</td><td>*</td><td>B/LG</td><td>*</td><td>R</td><td>W</td><td>Y/W</td><td>Y/R</td><td>GY/R</td><td>B/L</td> </tr> <tr> <td>2T</td><td>2R</td><td>2P</td><td>2N</td><td>2L</td><td>2J</td><td>2H</td><td>2F</td><td>2D</td><td>2B</td> </tr> </table> | 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | * | B/Y | L/R | W/L | L | W/G | L/Y | L/Q | * | LG/R | L/W | * | B/LG | * | R | W | Y/W | Y/R | GY/R | B/L | 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | <p>H2-02 SOLENOID VALVE (EC-AT) (F)</p> <table border="1"> <tr> <td>L</td><td>W/B</td><td>L/Q</td> </tr> <tr> <td>B/LG</td><td>W/G</td><td>L/Y</td> </tr> </table> | L | W/B | L/Q | B/LG | W/G | L/Y | <p>H2-03 INPUT/TURBINE SPEED SENSOR (F)</p> <table border="1"> <tr> <td>R</td><td>W</td> </tr> </table> | R | W | <p>H2-04 HOLD SWITCH (RA)</p> <table border="1"> <tr> <td>V/W</td><td>R/B</td><td>*</td> </tr> <tr> <td>B</td><td>R</td><td>*</td> </tr> </table> | V/W | R/B | * | B | R | * |
| 10 | 1M | 1K | 1L | 1G | 1E | 1C | 1A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/W | * | B/Y | * | W/B | Y | O | LG/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| V/R | R/G | * | B/LG | V/W | G | P | BR/Y | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| * | B/Y | L/R | W/L | L | W/G | L/Y | L/Q | * | LG/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L/W | * | B/LG | * | R | W | Y/W | Y/R | GY/R | B/L | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L | W/B | L/Q | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/LG | W/G | L/Y | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | W | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| V/W | R/B | * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B | R | * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



Terminal Voltage Chart

| | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 2S | 2Q | 2O | 2M | 2K | 2I | 2G | 2E | 2C | 2A | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| 2T | 2R | 2P | 2N | 2L | 2J | 2H | 2F | 2D | 2B | 1P | 1N | 1L | 1J | 1H | 1F | 1D | 1B |

B+: Battery positive voltage

| Terminal | Connected to | Voltmeter | | Voltage | Condition |
|--------------------|--|------------|-----------|---|--|
| | | + terminal | -terminal | | |
| 1A (Output) | Engine control module (Reduce torque signal 2) | 1A | Ground | Below 5 V B+ | D, S, or L ranges and downshifting (except 4→3 shift) with throttle valve opening 1/8 or more Others |
| 1B (Output) | HOLD indicator light | 1B | Ground | 0 V B+ | HOLD mode NORMAL mode |
| 1C (Output) | FAT terminal (Data link connector) | 1C | Ground | 0 V B+ 0V or Approx. B+ (fluctuating) Code signal | HOLD mode NORMAL mode If malfunction present TAT terminal grounded |
| 1D (Output) | Engine control module (Park / neutral position signal) | 1D | Ground | Below 1.6 V B+ | P or N position R position, All ranges |
| 1E (Input) | TAT terminal (Data link connector) | 1E | Ground | B+ 0 V | Normal TAT terminal grounded |
| 1F (Input) | Brake switch | 1F | Ground | B+ 0 V | Brake pedal depressed Brake pedal released |
| 1G (Input) | Transaxle fluid temperature sensor | 1G | Ground | Approx. 4.95 V-1.12 V [ATF temp. -30°C (-20°F)-150°C (302°F)] | While warming-up ATF Note Approx. 4.6 V: ATF temp. 20°C (68°F) Approx. 1.5 V: ATF temp. 130°C (266°F) |
| 1H (Input) | HOLD switch | 1H | Ground | 0 V B+ | Switch depressed point Switch released point |
| 1I | — | — | — | — | — |
| 1J (Ground) | Battery ground | 1J | Ground | 0 V | Constant |
| 1K (Battery power) | Battery | 1K | Ground | B+ 0 V | Ignition switch ON Ignition switch OFF |
| 1L | — | — | — | — | — |
| 1M | — | — | — | — | — |
| 1N (Input) | Engine control module (Torque reduced signal/ water thermo signal) | 1N | Ground | B+ 0 V 0 V | Above 60°C(140°F) Operate torque reduction Below 60°C(140°F) |
| 1O (Input) | Closed throttle position switch | 1O | Ground | 0 V B+ | Closed throttle position switch ON (Closed throttle position) Closed throttle position switch OFF (Throttle valve open) |
| 1P (Input) | Vehicle speed sensor | 1P | Ground | 3 V-4 V 0 V or 6 V-8 V | While driving Vehicle stopped |

| Terminal | Connected to | Voltmeter | | Voltage | Condition |
|--------------------|--|------------|-----------|----------------------------|---|
| | | + terminal | -terminal | | |
| 2A (Input) | Throttle position sensor (VREF) | 2A | Ground | 4.5 V-5.5 V 0 V | Ignition switch ON Ignition switch OFF |
| 2B (Input) | Transaxle range switch (P or N position) | 2B | Ground | 0 V B+ | P or N position R position, All ranges |
| 2C | — | — | — | — | — |
| 2D (Input) | Transaxle range switch (D range) | 2D | Ground | B+ 0 V | D range Other ranges, All positions |
| 2E (Output) | Shift solenoid A | 2E | Ground | B+ 0 V | Solenoid valve ON Solenoid valve OFF |
| 2F (Input) | Transaxle range switch (S range) | 2F | Ground | B+ 0 V | S range Other ranges, All positions |
| 2G (Output) | Shift solenoid B | 2G | Ground | B+ 0 V | Solenoid valve ON Solenoid valve OFF |
| 2H (Input) | Transaxle range switch (L range) | 2H | Ground | B+ 0 V | L range Other ranges, All positions |
| 2I (Output) | Shift solenoid C | 2I | Ground | B+ 0 V | Solenoid valve ON Solenoid valve OFF |
| 2J (Input) | Input / turbine speed sensor* | 2J | Ground | 0 V Approx. 0.5 V | Engine stopped Engine running (N position) |
| 2K (Output) | Torque converter clutch solenoid valve | 2K | Ground | B+ 0 V | Solenoid valve ON Solenoid valve OFF |
| 2L (Ground) | Input / turbine speed sensor | 2L | Ground | 0 V | Constant |
| 2M (Output) | Engine control module (Reduce torque signal 1) | 2M | Ground | B+ Below 2.5 V | D, S, or L ranges and 1→2 or 2→3 upshifting with throttle valve opening 6/8 or more Others |
| 2N | — | — | — | — | — |
| 2O (Memory power) | Battery | 2O | Ground | B+ | Constant |
| 2P (Ground) | Battery ground | 2P | Ground | 0 V | Constant |
| 2Q (Battery power) | Battery | 2Q | Ground | B+ 0 V | Ignition switch ON Ignition switch OFF |
| 2R | — | — | — | — | — |
| 2S | — | — | — | — | — |
| 2T (Input) | Throttle position sensor (TVO) | 2T | Ground | 0.1 V-1.1 V 3.1 V-4.4 V | Closed throttle position Wide open throttle |

* Checked in AC range

Replacement

1. Disconnect the negative battery cable.
2. Disconnect the transaxle control module connector.
3. Remove the nuts and remove the transaxle control module.

4. Install the new transaxle control module.

Tightening torque:


19-25 N·m {1.9-2.6 kgf·m, 14-18 ft·lbf}

5. Connect the transaxle control module connector.
6. Connect the negative battery cable.


Z WIRING DIAGRAM

H-3 ■ SHIFT-LOCK SYSTEM

« »...CANADA
 < >...KB DOHC




H3-01 SHIFT-LOCK ACTUATOR (RA)



Z WIRING DIAGRAM

I-1 ■ REAR WINDOW DEFROSTER ■ CIGARETTE LIGHTER

C > ... CANADA
< > ... K8 DOHC



11-01 REAR WINDOW DEFROSTER RELAY (F)

| | |
|-----|-----|
| B/L | B/Y |
| L | Y |

11-02 REAR WINDOW DEFROSTER (R3)

| | |
|-----|--|
| E/L | |
|-----|--|

11-03 REAR WINDOW DEFROSTER GROUND CORD

| | |
|---|--|
| B | |
|---|--|

11-04 CIGARETTE LIGHTER (I)





| | | | |
|---|---|-----|-----|
| B | R | R/B | L/E |
|---|---|-----|-----|

11-05 REAR WINDOW DEFROSTER SWITCH (I)


| | | | | |
|-----|---|-----|---|---|
| B/L | R | | * | B |
| Y | * | R/B | * | * |

I-1

MAIN FUSE BLOCK



REAR WINDOW DEFROSTER SWITCH I1-05




X-07 (F)-(1)

X-22 (R2)-(R3)


(BLACK) REAR WINDOW DEFROSTER GROUND CORD I1-03



JOINT BOX




REAR WINDOW DEFROSTER RELAY I1-01



Z WIRING DIAGRAM

I-2 ■ ILLUMINATION LIGHTS ■ DIGITAL CLOCK

◁ ▷...CANADA < >...KB ECHC ()...ATX
 ◁ ▷...WITH ABS | |...WITH A/R BAG SYSTEM



12-01 PANEL LIGHT CONTROL SWITCH (I)

| | | | |
|---|---|-----|---|
| B | R | R/B | * |
|---|---|-----|---|

C1-01 INSTRUMENT CLUSTER (ILLUMINATION/DIGITAL CLOCK) (F)
 <C2-01>

| | | | | | | | | | | | |
|----|-----|-----|-----|-----------|-----|-----|----|-----|-----|----|----|
| R | R/B | B/Y | R/L | B/L (B/R) | B/G | L/R | Y | V/R | Y/L | * | R |
| 2L | 2K | 2J | 2I | 2H | 2G | 2F | 2E | 2D | 2C | 2B | 2A |

G/W G/B * GY L/B 1V/VI 1R/YI 1L/YI 1B/YI GY/R

| | | | | |
|-----|-----|---|----|-----|
| G/W | G/B | * | GY | L/B |
|-----|-----|---|----|-----|

F1-02 HAZARD WARNING SWITCH ILLUMINATION (I)

| | | | |
|---|---|-----|-----|
| R | B | G/Y | R/B |
|---|---|-----|-----|

G3-02 HEATER CONTROL UNIT ILLUMINATION (I)

WIRE TYPE

| | | | | |
|-----|-----|-----|---|-----|
| O/B | L/R | L/Y | R | R/B |
| L/W | L | B | | |

G4-01 HEATER CONTROL UNIT ILLUMINATION (I)

LOGIC TYPE

| | | | | | | | |
|-----|-----|------|----|---|-----|---|-----|
| O | G/O | Y/R | LG | R | R/B | L | L/R |
| L/B | L/W | BR/Y | V | Y | B | * | GY |

H1-04 SELECTOR ILLUMINATION (ATX ONLY) (RA)
 <H2-04>

| | | |
|-----|-----|---|
| V/W | R/B | * |
| B | R | * |

I1-04 CIGARETTE LIGHTER ILLUMINATION (I)

| | | | |
|---|---|-----|-----|
| B | R | R/B | L/B |
|---|---|-----|-----|

I1-05 REAR WINDOW DEFROSTER SWITCH ILLUMINATION (I)

| | | | |
|-----|---|-----|---|
| B/L | R | * | B |
| Y | * | R/B | * |

J-01 AUDIO UNIT ILLUMINATION (I)



| | | | | |
|-----|-----|-----|-----|-----|
| 1M | 1K | 1E | 1C | 1A |
| L/W | Y | R/B | L/R | L/B |
| W | L/O | * | * | R |
| 1N | 1L | 1J | 1H | 1F |

Q-02 CRUISE CONTROL MAIN SWITCH ILLUMINATION (I)

| | | | |
|-----|-----|---|---|
| R | R/B | * | * |
| B/Y | * | Y | O |

I-2

MAIN FUSE BLOCK




CRUISE CONTROL MAIN SWITCH ILLUMINATION Q-02

REAR WINDOW DEFROSTER SWITCH ILLUMINATION I1-05

(LOGIC TYPE) HEATER CONTROL UNIT ILLUMINATION G4-01

PANEL LIGHT CONTROL SWITCH 12-01



X-08 (F)-(1) (BLUE)



(BLACK) INSTRUMENT CLUSTER C1-01 <C2-01> ← K8 DOHC


INSTRUMENT CLUSTER C1-01 <C2-01> ← K8 DOHC

JOINT BOX



H1-04 <H2-04> ← K8 DOHC SELECTOR ILLUMINATION (ATX ONLY)




X-09 (F)-(RA) (BLACK)



Z WIRING DIAGRAM

I-3 ■ INTERIOR LIGHT ■ CARGO COMPARTMENT LIGHT


< >...K8 DOHC




Z WIRING DIAGRAM

J ■ AUDIO SYSTEM (OPTION)

< >...AB DOHC
()...CANADA



J-01 AUDIO UNIT (T)




J-02 DOOR SPEAKER LH (DR1)



J-03 DOOR SPEAKER RH (DR2)




J-04 REAR SPEAKER LH (RB)



J-05 REAR SPEAKER RH (RB)






J-06 AUDIO GROUND CORD






J

MAIN FUSE BLOCK




JOINT BOX



Z WIRING DIAGRAM

K-1 ■ POWER WINDOW SYSTEM

() ... CANADA
 < > ... K8 DOHC



K1-01 POWER WINDOW MAIN SWITCH ASSEMBLY (DR1)

| | | |
|-----|-----|-----|
| R/W | B | R/G |
| G/W | B/W | R/B |

K1-02 POWER WINDOW REGULATOR (DRIVER) (DR1)

| |
|-----|
| R/B |
| R/G |

K1-03 POWER WINDOW SUBSWITCH (DR2)

| | | | | | |
|-----|---|---|-----|-----|---|
| B/W | G | * | R/W | G/W | R |
|-----|---|---|-----|-----|---|


K1-04 POWER WINDOW REGULATOR (PASSENGER) (DR2)

| |
|---|
| R |
| G |

Z WIRING DIAGRAM

K-2 POWER DOOR LOCK SYSTEM


...KE DOHC




K2-01 DOOR LOCK-LINK SWITCH (DR1)



K2-02 DOOR LOCK TIMER UNIT (F)






K2-03 DOOR LOCK ACTUATOR (DR2)





K-2

MAIN FUSE BLOCK




JOINT BOX



Z WIRING DIAGRAM

L ■ POWER OUTSIDE MIRROR

() ... WITH POWER WINDOW
 () ... CANADA
 < > ... KB DOHC



L-01 POWER OUTSIDE MIRROR SWITCH (I)

| | | | | |
|----|-----|--------------|----|-----|
| * | L/B | | LG | W/R |
| BR | B | BR/Y BR/W | * | * |

L-02 POWER OUTSIDE MIRROR LH (DR1)

| | |
|----------------|----|
| LG (LG/B) | BR |
| BR/Y (BR/B) | * |


L-03 POWER OUTSIDE MIRROR RH (DR2)

| | |
|------|----|
| W/R | BR |
| BR/W | * |

Z WIRING DIAGRAM

M ■ SLIDING SUNROOF


⌘ ... CANADA
< > ... K8 DOHC




M-01 SUNROOF SWITCH



M-02 SUNROOF RELAY



M-03 SUNROOF MOTOR ASSEMBLY




I3-01 SUNROOF SWITCH (IN)



0 4 WHEEL ANTILOCK BRAKE SYSTEM(4WABS)

U D...CANADA
< >...K8 00HC



0-01 ABS CONTROL MODULE (RA)



| | | | | |
|----|-----|-----|-----|----|
| 1M | 1K | 1E | 1C | 1A |
| G | * | B/G | L/O | V |
| * | R/Y | * | R/W | B |
| 1N | 1L | 1J | 1H | 1F |
| | | 1D | 1B | |

0-02 ABS RELAY (F)

| | | | | | | | |
|----|-----|----|----|-----|-----|-----|----|
| 2S | 2Q | 2O | 2N | 2G | 2E | 2C | 2A |
| Ø | V/W | R | L | * | * | * | GY |
| P | Y | W | G | L/Y | B/L | W/G | * |
| 2T | 2R | 2P | 2M | 2L | 2J | 2H | 2F |
| | | | | | | | 2B |


0-03 ABS HYDRAULIC UNIT (F)

| | | |
|-----|-----|-----|
| R/Y | B | |
| BR | Y/G | B/W |
| V | L/O | B/W |



0

Check ABS control module




B+: Battery Positive Voltage

| Connector | Terminal | Connected to | Condition | Voltage (v) | Remark |
|-----------|--------------|----------------------------|---------------------|-------------|---|
| 12 pins | 1A | Right rear wheel solenoid | Solenoid ON* | 0-2 | * Solenoid is ON only when ABS system is functioning. Voltage when solenoid is ON can be measured following "Hydraulic System Test". (Refer to P-69.) |
| | | | Ignition switch ON | B+ | |
| | 1B | Left front wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1C | Right front wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1D | Left rear wheel solenoid | Solenoid ON* | 0-2 | |
| | | | Ignition switch ON | B+ | |
| | 1E | Ground | Constant | 0 | |
| | 1F | Ground | Constant | 0 | |
| | 1H | Battery | Ignition switch ON | B+ | |
| | | | Ignition switch OFF | 0 | |
| | 1J | Not used | — | — | |
| | 1K | Not used | — | — | |
| 1L | Motor | Motor running | B+ | | |
| | | Motor stopped | 0-1 | | |
| 1M | Brake switch | Brake pedal depressed | B+ | | |
| | | Brake pedal released | 0-2 | | |
| 1N | Not used | — | — | | |

| Connector | Terminal | Connected to | Condition | Voltage (v) | Remark | |
|-----------|------------|------------------------|------------------------|--------------------------------------|--|----------|
| 18 pins | 2A | FBS check terminal | Ignition switch ON | 0 | <ul style="list-style-type: none"> ◆ Turn wheel at specified speed to prevent incorrect diagnosis ◆ Check following terminals of ABS wheel-speed sensor in AC range: 2N-2M (right front) 2O-2P (left front) 2R-2Q (left rear) 2S-2T (right rear) ◆ In DC range, ABS wheel-speed sensor voltage will be approx. 1.0V (with ignition switch ON) | |
| | 2B | TBS check terminal | Normal mode | B+ | | |
| | | | Diagnostic mode | 0 | | |
| | 2C | Not used | — | — | | |
| | 2D | Not used | — | — | | |
| | 2E | Not used | — | — | | |
| | | | — | — | | |
| | 2F | Not used | — | — | | |
| | | | Engine idling | B+ | | |
| | 2H | Motor relay | Motor relay ON | 0-2 | | |
| | | | Motor relay OFF | B+ | | |
| | 2J | Fail-safe relay | Normal | 0-2 | | |
| | | | If malfunction present | B+ | | |
| | 2L | Warning light | Illuminated | 0-3 | | |
| | | | Not illuminated | B+ | | |
| | 2M | ABS wheel-speed sensor | Right front | Vehicle stopped | | 0 |
| | 2N | | | Wheel turned 1 revolution per second | | 0.25-1.2 |
| | 2O | | Left front | Vehicle stopped | | 0 |
| 2P | | | | Wheel turned 1 revolution per second | 0.25-1.2 | |
| 2Q | Left rear | | Vehicle stopped | 0 | | |
| | | | 2R | Wheel turned 1 revolution per second | 0.25-1.2 | |
| 2S | Right rear | | Vehicle stopped | 0 | | |
| | | | 2T | Wheel turned 1 revolution per second | 0.25-1.2 | |

Q K8 DOHC ■ CRUISE CONTROL SYSTEM




| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-----|-----|-----|-----|-----|-----|---|----|-----|-----|-----|-----|---|---|-----|-----|---|-----|---|---|-----|---|---|-----|---|---|---|-----|---|---|---|---|---|---|---|---|---|---|--|---|-----|--|---|---|-----|---|---|---|---|---|--|---|---|--|---|---|----|-----|---|---|---|---|
| <p>Q-01 CRUISE CONTROL MODULE (F) ()...ATX</p> <table border="1"> <tr> <td>S</td><td>G</td><td>O</td><td>M</td><td></td><td>G</td><td>E</td><td>C</td><td>A</td> </tr> <tr> <td>G/W</td><td>*</td><td>P</td><td>G</td><td></td><td>(7)</td><td>Y</td><td>L</td><td>LG</td> </tr> <tr> <td>B</td><td>*</td><td>V/R</td><td>R</td><td>*</td><td>B/Y</td><td>Y</td><td>O</td><td>*</td><td>G/B</td> </tr> <tr> <td>T</td><td>R</td><td>P</td><td>N</td><td>L</td><td>J</td><td>H</td><td>F</td><td>D</td><td>B</td> </tr> </table> | S | G | O | M | | G | E | C | A | G/W | * | P | G | | (7) | Y | L | LG | B | * | V/R | R | * | B/Y | Y | O | * | G/B | T | R | P | N | L | J | H | F | D | B | <p>Q-02 CRUISE CONTROL MAIN SWITCH(I)</p> <table border="1"> <tr> <td>R</td><td>R/B</td><td></td><td>*</td><td>*</td> </tr> <tr> <td>B/Y</td><td>*</td><td>Y</td><td>O</td><td>*</td><td>B</td> </tr> </table> | R | R/B | | * | * | B/Y | * | Y | O | * | B | <p>Q-03 BRAKE SWITCH (F)</p> <table border="1"> <tr> <td>V</td><td>P</td> </tr> </table> | V | P | <p>Q-04 CRUISE ACTUATOR (F)</p> <table border="1"> <tr> <td>P</td><td>L</td> </tr> <tr> <td>LG</td><td>G/B</td> </tr> </table> | P | L | LG | G/B | <p>Q-05 CRUISE CONTROL SWITCH (F) WITH AIR BAG SYSTEM</p> <table border="1"> <tr> <td>R</td><td>B</td><td>*</td> </tr> </table> | R | B | * |
| S | G | O | M | | G | E | C | A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| G/W | * | P | G | | (7) | Y | L | LG | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B | * | V/R | R | * | B/Y | Y | O | * | G/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| T | R | P | N | L | J | H | F | D | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | R/B | | * | * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/Y | * | Y | O | * | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| V | P | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P | L | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LG | G/B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R | B | * | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>E1-01 COMBINATION SWITCH (CRUISE CONTROL SWITCH) (F) WITHOUT AIR BAG SYSTEM</p> <table border="1"> <tr> <td>R/Y</td><td>*</td><td>R</td><td></td><td>LG</td><td>R/L</td><td>W/R</td> </tr> <tr> <td>R/W</td><td>*</td><td>B</td><td>G/O</td><td>Y/L</td><td>P</td><td>B/Y</td><td>*</td><td>B</td><td>R</td> </tr> <tr> <td></td><td></td><td>P</td><td></td><td></td><td></td><td>D</td><td></td><td>B</td><td></td> </tr> </table> | | | | | R/Y | * | R | | LG | R/L | W/R | R/W | * | B | G/O | Y/L | P | B/Y | * | B | R | | | P | | | | D | | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/Y | * | R | | LG | R/L | W/R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| R/W | * | B | G/O | Y/L | P | B/Y | * | B | R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | P | | | | D | | B | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Q

B+: Battery positive voltage

| Terminal (Input / Output) | Connection | Test condition | | Voltage/ Continuity |
|---------------------------|---------------------------------------|---|---|---------------------|
| A (Output) | Cruise actuator (vent 1) | Ignition switch at ON | | 0V |
| | | Ignition switch at ON and cruise control main switch on | | Approx. 9V |
| B (Output) | Cruise actuator (vac) | Ignition switch at ON | | 0V |
| | | Ignition switch at ON and cruise control main switch on | | Approx. 9V |
| C (Output) | Cruise actuator (vent 2) | Ignition switch at ON | | 0V |
| | | Ignition switch at ON and cruise control main switch on | | Approx. 9V |
| E (Input) | Cruise control main switch (N.C.) | Ignition switch at ON | Cruise control main switch at off | B+ |
| | | | Cruise control main switch at on | 0V |
| F (Input) | Cruise control main switch (N.O.) | Ignition switch at ON | Cruise control main switch at off | 0V |
| | | | Cruise control main switch at on | B+ |
| G (Input) | TCM | Ignition switch at ON | | B+ |
| H (Input) | Brake switch (N.C.) | Ignition switch and cruise control main switch at ON | | Approx. 9V |
| | | Brake pedal depressed | | B+ |
| J (Input) | A T X Transaxle range switch | Ignition switch at ON | N or P range | 0V |
| | | | Other | B+ |
| | M T X Clutch switch | Ignition switch at ON | Depress clutch pedal or in neutral position | 0V |
| | | | Other | B+ |
| M (Input) | Brake switch (N.O.) | Depress brake pedal | | B+ |
| | | Other | | 0V |
| N (Input) | Cruise control switch | Ignition switch at ON and cruise control main switch on | | 5V |
| | | Ignition switch at ON and cruise control main switch on | SET/COAST switch pushed | 2V |
| | | | RESUME/ACCEL switch pushed | 3V |
| O (Input) | Brake switch (N.C.) | Ignition switch at ON | | 0V |
| | | Ignition switch at ON and cruise control main switch on | | 9V |
| P (Input) | Vehicle speedometer sensor | While rear tires rotating | | 0-5V |
| S (Input) | Battery (STOP 20 A fuse) | Constant | | B+ |
| T (Input) | GND | Constant: check for continuity | | 0V/Yes |


S



SERVICE WARNINGS


Component Disassembly

- Disassembling and reassembling the components of the air bag system can render the system inoperative, which may result in serious injury or death in the event of an accident. Do not disassemble any air bag system components.




Wiring Harness Repair

- Incorrectly repairing an air bag system wiring harness can accidentally deploy the air bag, which can cause serious injury. If a problem is found in the system wiring, replace the wiring harness. Do not try to repair it.




Air Bag Module Inspection

- Inspecting the air bag module with an ohmmeter can deploy the air bag, which can cause serious injury. Do not use an ohmmeter to inspect the air bag module.



Air Bag Module Handling


- A live (undeployed) air bag may accidentally deploy when it is handled and cause serious injury. When carrying a live air bag module, point the trim cover away from your body to lessen the chance of injury in case it deploys.



- A live air bag placed face down on a surface is dangerous. If the air bag deploys, the motion of the module can cause serious injury. Always face the trim cover up to reduce the motion of the module in case it accidentally deploys.

S AIR BAG SYSTEM

...CANADA
...KB DOHC




S-01 DIAGNOSTIC MODULE (AB)


| | | | | | | | | |
|----|-----|-----|-----|-----|----|------|----|-----|
| 1Q | 1O | 1M | 1K | 1I | 1G | 1E | 1C | 1A |
| * | V | BR | Y/R | B/Y | W | R/B | * | B/V |
| B | B/R | B/G | P | G | Y | LG/R | * | * |
| 1R | 1P | 1N | L | J | 1H | 1F | 1D | 1B |

| | | | | | | |
|-----|----|-----|-----|-----|-----|-----|
| 2M | 2K | 2I | 2G | 2E | 2C | 2A |
| LG | LG | R | B/Y | G/O | R/Y | V/W |
| W/G | D | G/W | L | GY | B/L | B |
| 2N | 2L | 2J | 2H | 2F | 2D | 2B |


S-02 D-SENSOR LH (AB)




S-03 D-SENSOR CENTER (AB)




S-04 D-SENSOR RH (AB)



S-05 S-SENSOR (AB)




S-06 DRIVER-SIDE AIR BAG MODULE (AB)




S-07 PASSENGER-SIDE AIR BAG MODULE (AB)




S



MAIN FUSE BLOCK




JOINT BOX



T ■ IGNITION KEY ILLUMINATION ■ CENTRAL PROCESSING UNIT (CPU)

■ ... CANADA
< > ... KB DOHC




T-01 KEY REMINDER SWITCH (F)

WITHOUT AIR BAG SYSTEM



WITH AIR BAG SYSTEM



T-02 BUCKLE SWITCH (RA)



T-03 DOOR SWITCH LH (RA)



T-04 DOOR SWITCH RH (RA)



D1-01 COMBINATION SWITCH (IGNITION KEY ILLUMINATION) (F)

WITHOUT AIR BAG SYSTEM



WITH AIR BAG SYSTEM



⊗ ... WITHOUT REAR WIPER AND WASHER

T

Inspection

1. Remove the CPU from the joint box and measure the voltage from the joint box side.
2. If not as specified, inspect the parts listed under "Inspection area" and the related wiring harnesses.
3. If the parts and wiring harnesses are OK but system still does not work properly, replace the CPU.

Terminal voltage list

B+: Battery positive voltage


16-PIN CONNECTOR

P O N M L K J I H G F E D C B A

| Terminal | Signal | Connection | Test condition | | Voltage (V) Continuity | Inspection area |
|----------|-------------------|---------------------------|-------------------------------|------------------------|---------------------------|--|
| A | Key insert | Key reminder switch | Ignition key inserted | | B+ | <ul style="list-style-type: none"> • ROOM 15 A fuse • Key reminder switch |
| | | | Ignition key removed | | 0 | |
| B | Rear wiper | Rear wiper motor | Ignition switch at ON | | B+ | <ul style="list-style-type: none"> • REAR WIPER 15 A fuse • Rear wiper motor |
| C | TNS | TNS relay | Headlight switch on | | B+ | <ul style="list-style-type: none"> • TAIL 15 A fuse • TNS relay • Combination switch |
| | | | Headlight switch off | | 0 | |
| D | Seat belt warning | Buckle switch | Continuity inspection | Seat belt unfastened | Yes | Buckle switch |
| | | | | Seat belt fastened | No | |
| E | — | — | — | | — | — |
| F | Rear wiper | Rear wiper switch | Continuity inspection | Rear wiper switch on | Yes | Combination switch |
| | | | | Rear wiper switch off | No | |
| G | Rear washer | Rear washer switch | Ignition switch at ON | Rear washer switch on | 0 | <ul style="list-style-type: none"> • METER 15 A fuse • Rear washer motor • Combination switch |
| | | | | Rear washer switch off | B+ | |
| H | — | — | — | | — | — |
| I | — | — | — | | — | — |
| J | Seat belt warning | Seat belt warning light | Ignition switch at ON | | B+ | <ul style="list-style-type: none"> • METER 15 A fuse • Seat belt warning light |
| K | CPU ground | GND | Continuity inspection | | Yes | — |
| L | Key illumination | Ignition key illumination | Constant | | B+ | <ul style="list-style-type: none"> • ROOM 15 A fuse • Ignition key illumination |
| M | — | — | — | | — | — |
| N | Interior light | Interior light switch | Interior light switch at DOOR | Any door open | 0 | <ul style="list-style-type: none"> • ROOM 15 A fuse • Interior light • Door switch |
| | | | | All doors closed | B+ | |
| O | +B | Battery | Constant | | B+ | ROOM 15 A fuse |
| P | IG 1 | Ignition switch | Ignition switch at ON | | B+ | METER 15 A fuse |

Z WIRING DIAGRAM

U-1 B6 DOHC ■ DATA LINK CONNECTOR



U1-01 DATA LINK CONNECTOR (EM)

()...ATX


| | | | | | |
|------|-----|-----|-----|-----|------|
| | FEN | MEN | | TEN | +B |
| GND | FAT | FBS | FAC | FWS | FSC |
| | TAT | TBS | TAC | TWS | TSC |
| FAB | IG- | GND | TFA | F/P | TAB |
| BUSA | | | | | BUSB |

| | | | | | |
|-----|------|-----|---|------|-----|
| | GY/R | W/Y | | LG/Y | W/R |
| B | (*) | GY | * | * | * |
| (Y) | G/R | * | * | * | * |
| R/Y | R | B | * | LG | Y/R |
| * | | | | | * |

NOTES: THIS IS THE CONNECTOR AS SEEN FROM THE TERMINAL SIDE.

Z WIRING DIAGRAM

U-2 K8 DOHC ■ DATA LINK CONNECTOR



U2-01 DATA LINK CONNECTOR (EM)

()...ATX



| | | | | | |
|------|-----|-----|-----|-----|------|
| | FEN | MEN | | TEN | +B |
| GND | FAT | FBS | FAC | FWS | FSC |
| TAT | TBS | TAC | TWS | TSC | |
| FAB | IG- | GND | TFA | F/P | TAB |
| BUSA | | | | | BUSB |

| | | | | | |
|-----|------|--------|---|------|-----|
| | GY/R | W/Y | | LG/Y | W/R |
| B | (*) | GY (*) | * | * | * |
| (Y) | G/R | * | * | * | * |
| R/Y | R | B | * | LG | Y/R |
| * | | | | | * |



NOTES: THIS IS THE CONNECTOR AS SEEN FROM THE TERMINAL SIDE.

X-1 COMMON CONNECTOR LIST


X-01 MAIN FUSE BLOCK (E)




X-02 FUSE BLOCK (E)






X-03 IGNITION SWITCH (F)





X-04 CONNECTOR BETWEEN FRONT(F) AND EMISSION(EM)




X-05 CONNECTOR BETWEEN FRONT(F) AND EMISSION(EM)





X-07 CONNECTOR BETWEEN FRONT(F) AND INSTRUMENT PANEL(I)




X-10 CONNECTOR BETWEEN FRONT(F) AND REAR A(RA)




X-08 CONNECTOR BETWEEN FRONT(F) AND INSTRUMENT PANEL(I)




X-11 CONNECTOR BETWEEN FRONT(F) AND REAR A(RA)



X-09 CONNECTOR BETWEEN FRONT(F) AND REAR A(RA)



X-12 CONNECTOR BETWEEN FRONT(F) AND ENGINE(E)






1

2

X-2 ■ COMMON CONNECTOR LIST


X-13 CONNECTOR BETWEEN FRONT(F) AND ENGINE(E)
()...WITH AIR BAG SYSTEM




X-14 CONNECTOR BETWEEN FRONT(F) AND INTERIOR LIGHT(IN)



X-15 CONNECTOR BETWEEN FRONT(F) AND DOOR NO.1(DR1) ()...WITHOUT POWER WINDOW AND POWER DOOR LOCK (DR1)




X-16 CONNECTOR BETWEEN FRONT(F) AND DOOR NO.2(DR2)




X-18 CONNECTOR BETWEEN EMISSION(EM) AND ENGINE(E)



X-17 CONNECTOR BETWEEN FRONT(F) AND A/C(AC)




X-19 CONNECTOR BETWEEN EMISSION(EM) AND INJECTION(INJ)




X-20 CONNECTOR BETWEEN REAR A(RA) AND REAR B(RB)


< >...WITH REAR WIPER AND WASHER




X-21 CONNECTOR BETWEEN REAR A(RA) AND REAR NO.2(R2)



X-22 CONNECTOR BETWEEN REAR NO.2(R2) AND REAR NO.3(R3) < >...WITH REAR WIPER AND WASHER



X-23 CONNECTOR BETWEEN FRONT(F) AND AIR BAG(AB)




X-24 JOINT CONNECTOR (F) ()...ATX & ()...WITH CRUISE CONTROL




X-25 JOINT CONNECTOR (I)













X-26 JOINT CONNECTOR (EM) ()...KB DOHC & ()...B6 DOHC MTX



INTERCONNECTING DIAGRAM OF JOINT BOX



JB ■ JOINT BOX



JB

| No. | CIRCUIT NAME | FUSE | COLOR CODE | No. | CIRCUIT NAME | FUSE | COLOR CODE |
|-----|--------------|------|------------|-----|--------------|------|------------|
| ① | (REAR WIPER) | 10A | R | ⑨ | METER | 15A | L |
| ② | HAZARD | 15A | L | ⑩ | WIPER | 20A | Y |
| ③ | ROOM | 15A | L | ⑪ | STOP | 20A | Y |
| ④ | ENGINE | 10A | R | ⑫ | TAIL | 15A | L |
| ⑤ | RADIO | 15A | L | ⑬ | (SUN ROOF) | 15A | L |
| ⑥ | (DOOR LOCK) | 10A | R | ⑭ | (ABS) | 10A | R |
| ⑦ | — | — | — | ⑮ | — | — | — |
| ⑧ | (POWER WIND) | 30A | G | ⑯ | — | — | — |

PARTS INDEX

PI

| PARTS | PAGE | PARTS | PAGE |
|---------------------------------------|------------|--|--------------------------|
| A A/C RELAY..... | Z-80, 82 | E ECM | Z-32, 34, 36, 40, 42, 44 |
| ABS CONTROL MODULE..... | Z-112 | EGR SOLENOID VALVE (VACUUM)..... | Z-34, 42 |
| ABS HYDRAULIC UNIT | Z-112 | EGR SOLENOID VALVE (VENT)..... | Z-34, 40 |
| ABS RELAY..... | Z-112 | EGR VALVE POSITION SENSOR..... | Z-34, 42 |
| ABS WHEEL-SPEED SENSORS | Z-112 | ENGINE COOLANT TEMPERATURE | |
| AIR INTAKE ACTUATOR..... | Z-86 | SENSOR..... | Z-32, 42 |
| AIRFLOW MODE ACTUATOR..... | Z-86 | F FAN SWITCH..... | Z-86 |
| AUDIO GROUND CORD..... | Z-102 | FLASHER UNIT | Z-74 |
| AUDIO UNIT..... | Z-102 | FRONT COMBINATION LIGHT | |
| AUDIO UNIT ILLUMINATION..... | Z-96 | FRONT TURN LIGHTS..... | Z-74 |
| B BACK-UP LIGHT SWITCH..... | Z-76 | PARKING LIGHTS..... | Z-72 |
| BLOWER MOTOR..... | Z-84 | FRONT SIDE MARKER LIGHTS..... | Z-72 |
| BLOWER RELAY..... | Z-84, 86 | FUEL GAUGE SENDER UNIT | Z-48 |
| BRAKE FLUID LEVEL SENSOR..... | Z-56, 60 | FUEL INJECTORS..... | Z-32, 34, 40 |
| BRAKE SWITCH..... | Z-76, 116 | FUEL PUMP RELAY..... | Z-48 |
| BUCKLE SWITCH..... | Z-124 | G GENERATOR..... | Z-28, 30 |
| C CARGO COMPARTMENT LIGHT..... | Z-100 | H HAZARD WARNING SWITCH..... | Z-74 |
| CARGO COMPARTMENT LIGHT SWITCH..... | Z-100 | HAZARD WARNING SWITCH ILLUMINATION..... | Z-98 |
| CIGARETTE LIGHTER..... | Z-96 | HEADLIGHT RELAY..... | Z-66, 68 |
| CIGARETTE LIGHTER ILLUMINATION..... | Z-98 | HEADLIGHT SWITCH..... | Z-66, 68 |
| CIRCUIT BREAKER..... | Z-84, 86 | HEADLIGHTS..... | Z-68, 68 |
| CLUTCH SWITCH..... | Z-34, 42 | HEATED OXYGEN SENSOR..... | Z-32 |
| COMBINATION SWITCH | | HEATED OXYGEN SENSORS..... | Z-40 |
| HORN SWITCH..... | Z-78 | HEATER CONTROL UNIT..... | Z-86 |
| CRUISE CONTROL SWITCH..... | Z-116 | HEATER CONTROL UNIT ILLUMINATION..... | Z-98 |
| IGNITION KEY ILLUMINATION..... | Z-124 | HEATER CONTROL UNIT (A/C SWITCH)..... | Z-84 |
| CONDENSER FAN..... | Z-80, 82 | HEATER CONTROL UNIT (FAN SWITCH)..... | Z-84 |
| CONDENSER FAN RELAY..... | Z-80 | HIGH-MOUNT BRAKE LIGHT..... | Z-76 |
| CONDENSER FAN RELAYS..... | Z-82 | HOLD SWITCH..... | Z-88, 90 |
| COOLANT FAN MOTOR..... | Z-50, 52 | HORN..... | Z-78 |
| COOLANT FAN RELAY..... | Z-50 | HORN RELAY..... | Z-78 |
| COOLANT FAN RELAYS..... | Z-52 | HORN SWITCH..... | Z-78 |
| CRANKSHAFT POSITION SENSOR..... | Z-44 | I IAC VALVE..... | Z-32, 40 |
| CRUISE ACTUATOR..... | Z-116 | INPUT/TURBINE SPEED SENSOR..... | Z-88, 90 |
| CRUISE CONTROL MAIN SWITCH..... | Z-116 | INSTRUMENT CLUSTER..... | Z-54, 56, 58, 60 |
| CRUISE CONTROL MAIN SWITCH | | INSTRUMENT CLUSTER ILLUMINATION..... | Z-98 |
| ILLUMINATION..... | Z-98 | INTERIOR LIGHT..... | Z-100 |
| CRUISE CONTROL MODULE..... | Z-116 | K KEY REMINDER SWITCH..... | Z-124 |
| CRUISE CONTROL SWITCH..... | Z-116 | KNOCK SENSOR..... | Z-44 |
| D D-SENSORS..... | Z-122 | L LICENCE PLATE LIGHTS..... | Z-72 |
| DATA LINK CONNECTOR..... | Z-128, 130 | M MAGNETIC CLUTCH..... | Z-80, 82 |
| DIAGNOSTIC MODULE..... | Z-22 | MAIN RELAY..... | Z-32, 40 |
| DIGITAL CLOCK..... | Z-98 | MASS AIR FLOW SENSOR..... | Z-32 |
| DISTRIBUTOR..... | Z-32, 40 | N NEUTRAL SWITCH..... | Z-34, 42 |
| DOOR LOCK ACTUATOR..... | Z-106 | O OIL PRESSURE SWITCH..... | Z-56, 60 |
| DOOR LOCK TIMER UNIT..... | Z-106 | P PANEL LIGHT CONTROL SWITCH..... | Z-98 |
| DOOR LOCK-LINK SWITCH..... | Z-106 | PARKING BRAKE SWITCH..... | Z-56, 60 |
| DOOR SPEAKERS..... | Z-102 | PASSENGER-SIDE AIR BAG MODULE..... | Z-78, 122 |
| DOOR SWITCHES..... | Z-124 | POWER OUTSIDE MIRROR SWITCH..... | Z-108 |
| DRIVER-SIDE AIR BAG MODULE..... | Z-122 | | |
| DRL CONTROL MODULE..... | Z-70 | | |
| DRL RELAY..... | Z-70 | | |
| DRL RESISTOR..... | Z-70 | | |

Z WIRING DIAGRAM

PI

PARTS INDEX

| PARTS | PAGE | PARTS | PAGE |
|---|--------------|-------|------|
| P | | | |
| POWER OUTSIDE MIRRORS..... | Z-108 | | |
| POWER STEERING PRESSURE SWITCH..... | Z-34, 44 | | |
| POWER WINDOW MAIN SWITCH ASSEMBLY ... | Z-104 | | |
| POWER WINDOW REGULATORS..... | Z-104 | | |
| POWER WINDOW SUBSWITCHE..... | Z-104 | | |
| PRG SOLENOID VALVES..... | Z-34, 42 | | |
| PURGE SOLENOID VALVE..... | Z-32, 42 | | |
| R | | | |
| REAR COMBINATION LIGHT | | | |
| BRAKE LIGHTS..... | Z-76 | | |
| REAR TURN LIGHTS..... | Z-74 | | |
| TAILLIGHTS..... | Z-72 | | |
| BACK-UP LIGHTS..... | Z-76 | | |
| REAR SIDE MARKER LIGHTS..... | Z-72 | | |
| REAR SPEAKERS..... | Z-102 | | |
| REAR WASHER MOTOR..... | Z-64 | | |
| REAR WINDOW DEFROSTER..... | Z-96 | | |
| REAR WINDOW DEFROSTER GROUND CORD.... | Z-96 | | |
| REAR WINDOW DEFROSTER RELAY..... | Z-96 | | |
| REAR WINDOW DEFROSTER SWITCH..... | Z-96 | | |
| REAR WINDOW DEFROSTER SWITCH ILLUMINATION..... | Z-98 | | |
| REAR WIPER AND WASHER SWITCH..... | Z-64 | | |
| REAR WIPER MOTOR..... | Z-64 | | |
| REFRIGERANT PRESSURE SWITCH..... | Z-84, 86 | | |
| RESISTOR..... | Z-84, 86 | | |
| S | | | |
| S-SENSOR..... | Z-122 | | |
| SELECTOR ILLUMINATION..... | Z-98 | | |
| SHIFT-LOCK ACTUATOR..... | Z-94 | | |
| SOLENOID VALVE (EG-AT)..... | Z-88, 90 | | |
| STARTER..... | Z-28, 30 | | |
| STARTER INTERLOCK SWITCH..... | Z-28 | | |
| SUNHOOF MOTOR ASSEMBLY..... | Z-110 | | |
| SUNHOOF RELAY..... | Z-110 | | |
| SUNROOF SWITCH..... | Z-110 | | |
| T | | | |
| TCM..... | Z-88, 90 | | |
| THERMOSWITCH..... | Z-84, 86 | | |
| THROTTLE POSITION SENSOR..... | Z-34, 42 | | |
| TNS RELAY..... | Z-72 | | |
| TRANSAXLE RANGE SWITCH..... | Z-30, 88, 90 | | |
| TRUN SWITCH..... | Z-74 | | |
| V | | | |
| VEHICLE SPEEDOMETER SENSOR..... | Z-54, 58 | | |
| VICS SOLENOID VALVE..... | Z-34 | | |
| VOLUME AIR FLOW SENSOR..... | Z-42 | | |
| VRIS SOLENOID VALVES..... | Z-42 | | |
| W | | | |
| WATER TEMPERATURE BENDER UNIT..... | Z-54, 58 | | |
| WINDSHIELD WASHER MOTOR..... | Z-62 | | |
| WINDSHIELD WIPER AND WASHER SWITCH..... | Z-62 | | |
| WINDSHIELD WIPER MOTOR..... | Z-62 | | |